

EDSVF9383V
13260707



System Manual

9300 vector 110 ... 400 kW



[EVF9335 ... EVF9338, EVF9381 ... EVF9383](#)

Frequency inverter

Lenze



Tip!

Current documentation and software updates concerning Lenze products can be found on the Internet in the "Services & Downloads" area under
<http://www.Lenze.com>

© 2008 Lenze Drive Systems GmbH, Hans-Lenze-Straße 1, D-31855 Aerzen
No part of this documentation may be reproduced or made accessible to third parties without written consent by Lenze Drive Systems GmbH.

All information given in this documentation has been selected carefully and complies with the hardware and software described. Nevertheless, discrepancies cannot be ruled out. We do not take any responsibility or liability for any damage that may occur. Necessary corrections will be included in subsequent editions.

1	Preface	1-1
1.1	How to use this System Manual	1.1-1
1.1.1	Information provided by the System Manual	1.1-1
1.1.2	Document history	1.1-2
1.1.3	Products to which the System Manual applies	1.1-3
1.2	Legal regulations	1.2-1
2	Safety instructions	2-1
2.1	General safety and application notes for Lenze controllers	2.1-1
2.2	General safety and application instructions for Lenze motors	2.2-1
2.3	Residual hazards	2.3-1
2.4	Definition of notes used	2.4-1
3	Technical data	3-1
3.1	General data and operating conditions	3.1-1
3.2	Weights	3.2-1
3.3	Open and closed-loop control	3.3-1
3.4	Safety relay KSR	3.4-1
3.5	Rated data (devices in 400V design)	3.5-1
3.6	Rated data (devices for 400/500V mains)	3.6-1
3.6.1	Rated data for 400 V mains voltage	3.6-1
3.6.2	Rated data for 500 V mains voltage	3.6-2
3.7	Fuses and cable cross-sections	3.7-1
3.7.1	Mains supply	3.7-1
3.7.2	DC supply	3.7-2
3.7.3	Notes for mains and motor cables	3.7-3
4	Installation of the standard device	4-1
4.1	Important notes	4.1-1
4.2	Basic devices in the power range 110 ... 200 kW	4.2-1
4.2.1	Dimensions	4.2-1
4.2.2	Drilling the holes into the mounting plate	4.2-2
4.2.3	Fasten the mounting rails on the mounting plate	4.2-3
4.2.4	Fasten controller on mounting plate	4.2-4
4.3	Basic devices in the power range 250 ... 400 kW	4.3-1
4.3.1	Dimensions	4.3-1
4.3.2	Drilling the holes into the mounting plate	4.3-2
4.3.3	Fasten the mounting rails on the mounting plate	4.3-3
4.3.4	Fasten controller on mounting plate	4.3-4

5	Wiring of the standard device	5-1
5.1	Important notes	5.1-1
5.1.1	Protection of persons	5.1-1
5.1.2	Device protection	5.1-3
5.1.3	Motor protection	5.1-3
5.1.4	Supply forms / electrical supply conditions	5.1-4
5.1.5	Interaction with compensation equipment	5.1-4
5.2	Basics for wiring according to EMC	5.2-1
5.2.1	Shielding	5.2-1
5.2.2	Mains connection, DC supply	5.2-1
5.2.3	Motor cables	5.2-2
5.2.4	Control cables	5.2-3
5.2.5	Installation in the control cabinet	5.2-4
5.2.6	Wiring outside the control cabinet	5.2-5
5.2.7	Detecting and eliminating EMC interferences	5.2-6
5.3	Basic devices in the power range 110 ... 200 kW	5.3-1
5.3.1	Wiring according to EMC (CE-typical drive system)	5.3-1
5.3.2	Mains connection of the controller for 400 V mains voltage	5.3-3
5.3.3	Supply and fan connection of the controller for 400 V/500V mains voltage	5.3-4
5.3.4	Motor connection	5.3-7
5.3.5	Wiring of motor temperature monitoring	5.3-8
5.4	Basic devices in the power range 250 ... 400 kW	5.4-1
5.4.1	Wiring according to EMC (CE-typical drive system)	5.4-1
5.4.2	Master and slave connection	5.4-3
5.4.3	Mains connection of the controller for 400 V mains voltage	5.4-7
5.4.4	Supply and fan connection of the controller for 400 V/500V mains voltage	5.4-8
5.4.5	Motor connection	5.4-12
5.4.6	Wiring of motor temperature monitoring	5.4-14
5.5	Connection terminal of the control card	5.5-1
5.6	Control terminals	5.6-1
5.6.1	Important notes	5.6-1
5.6.2	With function "Safe torque off" active	5.6-2
5.6.3	With function "Safe torque off" deactivated	5.6-5
5.6.4	Terminal assignment	5.6-7
5.7	Wiring of the system bus (CAN)	5.7-1
5.8	Wiring of the feedback system	5.8-1
5.8.1	Important notes	5.8-1
5.8.2	Incremental encoder with TTL level at X8	5.8-2
5.8.3	Incremental encoder with HTL level at X9	5.8-3

5.9	Wiring of digital frequency input / digital frequency output	5.9-1
5.10	Communication modules	5.10-1
6	Commissioning	6-1
6.1	Before switching on	6.1-1
6.2	Selection of the correct operating mode	6.2-1
6.3	Parameter setting with the XT EMZ9371BC keypad	6.3-1
6.3.1	Commissioning example in V/f characteristic control mode	6.3-1
6.3.2	Commissioning example in vector control mode	6.3-5
6.4	Controller inhibit	6.4-1
6.5	Changing the assignment of the control terminals X5 and X6	6.5-1
6.5.1	Free configuration of digital input signals	6.5-1
6.5.2	Free configuration of digital outputs	6.5-3
6.5.3	Free configuration of analog input signals	6.5-4
6.5.4	Free configuration of analog outputs	6.5-6
6.6	Adjusting the motor	6.6-1
6.6.1	Entry of motor data	6.6-1
6.6.2	Motor selection list	6.6-4
6.6.3	Motor temperature monitoring with PTC or thermal contact	6.6-9
6.6.4	Motor temperature monitoring with KTY	6.6-11
6.6.5	Current limits	6.6-15
6.6.6	Automatic collection of motor data	6.6-16
6.7	Setting the speed feedback	6.7-1
6.7.1	Incremental encoder with TTL level at X8	6.7-2
6.7.2	Incremental encoder with HTL level at X9	6.7-3
6.8	Operating mode	6.8-1
6.8.1	V/f characteristic control	6.8-4
6.8.2	Vector control	6.8-8
6.9	Switching frequency of the inverter	6.9-1
6.10	Acceleration, deceleration, braking, stopping	6.10-1
6.10.1	Speed range	6.10-1
6.10.2	Setting acceleration times and deceleration times in speed mode	6.10-3
6.10.3	Quick stop	6.10-4
6.10.4	Changing the direction of rotation	6.10-5
6.11	Optimising the operating behaviour	6.11-1
6.11.1	Slip compensation	6.11-1
6.11.2	Oscillation damping	6.11-3
6.11.3	Boost correction with V/f characteristic control	6.11-5
6.11.4	Motor magnetising current with vector control	6.11-9

7	Parameter setting	7-1
7.1	Important notes	7.1-1
7.2	Parameter setting with the XT EMZ9371BC keypad	7.2-1
7.2.1	General data and operating conditions	7.2-1
7.2.2	Installation and commissioning	7.2-2
7.2.3	Display elements and function keys	7.2-2
7.2.4	Changing and saving parameters	7.2-4
7.2.5	Loading a parameter set	7.2-6
7.2.6	Transferring parameters to other standard devices	7.2-7
7.2.7	Activating password protection	7.2-9
7.2.8	Diagnostics	7.2-10
7.2.9	Menu structure	7.2-11
8	Configuration	8-1
8.1	Important notes	8.1-1
8.2	Function blocks	8.2-1
8.2.1	Diameter calculator (DCALC)	8.2-1
8.2.2	Master frequency input (DFIN)	8.2-5
8.2.3	Master frequency output (DFOUT)	8.2-8
8.2.4	Master frequency ramp-function generator (DFRFG)	8.2-13
8.2.5	Master frequency processing (DFSET)	8.2-18
8.2.6	Internal motor control with V/f characteristic control (MCTRL1)	8.2-25
8.2.7	Internal motor control with vector control (MCTRL2)	8.2-40
8.3	Monitoring	8.3-1
8.3.1	Responses	8.3-1
8.3.2	Monitoring times for process data input objects	8.3-2
8.3.3	Maximum speed	8.3-3
8.3.4	Motor	8.3-3
8.3.5	Controller current load (I x t monitoring)	8.3-4
8.3.6	Motor temperature	8.3-5
8.3.7	Heatsink temperature	8.3-5
8.3.8	DC-bus voltage	8.3-6
8.3.9	External error (EEr)	8.3-6
8.4	Overview of monitoring functions	8.4-1
8.5	Code table	8.5-1

8.6	Selection lists	8.6-1
8.6.1	Selection list 1: Analog output signals	8.6-1
8.6.2	Selection list 2: Digital output signals	8.6-3
8.6.3	Selection list 3: Angle signals	8.6-6
8.6.4	Selection list 4: Speed signals	8.6-6
8.6.5	Selection list 5: Function blocks	8.6-7
8.7	Table of attributes	8.7-1
9	Troubleshooting and fault elimination	9-1
9.1	Display of operating data, diagnostics	9.1-1
9.1.1	Display of operating data	9.1-1
9.1.2	Diagnostics	9.1-2
9.2	Troubleshooting	9.2-1
9.2.1	Status display via LEDs at the controller	9.2-1
9.2.2	Fault analysis with the history buffer	9.2-1
9.3	Drive behaviour in the event of faults	9.3-1
9.4	Fault elimination	9.4-1
9.4.1	Drive errors	9.4-1
9.4.2	Controller in clamp operation	9.4-2
9.4.3	Behaviour in case of overvoltage in the DC bus (OU message)	9.4-3
9.5	System error messages	9.5-1
9.5.1	General error messages	9.5-1
9.5.2	Resetting system error messages	9.5-5
10	DC-bus operation	10-1
10.1	Function	10.1-1
10.2	Conditions for trouble-free DC-bus operation	10.2-1
10.2.1	Possible combinations of Lenze controllers in a network of several drives	10.2-1
10.3	Mains chokes for DC-bus operation	10.3-1
10.4	Fuses and cable cross-sections	10.4-1
10.4.1	Mains supply	10.4-1
10.4.2	DC supply	10.4-2
10.5	Basic dimensioning	10.5-1
10.5.1	Conditions	10.5-1
10.5.2	Calculation of the additional DC supply input	10.5-1
10.5.3	Dimensioning examples	10.5-2
10.6	Distributed supply (several supply points)	10.6-1
10.7	Braking operation in the network	10.7-1

11	Safety engineering	11-1
11.1	Important notes	11.1-1
11.2	Method of functioning	11.2-1
11.3	Safety relay KSR	11.3-1
11.4	Functional test	11.4-1
11.4.1	Important notes	11.4-1
11.4.2	Manual safety function check	11.4-2
11.4.3	Monitoring the safety function with a PLC	11.4-3
12	Braking operation	12-1
12.1	Brake operation with external brake resistor	12.1-1
12.1.1	Selection of the brake resistors	12.1-1
12.2	Lenze brake resistors	12.2-1
12.2.1	Rated data	12.2-1
12.2.2	Dimensions	12.2-2
12.2.3	Selection	12.2-2
12.2.4	Connection of external brake resistor	12.2-3
12.3	Rated data of the integrated brake transistor	12.3-1
12.4	Braking operation in the network	12.4-1
12.4.1	Selection	12.4-2
13	Accessories (overview)	13-1
13.1	General accessories	13.1-1
13.2	Type-specific accessories	13.2-1
14	Appendix	14-1
14.1	Glossary	14.1-1
14.1.1	Terminology and abbreviations used	14.1-1
14.2	Index	14.2-1

1 Preface**Contents**

1.1	How to use this System Manual	1.1-1
1.1.1	Information provided by the System Manual	1.1-1
1.1.2	Document history	1.1-2
1.1.3	Products to which the System Manual applies	1.1-3
1.2	Legal regulations	1.2-1

Preface and general information	1
How to use this System Manual	1.1
Information provided by the System Manual	1.1.1

1.1 How to use this System Manual

1.1.1 Information provided by the System Manual

Target group This System Manual is intended for all persons who design, install, commission, and adjust the 9300 vector frequency inverter.

Together with the System Manual (extension), document number EDSV9383V-EXT and the catalog it forms the basis for project planning for the manufacturer of plants and machinery.

Contents The System Manual is the basis for the description of the 9300 vector frequency inverter. Together with the System Manual (extension), document number EDSVF9383V-EXT, a complete System Manual is available:

- ▶ The features and functions are described in detail.
- ▶ Examples describe how to set the parameters for typical applications.
- ▶ In case of doubt, the Operating Instructions enclosed with the 9300 vector frequency inverter always apply.

Contents of the System Manual	Contents of the System Manual (extension)
1 Preface	1 Preface
2 Safety	–
3 Technical data	–
4 Installing the basic device	–
5 Wiring the basic device	–
6 Commissioning	–
7 Parameter setting	–
8 Configuration <ul style="list-style-type: none"> 8.1 Description of the function blocks <ul style="list-style-type: none"> Diameter calculator (DCALC) Digital frequency input (DFIN) Digital frequency output (DFOUT) Digital frequency ramp function generator (DFRGF) Digital frequency processing (DFSET) Internal motor control with V/f characteristic control (MCTRL1) Internal motor control with vector control (MCTRL2) 8.2 Code table 8.3 Selection lists 8.4 Table of attributes 	2 Configuration <ul style="list-style-type: none"> 2.1 Configuration with Global Drive Control 2.2 Basic configurations 2.3 How to use function blocks 2.4 Function blocks (description of the other function blocks) 2.5 Monitoring
9 Troubleshooting and fault elimination	–
10 DC-bus operation	–
11 Safety engineering	–
12 Braking operation	–
–	3 Application examples
–	4 Signal flow diagrams
13 Accessories	–
14 Appendix	5 Appendix

1 Preface and general information

- 1.1 How to use this System Manual**
- 1.1.2 Document history**

How to find information

Use the System Manual as the basis. It contains references to the corresponding chapters in the System Manual (Extension):

- Each chapter is a complete unit and comprehensively informs about a subject.
- The Table of Contents and Index help you to find all information about a certain topic.
- Descriptions and data of other Lenze products (Drive PLC, Lenze geared motors, Lenze motors, ...) can be found in the corresponding catalogs, Operating Instructions and manuals. The required documentation can be ordered at your Lenze sales partner or downloaded as PDF file from the Internet.



Tip!

Current documentation and software updates concerning Lenze products can be found on the Internet in the "Services & Downloads" area under

<http://www.Lenze.com>

1.1.2 Document history


What is new / what has changed?

Material number	Version			Description
13260707	5.0	08/2008	TD19	Revision for software version 8.0 and error corrections.
13154762	3.0	09/2006	TD23	Complete revision for software version 7.0. The System Manual also comprises the System Manual (extension), document no. EDSVF9383V-EXT.
00476715	1.0	10/2003	TD23	Documentation for hardware version 1.x and software version 6.x.

1.1.3 Products to which the System Manual applies

This documentation applies to 9300 frequency inverters as of version:

	EVF	93xx	①	E	V	Vxxxx	②	1x	③	8x	Nameplate
Controller type	EVF	Frequency inverter									
Type no. / power	400 V	500 V									
9335	110 kW	132 kW									
9336	132 kW	160 kW									
9337	162 kW	200 kW									
9338	200 kW	250 kW									
Design	E	Built-in unit									
Version	V	Vector-controlled frequency inverter									
Variant	Integrated RFI filter A										
	Integrated brake transistor										
–	400 V	–	–								
V030	400 V	•	–								
V060	400 V	–	•								
V110	400 V	•	•								
V210	400 V / 500 V	–	–								
V240	400 V / 500 V	•	–								
V270	400 V / 500 V	–	•								
V300	400 V / 500 V	•	•								
Hardware version											
Software version											






1 Preface and general information

1.1 How to use this System Manual

1.1.3 Products to which the System Manual applies

	EVF	93xx	①	E	V	Vxxxx	②	③	8x	Nameplate
Product series										
EVF Frequency inverter EVM: Master of EVF EVL: Slave of EVF										
Type no. / power										
400 V 500 V										
9381 250 kW 315 kW										
9382 315 kW 400 kW										
9383 400 kW 500 kW										
Type										
E Built-in unit										
Design										
V Vector-controlled frequency inverter X: Slave										
Variant										
Integrated RFI filter A										
Integrated brake transistor										
-										
- 400 V - -										
V030 400 V • -										
V060 400 V - •										
V110 400 V • •										
V210 400 V / 500 V - -										
V240 400 V / 500 V • -										
V270 400 V / 500 V - •										
V300 400 V / 500 V • •										
Hardware version										
Software version										
- Slave (no software version)										



1.2 Legal regulations

Labelling	Lenze controllers are unambiguously designated by the contents of the nameplate.
Manufacturer	Lenze Drive Systems GmbH, Hans-Lenze-Straße 1, D-31855 Aerzen, Germany
CE conformity	Conforms to the EC Low-Voltage Directive
Application as directed	<p>9300 vector frequency inverter and accessories</p> <ul style="list-style-type: none">▶ must only be operated under the conditions prescribed in this System Manual.▶ are components<ul style="list-style-type: none">– for open and closed loop control of variable speed drives with asynchronous standard motor or asynchronous servo motors– for installation in a machine– for assembly with other components to form a machine.▶ comply with the requirements of the Low-Voltage Directive.▶ are not machines for the purpose of the Machinery Directive.▶ are not to be used as domestic appliances, but only for industrial purposes.
	<p>Drives with 9300 vector frequency inverters</p> <ul style="list-style-type: none">▶ comply with the EMC Directive if they are installed according to the guidelines of CE-typical drive systems.▶ can be used<ul style="list-style-type: none">– for operation on public and non-public mains– for operation in industrial premises and residential areas.▶ The user is responsible for the compliance of his application with the EC directives.
	<p>Any other use shall be deemed as inappropriate!</p>

Liability

The information, data, and notes in this System Manual met the state of the art at the time of printing. Claims on modifications referring to controllers and components which have already been supplied cannot be derived from the information, illustrations, and descriptions.

The specifications, processes, and circuitry described in this System Manual are for guidance only and must be adapted to your own specific application. Lenze does not take responsibility for the suitability of the process and circuit proposals.

The specifications in this System Manual describe the product features without guaranteeing them.

Lenze does not accept any liability for damage and operating interference caused by:

- ▶ Disregarding the System Manual
- ▶ Unauthorised modifications to the controller
- ▶ Operating errors
- ▶ Improper working on and with the controller

Warranty

See terms of sales and delivery of the Lenze Drive Systems GmbH.

Warranty claims must be made to Lenze immediately after detecting the deficiency or fault.

The warranty is void in all cases where liability claims cannot be made.

2 Safety instructions

Contents

2.1	General safety and application notes for Lenze controllers	2.1-1
2.2	General safety and application instructions for Lenze motors	2.2-1
2.3	Residual hazards	2.3-1
2.4	Definition of notes used	2.4-1

2.1 General safety and application notes for Lenze controllers

(in accordance with Low-Voltage Directive 2006/95/EC)

For your personal safety

Depending on their degree of protection, some parts of the Lenze controllers (frequency inverters, servo inverters, DC speed controllers) and their accessory components can be live, moving and rotating during operation. Surfaces can be hot.

Non-authorised removal of the required cover, inappropriate use, incorrect installation or operation, creates the risk of severe injury to persons or damage to material assets.

For more information, please see the documentation.

High amounts of energy are produced in the controller. Therefore it is required to wear personal protective equipment (body protection, headgear, eye protection, ear protection, hand guard).

All operations concerning transport, installation, and commissioning as well as maintenance must be carried out by qualified, skilled personnel (IEC 364 or CENELEC HD 384 or DIN VDE 0100 and IEC report 664 or DIN VDE 0110 and national regulations for the prevention of accidents must be observed). According to this basic safety information, qualified, skilled personnel are persons who are familiar with the assembly, installation, commissioning, and operation of the product and who have the qualifications necessary for their occupation.

Application as directed

Controllers are components which are designed for installation in electrical systems or machines. They are not to be used as domestic appliances, but only for industrial purposes according to EN 61000-3-2.

When controllers are installed into machines, commissioning (i.e. starting of the operation as directed) is prohibited until it is proven that the machine complies with the regulations of the EC Directive 98/37/EC (Machinery Directive); EN 60204 must be observed.

Commissioning (i.e. starting of the operation as directed) is only allowed when there is compliance with the EMC Directive (2004/108/EC).

The controllers meet the requirements of the Low-Voltage Directive 2006/95/EC. The harmonised standard EN 61800-5-1 applies to the controllers.

The technical data and supply conditions can be obtained from the nameplate and the documentation. They must be strictly observed.

Warning: Controllers are products which can be installed in drive systems of category C2 according to EN 61800-3. These products can cause radio interferences in residential areas. In this case, special measures can be necessary.

Transport, storage

Please observe the notes on transport, storage, and appropriate handling. Observe the climatic conditions according to the technical data.

Installation

The controllers must be installed and cooled according to the instructions given in the corresponding documentation.

Ensure proper handling and avoid excessive mechanical stress. Do not bend any components and do not change any insulation distances during transport or handling. Do not touch any electronic components and contacts.

Controllers contain electrostatic sensitive devices which can easily be damaged by inappropriate handling.

Do not damage or destroy any electrical components since this might endanger your health!

Electrical connection

When working on live controllers, observe the applicable national regulations for the prevention of accidents (e.g. VBG 4).

The electrical installation must be carried out according to the appropriate regulations (e.g. cable cross-sections, fuses, PE connection). Additional information can be obtained from the documentation.

This documentation contains information on installation in compliance with EMC (shielding, earthing, filters, and cables). These notes must also be observed for CE-marked controllers. The manufacturer of the system is responsible for compliance with the limit values demanded by EMC legislation. The controllers must be installed in housings (e.g. control cabinets) to meet the limit values for radio interferences valid at the site of installation. The housings must enable an EMC-compliant installation. Observe in particular that e.g. the control cabinet doors have a circumferential metal connection to the housing. Reduce housing openings and cutouts to a minimum.

Lenze controllers can cause a direct current in the protective conductor. If a residual current device (RCD) is used as a protective means in case of direct or indirect contact, only a residual current device (RCD) of type B may be used on the current supply side of the controller. Otherwise, another protective measure such as separation from the environment through double or reinforced insulation or disconnection from the mains by means of a transformer must be applied.

Operation

If necessary, systems including controllers must be equipped with additional monitoring and protection devices according to the valid safety regulations (e.g. law on technical equipment, regulations for the prevention of accidents). The controllers can be adapted to your application. Please observe the corresponding information given in the documentation.

After the controller has been disconnected from the supply voltage, all live components and power connections must not be touched immediately because capacitors can still be charged. Please observe the corresponding stickers on the controller.

All protection covers and doors must be shut during operation.

Notes for UL-approved systems with integrated controllers: UL warnings are notes that only apply to UL systems. The documentation contains special UL notes.

Safety functions

Special controller variants support safety functions (e.g. "safe torque off", formerly "safe standstill") according to the requirements of Appendix I No. 1.2.7 of the EC Directive "Machinery" 98/37/EC, EN 954-1 Category 3 and EN 1037. Strictly observe the notes on the safety functions given in the documentation for the respective variants.

Maintenance and servicing	The controllers do not require any maintenance if the prescribed operating conditions are observed. If the ambient air is polluted, the cooling surfaces of the controller may become dirty or the air vents may be obstructed. Therefore, clean the cooling surfaces and air vents periodically under these operating conditions. Do not use sharp or pointed tools for this purpose!
Disposal	Recycle metal and plastic materials. Ensure professional disposal of assembled PCBs. The product-specific safety and application notes given in these instructions must be observed!

2.2 General safety and application instructions for Lenze motors

(According to: Low-Voltage Directive 2006/95/EC)

General	<p>Low-voltage machines have hazardous live and rotating parts and possibly also hot surfaces.</p> <p>Synchronous machines induce voltages at open terminals during operation.</p> <p>All operations concerning transport, connections, commissioning and maintenance must be carried out by qualified, skilled personnel (EN 50110-1 (VDE 0105-100) and IEC 60364 must be observed). Inappropriate use creates the risk of severe injury to persons and damage to material assets.</p> <p>Low-voltage machines may only be operated under the conditions that are indicated in the section "Application as directed".</p> <p>The conditions at the place of installation must comply with the data given on the nameplate and in the documentation.</p>
Application as directed	<p>Low-voltage machines are intended for commercial installations. They comply with the harmonised standards of the series EN 60034 (VDE 0530). Their use in potentially explosive atmospheres is prohibited unless they are expressly intended for such use (follow additional instructions).</p> <p>Low-voltage machines are components for installation into machines as defined in the Machinery Directive 98/37/EC. Commissioning is prohibited until the conformity of the end product with this directive has been established (follow i. a. EN 60204-1).</p> <p>Low-voltage machines with IP23 protection or less are only intended for outdoor use when applying special protective features.</p> <p>The integrated brakes must not be used as safety brakes. It cannot be ruled out that factors which cannot be influenced, such as oil ingress due to a defective A-side shaft seal, cause a brake torque reduction.</p>
Transport, storage	<p>Damage must be reported immediately to the forwarder upon receipt; if required, commissioning must be excluded. Tighten screwed-in ring bolts before transport. They are designed for the weight of the low-voltage machines, do not apply extra loads. If necessary, use suitable and adequately dimensioned means of transport (e. g. rope guides).</p> <p>Remove transport locking devices before commissioning. Reuse them for further transport. When storing low-voltage machines, ensure a dry, dust-free and low-vibration ($v_{eff} \leq 0.2 \text{ mm/s}$) environment (bearing damage while being stored).</p>

Installation

Ensure an even surface, solid foot/flange mounting and exact alignment if a direct clutch is connected. Avoid resonances with the rotational frequency and double mains frequency which may be caused by the assembly. Turn rotor by hand, listen for unusual slipping noises. Check the direction of rotation when the clutch is not active (observe section "Electrical connection").

Use appropriate means to mount or remove belt pulleys and clutches (heating) and cover them with a touch guard. Avoid impermissible belt tensions.

The machines are half-key balanced. The clutch must be half-key balanced, too. The visible jutting out part of the key must be removed.

If required, provide pipe connections. Designs with shaft end at bottom must be protected with a cover which prevents the ingress of foreign particles into the fan. Free circulation of the cooling air must be ensured. The exhaust air - also the exhaust air of other machines next to the drive system - must not be taken in immediately.

Electrical connection

All operations must only be carried out by qualified and skilled personnel on the low-voltage machine at standstill and deenergised and provided with a safe guard to prevent an unintentional restart. This also applies to auxiliary circuits (e. g. brake, encoder, blower).

Check safe isolation from supply!

If the tolerances specified in EN 60034-1; IEC 34 (VDE 0530-1) - voltage $\pm 5\%$, frequency $\pm 2\%$, waveform, symmetry - are exceeded, more heat will be generated and the electromagnetic compatibility will be affected.

Observe the data on the nameplate, operating notes, and the connection diagram in the terminal box.

The connection must ensure a continuous and safe electrical supply (no loose wire ends); use appropriate cable terminals. The connection to the PE conductor must be safe. The plug-in connectors must be bolted tightly (to stop).

The clearances between blank, live parts and to earth must not fall below 8 mm at $U_r \leq 550$ V, 10 mm at $U_r \leq 725$ V, 14 mm at $U_r \leq 1000$ V.

The terminal box must be free of foreign particles, dirt and moisture. All unused cable entries and the box itself must be sealed against dust and water.

Commissioning and operation	<p>Before commissioning after longer storage periods, measure insulation resistance. In case of values $\leq 1 \text{ k}\Omega$ per volt of rated voltage, dry winding.</p> <p>For trial run without output elements, lock the featherkey. Do not deactivate the protective devices, not even in a trial run.</p> <p>Check the correct operation of the brake before commissioning low-voltage machines with brakes.</p> <p>Integrated thermal detectors do not provide full protection for the machine. If necessary, limit the maximum current. Parameterise the controller so that the motor will be switched off with $I > I_{\text{f}}$ after a few seconds of operation, especially at the risk of blocking.</p> <p>Vibrational severities $v_{\text{eff}} \leq 3.5 \text{ mm/s}$ ($P_r \leq 15 \text{ kW}$) or 4.5 mm/s ($P_r > 15 \text{ kW}$) are acceptable if the clutch is activated.</p> <p>If deviations from normal operation occur, e.g. increased temperatures, noises, vibrations, find the cause and, if required, contact the manufacturer. In case of doubt, switch off the low-voltage machine.</p> <p>If the machine is exposed to dirt, clean the air paths regularly.</p> <p>Shaft sealing rings and roller bearings have a limited service life.</p> <p>Regrease bearings with relubricating devices while the low-voltage machine is running. Only use the grease recommended by the manufacturer. If the grease drain holes are sealed with a plug, (IP54 drive end; IP23 drive and non-drive end), remove plug before commissioning. Seal bore holes with grease. Replace prelubricated bearings (2Z bearing) after approx. 10,000 h - 20,000 h, at the latest however after 3 - 4 years.</p> <p>The product-specific safety and application notes given in these instructions must be observed!</p>
------------------------------------	--

2.3 Residual hazards

Protection of persons

- ▶ Before working on the controller, check that no voltage is applied to the power terminals:
 - The power terminals U, V, W, +U_G, -U_G, BR1, BR2 and 101 ... 104 remain live for at least five minutes after disconnecting from the mains.
 - The power terminals L1, L2, L3, U, V, W, +U_G, -U_G, BR1, BR2 and 101 ... 104 remain live when the motor is stopped.
- ▶ The leakage current to earth (PE) is >3.5 mA. EN 50178 requires a fixed installation.
- ▶ The heatsink of the controller has an operating temperature of > 80 °C:
 - Direct skin contact causes burns.
- ▶ During the parameter set transfer, the control terminals of the controller can assume undefined states.
 - For this reason, the connectors X5 and X6 have to be unplugged before the transfer is executed. This ensures that the controller is inhibited and all control terminals are in the defined state “LOW”.

Device protection

- ▶ Frequent mains switching (e.g. inching mode via mains contactor) can overload and destroy the input current limitation of the controller.
 - Thus, at least five minutes have to pass between two switch-on processes.
 - In case of frequent, safety-related disconnections use the “safe torque off” safety function (STO).

Motor protection

- ▶ Certain drive controller settings can overheat the connected motor:
 - E. g. long-time operation of the DC injection brake.
 - Long-time operation of self-ventilated motors at low speeds.

Protection of the machine/system

- ▶ Drives can reach dangerous overspeeds (e. g. setting of high output frequencies in connection with motors and machines not suitable for this purpose):
 - The drive controllers do not provide protection against such operating conditions. For this purpose, use additional components.

2.4 Definition of notes used

The following pictographs and signal words are used in this documentation to indicate dangers and important information:

Safety instructions

Structure of safety instructions:



Danger!

(characterises the type and severity of danger)

Note

(describes the danger and gives information about how to prevent dangerous situations)

Pictograph and signal word	Meaning
Danger!	Danger of personal injury through dangerous electrical voltage. Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
Danger!	Danger of personal injury through a general source of danger. Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
Stop!	Danger of property damage. Reference to a possible danger that may result in property damage if the corresponding measures are not taken.

Application notes

Pictograph and signal word	Meaning
Note!	Important note to ensure troublefree operation
Tip!	Useful tip for simple handling
	Reference to another documentation

3 Technical data

Contents

3.1	General data and operating conditions	3.1-1
3.2	Weights	3.2-1
3.3	Open and closed-loop control	3.3-1
3.4	Safety relay KSR	3.4-1
3.5	Rated data (devices in 400V design)	3.5-1
3.6	Rated data (devices for 400/500V mains)	3.6-1
3.6.1	Rated data for 400 V mains voltage	3.6-1
3.6.2	Rated data for 500 V mains voltage	3.6-2
3.7	Fuses and cable cross-sections	3.7-1
3.7.1	Mains supply	3.7-1
3.7.2	DC supply	3.7-2
3.7.3	Notes for mains and motor cables	3.7-3

3.1 General data and operating conditions

General data

Conformity and approval			
Conformity			
CE	2006/95/EC	Low-Voltage Directive	
Protection of persons and equipment			
Type of protection	EN 60529 NEMA 250	IP20 Protection against accidental contact according to type 1	
Earth leakage current	EN 61800-5-1	> 3.5 mA	Observe regulations and safety instructions!
Insulation of control circuits	EN 61800-5-1	Safe mains isolation by double (reinforced) insulation for the terminals X1 and X5. Basic insulation (single isolating distance) for the terminals X3, X4, X6, X8, X9, X10 and X11.	
Insulation resistance	EN 61800-5-1	Site altitude < 2000 m: Overvoltage category III Site altitude > 2000 m: Overvoltage category II	
Protective measures		Against short circuit, earth fault (earth-fault protected during operation, limited earth-fault protection during mains power-up), overvoltage, motor stalling, motor overtemperature (input for PTC or thermal contact)	
EMC			
Noise emission	EN 61800-3	Cable-guided, up to 50 m motor cable length with RFI filter: Category C2. Radiation, with RFI filter and installation in control cabinet: Category C2	
Noise immunity	EN 61800-3	Category C3	

Operating conditions		Ambient conditions		
Climatic				
Storage	IEC/EN 60721-3-1	1K3 (-20 ... +60 °C)	< 6 months	
		1K3 (-25 ... +40 °C)	> 6 months	
			> 2 years: form DC bus capacitors	
Transport	IEC/EN 60721-3-2	2K3 (-25 ... +70 °C)		
Operation	IEC/EN 60721-3-3			
EVF9335		3K3 (0 ... +50 °C)		
EVF9336 ... EVF9338 EVF9381 ... EVF9383		3K3 (0 ... +50 °C) > +40 °C: reduce the rated output current by 2.5 %/°C.		
Pollution	EN 61800-5-1	Degree of pollution 2		
Site altitude		< 4000 m amsl > 1000 m amsl: reduce the rated output current by 5 %/ 1000 m.		
Internal fan		975 m ³ /h volume flow		
Mechanical				
Vibration resistance	EN 50178			
Electrical				
Mains connection				
Power system				
TT, TN (with earthed neutral)			Operation is permitted without restrictions.	
DC-bus operation			Possible for the variants V210, V240, V270, V300	
Motor connection				
Length of the motor cable			At rated mains voltage and a switching frequency of ≤ 2 kHz without additional output filter. For compliance with EMC regulations, the permissible cable lengths may change.	
shielded			100 m	
unshielded			200 m	
Mounting conditions				
Mounting place			In the control cabinet	
Mounting position			Vertical	
Free spaces			4-1	

3.2**Weights**

9300	Without RFI filter A	With integrated RFI filter A
Type	[kg]	[kg]
EVF9335-EV	160	175
EVF9336-EV	160	175
EVF9337-EV	160	175
EVF9338-EV	200	215
EVF9381-EV	320	350
EVF9382-EV	320	350
EVF9383-EV	400	430

3.3 Open and closed-loop control

Field	Values	
Control methods	V/f characteristic control (linear, square), vector control	
Switching frequency	1 kHz, 2 kHz or 4 kHz	
Torque behaviour in the case of vector control		
Maximum torque	1.5 × M_r for 60 s if rated motor power = rated 9300 vector power	
Setting range	Up to 1 : 10 (1 : 20 with feedback)	in the range 6 ... 100 % f_r
Speed control without feedback		
Min. mechanical motor frequency	1 % f_r	torque 0 ... M_r
Setting range	1 : 100	relating to f_r and M_r
Accuracy	± 0.5 % f_r	in the range 6 ... 100 % f_r
Speed control with feedback		
Min. mechanical motor frequency	0.1 % f_r	torque 0 ... M_r
Setting range	1 : 1000	relating to f_r and M_r
Accuracy	± 0.1 % of f_r	
Output frequency		
Field	- 300 Hz ... + 300 Hz	
Absolute resolution	0.06 Hz	
Standardised resolution	Parameter data: 0.01 %, Process data: 0.006 % (= 2^{14})	
Digital setpoint selection		
Accuracy	± 0.005 Hz (= ± 100 ppm)	
Analog setpoint selection		
Linearity	± 0,15 %	signal level: 5 V or 10 V
Temperature sensitivity	± 0,1 %	0 ... 50 Nm
Offset	± 0 %	
Analog inputs/analog outputs	<ul style="list-style-type: none"> ● 2 inputs (bipolar) ● 2 outputs (bipolar) 	
Digital inputs/digital outputs	<ul style="list-style-type: none"> ● 6 inputs (freely assignable) ● 1 input for controller inhibit ● 4 outputs (freely assignable) ● 1 incremental encoder input (500 kHz, TTL level); Design: 9-pole Sub-D socket ● 1 digital frequency input (500 kHz, TTL level or 200 kHz, HTL level); type: 9-pole Sub-D socket; can be alternatively used as incremental encoder input (200 kHz, HTL level) ● 1 master frequency output (500 kHz, TTL level); Design: 9-pole Sub-D socket 	
Cycle times		
Digital inputs	1 ms	
Digital outputs	1 ms	
Analog inputs	1 ms	
Analog outputs	1 ms (smoothing time: $\tau = 10$ ms)	
Operation in generator mode	Integrated brake transistor (optional)	

f_r rated motor frequency
 M_r rated motor torque

3.4

Safety relay K_{SR}

Terminal	Description	Field	Values
X11/K32	Safety relay K _{SR} 1st disconnecting path	Coil voltage at +20 °C	DC 24 V (20 ... 30 V)
X11/K31		Coil resistance at +20 °C	823 Ω ±10 %
X11/33		Rated coil power	Approx. 700 mW
X11/34		Max. switching voltage	AC 250 V, DC 250 V (0.45 A)
		Max. AC switching capacity	1500 VA
		Max. switching current (ohmic load)	AC 6 A (250 V), DC 6 A (50 V)
		Recommended minimum load	> 50 mW
		Max. switching rate	6 switchings per minute
		Mechanical service life	10 ⁷ switching cycles
	Electrical service life	at 250 V AC (ohmic load)	10 ⁵ switching cycles at 6 A 10 ⁶ switching cycles at 1 A 10 ⁷ switching cycles at 0.25 A
		at 24 V DC (ohmic load)	6 × 10 ³ switching cycles at 6 A 10 ⁶ switching cycles at 3 A 1.5 × 10 ⁶ switching cycles at 1 A 10 ⁷ switching cycles at 0.1 A

3.5 Rated data (devices in 400V design)

Basis of the data		Voltage	Frequency
Supply			
3/PE AC 400 V	[U _N]	340 V - 0 % ... 456 V + 0 %	45 Hz - 0 % ... 65 Hz + 0 %
DC (alternatively)	[U _{DC}]		Not possible
Output voltage	[U _{OUT}]	3 ~ 0 ... U _N	0 ... 300 Hz

9300	Mains current¹⁾	Typical motor power ASM (4-pole)		Power loss
Type	I _r [A]	P _N [kW]	P _N [hp]	P _V [kW]
EVF9335-EV EVF9335-EVVxxx ²⁾	200	110	150	2.8
EVF9336-EV EVF9336-EVVxxx ²⁾	238	132	200	3.3
EVF9337-EV EVF9337-EVVxxx ²⁾	285	160	250	4.0
EVF9338-EV EVF9338-EVVxxx ²⁾	356	200	300	5.0
EVF9381-EV EVF9381-EVVxxx ²⁾	475	250	350	6.6
EVF9382-EV EVF9382-EVVxxx ²⁾	570	315	450	8.0
EVF9383-EV EVF9384-EVVxxx ²⁾	713	400	550	10.0

The currents for EVF9381 ... EVF9383 are to be considered as total currents of master and slave

¹⁾ For a controller switching frequency of 2 kHz

²⁾ Device in variant V030, V060 or V110

9300	Output currents					
	Rated current			Maximum current ²⁾		
Type	I _{N1} [A]	I _{N2} [A]	I _{N4} [A]	I _{M1} [A]	I _{M2} [A]	I _{M4} [A]
EVF9335-EV EVF9335-EVVxxx ³⁾	210	210	210	315	315	315
EVF9336-EV EVF9336-EVVxxx ³⁾	250	250	250	375	375	375
EVF9337-EV EVF9337-EVVxxx ³⁾	300	300	270	450	450	405
EVF9338-EV EVF9338-EVVxxx ³⁾	375	375	330	560	560	495
EVF9381-EV EVF9381-EVVxxx ³⁾	500	500	500	750	750	750
EVF9382-EV EVF9382-EVVxxx ³⁾	600	600	540	900	900	810
EVF9383-EV EVF9384-EVVxxx ³⁾	750	750	660	1125	1125	990

The currents for EVF9381 ... EVF9383 are to be considered as total currents of master and slave

Bold print = Lenze setting

¹⁾ Switching frequency of the inverter

²⁾ The currents apply to a periodic load change with an overcurrent time of 1 minute at a maximum and a base load time of 2 minutes with maximally 75 % I_{Nx}

³⁾ Device in variant V030, V060 or V110

Technical data		3
Rated data (devices for 400/500V mains)		3.6
Rated data for 400 V mains voltage		3.6.1

3.6 Rated data (devices for 400/500V mains)



Note!

Types EVF9335 ... EVF9383 for 400 V/500 V mains voltage are suitable for DC supply or DC-bus operation together with controllers of the 9300 series.

3.6.1 Rated data for 400 V mains voltage

Basis of the data		Voltage	Frequency
Supply			
3/PE AC 400 V	[U _N]	340 V - 0 % ... 577 V + 0 %	45 Hz - 0 % ... 65 Hz + 0 %
DC 565 V (alternatively)	[U _{DC}]	DC 480 V - 0 % ... 800 V + 0 %	-
Output voltage	[U _{OUT}]	3 ~ 0 ... U _N	0 ... 300 Hz

9300	Mains current ¹⁾	Typical motor power ASM (4-pole)		Power loss
Type	I _r [A]	P _N [kW]	P _N [hp]	P _V [kW]
EVF9335-EVVxxx ²⁾	200	110	150	2.8
EVF9336-EVVxxx ²⁾	238	132	200	3.3
EVF9337-EVVxxx ²⁾	285	160	250	4.0
EVF9338-EVVxxx ²⁾	356	200	300	5.0
EVF9381-EVVxxx ²⁾	475	250	350	6.6
EVF9382-EVVxxx ²⁾	570	315	450	8.0
EVF9384-EVVxxx ²⁾	713	400	550	10.0

The currents for EVF9381 ... EVF9383 are to be considered as total currents of master and slave

¹⁾ For a controller switching frequency of 2 kHz

²⁾ Device in variant V210, V240, V270 or V300

9300	Output currents					
	Rated current			Maximum current ²⁾		
	I _{N1} [A]	I _{N2} [A]	I _{N4} [A]	I _{M1} [A]	I _{M2} [A]	I _{M4} [A]
EVF9335-EVVxxx ³⁾	210	210	210	315	315	315
EVF9336-EVVxxx ³⁾	250	250	250	375	375	375
EVF9337-EVVxxx ³⁾	300	300	270	450	450	405
EVF9338-EVVxxx ³⁾	375	375	330	560	560	495
EVF9381-EVVxxx ³⁾	500	500	500	750	750	750
EVF9382-EVVxxx ³⁾	600	600	540	900	900	810
EVF9384-EVVxxx ³⁾	750	750	660	1125	1125	990

The currents for EVF9381 ... EVF9383 are to be considered as total currents of master and slave

Bold print = Lenz setting

¹⁾ Switching frequency of the inverter

²⁾ The currents apply to a periodic load change with an overcurrent time of 1 minute at a maximum and a base load time of 2 minutes with maximally 75 % I_{Nx}

³⁾ Device in variant V210, V240, V270 or V300

3

Technical data

- 3.6 Rated data (devices for 400/500V mains)
 3.6.2 Rated data for 500 V mains voltage

3.6.2 Rated data for 500 V mains voltage

Basis of the data

	Voltage		Frequency
Supply			
3/PE AC 500 V	[U _N]	340 V - 0 % ... 577 V + 0 %	45 Hz - 0 % ... 65 Hz + 0 %
DC 705 V (alternatively)	[U _{DC}]	DC 480 V - 0 % ... 800 V + 0 %	—
Output voltage	[U _{OUT}]	3 ~ 0 ... U _N	0 ... 300 Hz

9300	Mains current ¹⁾	Typical motor power ASM (4-pole)		Power loss
Type	I _r [A]	P _N [kW]	P _N [hp]	P _V [kW]
EVF9335-EVVxxx ²⁾	200	132	200	3.0
EVF9336-EVVxxx ²⁾	238	160	250	3.5
EVF9337-EVVxxx ²⁾	285	200	300	4.3
EVF9338-EVVxxx ²⁾	356	250	350	5.3
EVF9381-EVVxxx ²⁾	475	315	450	7.0
EVF9382-EVVxxx ²⁾	570	400	550	8.6
EVF9383-EVVxxx ²⁾	713	500	??? 700 ???	10.6

The currents for EVF9381 ... EVF9383 are to be considered as total currents of master and slave

¹⁾ For a controller switching frequency of 2 kHz

²⁾ Device in variant V210, V240, V270 or V300

9300	Output currents					
	Rated current			Maximum current ²⁾		
	1 kHz ¹⁾	2 kHz ¹⁾	4 kHz ¹⁾	1 kHz ¹⁾	2 kHz ¹⁾	4 kHz ¹⁾
Type	I _{N1} [A]	I _{N2} [A]	I _{N4} [A]	I _{M1} [A]	I _{M2} [A]	I _{M4} [A]
EVF9335-EVVxxx ³⁾	210	210	210	315	315	315
EVF9336-EVVxxx ³⁾	250	250	250	375	375	375
EVF9337-EVVxxx ³⁾	300	300	270	450	450	405
EVF9338-EVVxxx ³⁾	375	375	330	560	560	495
EVF9381-EVVxxx ³⁾	500	500	500	750	750	750
EVF9382-EVVxxx ³⁾	600	600	540	900	900	810
EVF9384-EVVxxx ³⁾	750	750	660	1125	1125	990

The currents for EVF9381 ... EVF9383 are to be considered as total currents of master and slave

Bold print = Lenze setting

¹⁾ Switching frequency of the inverter

²⁾ The currents apply to a periodic load change with an overcurrent time of 1 minute at a maximum and a base load time of 2 minutes with maximally 75 % I_{Nx}

³⁾ Device in variant V210, V240, V270 or V300

Technical data	3
Fuses and cable cross-sections	3.7
Mains supply	3.7.1

3.7 Fuses and cable cross-sections

Information about fuses and cable cross-sections	Field	Description
	Fuses and cable cross-sections	All information given in this chapter are recommendations. They refer to <ul style="list-style-type: none"> • controllers installed in control cabinets. • cables with a distance to the wall which is at least as wide as the cable cross-section. • a max. ambient temperature of +40 °C.
	Selection of the cable cross-section	Consider the voltage drop under load ($\leq 3\%$ acc. to DIN 18015 part 1) for the selection.
	Protection of the cables on the AC side (L1, L2, L3)	On the AC side, the cables are protected by means of common fuses. Fuses in UL-conform plant must have UL approval.
	Protection of the cables on the motor side (U, V, W)	It is not necessary to fuse the motor cable.
	Further information	In the chapter "Wiring the basic device" → "Important notes" → "Device protection"
	Standards and regulations	The user is responsible for the compliance with national and regional standards and regulations (e.g. VDE 0113, VDE 0298, EN 60204).

3.7.1 Mains supply

For fusing the mains supply you can use the following fuses (gRL) and cable cross-sections:

9300 vector	Installation in accordance with EN 60204-1					
	Fuse	Cable cross-sections				PE
		Type	[A]	L1, L2, L3	[mm ²]	
EVF9335-EV EVF9335-EVVxxx	250			150 2 × 50 ¹⁾		95
EVF9336-EV EVF9336-EVVxxx	315			150 2 × 50 ¹⁾		95
EVF9337-EV EVF9337-EVVxxx	315			150 2 × 50 ¹⁾		95
EVF9338-EV EVF9338-EVVxxx	400			240 2 × 95 ¹⁾		150
	Master	Slave	Master	Slave	Master	Slave
EVF9381-EV EVF9381-EVVxxx	315	315	150 2 × 50 ¹⁾	150 2 × 50 ¹⁾	95	95
EVF9382-EV EVF9382-EVVxxx	315	315	150 2 × 50 ¹⁾	150 2 × 50 ¹⁾	95	95
EVF9383-EV EVF9383-EVVxxx	400	400	240 2 × 95 ¹⁾	240 2 × 95 ¹⁾	150	150

¹⁾ Multiple conductor; both conductors must have the same cross-section



Note!

We recommend to use semiconductor fuses (gRL).

3.7.2 DC supply

A DC supply is only possible for the variants V210, V240, V270, V300.

**Stop!**

- Only use semiconductor fuses (gRL).
- On principle, fuse DC cables as 2-pole ($+U_G$, $-U_G$).

9300 vector	Installation in accordance with EN 60204-1					
	Type	Fuse		Cable cross-sections		
		[A]		$+U_G$, $-U_G$ [mm ²]	PE [mm ²]	
EVF9335-EVV2xx EVF9335-EVV300		315		150 2 × 50 ¹⁾		95
EVF9336-EVV2xx EVF9336-EVV300		350		150 2 × 50 ¹⁾		95
EVF9337-EVV2xx EVF9337-EVV300		400		240 2 × 95 ¹⁾		95
EVF9338-EVV2xx EVF9338-EVV300		500		240 2 × 95 ¹⁾		150
	Master	Slave	Master	Slave	Master	Slave
EVF9381-EVV2xx EVF9381-EVV300	350	350	150 2 × 50 ¹⁾	150 2 × 50 ¹⁾	95	95
EVF9382-EVV2xx EVF9382-EVV300	400	400	240 2 × 95 ¹⁾	240 2 × 95 ¹⁾	95	95
EVF9383-EVV2xx EVF9383-EVV300	500	500	240 2 × 95 ¹⁾	240 2 × 95 ¹⁾	150	150

¹⁾ Multiple conductor; both conductors must have the same cross-section

Technical data	3
Fuses and cable cross-sections	3.7
Notes for mains and motor cables	3.7.3

3.7.3 Notes for mains and motor cables



Danger!

Observe all national and regional regulations for the cables.

You can use single and multi-core cables. If a cable consists of several cores per phase, it can be necessary to connect the controller by means of common cable glands.

Maximum cable cross-section for power connections (screw terminals):

9300 vector	Maximum cable cross-section				
	L1, L2, L3 U, V, W, BR1, BR2	[mm ²]	+U _G , -U _G	PE	
Type	[mm ²]	[mm ²]	[mm ²]		
EVF9335-EV EVF9335-EVxxx	150 (2 × 50) ¹⁾	150 (2 × 50) ¹⁾	95		
EVF9336-EV EVF9336-EVxxx	150 (2 × 50) ¹⁾	150 (2 × 50) ¹⁾	95		
EVF9337-EV EVF9337-EVxxx	150 (2 × 50) ¹⁾	240 (2 × 95) ¹⁾	95		
EVF9338-EV EVF9338-EVxxx	240 (2 × 95) ¹⁾	240 (2 × 95) ¹⁾	150		
	Master	Slave	Master	Slave	
EVF9381-EV EVF9381-EVxxx	150 (2 × 50) ¹⁾	150 (2 × 50) ¹⁾	150 (2 × 50) ¹⁾	95	95
EVF9382-EV EVF9382-EVxxx	150 (2 × 50) ¹⁾	150 (2 × 50) ¹⁾	240 (2 × 95) ¹⁾	95	95
EVF9383-EV EVF9383-EVxxx	240 (2 × 95) ¹⁾	240 (2 × 95) ¹⁾	240 (2 × 95) ¹⁾	150	150

¹⁾ Multiple conductor; both conductors must have the same cross-section

The effectively required cable cross-section depends e.g. on the application and environmental conditions and the cable type used. It is not required that mains and motor cable have the same cable cross-section.

Mains cable, DC cable

It is not necessary to shield the mains cable. In DC-bus operation or with DC supply we recommend shielded cables.

Motor cable

It is not necessary to fuse the motor cable. For EMC reasons we recommend shielded motor cables. You can use common metal clamps to connect the shield.

4 Installation of the standard device

Contents

4.1	Important notes	4.1-1
4.2	Basic devices in the power range 110 ... 200 kW	4.2-1
4.2.1	Dimensions	4.2-1
4.2.2	Drilling the holes into the mounting plate	4.2-2
4.2.3	Fasten the mounting rails on the mounting plate	4.2-3
4.2.4	Fasten controller on mounting plate	4.2-4
4.3	Basic devices in the power range 250 ... 400 kW	4.3-1
4.3.1	Dimensions	4.3-1
4.3.2	Drilling the holes into the mounting plate	4.3-2
4.3.3	Fasten the mounting rails on the mounting plate	4.3-3
4.3.4	Fasten controller on mounting plate	4.3-4

4.1 Important notes

Transport

- ▶ Manual lifting is only permitted up to the following weight limitations:
 - max. 30 kg [max. 66 lbs] for men
 - max. 10 kg [max. 22 lbs] for women
 - max. 5 kg [max. 11 lbs] for pregnant womenAbove these limits, use appropriate hoists or conveyors! Weights of the devices: (§ 3.2-1)
- ▶ For transport with hoists, observe the following basic rules:
 - The payload of the hoists and load handling devices at least has to correspond to the weight of the device. Weight of the devices: (§ 3.2-1)
 - Secure the device so that it cannot topple over or fall down.
 - Stay out from suspended loads!
 - Avoid heavy impacts during transport.
- ▶ The devices are equipped with an eye bolt. The load hook can be attached directly to the eye bolt.
- ▶ Alternatively the devices can be transported with lifting straps.
 - Attach the lifting straps so that the device is balanced and cannot slip from the lifting straps.

Mounting

- ▶ Controller must only be used as built-in unit.
- ▶ Possible mounting position: Vertically at the rear panel of the control cabinet.
- ▶ Observe free mounting spaces.
- ▶ Do not exceed the permissible operating and ambient temperatures:
 - Please ensure unimpeded ventilation of cooling air.
 - If the cooling air contains pollutants (dust, lint, grease, aggressive gases), which may impair the function of the controller take measures against it, such as separate air flow, filters, regular cleaning, etc..

4.2

Basic devices in the power range 110 ... 200 kW



Tip!

- Lenze recommends to install an air lock. It serves to dissipate the heated cooling air directly from the control cabinet.
– Order no. E93ZWL
- A drilling jig for marking the bore holes is available as dxf-file on the Internet in the "Download" area under www.Lenze.de.

4.2.1

Dimensions




Fig. 4.2-1 Dimensions

[A] Eyebolts

Type	a [mm]	a1 [mm]	a2 [mm]	b [mm]	b1 [mm]	b2 [mm]	c [mm]	d [mm]
EVF9335-EV								
EVF9335-EVVxxx								
EVF9336-EV								
EVF9336-EVVxxx	500	450	225	1145	1005	15	436	9 (8x)
EVF9337-EV								
EVF9337-EVVxxx								
EVF9338-EV								
EVF9338-EVVxxx								

Installing of the standard device

Basic devices in the power range 110 ... 200 kW

Drilling the holes into the mounting plate

4.2.2 Drilling the holes into the mounting plate

Assembly space	Minimum clearance
Left/right of other controllers	30 mm
Left/right of a non-heat-conducting wall	100 mm
Top/bottom	200 mm

Comply with the clearances given to ensure a sufficient cooling of the controller. When using an air lock, different clearances apply (see Mounting Instructions for the air lock).




Fig. 4.2-2 Bore holes in the mounting plate for fixing the controller

a1	a2	a3	b	d
450 mm	340 mm	225 mm	1005 mm	9 mm (12x)

1. Mark the bore holes on the mounting plate according to the figure.
2. Drill the holes into the mounting plate.


4.2.3 Fasten the mounting rails on the mounting plate

Fig. 4.2-3 Fastening the mounting rails on the mounting plate

- A** Mounting rail
- B** Mounting plate
- C** Hexagon socket screw M8 × 25 mm
- D** Spring washer M8

1. Hold the mounting rails behind the mounting plate.
2. Fasten the mounting rails exactly at the illustrated points using 2 hexagon socket screws and spring washers on each side.

Installing of the standard device

Basic devices in the power range 110 ... 200 kW

Fasten controller on mounting plate

4.2.4**Fasten controller on mounting plate****Danger!**

Risk of injury due to the high weight of the controller.

The controller has to be carried using the eyebolts and an adequate lifting tool.




Fig. 4.2-4 Fastening the controller on mounting plate

A Eye bolts

B Controller

C Mounting plate

D 8 hexagon socket screws M8 × 25 mm

E 8 spring washers M8

1. Put the controller on the mounting plate.
2. Fasten the controller exactly at the illustrated points using 5 hexagon socket screws and spring washers at the top and 3 hexagon socket screws and spring washers at the bottom.

4.3 Basic devices in the power range 250 ... 400 kW



Tip!

- Lenze recommends to install an air lock. The air lock serves to dissipate the heated cooling air directly from the control cabinet.
– Order no. E93ZWL2
- A drilling jig for marking the bore holes is available as dxf-file in the Internet in the "Download" area under www.Lenze.de.

4.3.1 Dimensions




Fig. 4.3-1 Dimensions

A Eyebolts


Type	a [mm]	a1 [mm]	a2 [mm]	a3 [mm]	b [mm]	b1 [mm]	b2 [mm]	c [mm]	d [mm]
EVF9381-EV									
EVF9381-EVVxxx									
EVF9382-EV									
EVF9382-EVVxxx	1050	450	225	50	1145	1005	15	436	9 (16x)
EVF9383-EV									
EVF9383-EVVxxx									

4.3.2

Drilling the holes into the mounting plate

Assembly space	Minimum clearance
Left/right of other controllers	30 mm
Left/right of a non-heat-conducting wall	100 mm
Top/bottom	200 mm

Comply with the clearances given to ensure a sufficient cooling of the controller. When using an air lock, different clearances apply (see Mounting Instructions for the air lock).




93vec079

Fig. 4.3-2 Bore holes in the mounting plate for fixing the controller

a	a1	a2	a3	b	d
550 mm	450 mm	340 mm	225 mm	1005 mm	9 mm (24x)

1. Mark the bore holes on the mounting plate according to the figure.
2. Drill the holes into the mounting plate.

4.3.3 Fasten the mounting rails on the mounting plate

9300vec080

Fig. 4.3-3 Fastening the mounting rails on the mounting plate

- A** Mounting rail
- B** Mounting plate
- C** Hexagon socket screw M8 × 25 mm
- D** Spring washer M8

1. Hold the mounting rails behind the mounting plate.
2. Fasten the mounting rails exactly at the illustrated points using 2 hexagon socket screws and spring washers on each side.

Installing of the standard device

Basic devices in the power range 250 ... 400 kW

Fasten controller on mounting plate

4.3.4**Fasten controller on mounting plate****Danger!**

Risk of injury due to the high weight of the controller.

The controller has to be carried using the eyebolts and an adequate lifting tool.




Fig. 4.3-4 Fastening the controller on mounting plate

A	Eyebolts	D	Mounting plate
B	Master	E	16 hexagon socket screws M8 × 25 mm
C	Slave	F	16 spring washers M8

1. Put master and slave on the mounting plate.
2. Fasten the master and slave each with five hexagon socket screws and spring washers at the top and 3 hexagon socket screws and spring washers at the bottom exactly at the marked point.

5 **Wiring of the standard device**

Contents

5.1	Important notes	5.1-1
5.1.1	Protection of persons	5.1-1
5.1.2	Device protection	5.1-3
5.1.3	Motor protection	5.1-3
5.1.4	Supply forms / electrical supply conditions	5.1-4
5.1.5	Interaction with compensation equipment	5.1-4
5.2	Basics for wiring according to EMC	5.2-1
5.2.1	Shielding	5.2-1
5.2.2	Mains connection, DC supply	5.2-1
5.2.3	Motor cables	5.2-2
5.2.4	Control cables	5.2-3
5.2.5	Installation in the control cabinet	5.2-4
5.2.6	Wiring outside the control cabinet	5.2-5
5.2.7	Detecting and eliminating EMC interferences	5.2-6
5.3	Basic devices in the power range 110 ... 200 kW	5.3-1
5.3.1	Wiring according to EMC (CE-typical drive system)	5.3-1
5.3.2	Mains connection of the controller for 400 V mains voltage	5.3-3
5.3.3	Supply and fan connection of the controller for 400 V/500V mains voltage	5.3-4
5.3.4	Motor connection	5.3-7
5.3.5	Wiring of motor temperature monitoring	5.3-8
5.4	Basic devices in the power range 250 ... 400 kW	5.4-1
5.4.1	Wiring according to EMC (CE-typical drive system)	5.4-1
5.4.2	Master and slave connection	5.4-3
5.4.3	Mains connection of the controller for 400 V mains voltage	5.4-7
5.4.4	Supply and fan connection of the controller for 400 V/500V mains voltage	5.4-8
5.4.5	Motor connection	5.4-12
5.4.6	Wiring of motor temperature monitoring	5.4-14
5.5	Connection terminal of the control card	5.5-1
5.6	Control terminals	5.6-1
5.6.1	Important notes	5.6-1
5.6.2	With function "Safe torque off" active	5.6-2
5.6.3	With function "Safe torque off" deactivated	5.6-5
5.6.4	Terminal assignment	5.6-7
5.7	Wiring of the system bus (CAN)	5.7-1

5.8	Wiring of the feedback system	5.8-1
5.8.1	Important notes	5.8-1
5.8.2	Incremental encoder with TTL level at X8	5.8-2
5.8.3	Incremental encoder with HTL level at X9	5.8-3
5.9	Wiring of digital frequency input / digital frequency output	5.9-1
5.10	Communication modules	5.10-1

Wiring of the standard device	5
Important notes	5.1
Protection of persons	5.1.1

5.1 **Important notes**



Stop!

The drive controller contains electrostatically sensitive components.

The personnel must be free of electrostatic charge when carrying out assembly and service operations.

5.1.1 **Protection of persons**



Danger!

Before working on the controller, check that no voltage is applied to the power terminals:

- ▶ The power terminals U, V, W, +U_G, -U_G, BR1, BR2 and 101 ... 104 remain live for at least five minutes after disconnecting the mains.
- ▶ The power terminals L1, L2, L3, U, V, W, +U_G, -U_G, BR1, BR2 and 101 ... 104 remain live when the motor is stopped.

Pluggable terminal strips

All pluggable terminals must only be connected or disconnected when no voltage is applied!


Electrical isolation

The terminals X1 and X5 have a double (reinforced) insulation in accordance with EN 61800-5-1. The protection against accidental contact is ensured without any further measures.



Danger!

- ▶ Terminals X3, X4, X6, X8, X9, X10, X11 have a single basic insulation (single isolating distance).
- ▶ Protection against accidental contact in case of a defective isolating distance is only guaranteed through external measures, e.g. double insulation.
- ▶ If an external DC 24 V voltage source is used, the insulation level of the controller depends on the insulation level of the voltage source.



9300VEC009

Fig. 5.1-1 Electrical isolation between power terminals, control terminals and housing



- ☰ Double (reinforced) insulation
- ☰ Basic insulation

Replacing defective fuses

Only replace defective fuses in the deenergised state to the type specified.

Disconnecting the controller from the mains

Only carry out the safety-related disconnection of the controller from the mains via a contactor on the input side or a manually operated toggle switch.

Wiring of the standard device	5
Important notes	5.1
Device protection	5.1.2

5.1.2 Device protection

- ▶ In the event of condensation, connect the controller to the mains voltage only after the humidity has evaporated.
- ▶ The controller is protected by external fuses.
- ▶ Length of the screws for connecting the shield sheet for the control cables: **12 mm**.
- ▶ Cyclic connection and disconnection of the supply voltage can overload and destroy the input current limitation of the controller. In case of cyclic mains switching over a longer period of time, the controller must not be switched on more frequently than every 5 minutes!
- ▶ Switching on the motor side of the controller is only permitted for emergency switch-off.
- ▶ Provide unused control inputs and outputs with terminal strips. Cover unused Sub-D sockets with protective covers included in the scope of supply.

5.1.3 Motor protection

- ▶ Extensive protection against overload:
 - By overcurrent relays or temperature monitoring.
 - We recommend the use of PTC thermistors or thermostats to monitor the motor temperature.
 - PTC thermistors or thermostats can be connected to the controller.
- ▶ Only use motors with an insulation suitable for the inverter operation:
 - Insulation resistance: max. $U = 1.5 \text{ kV}$, max. $du/dt = 5 \text{ kV}/\mu\text{s}$
 - When using motors with an unknown insulation resistance, please contact your motor supplier.



Note!

To avoid bearing currents, Lenze recommends to use motors with insulated non-drive end bearings. Optionally, motor chokes can be used to reduce bearing currents.

5.1.4 Supply forms / electrical supply conditions

Please observe the restrictions of each mains type!

Mains	Controller operation	Notes
With insulated neutral point (TT/TN systems)	No restrictions	Comply with controller ratings. • Effective mains current: See chapter "Technical data"
With insulated neutral point (IT systems)	Possible if the controller is protected in the event of an earth fault in the mains supply • by means of suitable equipment for detecting an earth fault and • the controller is disconnected directly from the mains	Safe operation cannot be guaranteed in the event of an earth fault at the inverter output.
DC-supply via $+U_G/-U_G$	Permitted if the DC voltage is symmetrical to PE	The controller will be destroyed when grounding $+U_G$ conductor or $-U_G$ conductor.

5.1.5 Interaction with compensation equipment

- Controllers only consume very little reactive power of the fundamental wave from the AC supply mains. Therefore, a compensation is not required.
- If the controllers are connected to a supply system with compensation equipment, this equipment must be used with chokes.
 - For this, contact the supplier of the compensation equipment.

Wiring of the standard device	5
Basics for wiring according to EMC	5.2
Shielding	5.2.1

5.2 **Basics for wiring according to EMC**

5.2.1 **Shielding**

The shielding quality is determined by a good shield connection:

- ▶ Connect the shield with a surface as large as possible.
- ▶ Use a conductive clamp to connect the shield to the conductive and grounded mounting plate with a surface as large as possible.
- ▶ Unshielded cable ends must always be as short as possible.

5.2.2 **Mains connection, DC supply**

- ▶ You can use unshielded single cores or unshielded cables to connect the controller and the mains choke to the mains.
- ▶ For DC-bus operation or DC supply, use shielded cables.
- ▶ The cable cross-section must be dimensioned for the assigned fuse protection (national and regional regulations).

5.2.3 Motor cables

- ▶ Use only shielded motor cables with braid made of tinned or nickel-plated copper. Shields made of steel braid are not suitable.
 - The overlap rate of the braid must be at least 70 % with an overlap angle of 90 °.
- ▶ The cables used must meet the requirements of the application (e.g. EN 60204-1).
- ▶ The cable for the motor temperature monitoring (PTC or thermal contact) must be shielded and separated from the motor cable.
 - With Lenze system cables, the cable for the motor temperature monitoring is integrated into the motor cable.
- ▶ Always place the shield of the motor cable at both sides - at the drive controller and at the motor.
 - Always connect the shields to the conductive and grounded mounting plate with a surface as large as possible.
- ▶ The motor cable is perfectly installed if
 - it is routed separately of mains cables and control cables,
 - crosses mains cables and control cables only at a right angle,
 - is not interrupted.
- ▶ If it is inevitable to have an interruption (e.g. through chokes, contactors or terminals):
 - The unshielded cable must not be longer than 100 mm (depending on the cable cross-section).
 - Chokes, contactors, terminals, etc. must be separated from other components (min. distance = 100 mm).
 - The motor cable shield must be connected to the mounting plate with a surface as large as possible directly before and after the point of interruption.
- ▶ Connect the shield in the motor terminal box or at the motor housing to PE with a surface as large as possible.
 - Metal cable glands at the motor terminal box ensure that the shield is connected to the motor housing with a surface as large as possible.

5.2.4 Control cables

- ▶ Control cables must be shielded to minimise interference injections.
- ▶ For lengths of 200 mm and more, use only shielded cables for analog and digital inputs and outputs. Under 200 mm, unshielded but twisted cables may be used.
- ▶ Connect the shield correctly:
 - The shield connections of the control cables must be at a distance of at least 50 mm from the shield connections of the motor cables and DC cables.
 - Connect the shield of digital input and output cables at both ends.
 - Connect the shield of analog input and output cables at one end (at the drive controller).
- ▶ To achieve an optimum shielding effect (in case of very long cables, with high interference) one shield end of analog input and output cables can be connected to PE potential via a capacitor (e.g. 10 nF/250 V) (see sketch).




Fig. 5.2-1 Shielding of long, analog control cables

5.2.5 Installation in the control cabinet

- | | |
|------------------------------------|--|
| Mounting plate requirements | <ul style="list-style-type: none">▶ Only use mounting plates with conductive surfaces (zinc-coated or V2A-steel).▶ Painted mounting plates are not suitable even if the paint is removed from the contact surfaces.▶ If several mounting plates are used, ensure a large-surface connection between the mounting plates (e.g. by using earthing strips). |
| Mounting of the components | <ul style="list-style-type: none">▶ Connect the controller and the chokes to the grounded mounting plate with a surface as large as possible. |
| Optimum cable routing | <ul style="list-style-type: none">▶ The motor cable is optimally installed if<ul style="list-style-type: none">– it is separated from mains cables and control cables,– it crosses mains cables and control cables at right angles.▶ Always install cables close to the mounting plate (reference potential), as freely suspended cables act like aerials.▶ Lead the cables to the terminals in a straight line (avoid tangles of cables).▶ Use separated cable channels for motor cables and control cables. Do not mix up different cable types in one cable channel.▶ Minimise coupling capacities and coupling inductances by avoiding unnecessary cable lengths and reserve loops.▶ Short-circuit unused cores to the reference potential.▶ Install the positive and negative wires for DC 24 V close to each other over the entire length to avoid loops. |
| Earth connections | <ul style="list-style-type: none">▶ Connect all components (controller, chokes) to a central earthing point (PE rail).▶ Set up a star-shape earthing system.▶ Comply with the corresponding minimum cable cross-sections. |

5.2.6 Wiring outside the control cabinet

Notes for cable routing outside the control cabinet:

- ▶ The longer the cables the greater the space between the cables must be.
- ▶ If cables for different signal types are routed in parallel, the interferences can be minimized by means of a metal barrier or separated cable ducts.




Fig. 5.2-2 Cable routing in the cable duct with barrier




Fig. 5.2-3 Cable routing in separated cable ducts

5.2.7 Detecting and eliminating EMC interferences

Fault	Cause	Remedy
Interferences of analog setpoints of your own or other devices and measuring systems	Unshielded motor cable	Use shielded motor cable
	Shield contact is not extensive enough	Carry out optimal shielding as specified
	Shield of the motor cable is interrupted by terminal strips, switched, etc.	<ul style="list-style-type: none">● Separate components from other component part with a minimum distance of 100 mm● Use motor choke/motor filter
	Install additional unshielded cables inside the motor cable (e.g. for motor temperature monitoring)	Install and shield additional cables separately
Conducted interference level is exceeded on the supply side	Too long and unshielded cable ends of the motor cable	Shorten unshielded cable ends to maximally 40 mm
	Terminal strips for the motor cable are directly located next to the mains terminals	Spatially separate the terminal strips for the motor cable from main terminals and other control terminals with a minimum distance of 100 mm
	Mounting plate varnished	Optimise PE connection: <ul style="list-style-type: none">● Remove varnish● Use zinc-coated mounting plate
HF short circuit		Check cable routing

	Wiring of the standard device	5
	Basic devices in the power range 110 ... 200 kW	5.3
	Wiring according to EMC (CE-typical drive system)	5.3.1

5.3 Basic devices in the power range 110 ... 200 kW

5.3.1 Wiring according to EMC (CE-typical drive system)

The drives comply with the EC Directive on "Electromagnetic Compatibility" if they are installed in accordance with the specifications for the CE-typical drive system. The user is responsible for the compliance of the machine application with the EC Directive.



Note!

Observe the notes given in chapter "Basics for wiring according to EMC"!




Fig. 5.3-1 Example for wiring in accordance with EMC regulations

F1 ... F3	Fuses
K10	Mains contactor
Z1	Programmable logic controller (PLC)
Z2	Brake resistor
S1	Mains contactor on
S2	Mains contactor off
+U _G , -U _G	DC-bus connection
PES	HF shield termination through large-surface connection to PE

5.3.2 Mains connection of the controller for 400 V mains voltage




Fig. 5.3-2 Mains connection example

BR1, BR2 Brake resistors can only be operated with variants V060 and V110

Fuses and cable cross-sections for the mains connection

9300 vector	Installation in accordance with EN 60204-1		
	Fuse 2)	Cable cross-sections	
Type		L1, L2, L3 [mm ²]	PE [mm ²]
EVF9335-EV EVF9335-EVVxxx	250	150 2 x 50 ¹⁾	95
EVF9336-EV EVF9336-EVVxxx	315	150 2 x 50 ¹⁾	95
EVF9337-EV EVF9337-EVVxxx	315	150 2 x 50 ¹⁾	95
EVF9338-EV EVF9338-EVVxxx	400	240 2 x 95 ¹⁾	150

1) Multiple conductor; both conductors must have the same cross-section

2) Lenze recommends to use fuses of the gRL utilisation category
 Observe the national and regional legislation

Wiring of the standard device

Basic devices in the power range 110 ... 200 kW

Supply and fan connection of the controller for 400 V/500V mains voltage

Supply and fan connection of the controller for 400 V/500V mains voltage



Stop!

The user is responsible for sufficient strain relief!

Mains connection




Fig. 5.3-3 Mains connection example

BR1, BR2 Brake resistors can only be operated with variants V270 and V300

Fuses and cable cross-sections for the mains connection

Type	Fuse ²⁾ [A]	Installation in accordance with EN 60204-1	
		Cable cross-sections L1, L2, L3 [mm ²]	PE [mm ²]
EVF9335-EV EVF9335-EVVxxx	250	150 2 x 50 ¹⁾	95
EVF9336-EV EVF9336-EVVxxx	315	150 2 x 50 ¹⁾	95
EVF9337-EV EVF9337-EVVxxx	315	150 2 x 50 ¹⁾	95
EVF9338-EV EVF9338-EVVxxx	400	240 2 x 95 ¹⁾	150

1) Multiple conductor; both conductors must have the same cross-section

2) Lenze recommends to use fuses of the gRL utilisation category

Observe the national and regional legislation

Wiring of the standard device

5

Basic devices in the power range 110 ... 200 kW


5.3

Supply and fan connection of the controller for 400 V/500V mains voltage

5.3.3

**Connection to the DC bus
(+UG, -UG)**

- For compliance with EMC requirements, Lenze recommends to use shielded DC-bus cables.
- Shield clamps are not included in the scope of supply.



9300VEC074

Fig. 5.3-4 Connection example to +UG and -UG

BR1, BR2 Brake resistors can only be operated with variants V270 and V300

A Connect the DC-bus cable shield to the conductive control cabinet mounting plate with a contact surface as large as possible by using the shield clamps.

B Conductive surface

Ensure to have the poles right!

**Fuses and cable cross-sections
for DC-bus connection**

9300 vector	Installation in accordance with EN 60204-1		
	Fuse ²⁾	Cable cross-sections	
Type	[A]	+UG, -UG [mm ²]	PE [mm ²]
EVF9335-EVV2xx	315	150 2 x 50 ¹⁾	95
EVF9335-EVV300			
EVF9336-EVV2xx	350	150 2 x 50 ¹⁾	95
EVF9336-EVV300			
EVF9337-EVV2xx	400	240 2 x 95 ¹⁾	95
EVF9337-EVV300			
EVF9338-EVV2xx	500	240 2 x 95 ¹⁾	150
EVF9338-EVV300			

¹⁾ Multiple conductor; both conductors must have the same cross-section


²⁾ Only use fuses of the gRL utilisation category

Observe the national and regional legislation

**Fan connection when
controller is supplied with
mains voltage**


Lay a bridge between the terminals when a controller is operated on a mains.

AC 340 ... 440 V



9300vec044

AC 440 ... 577 V
(when being delivered)




9300vec045

Fan connection when controller is supplied via the DC bus

**Danger!**

When the fan is externally supplied with voltage, the terminal L2 carries dangerous mains voltage!

When the controller is supplied via the DC bus, the fan must be separately supplied with mains voltage (see **B**). In this case, the bridge between the terminals 102 and 103 must be removed (see **A**).



Exchange defect fuse

In case of an external voltage supply the fan is protected by a fuse integrated in terminal 104.




Fig. 5.3-5 Fusing of the fan

A Open the fuse holder.

B Remove the defect fuse from the support and replace it by the following type:

Type: 500V SA 2A 6.32

Ref. no.: P098131

Manufacturer: Ferraz Shawmut

5.3.4 Motor connection

- To comply with the EMC regulations, Lenze recommends to use shielded motor cables.
- Shield clamps are not included in the scope of supply.



Stop!

The user is responsible for sufficient strain relief!




Fig. 5.3-6 Motor connection example

BR1, BR2 Brake resistors can only be operated with variants V060, V110, V270 and V300

A Connect the motor cable shield with a surface as large as possible to the control cabinet mounting plate by using the clamps.

B Conductive surface

Ensure to have the poles right!

Do not exceed the maximum motor cable length!

Cable cross-sections

9300 vector	Installation in accordance with EN 60204-1	
Type	U, V, W [mm ²]	PE [mm ²]
EVF9335-EV EVF9335-EVVxxx	150 2 × 50 ¹⁾	95
EVF9336-EV EVF9336-EVVxxx	150 2 × 50 ¹⁾	95
EVF9337-EV EVF9337-EVVxxx	150 2 × 50 ¹⁾	95
EVF9338-EV EVF9338-EVVxxx	240 2 × 95 ¹⁾	150

¹⁾ Multiple conductor; both conductors must have the same cross-section
 Observe the national and regional legislation

5.3.5 **Wiring of motor temperature monitoring**

The drive controller features 2 connections for motor temperature monitoring:

- ▶ Terminals T1, T2 for connecting a PTC thermistor or thermal contact (NC contact).
- ▶ Pin X8/5 and X8/8 of the incremental encoder input (X8) for connecting a KTY thermal sensor.

Motor with PTC thermistor or thermal contact (NC contact)

Wire T1, T2 only if the motor is equipped with a PTC thermistor or thermal contact (NC contact).

- An "open" cable acts like an antenna and can cause faults on the drive controller.



Danger!

- All control terminals only have basic insulation (single isolating distance) after connecting a PTC thermistor or a thermal contact.
- Protection against accidental contact in case of a defective isolating distance is only guaranteed through external measures, e.g. double insulation.




Fig. 5.3-7 Connection of PTC thermistor or thermal contact (NC contact) at T1, T2

Characteristics of the connection for motor temperature monitoring:


Terminals T1, T2

Connection	<ul style="list-style-type: none"> ● PTC thermistor <ul style="list-style-type: none"> – PTC thermistor with defined tripping temperature (acc. to DIN 44081 and DIN 44082) ● Thermal contact (NC contact) <ul style="list-style-type: none"> – Thermostat as NC contact
Tripping point	<ul style="list-style-type: none"> ● Fixed (depending on the PTC/thermal contact) ● PTC: $R_9 > 1600 \Omega$ ● Configurable as warning or error (TRIP)
Notes	<ul style="list-style-type: none"> ● Monitoring is not active in the Lenze setting. ● If you do not use a Lenze motor, we recommend the use of a PTC thermistor up to 150°C.

Motor with KTY thermal sensor


Note!

- We recommend to use Lenze system cables for wiring.
- For self-made cables only use cables with shielded cores twisted in pairs.



9300vec121

Fig. 5.3-8 Connection of KTY thermal sensor at incremental encoder input X8

Characteristics of the connection for motor temperature monitoring:

Pins X8/5, X8/8 of incremental encoder input (X8)

Connection	Linear KTY thermal sensor
Tripping point	<ul style="list-style-type: none"> ● Warning: Adjustable ● Error (TRIP): Fixed at 150 °C
Notes	<ul style="list-style-type: none"> ● Monitoring is not active in the Lenze setting. ● The KTY thermal sensor is monitored with regard to interruption and short circuit.

	Wiring of the standard device	5
	Basic devices in the power range 250 ... 400 kW	5.4
	Wiring according to EMC (CE-typical drive system)	5.4.1

5.4 Basic devices in the power range 250 ... 400 kW

5.4.1 Wiring according to EMC (CE-typical drive system)

The drives comply with the EC Directive on "Electromagnetic Compatibility" if they are installed in accordance with the specifications for the CE-typical drive system. The user is responsible for the compliance of the machine application with the EC Directive.



Note!

Observe the notes given in chapter "Basics for wiring according to EMC"!




Fig. 5.4-1 Example for wiring in accordance with EMC regulations

F1 ... F3,	Fuses
F4 ... F6	
K10	Mains contactor
Z1, Z2	Motor choke
Z3, Z4	Brake resistor
Z5	Programmable logic controller (PLC)
S1	Mains contactor on
S2	Mains contactor off
+UG, -UG	DC-bus connection
PES	HF shield termination through large-surface connection to PE

5.4.2 Master and slave connection

Important notes



Danger!

Danger of personal injury! Destruction of the controller!

Damaged control cables in the controller (master and slave) may cause a faulty control of the output stage.


Possible consequences:

- ▶ When switching on the mains voltage, high energies may discharge like an explosion.
- ▶ Explosive noises may damage your hearing. A shock by an unexpected and loud explosion may cause distress.
- ▶ The controller will be destroyed.

Protective measures:

- ▶ When working with the DC busbars, make sure that you do not damage any internal connectors and cables.
- ▶ Before attaching the cover again:
 - Check all plugs selected in Fig. 5.4-5 for damage and correct fit.
 - Check all cables involved for damages.
 - If the plugs do not fit correctly, or the plugs or cables are damaged, commissioning is prohibited. Contact the Lenze service.

Preliminary work



9300vec164

Fig. 5.4-2 Fastening the covers to the master and slave


- ▶ Remove the upper cover from the master **A** and the slave **B** to access the power sections. Each cover is fastened with 4 screws.

Wiring of the standard device

Basic devices in the power range 250 ... 400 kW

Master and slave connection

Installation of the DC busbars



9300VEC024

Fig. 5.4-3 Mounting of +DC/-DC busbars

How to mount the DC busbars


1. Mount +DC busbar **D** :

- Remove hexagon socket screws M8 **A**.
- Position the DC busbar in the master and the slave.
- Fasten the DC busbar in the master and the slave with 1 hexagon socket screw M8 × 45 mm **A**, 1 plain washer **B** and 1 distance sleeve **C** each.
- Tighten the hexagon socket screws **A** (tightening torque: 10.9 Nm).

2. Mount -DC busbar **H** :

- Remove hexagon socket screws M8 **E**.
- Put both connecting cables **I** aside.
- Position the DC busbar in the master and the slave.
- Insert 2 hexagon socket screws M8 × 45 mm **E** each with plain washers **F** into the bore holes of the DC busbar, finally passing them through the distance sleeves **G**.
- Screw the hexagon socket screws **E** into the threaded holes in the master and slave.
- Lay the connecting cable **I** in the master and slave with cable lug between the busbar **H** and plain washer **F**.
- Tighten the hexagon socket screws **E** (tightening torque: 10.9 Nm).

Connection of the control cables between master and slave



9300VEC028

Fig. 5.4-4 Connection of the control cables between master and slave

How to connect the control cables

1. Installation and connection of the ribbon cable **A**:

By default the ribbon cable is inside the master. The plug **C** is already attached to the Drive Board.

- Route the ribbon cable from the master to the Drive Board connection in the slave, inserting the ribbon cable into the cable ducts **B**.
- Plug the ribbon cable plug **A** into the socket **D** at the Drive Board.

2. Laying and connecting 2-core cables with plugs **E**:

By default the cable is inside the master. The corresponding cable with socket is in the slave.

- Lay the two-core cable from the master to the socket in the slave.
- Connect the 2-pole plug with the 2-pole socket in the slave.

3. Laying and connecting 10-core cables with plugs **F**:

By default the cable is inside the master. The corresponding cable with socket is in the slave.

- Lay the two-core cable from the master to the socket in the slave.
- Connect the 10-pole plug with the 10-pole socket in the slave.

Wiring of the standard device

Basic devices in the power range 250 ... 400 kW

Master and slave connection


Final works



9300vec163

Fig. 5.4-5 Control cables in the master and slave

1. Check the control cables (plugs and cables) for correct fit and possible damages. (O)
 - If the plugs do not fit correctly, or the plugs or cables are damaged, commissioning is prohibited. Contact the Lenze service.



9300vec164

Fig. 5.4-6 Fastening the covers to the master and slave

2. Close the housings using the covers **A** **B**. Fasten the covers with 4 screws each.

5.4.3 Mains connection of the controller for 400 V mains voltage



Stop!

The user is responsible for sufficient strain relief!

► Both, the master **and** the slave must be supplied!




Fig. 5.4-7 Mains connection example

BR1, BR2 Brake resistors can only be operated with variants V060 and V110

■	Master terminals
■	Slave terminals

Fuses and cable cross-sections for the mains connection

9300 vector		Installation in accordance with EN 60204-1					
Type	[A]	Fuse ²⁾		Cable cross-sections			
		L1, L2, L3 [mm ²]		PE [mm ²]			
		Master	Slave	Master	Slave	Master	Slave
EVF9381-EV EVF9381-EVVxxx	315	315		150 2 x 50 ¹⁾	150 2 x 50 ¹⁾	95	95
EVF9382-EV EVF9382-EVVxxx	315	315		150 2 x 50 ¹⁾	150 2 x 50 ¹⁾	95	95
EVF9383-EV EVF9383-EVVxxx	400	400		240 2 x 95 ¹⁾	240 2 x 95 ¹⁾	150	150

¹⁾ Multiple conductor; both conductors must have the same cross-section

²⁾ Lenze recommends to use fuses of the gRL utilisation category
 Observe the national and regional legislation

5.4.4**Supply and fan connection of the controller for 400 V/500V mains voltage****Stop!**

The user is responsible for sufficient strain relief!


Mains connection► Both, the master **and** the slave must be supplied!

Fig. 5.4-8 Mains connection example

BR1, BR2 Brake resistors can only be operated with variants V270 and V300

A	Master terminals
B	Slave terminals

**Fuses and cable cross-sections
for the mains connection**

Type	9300 vector		Installation in accordance with EN 60204-1					
	Fuse ²⁾		Cable cross-sections					
	[A]		L1, L2, L3 [mm ²]		PE [mm ²]		Master	Slave
	Master	Slave	Master	Slave	Master	Slave		
EVF9381-EV EVF9381-EVVxxx	315	315	150 2 x 50 1)	150 2 x 50 1)	95	95		
EVF9382-EV EVF9382-EVVxxx	315	315	150 2 x 50 1)	150 2 x 50 1)	95	95		
EVF9383-EV EVF9383-EVVxxx	400	400	240 2 x 95 1)	240 2 x 95 1)	150	150		

1) Multiple conductor; both conductors must have the same cross-section

2) Lenze recommends to use fuses of the gRL utilisation category

Observe the national and regional legislation

Wiring of the standard device

Basic devices in the power range 250 ... 400 kW
Supply and fan connection of the controller for 400 V/500V mains voltage


5

5.4

5.4.4

Connection to the DC bus (+UG, -UG)

- ▶ For compliance with EMC requirements, Lenze recommends to use shielded DC-bus cables.
- ▶ Shield clamps are not included in the scope of supply.
- ▶ Both, the master **and** the slave must be supplied!



9300VEC083

Fig. 5.4-9 Connection example to +UG and -UG

BR1, BR2 Brake resistors can only be operated with variants V270 and V300

A Master terminals

B Slave terminals

C Connect the DC-bus cable shield to the conductive control cabinet mounting plate with a contact surface as large as possible by using the shield clamps.

D Conductive surface

Ensure to have the poles right!

Fuses and cable cross-sections for DC-bus connection

Type	Fuse ²⁾		Installation in accordance with EN 60204-1			
			Cable cross-sections		PE	
	[A]		+UG, -UG [mm ²]	[mm ²]	Master	Slave
	Master	Slave	Master	Slave	Master	Slave
EVF9381-EVV2xx EVF9381-EVV300	350	350	150 2 x 50 ¹⁾	150 2 x 50 ¹⁾	95	95
EVF9382-EVV2xx EVF9382-EVV300	400	400	240 2 x 95 ¹⁾	240 2 x 95 ¹⁾	95	95
EVF9383-EVV2xx EVF9383-EVV300	500	500	240 2 x 95 ¹⁾	240 2 x 95 ¹⁾	150	150

1) Multiple conductor; both conductors must have the same cross-section

2) Only use fuses of the gRL utilisation category

Observe the national and regional legislation


Fan connection**Note!**

Connect the fan to the master **and** the slave.

Fan connection when controller is supplied with mains voltage


Lay a bridge between the terminals when a controller is operated on a mains.

AC 340 ... 440 V



9300vec044

AC 440 ... 577 V
(when being delivered)




9300vec045


Fan connection when controller is supplied via the DC bus**Danger!**

When the fan is externally supplied with voltage, the terminal L2 carries dangerous mains voltage!


When the controller is supplied via the DC bus, the fan must be separately supplied with mains voltage (see **B**). In this case, the bridge between the terminals 102 and 103 must be removed (see **A**).

Remove bridge

9300vec160

Mains connection for the operation of the fan on
AC 340 ... 440 V

9300vec046

AC 440 ... 577 V

9300vec047

Wiring of the standard device

Basic devices in the power range 250 ... 400 kW
Supply and fan connection of the controller for 400 V/500V mains voltage


5

5.4

5.4.4

Exchange defect fuse

In case of an external voltage supply the fan is protected by a fuse integrated in terminal 104.



9300vec161

Fig. 5.4-10 Fusing of the fan

- [A] Open the fuse holder.
- [B] Remove the defect fuse from the support and replace it by the following type:

Type: 500V SA 2A 6.32

Ref. no.: P098131

Manufacturer: Ferraz Shawmut

5.4.5**Motor connection**

- ▶ To comply with the EMC regulations, Lenze recommends to use shielded motor cables.
- ▶ Shield clamps are not included in the scope of supply.

**Stop!**

The user is responsible for sufficient strain relief!

Parallel connection of master and slave (motor side)

In order to connect the motor cables of master and slave to the motor, the outputs must be connected in parallel.

It is important for the parallel connection of the inverter outputs that the outputs are decoupled by means of an inductance between master and slave. The length of the motor cables determine whether the inductance of the cables is sufficient for a decoupling.

2 motor connections ensure sufficient decoupling.

► Decoupling via motor chokes

If the single motor cable length is ≤ 10 m, master and slave must be connected in parallel via chokes on the motor side to achieve a sufficient decoupling between master and slave.

► Decoupling via motor cables

If the single motor cable length is > 10 m, the motor cables of master and slave can be connected in parallel at the motor to achieve a sufficient decoupling between master and slave.




Fig. 5.4-11 Variants for parallel connection of master and slave (motor side)

Z1, Z2 Motor choke

ELM3-0003H275

ELM3-0002H320

ELM3-0002H410


for controller

EVF9381

EVF9382

EVF9383

Motor connection



9300VEC036

Fig. 5.4-12 Motor connection example

BR1, BR2 Brake resistors can only be operated with variants V060, V110, V270 and V300

[A] Master terminals

[B] Slave terminals

[C] Connect the motor cable shield with a surface as large as possible to the control cabinet mounting plate by using the clamps.

[D] Conductive surface

Ensure to have the poles right!

Do not exceed the maximum motor cable length!

Cable cross-sections

Type	9300 vector		Installation in accordance with EN 60204-1			
	U, V, W [mm ²]		PE			
	Master	Slave	Master	Slave		
EVF9381-EV	150	150	95	95		
EVF9381-EVVxxx	2 × 50 ¹⁾	2 × 50 ¹⁾				
EVF9382-EV	150	150	95	95		
EVF9382-EVVxxx	2 × 50 ¹⁾	2 × 50 ¹⁾				
EVF9383-EV	240	240	150	150		
EVF9383-EVVxxx	2 × 95 ¹⁾	2 × 95 ¹⁾				

¹⁾ Multiple conductor; both conductors must have the same cross-section
 Observe the national and regional legislation

5.4.6 Wiring of motor temperature monitoring

The drive controller features 2 connections for motor temperature monitoring:

- ▶ Terminals T1, T2 for connecting a PTC thermistor or thermal contact (NC contact).
- ▶ Pin X8/5 and X8/8 of the incremental encoder input (X8) for connecting a KTY thermal sensor.

Motor with PTC thermistor or thermal contact (NC contact)

Wire T1, T2 only if the motor is equipped with a PTC thermistor or thermal contact (NC contact).

- An "open" cable acts like an antenna and can cause faults on the drive controller.



Danger!

- All control terminals only have basic insulation (single isolating distance) after connecting a PTC thermistor or a thermal contact.
- Protection against accidental contact in case of a defective isolating distance is only guaranteed through external measures, e.g. double insulation.




Fig. 5.4-13 Connection of PTC thermistor or thermal contact (NC contact) at T1, T2

Characteristics of the connection for motor temperature monitoring:


Terminals T1, T2

Connection	<ul style="list-style-type: none"> ● PTC thermistor <ul style="list-style-type: none"> – PTC thermistor with defined tripping temperature (acc. to DIN 44081 and DIN 44082) ● Thermal contact (NC contact) <ul style="list-style-type: none"> – Thermostat as NC contact
Tripping point	<ul style="list-style-type: none"> ● Fixed (depending on the PTC/thermal contact) ● PTC: $R_9 > 1600 \Omega$ ● Configurable as warning or error (TRIP)
Notes	<ul style="list-style-type: none"> ● Monitoring is not active in the Lenze setting. ● If you do not use a Lenze motor, we recommend the use of a PTC thermistor up to 150°C.

Motor with KTY thermal sensor


Note!

- We recommend to use Lenze system cables for wiring.
- For self-made cables only use cables with shielded cores twisted in pairs.



9300vec121

Fig. 5.4-14 Connection of KTY thermal sensor at incremental encoder input X8

Characteristics of the connection for motor temperature monitoring:

Pins X8/5, X8/8 of incremental encoder input (X8)

Connection	Linear KTY thermal sensor
Tripping point	<ul style="list-style-type: none"> ● Warning: Adjustable ● Error (TRIP): Fixed at 150 °C
Notes	<ul style="list-style-type: none"> ● Monitoring is not active in the Lenze setting. ● The KTY thermal sensor is monitored with regard to interruption and short circuit.

5.5 Connection terminal of the control card




Fig. 5.5-1 Connection terminal of the control card

- ① 2 light-emitting diodes (red, green) for status display
- x1 Automation interface (AIF)
- x3 Slot for communication modules (e.g. keypad XT)
- x4 Preselection of signal type with jumper for input signal at X6/1, X6/2
- x4 Terminal strip for system bus (CAN)
- x5 Terminal strips for digital inputs and outputs
- x6 Terminal strips for analog inputs and outputs
- x8 Sub-D socket for incremental encoders
- x9 Sub-D socket for master frequency input
- x10 Sub-D socket for master frequency output
- x11 Terminal strip for safety relay K_{SR}

5.6 Control terminals

5.6.1 Important notes



Stop!

The control card will be damaged if


- ▶ the voltage between X5/39 and PE or X6/7 and PE is greater than 50 V,
- ▶ the voltage between voltage source and X6/7 exceeds 10 V (common mode) in case of supply via external voltage source.

Limit the voltage before switching on the drive controller:

- ▶ Connect X5/39, X6/2, X6/4 and X6/7 directly to PE or
- ▶ use voltage-limiting components.

- ▶ For trouble-free operation, the control cables must be shielded:
 - Connect the shield of digital input and output cables at both ends.
 - Connect the shield of analog input and output cables at one end (at the drive controller).
 - For lengths of 200 mm and more, use only shielded cables for analog and digital inputs and outputs. Under 200 mm, unshielded but twisted cables may be used.

How to connect the shield



9300vec063

Fig. 5.6-1 Connection of the cable shield with shield clip and strain relief with cable binder

- Ⓐ Shield sheet
- Ⓑ Fasten shield sheet with two screws M4 × 12 mm at the bottom of the control card
- Ⓒ Connect cable shield with shield clip to the shield sheet
- Ⓓ Provide a strain relief of the control cable at the shield sheet by means of a cable binder

Wiring of the standard device

Control terminals

With function "Safe torque off" active

Terminal data



Stop!

- ▶ Connect or disconnect the terminal strips only if the controller is disconnected from the mains!
- ▶ Wire the terminal strips before connecting them!
- ▶ Unused terminal strips must also be plugged on to protect the contacts.

Cable type	Wire end ferrule	Maximum cable cross-section	Tightening torque	Stripping length
Rigid	–	2.5 mm ² (AWG 14)	0.5 ... 0.6 Nm (4.4 ... 5.3 lb-in)	5 mm
Flexible	Without wire end ferrule	2.5 mm ² (AWG 14)		
Flexible	Wire end ferrule without plastic sleeve	2.5 mm ² (AWG 14)		
Flexible	Wire end ferrule with plastic sleeve	2.5 mm ² (AWG 14)		

5.6.2 With function "Safe torque off" active

Safety instructions for the installation of the "Safe torque off" function

- ▶ The installation and commissioning of the "Safe torque off" function must be carried out by skilled personnel only.
- ▶ All safety-relevant cables (e.g. control cable for the safety relay, feedback contact) outside the control cabinet must be protected, for instance by a cable duct. Short circuits between the single cables must be ruled out!
- ▶ Wiring of the safety relay K_{SR} with insulated wire end ferrules or rigid cables is absolutely vital.
- ▶ The electrical reference point for the coil of the safety relay K_{SR} must be connected with the protective conductor system (DIN EN 60204-1 paragraph 9.4.3). Only this measure guarantees that the operation is protected against earth faults.




Tip!

A complete description can be found in the chapter "Safe torque off".

Supply via internal voltage source

- If a freely assignable digital output (e.g. X5/A1) is assigned permanently to HIGH level, it serves as an internal voltage source. Every output has a maximum load capacity of 50 mA.
 - The relay K_{SR} and two digital inputs (X5/28 and e.g. X5/E1) can be supplied with voltage via a digital output.
 - Two digital outputs must be connected in parallel and assigned permanently to HIGH level in order to obtain the maximum wiring (relays K_{SR} and X5/E1 ... X5/E5, X5/ST1).
- For the supply of the analog inputs (X6/1, X6/2 and X6/3, X6/4) you have to set a freely assignable analog output (e.g. X6/63) permanently to HIGH level.



9300vec135

Fig. 5.6-2 Wiring of digital and analog inputs/outputs with active "Safe torque off" function and internal voltage source

S1 Deactivate pulse inhibit (1st disconnecting path)

S2 Enable controller (2nd disconnecting path)

Z1 Programmable logic controller (PLC)

The PLC monitors the "Safe torque off" function

X5/A4 Feedback via a digital output (e.g. DIGOUT4)

NO contact or NC contact

Load

Minimum wiring required for operation

Terminal assignment in the Lenze setting: 5.6-7



Note!

If you load a basic configuration C0005 = xx1x (e.g. 1010 for speed control with control via terminals), the following terminals are switched to a fixed signal level:

- Terminal X5/A1 to FIXED1 (corresponds to DC 24 V).
- Terminal X6/63 to FIXED100% (corresponds to 10 V).

Supply via external voltage source




Fig. 5.6-3 Wiring of digital and analog inputs/outputs with active "Safe torque off" function and external voltage source

S1 Deactivate pulse inhibit (1st disconnecting path)

S2 Enable controller (2nd disconnecting path)

Z1 Programmable logic controller (PLC)

The PLC monitors the "Safe torque off" function

X5/A4 Feedback via a digital output (e. g. DIGOUT4)

NO contact or NC contact

Load

— Minimum wiring required for operation

Terminal assignment in the Lenze setting: 5.6-7



Note!

Supplying the digital inputs via an external voltage source enables a **backup operation in case of mains failure**. After switching off the mains voltage, all actual values are continued to be detected and processed.

- ▶ Connect the positive pole of the external voltage source with X5/59 to establish the backup operation in the event of mains failure.
- ▶ The external voltage source must be able to supply a current $\geq 1 \text{ A}$.
- ▶ The starting current of the external voltage source is not limited by the controller. Lenze recommends the use of voltage sources with current limitation or with an internal impedance of $Z > 1 \Omega$.

5.6.3 With function "Safe torque off" deactivated



Note!

If the function "Safe torque off" is not made use of, the safety relay K_{SR} must be energised permanently to ensure the tension supply of the power output stage.

Supply via internal voltage source

- If a freely assignable digital output (e.g. X5/A1) is assigned permanently to HIGH level, it serves as an internal voltage source. Every output has a maximum load capacity of 50 mA.
 - The relay K_{SR} and two digital inputs (X5/28 and e.g. X5/E1) can be supplied with voltage via a digital output.
 - Two digital outputs must be connected in parallel and assigned permanently to HIGH level in order to obtain the maximum wiring (relays K_{SR} and X5/E1 ... X5/E5, X5/ST1).
- For the supply of the analog inputs (X6/1, X6/2 and X6/3, X6/4) you have to set a freely assignable analog output (e.g. X6/63) permanently to HIGH level.




Fig. 5.6-4 Wiring of digital and analog inputs/outputs with function "Safe torque off" deactivated, given an internal voltage source

S1 Controller enable

NO contact or NC contact

Load

— Minimum wiring required for operation

Terminal assignment in the Lenze setting: 5.6-7



Note!

If you load a basic configuration C0005 = xx1x (e.g. 1010 for speed control with control via terminals), the following terminals are switched to a fixed signal level:

- Terminal X5/A1 to FIXED1 (corresponds to DC 24 V).
- Terminal X6/63 to FIXED100% (corresponds to 10 V).

Supply via external voltage source




Fig. 5.6-5 Wiring of digital and analog inputs/outputs with function "Safe torque off" deactivated, given an external voltage source

S1 Controller enable

NO contact or NC contact

Load

— Minimum wiring required for operation

Terminal assignment in the Lenze setting: [Fig. 5.6-7](#)



Note!

Supplying the digital inputs via an external voltage source enables a **backup operation in case of mains failure**. After switching off the mains voltage, all actual values are continued to be detected and processed.

- ▶ Connect the positive pole of the external voltage source with X5/59 to establish the backup operation in the event of mains failure.
- ▶ The external voltage source must be able to supply a current $\geq 1 \text{ A}$.
- ▶ The starting current of the external voltage source is not limited by the controller. Lenze recommends the use of voltage sources with current limitation or with an internal impedance of $Z > 1 \Omega$.

Wiring of the standard device

5

Control terminals

5.6

Terminal assignment

5.6.4

5.6.4 Terminal assignment

Terminal	Function Bold print = Lenze setting	Level / state	Technical data
X11/K32 X11/K31	Safety relay K _{SR} 1st disconnecting path	Feedback - pulse inhibit	Open contact: Pulse inhibit is inactive (operation) Closed contact: Pulse inhibit is active
X11/33		- coil of safety relay K _{SR}	Coil is not carrying any current: Active pulse inhibit
X11/34		+ coil of safety relay K _{SR}	Coil is carrying current: Inactive pulse inhibit (operation)
X5/28	Controller inhibit (DCTRL-CINH) 2nd disconnecting path	Controller enable/inhibit	LOW: Controller inhibited HIGH: Controller enabled
X5/E1 X5/E2 X5/E3 X5/E4 X5/E5 X5/ST1 X5/ST2	Digital inputs (freely assignable)	Deactivate CW rotation / quick stop	HIGH
		Deactivate CCW rotation / quick stop	HIGH
		Activate fixed frequency 1 (JOG1)	HIGH
		Set error message (TRIP SET)	LOW
		Reset error message (TRIP RESET)	LOW-HIGH edge
		Additional digital input (E6)	HIGH
X5/A1		Error message present	LOW
X5/A2	Digital outputs (freely assignable)	Switching threshold Q _{MIN} : Actual speed < setpoint speed in C0017	LOW
X5/A3		Ready for operation (DCTRL-RDY)	HIGH
X5/A4		Maximum current reached (DCTRL-IMAX)	HIGH
X5/39		GND2, reference potential for digital signals	—
X5/59	—	Connection of external voltage source for backup operation of the drive controller in case of mains failure	DC 24 V (+18 ... +30 V)
X6/1 X6/2	Analog input 1	Voltage input range Main setpoint	6 5 4 3 2 1 Jumper X3
		Current input range	6 5 4 3 2 1 Jumper X3
X6/3 X6/4	Analog input 2	Voltage input range Not active	Jumper X3 has no effect
X6/62	Analog output 1	Monitor 1 Actual speed value	
X6/63	Analog output 2	Monitor 2 Actual motor current value	
X6/7	—	GND1, reference potential for analog signals	—

5.7 Wiring of the system bus (CAN)

Wiring




Fig. 5.7-1 System bus (CAN) wiring

- A₁ Bus device 1 (controller)
- A₂ Bus device 2 (controller)
- A₃ Bus device 3 (controller)
- A_n Bus device n (e. g. PLC), n = max. 63
- X4/GND CAN-GND: System bus reference potential
- X4/LO CAN-LOW: System bus LOW (data line)
- X4/HI CAN-HIGH: System bus HIGH (data line)



Stop!

Connect a 120 Ω terminating resistor to the first and last bus device.

For the use of the transmission cable, follow our recommendations:

Specification of the transmission cable

Total length	≤ 300 m	≤ 1000 m
Cable type	LIYCY 2 x 2 x 0.5 mm ² (paired with shielding)	CYPIMF 2 x 2 x 0.5 mm ² (paired with shielding)
Cable resistance	≤ 80 Ω/km	≤ 80 Ω/km
Capacitance per unit length	≤ 130 nF/km	≤ 60 nF/km

Wiring of the standard device	5
Wiring of the feedback system	5.8
Important notes	5.8.1

5.8 **Wiring of the feedback system**

5.8.1 **Important notes**

- ▶ An incremental encoder can be connected to input X8 or input X9:
 - Incremental encoders with TTL level are connected to X8.
 - Incremental encoders with HTL level are connected to X9.
- ▶ The incremental encoder signal can be output for slave drives at the digital frequency output X10.



Note!

- ▶ We recommend to use Lenze system cables for wiring.
- ▶ For self-made cables only use cables with shielded cores twisted in pairs.

Wiring of the standard device

Wiring of the feedback system

Incremental encoder with TTL level at X8

5.8.2 Incremental encoder with TTL level at X8

Technical data

Field	Values
Connectable incremental encoder	Incremental encoder with TTL level <ul style="list-style-type: none"> Encoder with two 5 V complementary signals electrically offset by 90° Connection of zero track is possible (optional)
Connection at drive controller	9-pin Sub-D socket
Input frequency	0 ... 500 Nm
Current consumption	6 mA per channel
Internal voltage source (X8/4, X8/5)	5 V DC / max. 200 mA

Wiring




Fig. 5.8-1 Connection of incremental encoder with TTL level

- ① Signals for CW rotation
/ Cores twisted in pairs

Assignment of 9-pin Sub-D socket (X8) at the controller


Pin	1	2	3	4	5	6	7	8	9
Signal	B	\bar{A}	A	V _{CC}	GND (-KTY)	\bar{Z}	Z	+KTY	\bar{B}
				0.14 mm ² (AWG 26)		1 mm ² (AWG 18)		0.14 mm ² (AWG 26)	

5.8.3 Incremental encoder with HTL level at X9

Technical data

Field	Values
Connectable incremental encoder	Incremental encoder with HTL-level <ul style="list-style-type: none"> Two-track with inverse signals and zero track Two-track without inverse signals and zero track
Connection at drive controller	9-pin Sub-D socket
Input frequency	0 ... 200 kHz
Current consumption	5 mA per channel
Supply of incremental encoder	External voltage source
Internal voltage source (X9/4, X9/5)	5 V DC / max. 200 mA Total current at X9/4, X9/5 and X10/4, X10/5: max. 200 mA

Wiring



9300VEC020

Fig. 5.8-2 Connection of incremental encoder with HTL level

- ① Signals for CW rotation
- ② External voltage source for the incremental encoder
- Cores twisted in pairs

Assignment of 9-pin Sub-D socket (X9) at the controller

Pin	1	2	3	4	5	6	7	8	9
Signal	B	A-bar	A	+5 V	GND	Z-bar	Z	-	B-bar
Wire	0.14 mm ² (AWG 26)			1 mm ² (AWG 18)				0.14 mm ² (AWG 26)	



Note!

Connection of single-track incremental encoder with HTL level:

- Connect the signal A to pin X9/2 (A-bar) and the signal B to pin X9/9 (B-bar).
- Wire pins X9/3 (A) and X9/1 (B) to the positive terminal of the external voltage source for the incremental encoder.

5.9 Wiring of digital frequency input / digital frequency output

Technical data	Field	Digital frequency output X10
	Connection at drive controller	9-pin Sub-D socket
	Pin assignment	Dependent on the selected basic configuration
	Output frequency	0 ... 500 kHz
	Signal	Two-track with inverse 5 V signals (RS422) and zero track
	Load capacity	Maximum 20 mA per channel (up to 3 slave drives can be connected)
	Special features	The "Enable" output signal at X10/8 switches to LOW if the drive controller is not ready for operation (e.g. disconnected from mains). This may trip SD3 monitoring at the slave drive.
	Internal voltage source (X10/4, X10/5)	DC 5 V / max. 50 mA Total current at X9/4, X9/5 and X10/4, X10/5: max. 200 mA
	Field	Digital frequency input X9
	Connection at drive controller	9-pin Sub-D socket
	Input frequency	TTL level: 0 ... 500 kHz HTL level: 0 ... 200 kHz
	Signal	Two-track with inverse signals and zero track Single-track without inverse signals and zero track (only for HTL level)
	Signal evaluation	Via code C0427
	Current consumption	Maximum 5 mA
	Special features	With activated SD3 monitoring, TRIP or warning is tripped if the "Lamp Control" input signal at X9/8 switches to LOW. This may cause the drive controller to respond if the master drive is not ready for operation.

Wiring



Note!

- We recommend to use Lenze system cables for wiring.
- For self-made cables only use cables with shielded cores twisted in pairs.




Fig. 5.9-1 Connection of digital frequency input (X9) / digital frequency output (X10)

X9 Slave drive
X10 Master drive

① Signals for CW rotation
—/— Cores twisted in pairs

Assignment of 9-pin Sub-D socket (X9) at the controller

Pin	1	2	3	4	5	6	7	8	9
Signal	B	\bar{A}	A	+5 V	GND	\bar{Z}	Z	LC	\bar{B}
—/—	0.14 mm ² (AWG 26)			0.5 mm ² (AWG 20)		0.14 mm ² (AWG 26)	0.5 mm ² (AWG 20)	0.14 mm ² (AWG 26)	

Assignment of 9-pin Sub-D socket (X10) at the controller

Pin	1	2	3	4	5	6	7	8	9
Signal	B	\bar{A}	A	+5 V	GND	\bar{Z}	Z	EN	\bar{B}
—/—	0.14 mm ² (AWG 26)			0.5 mm ² (AWG 20)		0.14 mm ² (AWG 26)	0.5 mm ² (AWG 20)	0.14 mm ² (AWG 26)	

Adjustment

Evaluation of the input signals at X9

Code	Function	
C0427 = 0	CW rotation	Track A leads track B by 90 ° (positive value at DFIN-OUT)
	CCW rotation	Track A lags track B by 90 ° (negative value at DFIN-OUT)
C0427 = 1	CW rotation	Track A transmits the speed Track B = LOW (positive value at DFIN-OUT)
	CCW rotation	Track A transmits the speed Track B = HIGH (negative value at DFIN-OUT)
C0427 = 2	CW rotation	Track A transmits the speed and direction of rotation (positive value at DFIN-OUT) Track B = LOW
	CCW rotation	Track B transmits the speed and direction of rotation (negative value at DFIN-OUT) Track A = LOW

5.10 Communication modules



Further information

on wiring and application of communication modules can be found in the corresponding Mounting Instructions and Communication Manuals.

Possible communication modules

Communication module	Type/order number
Keypad XT	EMZ9371BC
LECOM-A/B (RS232/485)	EMF2102IBV001
LECOM-B (RS485)	EMF2102IBV002
LECOM-LI (optical fibre)	EMF2102IBV003
LON	EMF2141IB
INTERBUS	EMF2113IB
INTERBUS Loop	EMF2112IB
PROFIBUS-DP	EMF2133IB
DeviceNet/CANopen	EMF2175IB

Handling

Plug the communication module onto the AIF interface (X1) or pull it off from the interface. The communication module can also be connected/disconnected during operation.

6

Commissioning

Contents

6.1	Before switching on	6.1-1
6.2	Selection of the correct operating mode	6.2-1
6.3	Parameter setting with the XT EMZ9371BC keypad	6.3-1
6.3.1	Commissioning example in V/f characteristic control mode	6.3-1
6.3.2	Commissioning example in vector control mode	6.3-5
6.4	Controller inhibit	6.4-1
6.5	Changing the assignment of the control terminals X5 and X6	6.5-1
6.5.1	Free configuration of digital input signals	6.5-1
6.5.2	Free configuration of digital outputs	6.5-3
6.5.3	Free configuration of analog input signals	6.5-4
6.5.4	Free configuration of analog outputs	6.5-6
6.6	Adjusting the motor	6.6-1
6.6.1	Entry of motor data	6.6-1
6.6.2	Motor selection list	6.6-4
6.6.3	Motor temperature monitoring with PTC or thermal contact	6.6-9
6.6.4	Motor temperature monitoring with KTY	6.6-11
6.6.5	Current limits	6.6-15
6.6.6	Automatic collection of motor data	6.6-16
6.7	Setting the speed feedback	6.7-1
6.7.1	Incremental encoder with TTL level at X8	6.7-2
6.7.2	Incremental encoder with HTL level at X9	6.7-3
6.8	Operating mode	6.8-1
6.8.1	V/f characteristic control	6.8-4
6.8.2	Vector control	6.8-8
6.9	Switching frequency of the inverter	6.9-1
6.10	Acceleration, deceleration, braking, stopping	6.10-1
6.10.1	Speed range	6.10-1
6.10.2	Setting acceleration times and deceleration times in speed mode	6.10-3
6.10.3	Quick stop	6.10-4
6.10.4	Changing the direction of rotation	6.10-5
6.11	Optimising the operating behaviour	6.11-1
6.11.1	Slip compensation	6.11-1
6.11.2	Oscillation damping	6.11-3
6.11.3	Boost correction with V/f characteristic control	6.11-5
6.11.4	Motor magnetising current with vector control	6.11-9

6.1 Before switching on



Note!

- ▶ Observe the corresponding switch-on sequence.
- ▶ In the event of faults or errors during commissioning, see chapter "Troubleshooting and fault elimination".

To avoid injury to persons and damage to material, check ...

... before connecting the mains voltage:

- ▶ Wiring for completeness, short-circuit, and earth fault
- ▶ The supply of the internal fan in case of the variants V210, V240, V270 and V300.
 - The bridge position depends on the mains voltage applied
- ▶ The function "emergency-off" of the total system.
- ▶ The motor circuit configuration (star/delta) must be adapted to the output voltage of the controller.
 - E. g. the in-phase connection of the motor.
- ▶ The direction of rotation of the incremental encoder

... the setting of the main drive parameters before enabling the controller:



Stop!

Only the variants V210, V240, V270, V300:

- ▶ Adapt the DC bus voltage threshold to the mains voltage via C0173.
 - The Lenze setting of C0173 = 1 ($U_{OU} = 770 \text{ V}$) is only permissible for controller operation with a mains voltage of 400 V.

- ▶ Only the variants V210, V240, V270, V300:

Adapt the brake transistor threshold to the mains voltage via C0174. The Lenze setting of code C0174 = 3 ($U_{Br} = 885 \text{ V}$) is valid for operating the controller on a 500 V mains voltage.

- ▶ Is the V/f rated frequency adapted to the motor connection?
- ▶ Are the drive parameters relevant for your application set correctly?
- ▶ Is the configuration of the analog and digital inputs and outputs adapted to the wiring?

6.2 Selection of the correct operating mode

Description

The control mode of the controller can be selected via the operating mode. You can select between the following modes:


- ▶ V/f characteristic control
- ▶ Vector control

Selection of the correct operating mode

The V/f characteristic control is the classic operating mode for standard applications.

When using the vector control you will achieve improved drive features compared to the V/f characteristic control due to:

- ▶ Higher torque via the complete speed range
- ▶ Higher speed accuracy and higher concentricity factor
- ▶ Higher efficiency



8200vec524

Fig. 6.2-1 Comparison of V/f characteristic control and vector control

- ① V/f characteristic control
- ② Vector control

Recommended operating modes

The frequency inverter is mainly designed for the applications listed in the below table.

The table helps you to select the correct operating mode for your application:

- C0006 = 5: V/f characteristic control with constant V_{min} boost
- C0006 = 1: Vector control

Power range 110 ... 400 kW	Selection of the operating mode in C0006			
	Motor cable shielded ≤ 100 m unshielded ≤ 200 m		Motor cable shielded > 100 m unshielded > 200 m	
	Applications with asynchronous motors	recommended	alternatively	recommended
Single drives				
Drives with constant load	5	1	5	-
Drives with heavy start conditions	1	5	5	-
Travelling drives, conveyor belts	5	1	5	-
Pump drives, fan drives ¹⁾	5	-	5	-
Extruder drives	5	1	5	-
Drives for wire drawing machines	5	1	5	-
Drives for rolling machines	5	1	5	-
Drives for rewinders with dancer (speed-controlled)	1	5	-	-
Group drives (the resulting motor cable length is decisive I_{res})	5	-	5	-
$I_{res} = \sqrt{(i \cdot (I_1 + I_2 + \dots + I_i))}$				



¹⁾ A square voltage characteristic (C0014 = 1) is recommended for this application





Commissioning	6
Parameter setting with the XT EMZ9371BC keypad	6.3
Commissioning example in V/f characteristic control mode	6.3.1


6.3 Parameter setting with the XT EMZ9371BC keypad

6.3.1 Commissioning example in V/f characteristic control mode

The example describes how to commission a speed control for the controller with power-related three-phase asynchronous motor.

Switch-on sequence		Note
1.	Insert the keypad	
2.	Ensure that the controller is inhibited after switching on the mains	  Terminal X5/28 = LOW (see chapter "Commissioning" → "controller inhibit")
3.	Ensure that no external error is active	
4.	Switch on	
A	The control card is supplied via an external voltage: Switch on the external DC 24 V supply voltage	 Terminal X5/E4 = HIGH
B	The control card is supplied via the internal voltage: Switch on the mains. The controller provides the DC 24 V supply.	 Terminal X5/E4 = HIGH
5.	After approx. 2 s the controller is initialised and the keypad is in the operating level and displays the current speed (C0051)	 9371BC004
6.	Change to the "Terminal I/O" menu and configure the function of the control terminals to adapt them to your application. Lenze setting: C0005 = 1000 (basic configuration "speed control")	Use C0002 = 0 to restore the Lenze setting (see chapter "Commissioning" → "Change assignment of the control terminal X5 and X6")
7.	For quick commissioning select the menu "Short setup"	The submenu "Setup V/f" contains the codes that are required for commissioning a standard application. The digital inputs are configured in the Lenze setting: X5/E1: Deactivate CW rotation/quick stop X5/E2: Deactivate CCW rotation/quick stop X5/E3: Activate fixed setpoint 1 (JOG1) X5/E4: Set error message (TRIP SET) X5/E5: Reset error message (TRIP RESET) (see chapter "Parameter setting")
A	Use  to change to the menu level	 9371BC008
B	Use     to change to the menu "Short setup" and then to the submenu "Setup V/f"	  9371BC008
C	Use  to change to the code level to parameterise your drive	
8.	Adapt the controller to the mains (C0173) Lenze setting: 1 (400 V mains voltage)	
9.	Only for the variants V060, V110, V270, V300 in the power range of 110 ... 400 kW: Adapt the brake transistor threshold (C0174) Lenze setting: 3 (500 V mains voltage, 885 V brake voltage)	See code table

Switch-on sequence		Note
10.	Enter the motor data	
A	If you use a Lenze motor: Select the motor type connected under C0086.	 See motor nameplate and chapter "Commissioning" → "Adapt motor data"
B	If you do not use a Lenze motor: Enter the data of the motor nameplate	The data of the Lenze motors are saved under C0086.
	● Rated motor power (C0081) – Lenze setting: device-dependent	
	● Rated motor speed (C0087) – Lenze setting: device-dependent	
	● Rated motor current (C0088) – Lenze setting: device-dependent	Enter value for the selected motor connection method (star/delta)!
	● Rated motor frequency (C0089) – Lenze setting: device-dependent	
	● Rated motor voltage (C0090) – Lenze setting: device-dependent	Enter value for the selected motor connection method (star/delta)!
	● Motor cosφ (C0091) – Lenze setting: device-dependent	
11.	If required, set a base frequency which differs from the rated motor frequency (C0015) Lenze setting: C0015 = C0089	 Changes in C0086 and C0089 overwrite the setting in C0015 (see chapter "Commissioning" → "Operating mode" → "V/f characteristic control")
12.	If required, adapt the slip compensation (C0021) Lenze setting: Rated slip in [%] with regard to N _{max} in C0011. The value is calculated from the data of the nameplate and is thus suitable for the majority of applications.	Due to changes in C0086, C0087, C0089 the rated slip is recalculated and automatically entered into C0021 (see chapter "Commissioning" → "Slip compensation")
13.	For protecting the motor, set the current limit values "I _{max} current" (C0022, C0023) Guide value ≤ 2-fold rated motor current	Power range 0.37 ... 90 kW: For dissipating the regenerative energy, use a brake chopper or feedback module, if necessary Power range 110 ... 400 kW: For dissipating regenerative energy, use a brake resistor, if necessary (see chapter "Commissioning" → "Motor adjustment" → "Current limit values")
A	In motor mode and generator mode (C0022)	
B	Additional limitation in generator mode (C0023) Condition: C0023 < C0022	
14.	Set the operating mode "V/f" (C0006) Lenze setting: 5 (V/f characteristic control)	(see chapter "Commissioning" → "Operating mode" → "V/f characteristic control")
15.	Set the V/f characteristic (C0014) Lenze setting: 0 (linear characteristic)	
A	Linear characteristic (C0014 = 0)	
B	Square-law characteristic (C0014 = 1)	 For applications with e. g. pumps or fans

Switch-on sequence		Note
16.	If required, set U_{\min} boost (C0016) Lenze setting: 0 %	C0016 = 1 % corresponds to a boost of 1 % of the rated voltage "Mot voltage" (C0090) (see chapter "Commissioning" → "Operating mode" → "V/f characteristic control")
17.	Set the switching frequency "fchop" (C0018) Lenze setting: Power range 0.37 ... 90 kW: 6 (8/2 kHz sin) Power range 110 ... 400 kW: 6 (4/2 kHz sin)	See chapter "Commissioning" → "Switching frequency of the inverter"
18.	Set your type of the speed feedback system "Feedback type" (C0025) Lenze setting: 1 (no feedback)	See chapter "Commissioning" → "Setting of speed feedback"
A	When using a TTL encoder: Select the encoder used under C0025	
B	When using a TTL encoder with a number of increments which cannot be set under C0025: Set C0025 = 100 Enter the number of increments under C0420	
C	If required, compensate a voltage drop in the incremental encoder cable. Use C0421 to adjust the supply voltage for the TTL encoder.	
D	When using a HTL encoder: Set C0025 = 101 Enter the number of increments under C0420	
19.	Set the maximum speed (C0011) Lenze setting: 3000 rpm	 See chapter "Commissioning" → "Acceleration, deceleration, braking, stopping"
20.	Set the acceleration time T_{ir} (C0012) Lenze setting: 5.00 s	$T_{ir} = t_{ir} \cdot \frac{C0011}{f_2 - f_1}$ (see chapter "Commissioning" → "Acceleration, deceleration, braking, stopping")
21.	Set the deceleration time T_{if} (C0013) Lenze setting: 5.00 s	$T_{if} = t_{if} \cdot \frac{C0011}{f_2 - f_1}$ (see chapter "Commissioning" → "Acceleration, deceleration, braking, stopping")
22.	If required, set the quick stop deceleration ramp (C0105) Lenze setting: 5.00 s	See chapter "Commissioning" → "Acceleration, deceleration, braking, stopping"
23.	If required, adapt the fixed setpoints JOG.	See code table
A	JOG 1 (C0039/1) Lenze setting: 1500 rpm	Activation: X5/E3 = HIGH
B	Further fixed setpoints: JOG 2 (C0039/2) ... JOG 15 (C0039/15)	
24.	Ensure a powerfail-proof saving of the settings in one of the four parameter sets (C0003) Use C0003 = 1 to save the settings in parameter set 1.	Code C0003 is the first code in the menu "Setup V/f". After switching on the DC 24 V supply or mains connection, parameter set 1 is automatically activated. (see chapter "Parameter setting")
25.	Switch on the mains if the external DC 24 V supply voltage is switched on only.	
26.	Enable controller	 X5 → 28 misc009 Terminal X5/28 = HIGH (see chapter "Commissioning" → "controller inhibit")



Switch-on sequence		Note
27.	Enter the setpoint	<p>Analog setpoint selection: -10 ... +10 V via potentiometer at X6/1 and X6/2</p> <p>Fixed speed: Activate JOG 1 with X5/E3 = HIGH</p>
		JOG 1 is parameterised in C0039/1
28.	The drive is running now	<p>CW rotation: X5/E1 = HIGH and X5/E2 = LOW</p> <p>CCW rotation: X5/E1 = LOW and X5/E2 = HIGH</p> <p>If the drive does not start, press RUN in addition (see chapter "Commissioning" → "Acceleration, deceleration, braking, stopping")</p>

**Note!**



In the menu "Diagnostic" the most important drive parameters can be monitored

6.3.2 Commissioning example in vector control mode

The example describes how to commission a speed control for the controller with power-related three-phase asynchronous motor.

Switch-on sequence		Note
1.	Insert the keypad	
2.	Ensure that the controller is inhibited after switching on the mains	 
3.	Ensure that no external error is active	Terminal X5/E4 = HIGH
4.	Switch on	
A	The control card is supplied via an external voltage: Switch on the external DC 24 V supply voltage	
B	The control card is supplied via the internal voltage: Switch on the mains. The controller provides the DC 24 V supply.	
5.	After approx. 2 s the controller is initialised and the keypad is in the operating level and displays the current speed (C0051)	 9371BC004
6.	Change to the "Terminal I/O" menu and configure the function of the control terminals to adapt them to your application. Lenze setting: C0005 = 1000 (basic configuration "speed control")	Use C0002 = 0 to restore the Lenze setting (see chapter "Commissioning" → "Change assignment of the control terminal X5 and X6")
7.	For quick commissioning select the menu "Short setup"	 9371BC007
A	Use PRG to change to the menu level	
B	Use ▲ ▼ ↺ ↻ to change to the menu "Short setup" and then to the submenu "Setup vector"	
C	Use ◆ to change to the code level to parameterise your drive	  9371BC008
8.	Adapt the controller to the mains (C0173) Lenze setting: 1 (400 V mains voltage)	
9.	Only for the variants V060, V110, V270, V300 in the power range of 110 ... 400 kW: Adapt the brake transistor threshold (C0174) Lenze setting: 3 (500 V mains voltage, 885 V brake voltage)	See code table

Switch-on sequence		Note
10.	Enter the motor data	
A	If you use a Lenze motor: Select the motor type connected under C0086.	See motor nameplate and chapter "Commissioning" → "Adapt motor data"
B	If you do not use a Lenze motor: Enter the data of the motor nameplate	The data of the Lenze motors are saved under C0086.
	<ul style="list-style-type: none"> ● Rated motor power (C0081) <ul style="list-style-type: none"> – Lenze setting: device-dependent ● Rated motor speed (C0087) <ul style="list-style-type: none"> – Lenze setting: device-dependent ● Rated motor current (C0088) <ul style="list-style-type: none"> – Lenze setting: device-dependent ● Rated motor frequency (C0089) <ul style="list-style-type: none"> – Lenze setting: device-dependent ● Rated motor voltage (C0090) <ul style="list-style-type: none"> – Lenze setting: device-dependent ● Motor cosφ (C0091) <ul style="list-style-type: none"> – Lenze setting: device-dependent 	Enter value for the selected motor connection method (star/delta)!
		Enter value for the selected motor connection method (star/delta)!
11.	For protecting the motor, set the current limit values "I _{max} current" (C0022, C0023) Guide value ≤ 2-fold rated motor current	<p>Power range 0.37 ... 90 kW: For dissipating the regenerative energy, use a brake chopper or feedback module, if necessary</p> <p>Power range 110 ... 400 kW: For dissipating regenerative energy, use a brake resistor, if necessary (see chapter "Commissioning" → "Motor adjustment" → "Current limit values")</p>
A	In motor mode and generator mode (C0022)	
B	Additional limitation in generator mode (C0023) Condition: C0023 < C0022	
12.	If the motor temperature is monitored with a thermal sensor KTY: Activate the temperature feedback with C0594 (fault SD6) Lenze setting: 3 (switched off)	A temperature feedback with KTY has a positive effect on the vector control, since the motor data identification considers the temperature influence in the motor model. (see chapter "Commissioning" → "Motor adjustment")
13.	Start the motor data identification "ident run" (C0148)	(see chapter "Commissioning" → "Adjusting the motor")
A	Ensure that the controller inhibit is active	 X5 ————— 28 misc008
B	Switch on the mains	
C	Set C0148 = 1	
D	Enable controller	 X5 ————— 28 misc009
E	If after approx. 1 ... 2 min the segment IMP is active again, inhibit the controller	<p>Terminal X5/28 = HIGH The identification starts:</p> <ul style="list-style-type: none"> ● The segment IMP goes off ● "WRK run" is displayed ● The motor is energised and "whistles" ● The motor does not rotate <p>Terminal X5/28 = LOW The identification is completed. The following values have been detected and entered into the codes:</p> <ul style="list-style-type: none"> ● Inverter error characteristic (C1753/xx) ● Rotor resistance "Mot Rr" (C0082) ● Stator resistance "Mot Rs" (C0084) ● Leakage inductance "Mot Lss" (C0085) ● Stator inductance "Mot Ls" (C0092)

Switch-on sequence		Note
14.	Set the operating mode "vector ctrl" (C0006) Lenze setting: 5 (V/f characteristic control)	(see chapter "Commissioning" → "Operating mode" → "Vector control")
15.	Set the switching frequency "fchop" (C0018) Lenze setting: Power range 0.37 ... 90 kW: 6 (8/2 kHz sin) Power range 110 ... 400 kW: 6 (4/2 kHz sin)	See chapter "Commissioning" → "Switching frequency of the inverter"
16.	Set your type of the speed feedback system "Feedback type" (C0025) Lenze setting: 1 (no feedback)	See chapter "Commissioning" → "Setting of speed feedback"
A	When using a TTL encoder: Select the encoder used under C0025	
B	When using a TTL encoder with a number of increments which cannot be set under C0025: Set C0025 = 100 Enter the number of increments under C0420	
C	If required, compensate a voltage drop in the incremental encoder cable. Use C0421 to adjust the supply voltage for the TTL encoder.	
D	When using a HTL encoder: Set C0025 = 101 Enter the number of increments under C0420	
17.	Set the maximum speed (C0011) Lenze setting: 3000 rpm	 <p>See chapter "Commissioning" → "Acceleration, deceleration, braking, stopping"</p>
18.	Set the acceleration time T_{ir} (C0012) Lenze setting: 5.00 s	$T_{ir} = t_{ir} \cdot \frac{C0011}{f_2 - f_1}$ <p>(see chapter "Commissioning" → "Acceleration, deceleration, braking, stopping")</p>
19.	Set the deceleration time T_{if} (C0013) Lenze setting: 5.00 s	$T_{if} = t_{if} \cdot \frac{C0011}{f_2 - f_1}$ <p>(see chapter "Commissioning" → "Acceleration, deceleration, braking, stopping")</p>
20.	If required, set the quick stop deceleration ramp (C0105) Lenze setting: 5.00 s	See chapter "Commissioning" → "Acceleration, deceleration, braking, stopping"
21.	If required, adapt the fixed setpoints JOG.	See code table
A	JOG 1 (C0039/1) Lenze setting: 1500 rpm	Activation: X5/E3 = HIGH
B	Further fixed setpoints: JOG 2 (C0039/2) ... JOG 15 (C0039/15)	
22.	Ensure a powerfail-proof saving of the settings in one of the four parameter sets (C0003) Use C0003 = 1 to save the settings in parameter set 1.	Code C0003 is the first code in the menu "Setup V/f". After switching on the DC 24 V supply or mains connection, parameter set 1 is automatically activated. (see chapter "Parameter setting")
23.	Switch on the mains if the external DC 24 V supply voltage is switched on only.	
24.	Enable controller	  <p>Terminal X5/28 = HIGH (see chapter "Commissioning" → "controller inhibit")</p>

Switch-on sequence		Note
25.	Enter the setpoint	<p>Analog setpoint selection: -10 ... +10 V via potentiometer at X6/1 and X6/2</p> <p>Fixed speed: Activate JOG 1 with X5/E3 = HIGH</p>
		JOG 1 is parameterised in C0039/1
26.	The drive is running now	<p>CW rotation: X5/E1 = HIGH and X5/E2 = LOW</p> <p>CCW rotation: X5/E1 = LOW and X5/E2 = HIGH</p> <p>If the drive does not start, press RUN in addition (see chapter "Commissioning" → "Acceleration, deceleration, braking, stopping")</p>

**Note!**

In the menu "Diagnostic" the most important drive parameters can be monitored

6.4 Controller inhibit

Description If the controller inhibit is active, the power outputs are inhibited.

- The drive coasts in zero-torque mode.
- Status display of keypad: Pulse inhibit **IMP**
- Status display at the controller: The green LED is blinking.



Danger!

Do not use the "controller inhibit" function (DCTRL1-CINH) for emergency-off. The controller inhibit only inhibits the power outputs and does **not** disconnect the controller from the mains! The drive could start again any time.

Codes for parameter setting

Code		Possible settings		IMPORTANT	
No.	Name	Lenze	Selection		
C0040	Ctrl enable	0		Controller enable	6.4-1
			0 Ctrl inhibit	Controller inhibited	
			1 Ctrl enable	Controller enabled	

Activation

Via terminal X5/28:

- A LOW level at the terminal inhibits the controller (cannot be inverted)
- A HIGH level re-enables the controller

Via the keys of the keypad (if C0469 = 1):

- **STOP** inhibits the controller
- **RUN** re-enables the controller

Via code C0040:


- C0040 = 0 inhibits the controller
- C0040 = 1 re-enables the controller



Note!

- The sources for controller inhibit are ANDed, i.e. the drive will only restart if the controller inhibit signals of all signal sources have been eliminated.
- The restart starts with zero speed. If centrifugal masses are still rotating, this can lead to an overcurrent.

6.5 **Changing the assignment of the control terminals X5 and X6**



6.5.1 **Free configuration of digital input signals**

- | | |
|--------------------|---|
| Description | <ul style="list-style-type: none"> ► Internal digital signals can be freely linked with external digital signal sources. This serves to establish a freely configurable control of the drive controller. – Digital inputs X5/E1 ... X5/E5 ► A signal source can be linked with several targets. Ensure reasonable linkages for not activating functions that are mutually exclusive (e. g. linking a digital input with quick stop and DC injection braking at the same time). |
|--------------------|---|

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0114			0	High active HIGH level is active	Inversion of digital input signals at X5, function block DIGIN	6.5-1 See System Manual (extension)
			1	LOW active LOW level is active		
1	DIGIN1 pol	0			Terminal X5/E1	
2	DIGIN2 pol	0			Terminal X5/E2	
3	DIGIN3 pol	0			Terminal X5/E3	
4	DIGIN4 pol	1			Terminal X5/E4	
5	DIGIN5 pol	0			Terminal X5/E5	
5	DIGIN6 (ST) pol	0			Terminal X5/ST	

Linking signals

The internal digital signal can be linked with an external signal source by entering the selection figure of the external signal into the configuration code of the internal digital signal.

Example

- C0787/2 =53 ⇒ signal source for JOG2 is terminal X5/E3




Fig. 6.5-1 Connecting digital signal JOG2 with terminal X5/E3

**Tip!**

- A list with all selection figures is included in the chapter "Configuration" → "Selection lists".
- For signal linkage we recommend the function block editor in GDC (ESP-GDC2).

Signal level

- Terminals (X5/E1 ... X5/E5):

- HIGH = +12 V ... +30 V
- LOW = 0 V ... +3 V

- Response times: 1 ms

Inverting the signal level

In C0114 you can define the active signal level (HIGH level active or LOW level active) for the terminals X5/E1 ... X5/E5.

Example

- C0114/3 =1 ⇒ LOW level at X5/E3 activates JOG2

Commissioning	6
Changing the assignment of the control terminals X5 and X6	6.5
Free configuration of digital outputs	6.5.2

6.5.2 Free configuration of digital outputs

- Description**
- ▶ The digital outputs X5/A1 ... X5/A4 can be freely linked with internal digital signals.
 - ▶ One signal source can be linked with several targets.

Codes for parameter setting

Code		Possible settings		IMPORTANT
No.	Name	Lenze	Selection	
C0117 <small>STOP</small>			Selection list 2	Configuration of digital inputs signals, function block DIGOUT A change of the basic configuration in C0005 changes the signal assignment!
1	CFG: DIGOUT1	15000	DCTRL-TRIP	Terminal X5/A1
2	CFG: DIGOUT2	10650	CMP1-OUT	Terminal X5/A2
3	CFG: DIGOUT3	500	DCTRL-RDY	Terminal X5/A3
4	CFG: DIGOUT4	5003	MCTRL-MMAX	Terminal X5/A4
C0118		0	High active HIGH level is active	Inversion of digital output signals, function block DIGOUT
		1	LOW active LOW level is active	
1	DIGOUT1 pol	1		Terminal X5/A1
2	DIGOUT2 pol	1		Terminal X5/A2
3	DIGOUT3 pol	0		Terminal X5/A3
4	DIGOUT4 pol	0		Terminal X5/A4

Linking signals

The digital outputs can be linked with internal digital signals by entering the selection figure of the internal signal into corresponding subcode of C0117.

Example

- ▶ C0117/2 = 505 ⇒ signal source for X5/A2 is the status message "direction of rotation" (DCTRL-CW/CCW)

Signal level

- ▶ Terminals (X5/A1 ... X5/A4):
 - HIGH = +12 V ... +30 V
 - LOW = 0 V ... +3 V
- ▶ Response times: 1 ms

Inverting the signal level

In C0118 you can define the active signal level (HIGH level active or LOW level active) for the terminals X5/A1 ... X5/A4.

Example

- ▶ C0118/2 =1 ⇒ With LOW level at X5/A2 the motor rotates in CW direction (with in-phase motor connection)

6.5.3 Free configuration of analog input signals**Description**

- Internal analog signals can be freely linked with external analog signal sources:
 - Analog inputs X3/1, X3/2 and X3/3, X3/4
- One signal source can be linked with several targets.

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0026			-199.99	{0.01 %}	199.99	Free control code FCODE 26/1 and FCODE26/2 6.5-4 See System Manual (extension)
	1 FCODE (offset)	0.00				Offset of AIN1 (X6/1, X6/2)
	2 FCODE (offset)	0.00				Offset of AIN2 (X6/3, X6/4)
C0027			-199.99	{0.01 %}	199.99	Free control code FCODE 27/1 and FCODE27/2 Gain AIN1 (X6/1, X6/2) ● 100 % = gain 1
	1 FCODE (gain)	100.00				Gain AIN2 (X6/3, X6/4) ● 100 % = gain 1
	2 FCODE (gain)	100.00				
C0034	Mst current	0	0	-10 V ... +10 V		Voltage / current range for analog signals at input X6/1, X6/2 5.6-7
			1	4 mA ... 20 mA		● Observe jumper position of X3 6.5-4
			2	-20 mA ... +20 mA		

Linking signals

The internal analog signals can be linked with an external signal source by entering the selection figure of the external signal into the configuration code of the internal analog signal.

Example

- C0780 = 50 ⇒ Signal source for the main setpoint (NSET-N) is terminal X6/1, X6/2




Fig. 6.5-2 Linking analog signal NSET-N with terminal X6/1, X6/2

**Tip!**

- A list with all selection figures is included in the chapter "Configuration" → "Selection lists".
- For signal linkage we recommend the function block editor in GDC (ESP-GDC2).

Commissioning	6
Changing the assignment of the control terminals X5 and X6	6.5
Free configuration of analog input signals	6.5.3

Adjustment

Gain and offset

Set gain (C0027) and offset (C0026) to adapt the input signal to the application.

Input range of X6/1, X6/2

Input range	C0034	Position of jumper at X3
-10 V ... +10 V	C0034 = 0	 6 □ □ 5 4 □ □ 3 2 □ □ 1
+4 mA ... +20 mA	C0034 = 1	 6 □ □ 5 4 □ □ 3 2 □ □ 1
-20 mA ... +20 mA	C0034 = 2	 6 □ □ 5 4 □ □ 3 2 □ □ 1



Note!

Different settings in C0034 and of X3 result in a wrong input signal.

Commissioning

Changing the assignment of the control terminals X5 and X6

Free configuration of analog outputs

6.5.4 Free configuration of analog outputs

Description

- The analog outputs (X6/62, X6/63) can be freely linked with internal analog process or monitoring signals. The controller outputs a voltage proportional to the internal signal at the analog outputs.
- One signal source can be linked with several targets.

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0108			-199.99	{0.01 %}	199.99	Free control code FCODE108/1 and FCODE108/2
1	FCODE (gain)	100.00				Gain of analog output signal AOUT1 (X6/62) ● 100 % = gain 1
	FCODE (gain)	100.00				Gain of analog output signal AOUT2 (X6/63) ● 100 % = gain 1
C0109			-199.99	{0.01 %}	199.99	Free control code FCODE109/1 and FCODE109/2
1	FCODE (offset)	0.00				Offset of analog output signal AOUT1 (X6/62)
	FCODE (offset)	0.00				Offset of analog output signal AOUT2 (X6/63)

 6.5-6
See System Manual (extension)

Linking signals

Analog outputs can be linked with internal analog signals by entering the selection figure of the internal signal into the code of C0431 (AOUT1, X6/62) or C0436 (AOUT2, X6/63).

Example

- C0436 = 5006 ⇒ signal source for X6/63 is the actual motor voltage



Tip!

- A list with all selection figures is included in the chapter "Configuration" → "Selection lists".
- For signal linkage we recommend the function block editor in GDC (ESP-GDC2).

Adjustment

Set gain (C0108) and offset (C0109) to adapt the output signal to the application.

With an internal signal of 100 % and a gain of 1, a voltage of 10 V is output at the terminal.

Commissioning

6

Adjusting the motor

6.6

Entry of motor data

6.6.1

6.6 Adjusting the motor

6.6.1 Entry of motor data

Description

The vector control mode requires considerably more motor data than the V/f characteristic control mode.

Basically all motor data should be entered independent of the operating mode. This enables the controller to detect further data as e.g. slip compensation (C0021), maximum torque (C0057), number of motor pole pairs (C0059) always conclusively and enter them into the corresponding codes.

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0081 STOP	Mot power	→	0.01 {0.01 kW}	500.00	Rated motor power → Change of C0086 resets value to factory setting • Change of C0081 sets C0086 = 0	
C0086 STOP	Mot type	→	Motor selection list		Motor type selection → depending on the controller used • Motor selection in C0086 sets the corresponding parameters in C0021, C0022, C0081, C0087, C0088, C0089, C0090, C0091	6.6-1
C0087 STOP	Mot speed	→	50 {1 rpm}	36000	Rated motor speed → depending on C0086 • Motor selection in C0086 set the corresponding rated motor speed in C0087 • Change of C0087 sets C0086 = 0	6.6-1
C0088 STOP	Mot current	→	0.5 {0.1 A}	1000.0	Rated motor current → depending on C0086 • Motor selection in C0086 sets the corresponding rated motor current in C0088 • Change of C0088 sets C0086 = 0	6.6-1
C0089 STOP	Mot frequency	→	10 {1 Hz}	5000	Rated motor frequency → depending on C0086 • Motor selection in C0086 sets the corresponding rated motor frequency in C0089 • Change of C0089 sets C0086 = 0	6.6-1

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0090 <small>STOP</small>	Mot voltage	→	0	{1 V}	1000	Rated motor voltage → depending on C0086 <ul style="list-style-type: none"> • Motor selection in C0086 sets the corresponding rated motor voltage in C0090 • Change of C0090 sets C0086 = 0
C0091 <small>STOP</small>	Mot cos phi	→	0.50	{0.01 }	1.00	Motor cos φ → depending on C0086 <ul style="list-style-type: none"> • Motor selection in C0086 sets the corresponding motor cos φ in C0091 • Change of C0091 sets C0086 = 0


Sequence of the motor data entry


Fig. 6.6-1 Sequence diagram for motor data entry

- P_N Rated motor power
- n₀ Synchronous speed
- n_N Rated motor speed
- I_{rΔ} Rated motor current for delta connection
- U_{rΔ} Rated motor voltage for delta connection

Commissioning	6
Adjusting the motor	6.6
Entry of motor data	6.6.1

Lenze motor which is included in C0086

By selecting the motor in C0086 all required motor data are automatically entered into the following codes.

Code	Description	Code	Description
C0022	Limit current for operation in motor mode	C0087	Rated motor speed
C0023	Limit current for operation in generator mode	C0088	Rated motor current
C0081	Rated motor power	C0089	Rated motor frequency
C0082	Motor rotor resistance	C0090	Rated motor voltage
C0084	Motor stator resistance	C0091	Power factor $\cos \varphi$
C0085	Motor leakage inductance	C0092	Motor stator inductance

Motor of another manufacturer or a Lenze motor which is not included in C0086

1. Select a similar motor in C0086.

– Selection criteria: Connection method, rated motor power, rated motor frequency

2. Enter the motor data of the motor nameplate or data sheet into C0081, C0087, C0088, C0089, C0090 and C0091.

Operating mode "87 Hz delta connection"

By changing from star to delta connection and changing the base frequency ($f_{\text{base}} = 87 \text{ Hz}$), the induction machine ($f_N = 50 \text{ Hz}$) develops $\sqrt{3}$ times the power with a frequency of 87 Hz. In the total range the machine runs with a $\sqrt{3}$ times higher delta current, which must be provided by the controller.

Example

A motor with the following data is to be connected in delta connection:

► DSM 50 Hz; Δ/Y 230/400 V; 18.5 kW; 62/35 A, 1450 min^{-1} , $\cos \varphi = 0.88$

Sequence	Note
1. Enter C0086 = 263 (DXRAXX 180-12-87; 32.4 kW; 87 Hz)	Select a motor in C0086, which has a $\sqrt{3}$ times higher rated motor power with delta connection.
2. Enter C0087 = 2548 min^{-1}	Consider the slip speed. With a rated motor torque the slip speed of an asynchronous motor is nearly constant over the total speed range. Calculation of the rated motor speed: $C0087 = (\sqrt{3} - 1) \cdot n_0 + n_N$ $C0087 = (\sqrt{3} - 1) \cdot 1500 \text{ min}^{-1} + 1450 \text{ min}^{-1}$ $n_0 = \text{synchronous speed}$ $n_N = \text{rated motor speed at } 50 \text{ Hz}$
3. Enter C0088 = 62 A	Rated motor current for delta connection
4. Enter C0090 = 400 V	Rated motor voltage for star connection
5. Enter C0089 = 87 Hz	Rated motor frequency
6. Enter C0091 = 0.88	Power factor $\cos \varphi$

6.6.2 Motor selection list

Three-phase asynchronous motors

The following table contains all asynchronous motors, which can be selected via C0086.

The "reference list of asynchronous motors" contains the asynchronous motors, the data of which must be entered manually. (□ 6.6-6)




Fig. 6.6-2 Nameplate of a Lenze motor

A	B	Lenze type	C0081 P _N [kW]	C0087 n _N [rpm]	C0088 I _r [A]	C0089 f _N [Hz]	C0090 U _N [V]	Motor type	Temperature sensor		
9	DSGA56-22-100	SDSGA056-22-100	0.24	2790	0.8	100	390	Asynchronous inverter - motor (Star connection)	KTY		
10	MDSKA56-140	MDSKAXX056-22	0.80	3950	2.4	140	390	Asynchronous servo motor	KTY		
11	MDFKA71-120	MDFKAXX071-22	2.20	3410	6.0	120					
12	MDSKA71-140	MDSKAXX071-22	1.70	4050	4.4	140					
13	MDFKA80-60	MDFKAXX080-22	2.10	1635	4.8	60					
14	MDSKA80-70	MDSKAXX080-22	1.40	2000	3.3	70					
15	MDFKA80-120	MDFKAXX080-22	3.90	3455	9.1	120					
16	MDSKA80-140	MDSKAXX080-22	2.30	4100	5.8	140					
17	MDFKA90-60	MDFKAXX090-22	3.80	1680	8.5	60					
18	MDSKA90-80	MDSKAXX090-22	2.60	2300	5.5	80	390				
19	MDFKA90-120	MDFKAXX090-22	6.90	3480	15.8	120					
20	MDSKA90-140	MDSKAXX090-22	4.10	4110	10.2	140					
21	MDFKA100-60	MDFKAXX100-22	6.40	1700	13.9	60					
22	MDSKA100-80	MDSKAXX100-22	4.00	2340	8.2	80					
23	MDFKA100-120	MDFKAXX100-22	13.20	3510	28.7	120					
24	MDSKA100-140	MDSKAXX100-22	5.20	4150	14.0	140					
25	MDFKA112-60	MDFKAXX112-22	11.00	1710	22.5	60	390				
26	MDSKA112-85	MDSKAXX112-22	6.40	2490	13.5	85					
27	MDFKA112-120	MDFKAXX112-22	20.30	3520	42.5	120					
28	MDSKA112-140	MDSKAXX112-22	7.40	4160	19.8	140					
30	DFQA100-50	MDFQAXX100-22	10.60	1420	26.5	50					
31	DFQA100-100	MDFQAXX100-22	20.30	2930	46.9	100					
32	DFQA112-28	MDFQAXX112-22	11.50	760	27.2	28					
33	DFQA112-58	MDFQAXX112-22	22.70	1670	49.1	58					
34	DFQA132-20	MDFQAXX132-32	17.00	555	45.2	20	360	Asynchronous servo motor	KTY		
35	DFQA132-42	MDFQAXX132-32	35.40	1200	88.8	42					
40	DFQA112-50	MDFQAXX112-22	20.10	1425	43.7	50					
41	DFQA112-100	MDFQAXX112-22	38.40	2935	81.9	100					
42	DFQA132-36	MDFQAXX132-32	31.10	1035	77.4	36					
43	DFQA132-76	MDFQAXX132-32	60.10	2235	144.8	76					
						340					

Commissioning

Adjusting the motor

Motor selection list

6

6.6

6.6.2

A	B	Lenze type	C0081 P _N [kW]	C0087 n _N [rpm]	C0088 I _r [A]	C0089 f _N [Hz]	C0090 U _N [V]	Motor type	Temperature sensor
210	DXRAXX071-12-50	DXRAXX071-12	0.25	1410	0.9				
211	DXRAXX071-22-50	DXRAXX071-22	0.37	1398	1.2				
212	DXRAXX080-12-50	DXRAXX080-12	0.55	1400	1.7				
213	DXRAXX080-22-50	DXRAXX080-22	0.75	1410	2.3				
214	DXRAXX090-12-50	DXRAXX090-12	1.10	1420	2.7				
215	DXRAXX090-32-50	DXRAXX090-32	1.50	1415	3.6				
216	DXRAXX100-22-50	DXRAXX100-22	2.20	1425	4.8				
217	DXRAXX100-32-50	DXRAXX100-32	3.00	1415	6.6	50	400	Asynchronous inverter - motor (Star connection)	Thermal contact
218	DXRAXX112-12-50	DXRAXX112-12	4.00	1435	8.3				
219	DXRAXX132-12-50	DXRAXX132-12	5.50	1450	11.0				
220	DXRAXX132-22-50	DXRAXX132-22	7.50	1450	14.6				
221	DXRAXX160-12-50	DXRAXX160-12	11.00	1460	21.0				
222	DXRAXX160-22-50	DXRAXX160-22	15.00	1460	27.8				
223	DXRAXX180-12-50	DXRAXX180-12	18.50	1470	32.8				
224	DXRAXX180-22-50	DXRAXX180-22	22.00	1456	38.8				
225	30kW-ASM-50	—	30.00	1470	52.0				
226	37kW-ASM-50	—	37.00	1470	66.0				
227	45kW-ASM-50	—	45.00	1480	82.0	50	400	Asynchronous inverter - motor (Star connection)	—
228	55kW-ASM-50	—	55.00	1480	93.0				
229	75kW-ASM-50	—	75.00	1480	132.0				
230	75kW-ASM-50	—	90.00	1480	132.0				
250	DXRAXX071-12-87	DXRAXX071-12	0.43	2525	1.5				
251	DXRAXX071-22-87	DXRAXX071-22	0.64	2515	2.0				
252	DXRAXX080-12-87	DXRAXX080-12	0.95	2515	2.9				
253	DXRAXX080-22-87	DXRAXX080-22	1.3	2525	4.0				
254	DXRAXX090-12-87	DXRAXX090-12	2.0	2535	4.7				
255	DXRAXX090-32-87	DXRAXX090-32	2.7	2530	6.2				
256	DXRAXX100-22-87	DXRAXX100-22	3.9	2535	8.3	87	400	Asynchronous inverter - motor (Delta connection)	Thermal contact
257	DXRAXX100-32-87	DXRAXX100-32	5.35	2530	11.4				
258	DXRAXX112-12-87	DXRAXX112-12	7.10	2545	14.3				
259	DXRAXX132-12-87	DXRAXX132-12	9.7	2555	19.1				
260	DXRAXX132-22-87	DXRAXX132-22	13.2	2555	25.4				
261	DXRAXX160-12-87	DXRAXX160-12	19.3	2565	36.5				
262	DXRAXX160-22-87	DXRAXX160-22	26.4	2565	48.4				
263	DXRAXX180-12-87	DXRAXX180-12	32.4	2575	57.8				
264	DXRAXX180-22-87	DXRAXX180-22	38.7	2560	67.4				
265	30kW-ASM-87	—	52.00	2546	90.0				
266	37kW-ASM-87	—	64.00	2546	114.0				
267	45kW-ASM-87	—	78.00	2563	142.0	87	400	Asynchronous inverter - motor (Delta connection)	—
268	55kW-ASM-87	—	95.00	2563	161.0				
269	75kW-ASM-87	—	130.00	2563	228.0				
270	90kW-ASM-87	—	156.00	2590	277.0				
410	MDXMAXM-071-12-50	MDXMAXM-071-12	0.25	1400	0.82	50	400		
411	MDXMAXM-071-32-50	MDXMAXM-071-32	0.37	1400	1.20	50	400		
412	MDXMAXM-080-12-50	MDXMAXM-080-12	0.55	1400	1.60	50	400		
413	MDXMAXM-080-32-50	MDXMAXM-080-32	0.75	1380	2.00	50	400		
414	MDXMAXM-090-12-50	MDXMAXM-090-12	1.10	1410	2.60	50	400		
415	MDXMAXM-090-32-50	MDXMAXM-090-32	1.50	1420	3.50	50	400		
416	MDXMAXM-100-12-50	MDXMAXM-100-12	2.20	1400	5.60	50	400		
417	MDXMAXM-100-32-50	MDXMAXM-100-32	3.00	1400	7.30	50	400		
418	MDXMAXM-112-22-50	MDXMAXM-112-22	4.00	1430	8.50	50	400		

A	B	Lenze type	C0081 P _N [kW]	C0087 n _N [rpm]	C0088 I _r [A]	C0089 f _N [Hz]	C0090 U _N [V]	Motor type	Temperature sensor
440	MDXMAXM-071-12-87	MDXMAXM-071-12	0.43	2510	1.40	87	400	Asynchronous inverter - motor (Delta connection)	Thermal contact
441	MDXMAXM-071-32-87	MDXMAXM-071-32	0.64	2510	2.10	87	400		
442	MDXMAXM-080-12-87	MDXMAXM-080-12	0.95	2510	2.80	87	400		
443	MDXMAXM-080-32-87	MDXMAXM-080-32	1.30	2490	3.50	87	400		
444	MDXMAXM-090-12-87	MDXMAXM-090-12	2.00	2520	4.50	87	400		
445	MDXMAXM-090-32-87	MDXMAXM-090-32	2.70	2530	6.10	87	400		
446	MDXMAXM-100-12-87	MDXMAXM-100-12	3.90	2510	9.70	87	400		
447	MDXMAXM-100-32-87	MDXMAXM-100-32	5.40	2510	12.70	87	400		
448	MDXMAXM-112-22-87	MDXMAXM-112-22	7.10	2540	14.80	87	400		
449	MDXMAXM-112-32-50	MDXMAXM-112-32	5.50	1440	12.50	50	400		
450	MDXMAXM-132-22-50	MDXMAXM-132-22	7.50	1460	16.80	50	400		
451	MDXMAXM-132-32-50	MDXMAXM-132-32	9.20	1450	19.50	50	400		

Reference list of asynchronous motors

The motors listed under "motor nameplate" are not available in Global Drive Control (GDC) and the device software.

1. Enter the corresponding value listed under C0086 into the code C0086.
2. Compare the codes for the motor data with the values in the table.
– If necessary, adapt the values in the controller to the values in the table.
3. If necessary, optimise the dynamic behaviour of your machine via the codes C0070 and C0071.

Information on the motor nameplate		Motor data															
C86	Type	C0086	C0022	C0081	C0084	C0085	C0087	C0088	C0089	C0090	C0091	C0070	C0071	C0075	C0076		
		I _{max} [A]	P _r [kW]	R _s [Ω]	L _σ [mH]	n _N [rpm]	I _N [A]	f _r [Hz]	U _r [V]	cos φ	V _{pn}	T _{nn}	V _{pi}	T _{ni}			
1006	MDXMAXx-071-12	210	1.28	0.25	39.90	157.20	1355	0.85	50	400	0.70	6	300	3.6	2		
1007	MDXMAXx-071-12	250	2.25	0.47	39.90	157.20	2475	1.50	87	400	0.66	6	300	2	2		
1008	MDXMAXx-071-32	211	1.73	0.37	25.03	122.60	1345	1.15	50	400	0.74	6	300	3.4	2		
1009	MDXMAXx-071-32	251	3.00	0.67	25.03	122.60	2470	2.00	87	400	0.70	6	300	2.5	2		
1010	MDXMAXx-080-12	212	2.40	0.55	20.69	89.00	1370	1.60	50	400	0.78	6	300	3.2	2		
1011	MDXMAXx-080-12	252	3.90	1.00	20.69	89.00	2480	2.60	87	400	0.73	6	300	1.6	2		
1012	MDXMAXx-080-32	213	2.85	0.75	11.69	65.20	1390	1.90	50	400	0.80	6	300	3.5	2		
1013	MDXMAXx-080-32	253	4.95	1.35	11.69	65.20	2510	3.30	87	400	0.77	6	300	1.9	3		
1014	MDXMAXx-090-12	214	3.90	1.10	10.01	40.20	1405	2.60	50	400	0.80	6	300	2.5	2		
1015	MDXMAXx-090-12	254	6.75	2.00	10.01	40.20	2520	4.50	87	400	0.77	6	300	2	2		
1016	MDXMAXx-090-32	215	5.25	1.50	5.85	28.80	1410	3.50	50	400	0.78	6	300	2	2		
1017	MDXMAXx-090-32	255	9.15	2.70	5.85	28.80	2525	6.10	87	400	0.76	6	300	1	2		
1018	MDXMAXx-100-12	216	7.20	2.20	2.90	20.00	1425	4.80	50	400	0.80	6	300	1	1.5		
1019	MDXMAXx-100-12	256	12.45	3.90	2.90	20.00	2535	8.30	87	400	0.76	6	300	0.8	1.5		
1020	MDXMAXx-100-32	217	9.75	3.00	2.10	17.00	1415	6.50	50	400	0.81	6	300	2.5	1.5		
1021	MDXMAXx-100-32	257	17.10	5.40	2.10	17.00	2530	11.40	87	400	0.78	6	300	1.4	1.8		
1022	MDXMAXx-112-22	218	12.45	4.00	1.50	11.00	1435	8.30	50	400	0.82	6	300	2	2		
1023	MDXMAXx-112-22	258	21.45	7.10	1.50	11.00	2545	14.30	87	400	0.83	6	300	1	2		
1024	MDXMAXx-132-12	219	16.50	5.50	0.86	13.00	1450	11.00	50	400	0.84	6	300	1.5	2		
1025	MDXMAXx-132-12	259	28.65	9.70	0.86	13.00	2555	19.10	87	400	0.83	6	300	1.3	2		
1026	MDXMAXx-132-22	220	21.90	7.50	0.80	11.00	1450	14.60	50	400	0.85	6	300	1.5	2		
1027	MDXMAXx-132-22	260	38.10	13.20	0.80	11.00	2555	25.40	87	400	0.84	6	300	0.95	1.8		
1028	MDXMAXx-160-22	221	31.50	11.00	0.50	7.00	1460	21.00	50	400	0.85	6	300	1.9	2.2		
1029	MDXMAXx-160-22	261	54.75	19.30	0.50	7.00	2565	36.50	87	400	0.85	6	300	1	2		
1030	MDXMAXx-160-32	222	41.70	15.00	0.40	5.50	1460	27.80	50	400	0.87	6	300	1.7	2.5		
1031	MDXMAXx-160-32	262	72.60	26.40	0.40	5.50	2565	48.40	87	400	0.86	6	300	1	1.8		

Commissioning

Adjusting the motor

Motor selection list

6

6.6

6.6.2

Information on the motor nameplate		Motor data													
C86	Type	C0086	C0022	C0081	C0084	C0085	C0087	C0088	C0089	C0090	C0091	C0070	C0071	C0075	C0076
		I _{max} [A]	P _r [kW]	R _s [Ω]	L _σ [mH]	n _N [rpm]	I _N [A]	f _r [Hz]	U _r [V]	cos φ	V _{pn}	T _{nn}	V _{pi}	T _{ni}	
1032	MDXMAXx-180-12	223	49.20	18.50	0.40	4.00	1470	32.80	50	400	0.90	6	300	1.4	1.7
1033	MDXMAXx-180-12	263	86.70	32.40	0.40	4.00	2575	57.80	87	400	0.89	6	300	1	1.7
1034	MDXMAXx-180-22	224	58.20	22.00	0.20	3.80	1456	38.80	50	400	0.90	6	300	1	1.5
1035	MDXMAXx-180-22	264	101.1	38.70	0.20	3.80	2560	67.40	87	400	0.89	6	300	1	1.5
1036	MDXMAXM-63-12	210	0.68	0.12	87.58	610.53	1390	0.45	50	400	0.65	6	300	1.5	10
1037	MDXMAXM-63-12	250	1.17	0.21	87.58	610.53	2500	0.78	87	400	0.65	6	300	1.5	10
1038	MDXMAXM-63-32	210	0.98	0.18	56.90	342.11	1400	0.65	50	400	0.65	6	300	1.5	10
1039	MDXMAXM-63-32	250	1.70	0.31	56.90	342.11	2510	1.13	87	400	0.65	6	300	1.5	10
1040	MDXMAXM-112-32	219	18.75	5.50	0.86	7.20	1440	12.50	50	400	0.78	6	300	1.5	10
1041	MDXMAXM-112-32	259	32.55	9.60	0.86	7.20	2550	21.70	87	400	0.78	6	300	1.5	10
1042	MDXMAXM-132-22	220	25.20	7.50	0.54	4.80	1460	16.80	50	400	0.77	6	300	1.5	10
1043	MDXMAXM-132-22	260	43.80	13.10	0.54	4.80	2570	29.20	87	400	0.77	6	300	1.5	10
1044	MDXMAXM-132-32	221	29.25	9.20	0.46	4.70	1450	19.50	50	400	0.85	6	300	1.5	10
1045	MDXMAXM-132-32	261	50.70	16.00	0.46	4.70	2560	33.80	87	400	0.85	6	300	1.5	10
1046	MDXMAXM-160-22	260	31.50	11.00	1.27	18.97	1466	21.00	50	400	0.86	6	300	1.5	10
1047	MDXMAXM-160-32	260	42.30	15.00	0.87	14.28	1466	28.20	50	400	0.87	6	300	1.5	10
1048	MDXMAXM-180-22	260	54.60	18.50	0.40	4.00	1440	36.40	50	400	0.87	6	300	1.5	10
1049	MDXMAXM-180-32	260	66.15	22.00	0.20	3.80	1465	44.10	50	400	0.85	6	300	1.5	10
1050	MDXMAXM-200-32	260	90.00	30.00	0.17	3.50	1455	60.00	50	400	0.85	6	300	1.5	10
1051	MDXMAXM-225-12	260	108.0	37.00	0.15	2.00	1460	72.00	50	400	0.86	6	300	1.5	10
1052	MDXMAXM-225-22	260	128.25	45.00	0.15	2.00	1475	85.50	50	400	0.84	6	300	1.5	10
1053	MDXMAXM-063-11	210	1.43	0.18	51.00	273.7	2760	0.95	50	400	0.80	6	300	1.5	10
1054	MDXMAXM-063-31	210	1.65	0.25	33.00	93.4	2760	1.10	50	400	0.83	6	300	1.5	10
1055	MDXMAXM-071-11	211	1.50	0.37	22.50	90.2	2840	1.00	50	400	0.78	6	300	1.5	10
1056	MDXMAXM-071-31	212	2.25	0.55	16.90	62.9	2840	1.50	50	400	0.82	6	300	1.5	10
1057	MDXMAXM-080-11	213	2.85	0.75	11.36	47.4	2850	1.90	50	400	0.80	6	300	1.5	10
1058	MDXMAXM-080-31	214	4.20	1.10	6.86	33.4	2810	2.80	50	400	0.82	6	300	1.5	10
1059	MDXMAXM-090-11	215	4.80	1.50	5.10	22.2	2840	3.20	50	400	0.85	6	300	1.5	10
1060	MDXMAXM-090-31	216	7.20	2.20	3.20	14.5	2840	4.80	50	400	0.86	6	300	1.5	10
1061	MDXMAXM-100-31	217	9.30	3.00	1.81	10.7	2850	6.20	50	400	0.88	6	300	1.5	10
1062	MDXMAXM-100-41	218	12.75	4.00	1.45	8.6	2830	8.50	50	400	0.85	6	300	1.5	10
1063	MDXMAXM-112-31	250	18.30	5.50	3.10	17	2890	12.20	50	400	0.83	6	300	1.5	10
1064	MDXMAXM-112-41	250	23.25	7.50	1.96	12	2900	15.50	50	400	0.87	6	300	1.5	10
1065	MDXMAXM-132-21	250	28.05	9.00	1.41	11.292	2925	18.70	50	400	0.89	6	300	1.5	10
1066	MDXMAXM-071-13	210	1.13	0.18	58.93	342	870	0.75	50	400	0.71	6	300	1.5	10
1067	MDXMAXM-071-13	250	1.95	0.31	58.93	342	1610	1.30	87	400	0.71	6	300	1.5	10
1068	MDXMAXM-071-33	210	1.50	0.25	37.90	116.8	920	1.00	50	400	0.63	6	300	1.5	10
1069	MDXMAXM-071-33	250	2.55	0.43	37.90	116.8	1660	1.70	87	400	0.63	6	300	1.5	10
1070	MDXMAXM-080-13	211	2.10	0.37	28.00	112.7	900	1.40	50	400	0.67	6	300	1.5	10
1071	MDXMAXM-080-13	251	3.60	0.64	28.00	112.7	1640	2.40	87	400	0.67	6	300	1.5	10
1072	MDXMAXM-080-33	212	2.85	0.55	16.60	78.6	900	1.90	50	400	0.68	6	300	1.5	10
1073	MDXMAXM-080-33	252	4.95	0.95	16.60	78.6	1640	3.30	87	400	0.68	6	300	1.5	10
1078	MDFMAXx-250-22	224	147.75	55.00	0.04	1.92	1475	98.50	50	400	0.86	6	300	1	2
1079	MDFMAXx-250-22	264	255.90	95.00	0.04	1.92	2585	170.60	87	400	0.86	6	300	1	2
1080	MDEBAXM-063-12	210	0.68	0.12	87.58	610.53	1390	0.45	50	400	0.65	6	300	1.5	10
1081	MDEBAXM-063-12	250	1.17	0.21	87.58	610.53	2500	0.78	87	400	0.65	6	300	1.5	10
1082	MDEBAXM-063-32	210	0.98	0.18	56.90	342.11	1400	0.65	50	400	0.65	6	300	1.5	10
1083	MDEBAXM-063-32	250	1.70	0.31	56.90	342.11	2510	1.13	87	400	0.65	6	300	1.5	10
1084	MDEBAXM-071-12	210	1.35	0.25	39.90	157.20	1390	0.90	50	400	0.64	6	300	3.6	2
1085	MDEBAXM-071-12	250	2.34	0.43	39.90	157.20	2500	1.56	87	400	0.64	6	300	2	2
1086	MDEBAXM-071-32	211	1.95	0.37	25.03	122.60	1380	1.30	50	400	0.64	6	300	3.4	2
1087	MDEBAXM-071-32	251	3.38	0.64	25.03	122.60	2490	2.25	87	400	0.64	6	300	2.5	2
1088	MDEBAXM-080-12	212	2.40	0.55	20.69	89.00	1400	1.60	50	400	0.68	6	300	3.2	2

Information on the motor nameplate		Motor data														
C86	Field	C0086	C0022	C0081	C0084	C0085	C0087	C0088	C0089	C0090	C0091	C0070	C0071	C0075	C0076	
			I _{max} [A]	P _r [kW]	R _s [Ω]	L _σ [mH]	n _N [rpm]	I _N [A]	f _r [Hz]	U _r [V]	cos φ	V _{pn}	T _{nn}	V _{pi}	T _{ni}	
1089	MDEBAXM-080-12	252	4.16	0.95	20.69	89.00	2510	2.77	87	400	0.68	6	300	1.6	2	
1090	MDEBAXM-080-32	213	3.00	0.75	11.69	65.20	1400	2.00	50	400	0.72	6	300	3.5	2	
1091	MDEBAXM-080-32	253	5.20	1.30	11.69	65.20	2510	3.46	87	400	0.72	6	300	1.9	3	
1092	MDEBAXM-090-12	214	4.05	1.10	6.40	37.00	1420	2.70	50	400	0.77	6	300	2.5	2	
1093	MDEBAXM-090-12	254	7.05	2.00	6.40	37.00	2535	4.70	87	400	0.77	6	300	2	2	
1094	MDEBAXM-090-32	215	5.40	1.50	4.80	26.00	1415	3.60	50	400	0.77	6	300	2	2	
1095	MDEBAXM-090-32	255	9.30	2.70	4.80	26.00	2530	6.20	87	400	0.77	6	300	1	2	
1096	MDEBAXM-100-12	216	7.20	2.20	2.90	20.00	1425	4.80	50	400	0.80	6	300	1	1.5	
1097	MDEBAXM-100-12	256	12.45	3.90	2.90	20.00	2535	8.30	87	400	0.80	6	300	0.8	1.5	
1098	MDEBAXM-100-32	217	9.90	3.00	2.10	17.00	1415	6.60	50	400	0.81	6	300	2.5	1.5	
1099	MDEBAXM-100-32	257	17.10	5.35	2.10	17.00	2530	11.40	87	400	0.81	6	300	1.4	1.8	
1100	MDEBAXM-112-22	218	12.45	4.00	1.50	11.00	1435	8.30	50	400	0.82	6	300	2	2	
1101	MDEBAXM-112-22	258	21.45	7.10	1.50	11.00	2545	14.30	87	400	0.82	6	300	1	2	
1102	MDEBAXM-112-32	219	17.85	5.50	2.71	21.40	1425	11.90	50	400	0.84	6	300	1.5	10	
1114	MDFMAXx-200-32	224	83.25	30.00	—	—	1465	55.50	50	400	0.85	6	300	1	2	
1115	MDFMAXx-200-32	264	145.50	52.00	—	—	2575	97.00	87	400	0.85	6	300	1	2	

Commissioning	6
Adjusting the motor	6.6
Motor temperature monitoring with PTC or thermal contact	6.6.3

6.6.3 Motor temperature monitoring with PTC or thermal contact

Description	<p>PTC resistors according to DIN 44081 and DIN 44082 can be connected via the terminal inputs T1 and T2. The motor temperature is measured and integrated into the drive monitoring.</p> <p>A thermal contact (NC contact) can also be connected to T1 and T2. Lenze three-phase AC motors provide thermal contacts as default.</p> <p>When using motors equipped with PTC resistors or thermostats, we recommend to always activate the PTC input. This prevents the motor from being destroyed by overheating.</p>
-------------	---



Stop!

- ▶ The motor temperature monitoring may only be connected to T1, T2 if the cable is terminated with a PTC or thermal contact (NC contact) on the motor side.
 - An "open" cable acts like an antenna and can cause faults on the drive controller.
 - Input signals at T1, T2 are processed with a delay of 2 s.
- ▶ The drive controller can only evaluate one PTC resistor! Do not connect several PTC resistors in series or in parallel:
 - The motor temperature would be measured incorrectly.
 - The motors could be destroyed by overheating.
- ▶ If you operated several motors on a drive controller, use thermal contacts (NC contacts) for motor temperature monitoring and connect these in series.
- ▶ To achieve full motor protection, an additional temperature monitoring with separate evaluation must be installed.

Codes for parameter setting

Code		Possible settings			IMPORTANT
No.	Name	Lenze	Selection		
C0585	MONIT OH8	3	0	TRIP	Configuration of motor temperature monitoring • Temperature monitoring via PTC input (T1, T2)
			2	Warning	
			3	Off	

Activation**Note!**

- In the Lenze setting, the motor temperature monitoring is switched off!
- If you work with several parameter sets, the monitoring must be activated separately in each parameter set!

1. Connect the monitoring circuit of the motor to T1 and T2.
 - With $1.6 \text{ k}\Omega < R < 4 \text{ k}\Omega$, the monitoring responds.
2. Set the controller reaction:
 - C0585 = 3: Temperature monitoring of the motor is switched off.
 - C0585 = 0: TRIP error message (display of keypad: OH8 Trip)
 - C0585 = 2: Warning signal (display of keypad: OH8 Warn)

Function test

Connect the PTC input with a fixed resistor:

- $R > 4 \text{ k}\Omega$: The fault message OH8 must be activated.
- $R < 1 \text{ k}\Omega$: Fault message must not be activated.

Commissioning	6
Adjusting the motor	6.6
Motor temperature monitoring with KTY	6.6.4

6.6.4 Motor temperature monitoring with KTY

Description	Via the incremental encoder connection X8 a KTY resistor can be connected to pin X8/5 and X8/8. The motor temperature is detected and integrated in the drive monitoring. The KTY resistor is monitored with regard to interruption and short circuit. We recommend to always activate the KTY input when using motors which are equipped with KTY resistors. This serves to prevent the motor from being destroyed by overheating.
-------------	---



Stop!

- ▶ The controller can only evaluate one KTY resistor! Do not connect several KTY resistors in series or parallel:
 - The motor temperature would be measured incorrectly.
 - The motors could be destroyed by overheating.
- ▶ If several motors are operated on one controller, use thermal contacts (NC contacts) connected in series for motor temperature monitoring.
- ▶ To achieve full motor protection, an additional temperature monitoring with separate evaluation must be installed.

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0121	OH7 limit	150	45	{1 °C}	150	Setting of the operating temperature for monitoring OH7 <ul style="list-style-type: none"> ● Only for KTY at X8 ● Monitoring OH7 is configured in C0584
C0583	MONIT OH3	3	0	TRIP		Configuration of motor temperature monitoring with fixed operating temperature <ul style="list-style-type: none"> ● Only for KTY at X8 ● The operating temperature is fixed at 150 °C
			3	Off		
C0584	MONIT OH7	3	2	Warning		Configuration of monitoring motor temperature with variable operating temperature <ul style="list-style-type: none"> ● Only for KTY at X8 ● When reaching the temperature set in C0121 the warning OH7 is activated
			3	Off		

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0594	MONIT SD6	3	0	TRIP	Activation of the motor temperature monitoring with KTY at X8 <ul style="list-style-type: none"> ● Use C0594 = 0 or 2 to activate monitoring ● In case of a short circuit or interruption at X8/5 and X8/8 the fault message SD6 is activated ● Configuration of the response when exceeding the motor temperature <ul style="list-style-type: none"> – Fixed operating temperature in C0583 – Variable operating temperature in C0584 	 6.6-11 See System Manual (extension)
			2	Warning		
			3	Off		
C1190	Motor PTC selection	0			Temperature characteristic for PTC thermistors	 6.6-11
			0	Standard	Characteristic for PTC thermistors in Lenze motors	
			1	Characteristic	Characteristic for application-specific PTC thermistors	
C1191	Temperature characteristic		0	{1 °C}	255	Temperature range for PTC thermistors <ul style="list-style-type: none"> ● Define temperature points on the characteristic for PTC thermistors
1	Temperature 1	100				Temperature point 1
2	Temperature 2	150				Temperature point 2
C1192	Resistance characteristic		0	{1 Ω}	3000	Resistance characteristic for PTC thermistors <ul style="list-style-type: none"> ● Define resistance points on the characteristic for PTC thermistors
1	Resistance 1	1670				Resistance point 1
2	Resistance 2	2225				Resistance point 2

Commissioning	6
Adjusting the motor	6.6
Motor temperature monitoring with KTY	6.6.4

Activation



Note!

- In the Lenze setting, the motor temperature monitoring is switched off!
- If you work with several parameter sets, the monitoring must be activated separately in each parameter set!

Use C0594 = 0 or C0594 = 2 to activate the motor temperature monitoring via X8. In addition, the connection is monitored for short circuit and interruption.

1. Connecting the monitoring circuit of the motor to X8/5 and X8/8.
2. Setting controller reaction to short circuit or interruption of the connection:
 - C0594 = 3: Monitoring is switched off.
 - C0594 = 0: TRIP error message (display of keypad: Sd6)
 - C0594 = 2: Warning signal (display of keypad: Sd6)

Adjustment

Monitoring with fixed operating temperature (150 °C)

1. Set the controller reaction:
 - C0583 = 3: Temperature monitoring of the motor is switched off.
 - C0583 = 0: TRIP error message (display of keypad: OH3)

Monitoring with variable operating temperature (45 ... 150 °C)

1. Set the operating temperature in C0121.
2. Set the controller reaction:
 - C0584 = 3: Temperature monitoring of the motor is switched off.
 - C0584 = 2: Warning signal (display of keypad: OH7)

Adjustment of KTY operating range

The temperature and resistance range can be adapted to the KTY used.

- C1190 = 0: Fixed operating range for KTY in Lenze motors (Lenze setting)
- C1190 = 1: Adjustable operating range




Fig. 6.6-3 Setting of the operating range for the KTY (C1190 = 1)

The operating range is specified by means of limit values and is in the almost linear section of the graph (a). The operating values are determined by interpolation.

- | | |
|---------|--|
| C1191/1 | Setting of the lower and upper temperature value (T_1, T_2) corresponding to the KTY used. |
| C1191/2 | Setting of the lower and upper resistance value corresponding to the KTY used. |
| C1192/1 | Setting of the lower and upper resistance value corresponding to the KTY used. |
| C1192/2 | Setting of the lower and upper resistance value corresponding to the KTY used. |

Commissioning	6
Adjusting the motor	6.6
Current limits	6.6.5

6.6.5 Current limits

Description	The controllers are provided with a current limit value control which determines the dynamic behaviour under load. The resulting utilisation is compared to the current limit value set under C0022 for motor load and under C0023 for generator load. If the current limit values are exceeded, the controller changes its dynamic behaviour.
Controller performance when a limit value is reached	<p>Motor overload during acceleration: The controller extends the acceleration ramp.</p> <p>Generator overload during deceleration: The controller extends the deceleration ramp.</p> <p>With increasing load and constant speed:</p> <ul style="list-style-type: none"> ► When the current limit of the motor mode is reached: <ul style="list-style-type: none"> – The controller reduces the speed up to 0 min^{-1}. – The controller cancels the change of the speed if the load falls below the limit value again. ► When the current limit in the generator mode is reached: <ul style="list-style-type: none"> – The controller increases the speed up to the maximum speed (C0011). – The controller cancels the change of the speed if the load falls below the limit value again. ► If a sudden load is built up at the motor shaft (e. g. the drive is blocked), the overcurrent disconnection can respond (fault message OCx).

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0022	I _{max} current	→	0	{0.1 A}	- I _{max} limit in motor mode → depending on C0086	6.6-15
C0023	I _{max} gen.	→	0	{0.1 A}	- I _{max} limit in generator mode → depending on C0086	6.6-15

- Adjustment**
- ▶ Set the acceleration and deceleration times so that the drive can follow the speed profile without reaching I_{max} of the controller.
 - ▶ A correct current control during operation in generator mode is only possible with an external brake resistor.
 - ▶ Drive behaviour with motor or generator overload (C0054 > C0022 or C0023):
 - The controller reduces the speed up to 0 min^{-1} .
 - The controller cancels the change of the speed if the load falls below the limit value again.
 - ▶ When operating with switching frequency $> 2 \text{ kHz}$, C0022 and C0023 must be adapted to the permissible output currents (derating).
 - ▶ A correct current control (C0075, C0076) in generator mode is only possible with a connected brake resistor or in DC bus connection with energy exchange.

6.6.6 Automatic collection of motor data

Description The motor data identification serves to detect the required motor data and influences of the motor cable.

Before executing the identification you must manually enter the motor data from the motor nameplate into the corresponding codes.

Vector control (C0006 = 1)

In the vector control mode the motor data identification must be executed before initial commissioning.

- ▶ In case of vector control without temperature feedback, the heating of the motor in the motor model is not taken into consideration.
- ▶ In case of vector control with thermal sensor KTY a motor temperature of 20°C in the motor model is considered.
Important: The temperature feedback must be activated (C0594 = 0 or C0594 = 2) before you execute the motor data identification.

V/f characteristic control (C0006 = 5)

In the Lenze setting, the controllers are defined for a power-adapted motor with 10 m of motor cable. Therefore the motor data identification is not essential.

- ▶ The identification of the motor data also influences the smooth running behaviour. When identifying the motor data for this operating mode, you can optimise the smooth running behaviour at low speeds.

Commissioning	6
Adjusting the motor	6.6
Automatic collection of motor data	6.6.6

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0084 STOP	Mot Rs	→	0.00	{0.01 mΩ}	100000.00	Motor stator resistance → Value is determined by motor parameter identification (C0148, C0149) 6.6-1 6.6-16
C0087 STOP	Mot speed	→	50	{1 rpm}	36000	Rated motor speed → depending on C0086 ● Motor selection in C0086 set the corresponding rated motor speed in C0087 ● Change of C0087 sets C0086 = 0
C0088 STOP	Mot current	→	0.5	{0.1 A}	1000.0	Rated motor current → depending on C0086 ● Motor selection in C0086 sets the corresponding rated motor current in C0088 ● Change of C0088 sets C0086 = 0
C0089 STOP	Mot frequency	→	10	{1 Hz}	5000	Rated motor frequency → depending on C0086 ● Motor selection in C0086 sets the corresponding rated motor frequency in C0089 ● Change of C0089 sets C0086 = 0
C0090 STOP	Mot voltage	→	0	{1 V}	1000	Rated motor voltage → depending on C0086 ● Motor selection in C0086 sets the corresponding rated motor voltage in C0090 ● Change of C0090 sets C0086 = 0
C0091 STOP	Mot cos phi	→	0.50	{0.01 }	1.00	Motor cos φ → depending on C0086 ● Motor selection in C0086 sets the corresponding motor cos φ in C0091 ● Change of C0091 sets C0086 = 0
C0092 STOP	Mot Ls	→	0.00	{0.01 mH}	6553.50	Motor stator inductance → Value is determined by motor parameter identification from C0088, C0089, C0090 and C0091 → Motor selection in C0086 sets corresponding stator inductance value in C0092

Code		Possible settings				IMPORTANT
No.	Name	Lenze	Selection			
C0148 	ident run	0	0	WRK	Ready	<p>Motor data identification</p> <ol style="list-style-type: none"> 1. Inhibit controller, wait until drive has stopped 2. Enter the correct values of the motor nameplate into C0087, C0088, C0089, C0090, C0091 3. Set C0148 = 1, confirm with  4. Enable controller The identification <ul style="list-style-type: none"> – starts,  goes off. The motor "whistles" but does not rotate! – lasts approx. 1 ... 2 min – is completed when  is lit again 5. Inhibit controller:
				1	WRK run Start identification	
C0149 	Auto ident	0	0	Id inactive	Automatic identification is inactive	<p>Automatic motor data identification</p> <ol style="list-style-type: none"> 1. Inhibit controller, wait until drive has stopped 2. Enter the correct values of the motor nameplate into C0087, C0088, C0089, C0090, C0091 3. Set C0149 = 1, confirm with  4. Enable controller The identification <ul style="list-style-type: none"> – starts,  goes off. The motor "whistles" but does not rotate! – lasts approx. 1 ... 2 min – is completed when  is lit again 5. Inhibit controller:
				1	Id active Automatic identification is active <ul style="list-style-type: none"> • The identification starts automatically after controller enable • After a faulty identification, the process is restarted after TRIP RESET or mains switching and subsequent controller enable 	

Commissioning	6
Adjusting the motor	6.6
Automatic collection of motor data	6.6.6

Adjustment

The identification is only executed for the parameter set which is activated at the moment:

- If you want to identify the motor data for another parameter set, you must switch to this parameter set and restart the identification.



Note!

- During the identification the motor is supplied with current. The motor does not rotate.
- The load machine can remain to be connected. Existing holding brakes can be kept in the braking position.
- If the motor is idling, a small phase offset may occur at the motor shaft.

Manual motor data identification (C0148)

1. Enter C0087, C0088, C0089, C0090 and C0091 of your motor (see nameplate):
 - It is vital to enter the correct values since these entries influence important parameters such as slip compensation and no-load current.
 - Enter the values according to the connection method (star or delta) for the rated motor current (C0088) and rated motor voltage (C0090).

1. Inhibit the controller. Wait until drive stands still.
2. Select C0148 = 1, confirm with **ENTER**.
3. Enable the controller. The identification starts.
 - The green LED at the controller is blinking very fast.
 - "WRK run" is displayed at the keypad.
 - The rotor resistance is calculated and saved in C0082.
 - The motor stator resistance is detected and saved in C0084.
 - The motor leakage inductance is measured and saved in C0085.
 - The inverter compensation characteristic is calculated from the measured motor stator resistance and saved in C1751/1 ... C1751/17.
 - The motor stator inductance is calculated from the entered data and saved in C0092.
 - The identification takes approx. 1 ... 2 min (dependent on the rated motor power).
 - The identification is completed when the green LED at the controller is lit (keypad, GDC: **IMP** is active).
4. Inhibit the controller.

If the motor data identification is has been completed incorrectly

If the identification is incorrect, the fault ID1 or ID2 is displayed.

- If the motor data identification is incorrect, the process must be repeated from step 2.

Automatic motor data identification (C0149)

The automatic motor data identification is suitable for standard and replacement devices which are pre-parameterised in the workshop and commissioned on site:

- ▶ Enter the motor data of the motor nameplate, set C0149 = 1 and save the settings.
 - ▶ The motor data identification is started with the first controller enable. After a successful identification the settings are automatically saved in the parameter set 1.
1. Inhibit controller (X5/28 = LOW).
 2. Switch on the mains.
 3. Select a Lenze motor under C0086 or enter motor data of the nameplate.
 4. If required, select C0149 = 1 and confirm with **ENTER**.
 5. Enable the controller. The identification starts.
 - The green LED at the controller is blinking very fast.
 - "WRK run" is displayed at the keypad.
 - The rotor resistance is calculated and saved in C0082.
 - The motor stator resistance is detected and saved in C0084.
 - The motor leakage inductance is measured and saved in C0085.
 - The inverter compensation characteristic is calculated from the measured motor stator resistance and saved in C1751/1 ... C1751/17.
 - The motor stator inductance is calculated from the entered data and saved in C0092.
 - The identification takes approx. 1 ... 2 min (dependent on the rated motor power).
 - The identification is completed when the green LED at the controller is lit (keypad, GDC: **IMP** is active).
 - Controller is inhibited.
 - If required, select C0149 = 0 and confirm with **ENTER**. The automatic motor data identification is deactivated.
 6. Inhibit the controller.

If the motor data identification has been completed incorrectly

If the identification is incorrect, the fault ID or ID is displayed.

1. Acknowledge fault with TRIP RESET or switch the mains.
2. Enable the controller. The identification restarts.

6.7 Setting the speed feedback

Description

For speed monitoring, the feedback signal via incremental encoder can either be supplied via input X8 or X9.

- ▶ At input X8 you can only attach an incremental encoder with TTL-levels.
- ▶ Incremental encoders with HTL-level can only be connected to input X9.

The incremental encoder signal can be output for slaves at the digital frequency output X10.

The master frequency input (DFIN) and master frequency output (DFOUT) are described in the chapter "Function library".



Note!

You can use maximally two of the three interfaces X8, X9, X10 at the same time. This may lead to the fact that the incremental encoder input cannot be activated or the master frequency input or master frequency output does not work.

- ▶ This does not apply if the input signal at X8 or X9 is directly output to master frequency output X10 (C0540 = 4 or 5).
- ▶ To deactivate the master frequency input, the internal signal connection of function block DFIN to the following function block must be removed. Remove the function block DFIN from the processing table.

Codes for parameter setting

Code		Possible settings			IMPORTANT
No.	Name	Lenze	Selection		
C0025 <small>STOP</small>	Feedback type	1		Speed feedback	6.7-1
			1 no feedback	No feedback	
			100 IT (C420) - X8	Input of the number of increments in C0420	
			101 IT (C420) - X9	Input of the number of increments in C0420	
				Number of increments:	
			110 IT512-5V	512 inc	
			111 IT1024-5V	1024 inc	
			112 IT2048-5V	2048 inc	
			113 IT4096-5V	4096 inc	

Commissioning

Setting the speed feedback

Incremental encoder with TTL level at X8

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0420 	Encoder const	512	1	{1 inc/rev}	8192	Number of increments for incremental encoder at X8 or X9 • Connect incremental encoders with HTL-level on X9 only
C0421 	Enc voltage	5.00	5.00	{0.1 V}	8.00	Supply voltage for the incremental encoder at X8 CAUTION! A wrong entry can destroy the incremental encoder!

6.7.1 Incremental encoder with TTL level at X8

On X8, only incremental encoders with TTL level can be operated. Wiring diagram and pin assignment of X8 are described in chapter "Wiring of the basic device" → "Wiring of the feedback system".

Activation

- ▶ C0025 = 100. In addition, you have to set the number of increments in C0420.
- ▶ C0025 = 110, 111, 112 or 113. The number of increments (512, 1024, 2048 or 4096) is automatically set.

Adjustment

The incremental encoder is supplied with voltage by the drive controller.



Stop!

If the supply voltage is too high, it may destroy the incremental encoder.

Under C0421 you can adjust the supply voltage V_{CC} (5 V) of the incremental encoder in order to compensate for the voltage drop along the incremental encoder cable (if required).

Calculation of the voltage drop

$$\Delta U \approx I [m] \cdot \frac{R [\Omega]}{[m]} \cdot I_{inc} [A]$$

I Length of the incremental encoder cable
R Resistance of the incremental encoder cable

I_{inc} Current consumption of the incremental encoder

Commissioning	6
Setting the speed feedback	6.7
Incremental encoder with HTL level at X9	6.7.2

6.7.2 Incremental encoder with HTL level at X9

On X9, incremental encoders with HTL level can be operated. Wiring diagram and pin assignment of X9 are described in chapter "Wiring of the basic device" → "Wiring of the feedback system".

- | | |
|------------|---|
| Activation | ► C0025 = 101. In addition, you have to set the number of increments in C0420. |
| Adjustment | <p>The incremental encoder must be operated with an external supply voltage. C0421 has no influence.</p> <p>► Incremental encoders with HTL level require DC 8 ... 30 V supply voltage. Please observe the information by the manufacturer.</p> |

6.8 **Operating mode**

Description	The control mode of the controller can be selected via the operating mode. You can select between the following modes: <ul style="list-style-type: none">▶ V/f characteristic control▶ Vector control
Selection of the correct operating mode	The V/f characteristic control is the classic operating mode for standard applications. When using the vector control you will achieve improved drive features compared to the V/f characteristic control due to: <ul style="list-style-type: none">▶ Higher torque via the complete speed range▶ Higher speed accuracy and higher concentricity factor▶ Higher efficiency

Speed/ torque characteristics




Fig. 6.8-1 Speed/ torque characteristics

- [A] Operation in motor mode (CW rotation)
- [B] Operation in generator mode (CCW rotation)
- [C] Operation in motor mode (CCW rotation)
- [D] Operation in generator mode (CW rotation)




Fig. 6.8-2 Speed/ torque characteristics

- [A] Operation in motor mode (CW rotation)
- [B] Operation in generator mode (CCW rotation)
- [C] Operation in motor mode (CCW rotation)
- [D] Operation in generator mode (CW rotation)

Recommended operating modes

The frequency inverter is mainly designed for the applications listed in the below table.

The table helps you to select the correct operating mode for your application:

- C0006 = 5: V/f characteristic control with constant V_{min} boost
- C0006 = 1: Vector control

Power range 110 ... 400 kW	Selection of the operating mode in C0006			
	Motor cable shielded ≤ 100 m unshielded ≤ 200 m		Motor cable shielded > 100 m unshielded > 200 m	
	Applications with asynchronous motors	recommended	alternatively	recommended
Single drives				
Drives with constant load	5	1	5	-
Drives with heavy start conditions	1	5	5	-
Travelling drives, conveyor belts	5	1	5	-
Pump drives, fan drives ¹⁾	5	-	5	-
Extruder drives	5	1	5	-
Drives for wire drawing machines	5	1	5	-
Drives for rolling machines	5	1	5	-
Drives for rewinders with dancer (speed-controlled)	1	5	-	-
Group drives (the resulting motor cable length is decisive I_{res})	5	-	5	-
$I_{res} = \sqrt{i \cdot (I_1 + I_2 + \dots + I_i)}$				

¹⁾ A square voltage characteristic (C0014 = 1) is recommended for this application



Note!

Only switch between the operating modes if the controller is inhibited!

6.8.1 V/f characteristic control

Description

The output voltage of the controller follows a defined characteristic. At low output frequencies, the characteristic can be boosted. It can be adapted to different load profiles.

- ▶ Linear characteristic for drives with constant load torque over the speed.
- ▶ Quadratic characteristic for drives with quadratic load torque over the speed:
 - Quadratic V/f characteristics are preferably used in centrifugal pump and fan drives. However, it must be checked whether your pump or fan drive can be operated in this operating mode!
 - If your pump or fan drive cannot be used for the operation with a quadratic V/f characteristic, the linear V/f characteristic or vector control mode must be used.




Fig. 6.8-3 Linear and square-law V/f characteristic

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0006 <small>STOP</small>	Op mode	5			Selection of the operating mode for the motor control	
			1 vector ctrl	Vector control without or with speed feedback	In case of the first selection enter the motor data and identify them with C0148.	<small>6.8-8</small>
			5 V/f	V/f characteristic control	Commissioning without identification of the motor data is possible • Advantage of identification with C0148: Improved smooth running at low speeds	<small>6.8-4</small>
C0014	V/f charact.	0			Characteristic in the V/f characteristic control mode	<small>8.2-25</small>
			0 Linear		Linear V/f characteristic	
			1 square		Square V/f characteristic	
C0015	Rated freq	50	10 {1 Hz}	5000	V/f-rated frequency In C0015 you can set a base frequency which differs from the rated motor frequency (C0089) • Lenze setting: C0015 = C0089 • Changing C0086 or C0089 overwrites the value in C0015	<small>8.2-25</small>

Commissioning	6
Operating mode	6.8
V/f characteristic control	6.8.1

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0016	Umin boost	0.00	0.00	{0.01 %}	100.00	U _{min} boost (FCODE) • C0016 = 1 % corresponds to a boost of 1 % of the rated motor voltage (C0090) • Code is freely configurable	6.8-4
C0021	slipcomp	→	-20.00	{0.01 %}	20.00	Slip compensation → Change of C0086, C0087 or C0089 sets C0021 to the calculated rated slip of the motor • When changing over to the vector control mode, C0021 is set to 0	6.11-1 8.2-25 8.2-40
C0090 <small>STOP</small>	Mot voltage	→	0	{1 V}	1000	Rated motor voltage → depending on C0086 • Motor selection in C0086 sets the corresponding rated motor voltage in C0090 • Change of C0090 sets C0086 = 0	6.6-1

Adjustment

1. Select "V/f characteristic control" mode (C0006 = 5, factory adjustment).
2. Select V/f characteristic (C0014) if necessary
3. Enter the data of the motor nameplate.
4. If required, you can set a base frequency in C0015 which differs from the rated motor frequency (C0089).

Set U_{\min} boost

Load-independent boost of the motor voltage for output frequencies below the V/f rated frequency. This serves to optimise the torque behaviour.

C0016 must be adapted to the asynchronous motor used. Otherwise the motor may be destroyed by overtemperature or the controller may be operated with overcurrent:

1. Operate the motor in idle state at 5 ... 10 % of the rated speed (n_N):

2. Increase V_{\min} until you reach the following motor current:

A Motor in short-time operation up to $0.5 \cdot n_N$:

- For self-ventilated motors: $I_{\text{motor}} \approx I_{N \text{ motor}}$

- For forced ventilated motors: $I_{\text{motor}} \approx I_{N \text{ motor}}$

B Motor in continuous operation up to $0.5 \cdot n_N$:

- For self-ventilated motors: $I_{\text{motor}} \approx 0.8 \cdot I_{N \text{ motor}}$

- For forced ventilated motors: $I_{\text{motor}} \approx I_{N \text{ motor}}$

**Note!**

Observe for all adjusting processes the thermal behaviour of the connected asynchronous motor at low speeds:

- Usually, standard asynchronous motors with insulation class B can be driven for a short time with its rated current in the speed range up to $0.5 \cdot n_N$.
- Contact the motor manufacturer for getting the exact setting values for the max. permissible motor current of self-ventilated motors in the lower speed range.




Fig. 6.8-4 Umin boost at linear and square-law V/f characteristic

Commissioning	6
Operating mode	6.8
V/f characteristic control	6.8.1

Optimising V/f characteristic control

In general the V/f characteristic control can be operated without any further measures. The V/f characteristic control must only be optimised in case of the following drive behaviour:

Drive behaviour	Remedy
Does not rotate concentrically at low speeds, especially when operating with long motor cables	Executing motor identification
Problems in case of high starting duty (high mass inertia), in extreme cases, the error message OC1 occurs	<p>Adjusting the voltage increase (C0016).</p> <ul style="list-style-type: none"> ● Set C0016 so that with an enabled controller and 5 ... 10 % of the rated speed an approx. 0.8-fold ... single rated motor current flows ● 6.8-6
The set voltage increase (C0016) does not result in the desired current flow (controller has problems at high starting duty, error message OC1 during acceleration).	Adapting the voltage increase with boost correction (6.11-5)
Drive does not follow the speed setpoint. Reason: The current controller intervenes in the rated field frequency to limit the controller output current to the maximum current (C0022, C0023)	<ul style="list-style-type: none"> ● Increasing acceleration / deceleration time ● Consider sufficient magnetising time of the motor. the magnetising time amounts to 0.1 ... 2 s depending on the motor power ● Increase permissible maximum current (C0022, C0023)
For operation without speed feedback (C0025 = 1): Lack of speed stability at high load (setpoint and motor speed are not proportional anymore)	<ul style="list-style-type: none"> ● Increase slip compensation (C0021). Important: unstable drive due to overcompensation! ● In case of cyclic load impulses (e.g. centrifugal pump) a smoother motor characteristic can be achieved by smaller values in C0021 (maybe negative values) <p>Note: The slip compensation is only active for operation without speed feedback.</p>
Error messages OC1 or OC3 with short acceleration times (C0012) compared with the load (controller cannot follow the dynamic processes)	<ul style="list-style-type: none"> ● Increase gain of the I_{max} controller (C0075) ● Reduce integral-action time of the I_{max} controller (C0076) ● Increase acceleration time (C0012)
Mechanical resonances at certain speeds	The function block NLIM1 serves to suppress those speed ranges in which resonances occur (see chapter "Function library").
Speed oscillations in no-load operation at speeds $> \frac{1}{3}$ rated speed	The oscillation damping minimises speed oscillations (see "Optimising operational performance" in chapter "Commissioning")

6.8.2 Vector control**Description**

Compared to the V/f characteristic control, the vector control serves to achieve a considerably higher torque and lower current consumption in idle state.

**Note!**

- The connected motor may be maximally two power classes smaller than the motor assigned to the drive controller.
- The motor data identification is essential.

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0006 <small>STOP</small>	Op mode	5			Selection of the operating mode for the motor control	
			1	vector ctrl	Vector control without or with speed feedback	In case of the first selection enter the motor data and identify them with C0148. <small>6.8-8</small>
			5	V / f	V/f characteristic control	Commissioning without identification of the motor data is possible <ul style="list-style-type: none">● Advantage of identification with C0148: Improved smooth running at low speeds <small>6.8-4</small>
C0021	slipcomp	→	-20.00	{0.01 %}	20.00	Slip compensation → Change of C0086, C0087 or C0089 sets C0021 to the calculated rated slip of the motor <ul style="list-style-type: none">● When changing over to the vector control mode, C0021 is set to 0 <small>6.11-1</small> <small>8.2-25</small> <small>8.2-40</small>
C0075	Vp curr CTRL	0.04	0.00	{0.01 }	0.99	Gain of current controller <ul style="list-style-type: none">● Vector control: Gain of current controller● V/f characteristic control: Maximum current controller <small>8.2-25</small> <small>8.2-40</small>
C0076	Tn curr CTRL	10.0	0.1	{0.1 ms}	2000.0	Integral-action time of current controller <ul style="list-style-type: none">● Vector control: integral-action time of current controller● V/f characteristic control: maximum current controller● C0076 = 2000 ms: current controller is switched off <small>8.2-25</small> <small>8.2-40</small>
C0077	Ti field CTRL	4.0	0.3	{0.1 ms}	6000.0	Integral-action time of field controller <ul style="list-style-type: none">● Only active in case of vector control with feedback
C0081 <small>STOP</small>	Mot power	→	0.01	{0.01 kW}	500.00	Rated motor power → Change of C0086 resets value to factory setting <ul style="list-style-type: none">● Change of C0081 sets C0086 = 0

Commissioning

6

Operating mode

6.8

Vector control

6.8.2

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0087 	Mot speed	→	50	{1 rpm}	36000	Rated motor speed → depending on C0086 <ul style="list-style-type: none"> ● Motor selection in C0086 sets the corresponding rated motor speed in C0087 ● Change of C0087 sets C0086 = 0 	 6.6-1
C0088 	Mot current	→	0.5	{0.1 A}	1000.0	Rated motor current → depending on C0086 <ul style="list-style-type: none"> ● Motor selection in C0086 sets the corresponding rated motor current in C0088 ● Change of C0088 sets C0086 = 0 	 6.6-1
C0089 	Mot frequency	→	10	{1 Hz}	5000	Rated motor frequency → depending on C0086 <ul style="list-style-type: none"> ● Motor selection in C0086 sets the corresponding rated motor frequency in C0089 ● Change of C0089 sets C0086 = 0 	 6.6-1
C0090 	Mot voltage	→	0	{1 V}	1000	Rated motor voltage → depending on C0086 <ul style="list-style-type: none"> ● Motor selection in C0086 sets the corresponding rated motor voltage in C0090 ● Change of C0090 sets C0086 = 0 	 6.6-1
C0091 	Mot cos phi	→	0.50	{0.01 }	1.00	Motor cos φ → depending on C0086 <ul style="list-style-type: none"> ● Motor selection in C0086 sets the corresponding motor cos φ in C0091 ● Change of C0091 sets C0086 = 0 	 6.6-1
C0092 	Mot Ls	→	0.00	{0.01 mH}	6553.50	Motor stator inductance → Value is determined by motor parameter identification from C0088, C0089, C0090 and C0091 → Motor selection in C0086 sets corresponding stator inductance value in C0092	 6.6-1
C0148 	ident run	0	0	WRK stop	Ready	Motor data identification 1. Inhibit controller, wait until drive has stopped 2. Enter the correct values of the motor nameplate into C0087, C0088, C0089, C0090, C0091 3. Set C0148 = 1, confirm with  4. Enable controller The identification – starts,  goes off. The motor "whistles" but does not rotate! – lasts approx. 1 ... 2 min – is completed when  is lit again 5. Inhibit controller:	 6.6-16
		1		WRK run	Start identification		

Set vector control

C0006 = 1 set the vector control mode.



Note!

When setting the vector control mode, the slip compensation (C0021) is automatically set to 0.0 %.

- When you switch back to the V/f characteristic control mode, the slip compensation must be re-adapted.

Prepare the motor data identification

The motor data of the motor nameplate must be entered:


- Rated motor speed (C0087)
- Rated motor current (C0088)
- Rated motor frequency (C0089)
- Rated motor voltage (C0090)
- Motor cos φ (C0091)

Executing the motor data identification

Execute the motor data identification. (□ 6.6-16)

Optimising vector control

In general the vector control can be operated without any further measures. The vector control must only be optimised in case of the following drive behaviour:

Drive behaviour	Remedy
Operation without feedback: <ul style="list-style-type: none"> The current consumption in idle state differs widely from the rated magnetising current ($I_{mR} \approx I_N \times \sin \varphi$). Calculate $\sin \varphi$ from the $\cos \varphi$ of the motor nameplate. The drive has an uneven starting performance 	<p>1. Optimise setpoint for the motor magnetising current. (6.11-9)</p> <p>2. Stator inductance (C0092) must be adapted after motor parameter identification. The calculation of the stator inductance by the motor data identification is based on the motor data entered before and does not consider the physical leakage of the motor and the inductive reactance of the motor cable.</p>  <p>9300vec040</p> <p>Tendency of the correction of C0092 PN: rated motor power</p>
Lack of speed stability at high load (setpoint and motor speed are not proportional anymore)	<p>Use C0021 (slip compensation) to change the influence of the rotor resistance (C0082) proportionally:</p> <ul style="list-style-type: none"> Reduce the value in C0021 at an increasing speed (negative values) Increase the value in C0021 at a decreasing speed <p>Note: If you activate the vector control (C0006 = 1), C0021 is automatically set to 0 %.</p>
Unstable control at higher speeds	<ul style="list-style-type: none"> Reduce the gain of the speed controller (C0070) (if required, speed-dependent adaptation via function block CURVE1 and MCTRL-VP-ADAPT) Control value in C0092 by comparing the current consumption in no-load operation with the rated magnetising current ($I_{mR} \approx I_N \times \sin \varphi$). Optimise oscillation damping (C0234 ... C0236)
Unstable control at higher speeds and high torque at high power (> 55 kW)	<ul style="list-style-type: none"> Reduce gain of the I_{max} controller (C0075) or reduce gain and influence of the oscillation damping (at a power of 55 ... 90 kW). For operation with feedback, deactivate oscillation damping with C0234 = 0.
Unstable control in field weakening range for operation with speed feedback	<ul style="list-style-type: none"> Reduce integral-action time of the field controller via C0077 Increase gain of the I_{max} controller (C0075)
Error messages OC1 or OC3 with short acceleration times (C0012) compared with the load (controller cannot follow the dynamic processes).	<ul style="list-style-type: none"> Increase gain of the I_{max} controller (C0075) Reduce integral-action time of the I_{max} controller (C0076) Increase acceleration time (C0012)
Mechanical resonances at certain speeds	The function block NLIM1 serves to suppress those speed ranges in which resonances occur (see chapter "Function library").
Speed oscillations in no-load operation at speeds > $1/3$ rated speed	The oscillation damping minimises speed oscillations (see "Optimising operational performance" in chapter "Commissioning")

6.9 Switching frequency of the inverter

Description

The switching frequency of the inverter influences the smooth running behaviour, the power loss in the controller and the noise generation in the connected motor. The Lenze setting is the optimal value for standard applications. The following general rule applies:

The lower the switching frequency, the

- ▶ lower the power loss.
- ▶ higher the noise generation.
- ▶ better the concentricity factor.

You can select between two switching frequency modes:

CoDe	sine-wave modulated (sin)	flat-top modulated (f_top)
C0018	1, 2, 4, 6	3



Note!

- ▶ The concentricity factor at low speeds is lower with flat top modulation than with sine-wave modulation. For standard application a sine-wave modulated switching frequency is optimal.
- ▶ The maximum output frequency of the controller depends on the selected switching frequency (see C0018).
- ▶ With C0018 = 6, the switching frequency will be automatically changed depending on the output current of the controller.
- ▶ Please observe that the output current must be reduced when operating with high switching frequencies to prevent an impermissible heating of the controller (derating).
- ▶ Adapt the current limit values (C0022 and C0023) so that the currents specified in the technical data are not exceeded.

Moreover, you can adjust whether it is switched to a lower switching frequency when the heatsink temperature reaches an adjustable limit value. This prevents the drive from being inhibited by the error "overtemperature" and the motor coasts without torque.

Codes for parameter setting

Code		Possible settings		IMPORTANT	
No.	Name	Lenze	Selection		
C0018	fchop	6		Switching frequency of the inverter	6.9-1
			1 1 kHz sin	loss-optimised	
			2 2 kHz sin	concentricity-optimised	
			3 4 kHz f_top	power-optimised	
			4 4 kHz sin	noise-optimised	
			6 4/2 kHz sin	noise/concentricity-optimised with automatic change-over to low switching frequency	
C0144 	OH switch	1	0 Switch off	Switch-over is not active	Temperature-dependent switching frequency reduction
			1 Switch on	Switch-over is active	

Function of automatic switching frequency reduction

C0144 = 0 (no temperature-dependent switching frequency reduction)

If the maximum permissible heatsink temperature (ϑ_{max}) is exceeded when operating with automatic switching frequency reduction, the inverter is inhibited, TRIP "OH" (overtemperature) is set and the motor coasts without torque.

C0144 = 1 (temperature-dependent switching frequency reduction is active):

- ▶ If the heatsink temperature set in C0122 (overtemperature OH4) is reached when operating with automatic switching frequency reduction, the controller automatically reduces the switching frequency to 2 kHz, thus keeping the operation running.
- ▶ After the heatsink has cooled down, the controller automatically switches to the set switching frequency again.

6.10 Acceleration, deceleration, braking, stopping

6.10.1 Speed range

Description

The speed range required for the application is set in the codes C0010 and C0011:

- ▶ The minimum speed (C0010) corresponds to a speed setpoint selection of 0 %.
- ▶ The maximum speed (C0011) corresponds to a speed setpoint selection of 100 %.




Fig. 6.10-1 Relation between setpoint and minimum and maximum output frequency

Codes for parameter setting

Code		Possible settings				IMPORTANT		
No.	Name	Lenze	Selection					
C0010	N _{min}	0	0	{1 rpm}	36000	<ul style="list-style-type: none"> ● Reference value for the absolute and relative setpoint selection for the acceleration and deceleration times ● C0059 must be set correctly ● Set C0010 < C0011 ● C0010 is only effective in case of analog setpoint selection via AIN1 <p>Important: For parameter setting via interface, major changes in one step should only be made when the controller is inhibited.</p>	Minimum speed	6.10-1
C0011	N _{max}	3000	0	{1 rpm}	36000		Maximum speed	

C0010

Features "minimum speed" (n_{min}):

- ▶ C0010 is approached via the acceleration ramp.
- ▶ C0010 is only effective with analog setpoint selection via AIN1 (terminal X6/1 and X6/2).

6

Commissioning

- 6.10 Acceleration, deceleration, braking, stopping
- 6.10.1 Speed range

C0011

Features "maximum output frequency" (n_{max}):

- ▶ For defining fixed setpoints (JOG) C0011 acts as limitation.
- ▶ C0011 is an internal scaling value! Therefore, changes must only be made when the controller is inhibited!



Stop!

Set C0011 so that the maximum motor speed is not exceeded.
Otherwise the motor can be destroyed.

Adjusting tips

Observe the internal speed limits (p = number of motor pole pairs):

- ▶ Switching frequency 2/4 kHz: $n_{max} = 36000/4p \text{ min}^{-1}$
- ▶ Switching frequency 1 kHz: $n_{max} = 36000/4p \text{ min}^{-1}$

6.10.2 Setting acceleration times and deceleration times in speed mode

Description The acceleration and deceleration times determine the controller response time after a setpoint change.

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0012	Tir (acc)	5.00	0.00	{0.01 s}	9999.90	Acceleration time T_{ir} of the main setpoint • Refers to speed change 0 ... C0011
C0013	Tif (dec)	5.00	0.00	{0.01 s}	9999.90	Deceleration time T_{if} of the main setpoint • Refers to speed change 0 ... C0011

Adjustment

- The acceleration and deceleration times refer to a speed change from 0 min^{-1} to the max. speed set in C0011.
- Calculate the times T_{ir} and T_{if} , which you can set under C0012 and C0013.




Fig. 6.10-2 Acceleration and deceleration times

$$T_{ir} = t_{ir} \cdot \frac{C0011}{n_2 - n_1}$$

t_{ir} and t_{if} are the desired times for the change between n_1 and n_2

$$T_{if} = t_{if} \cdot \frac{C0011}{n_2 - n_1}$$



Note!

If the acceleration and deceleration times are set too short and under unfavourable operating conditions the controller can be switched off with TRIP OC1 or OC3. In these cases, the acceleration and deceleration times must be set so that the drive can follow the speed profile without I_{max} reaching a drive system.

6 Commissioning

- 6.10 Acceleration, deceleration, braking, stopping
- 6.10.3 Quick stop

6.10.3 Quick stop

Description Quick stop brakes the drive to standstill with the deceleration time set in C0105.

► DC-injection braking (GSB) has priority over quick stop.

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0105	QSP Tif	5.00	0.00 {0.01 s}	999.90	Quick stop deceleration time ● The deceleration time refers to a speed variation of C0011 ... 0	8.2-25 8.2-40

Activation

Via digital signal:

- MCTRL-QSP = HIGH.
- Activating signal DCTRL-QSP. The signal can be activated via 3 OR'd inputs:
 - Control word CAN-CTRL.B3 from CAN-IN1
 - Control word AIF-CTRL.B 3 from AIF-IN
 - Control word C0135.B3

Via keyboard of the keypad:

For this the key must be assigned with the quick stop function (C0469 = 2):

- activates quick stop
- restarts the drive

Commissioning	6
Acceleration, deceleration, braking, stopping	6.10
Changing the direction of rotation	6.10.4

6.10.4 Changing the direction of rotation

Description In the basic configurations (C0005) the direction of rotation of the motor is reversed in a fail-safe way via the X5/E1 and X5/E2 and the function block R/L/Q. Thus, only the main setpoint is changed.

The reversing time depends on the ramp times set for the main setpoint or quick stop.

When the direction of rotation is changed, the drive brakes along the deceleration ramp (C0013) and accelerates along the acceleration ramp (C0012) into the other direction of rotation.

Direction of rotation with in-phase connection:

Direction of rotation	Signal level at		Notes
	X5/E1	X5/E2	
CCW rotation	LOW	HIGH	
CW rotation	HIGH	LOW	
Quick stop	LOW	LOW	
Unchanged	HIGH	HIGH	<ul style="list-style-type: none"> ● During operation: The direction of rotation results from the signal which was active first. ● At mains connection: The controller activates quick stop (QSP).

6.11 Optimising the operating behaviour

6.11.1 Slip compensation

Description The speed of an asynchronous machine decreases when being loaded. This load-dependent speed drop is called slip. By setting C0021 the slip can be partly compensated.

In the V/f characteristic control mode the slip compensation is only active at operation without feedback (C0025 = 1).

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0021	slipcomp	→	-20.00	{0.01 %}	20.00	<p>Slip compensation → Change of C0086, C0087 or C0089 sets C0021 to the calculated rated slip of the motor</p> <ul style="list-style-type: none"> ● When changing over to the vector control mode, C0021 is set to 0
C0078	Tn slip CTRL	100	1	{1 ms}	6000	<p>Integral-action time of slip controller</p> <ul style="list-style-type: none"> ● Filter time for slip compensation (C0021) ● Only active with V/f characteristic control

Adjustment**V/f characteristic control**

The slip compensation (C0021) is automatically calculated from the rated motor speed (C0087) and the rated motor frequency (C0089). The entered slip constant [%] is the rated slip of the motor in [%] relating to the synchronous speed of the motor.

- Calculating the slip compensation and entering it into C0021:

$s = \frac{n_{rsyn} - n_r}{n_{rsyn}} \cdot 100 \%$	E Slip constant (C0021) [%]
$n_{rsyn} = \frac{f_r \cdot 60}{p}$	n _{rsyn} Synchronous motor speed [min ⁻¹]
	n _r Rated motor speed according to motor nameplate [min ⁻¹]
	f _r Rated motor frequency according to motor nameplate [Hz]
	p Number of motor pole pairs (1, 2, 3, ...)

- If required, the slip compensation can be adapted manually:
 - If C0021 is set too high, the drive may get unstable.
 - With cyclic load impulses (e. g. centrifugal pump) a smooth motor characteristic is achieved by smaller values in C0021 (possibly negative values)
 - Parameterise C0078 (filter time for the slip compensation) if you want to change the motor response time to load changes (dynamic ↔ slow).
- The actual speed is output as an analog signal (in [%] of n_{max} (C0011)) to MCTRL-NACT.

**Note!**

When operating synchronous or reluctance motors, C0021 must be set to 0.

Vector control

Use C0021 to change the influence of the rotor resistance (C0082) proportionally:

- Reduce the value in C0021 at an increasing speed (negative values)
- Increase the value in C0021 at a decreasing speed

**Note!**

When setting the vector control mode, the slip compensation (C0021) is automatically set to 0.0 %.

- When you switch back to the V/f characteristic control mode, the slip compensation must be re-adapted.

6.11.2 Oscillation damping

Description

Suppressing no-load oscillations in case of:

- ▶ Drives with different rated power of controller and motor, e. g. when operating with high switching frequency and the power derating involved.
- ▶ Operation of higher-pole motors.
- ▶ Operation of three-phase AC drives > 10 kW.

Compensation of resonances in the drive kit:

- ▶ Certain asynchronous motors may show this behaviour above $\frac{1}{3}$ of the rated speed ($\frac{1}{3} \cdot n_n$). This may result in an unstable operation (current and speed variations).

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0234	damp value	20	-100	{1 %}	100	Influence of the oscillation damping, function block MCTRL <ul style="list-style-type: none"> ● Minimising a tendency to oscillation of the drive ● Influences the tendency to oscillation of the drive ● When C0025 >1 and C0006 = 1, C0234 is set to 0
C0235	damping	2	1	{1 ms}	600	Filter time of the oscillation damping, function block MCTRL <ul style="list-style-type: none"> ● Filter time for the internal signal for oscillation damping
C0236	damp limit	1.0	0.0	{0.1 Hz}	20.0	Limit value of oscillation damping, function block MCTRL <ul style="list-style-type: none"> ● Limit value for the internal signal of oscillation damping

Adjustment

The Lenze setting is designed for power-adapted motors.

Usually, the speed oscillations can be reduced by changing the Lenze setting of the codes C0234 oder C0236 by the factor 2 ... 5.

1. Approach the range with speed oscillations.
2. Change the influence of the oscillation damping in C0234 (generally, increase it).
3. Increase the limitation of the oscillation damping in C0236.
4. Change filter time in C0235 in the range of 1 ... 20 ms, if necessary.
► These can be indicators for smooth running:
 - Constant motor current characteristic
 - Reduction of the mechanical oscillations in the bearing seat

**Note!****Restricted effect with vector control**

- The oscillation damping has no influence on the drive behaviour at low tendency to oscillation of the speed controller.
- Especially for drives > 55 kW with a tendency to oscillation it may be necessary to deactivate the oscillation damping (C0234 = 0 %).
- For operation with feedback the oscillation damping has no influence.

6.11.3 Boost correction with V/f characteristic control

Description

In the V/f characteristic control mode (C0006 = 5), a constant voltage boost (in [%] von C0090) can be preset in code C0016 at low speeds or motor standstill.

If due to the setting in C0016 no current or a nonuniform current flows, the voltage boost can be further increased via the boost correction to inject a sufficiently high and uniform current into the motor.

If the voltage boost is insufficient, the following drive behaviour occurs:

- The required torque is not achieved at standstill.
- When the load is accelerated from standstill, the current overshoots as the motor had not been magnetised sufficiently before. OC1 can trip.



Note!

If the motor magnetising current is too low, Lenze recommends to operate the controller with sine-wave modulated switching frequency (C0018 = 0, 1, 4, 5 oder 6) only.

Codes for parameter setting

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0080	Vp field CTRL	0.50	0.00	{0.01 }	0.99	Influence on the motor magnetising current selected under C0095 <ul style="list-style-type: none"> ● Not effective with C0006 = 1 and C0025 > 1 at the same time ● Influence is effective from 0 Hz to the frequency selected under C1583 	6.6-1
C0095 <small>STOP</small>	Mot Io	→	0.0	{0.1 A}	1000.0	Motor magnetising current → dependent on C0086, C0088 and C0091 <ul style="list-style-type: none"> ● Change of C0086 sets C0095 to the Lenze setting ● Change of C0095 sets C0086 = 0 	6.6-1
C1583	fset high	100.0 0	0.00	{0.01 %}	199.99	Alterations by Lenze service only! Adaptation of the motor magnetising current set in C0095 (with V/f characteristic control: influence limit of the boost correction; with vector control: influence limit of the field precontrol) <ul style="list-style-type: none"> ● The output frequency is set up to which the motor magnetising current set in C0095 is to have an effect. ● C1583 = 100 % \triangleq half the rated motor frequency in C0089 	6.11-5

Adjustment**Stop!**

A longer operation of the motor in standstill may destroy the motor by overheating, especially in case of small motors.

- Connect the thermal contact (NC contact), PTC, or KTY of the motor and activate the motor temperature monitoring of the controller.
- Operate self-ventilated motors with a blower, if required.

Setting voltage boost

1. Set a voltage boost in C0016. (6.8-6)
 - When C0016 = 0 % no boost is possible.
2. For magnetising the motor, consider enough time from controller enable to the start of the speed ramp-function generator.
 - The bigger the motor the longer the time for magnetisation. A motor with the power of 90 kW requires up to 2 s.
 - If the desired continuous current does not flow, correct the boost using the codes C0080, C0095 and C1583.

Carry out a boost correction

3. If required, set the desired motor magnetising current (standstill current) in C0095 which is to be achieved by the boost correction.
 - The value in the Lenze setting has been evaluated by the controller from the entered motor data of the motor nameplate.
 - When C0095 = 0, the boost correction is deactivated.
4. Set the influence of the boost correction in C0080.




Fig. 6.11-1 Influence of boost correction

[A] Maximum height of the correction value when the field frequency is 0

C0080 = 0.99 Maximum correction value. The voltage boost U_{min} achieved by C0016 is increased sixfold.

C0080 = 0 No correction value. The voltage boost U_{min} achieved by C0016 is not increased, the boost correction is deactivated.

Increase the value in C0080 step by step and observe the effect on the current injection with an oscilloscope, if required.

- If the boost correction is too high, this can cause current overshoots when the current injection starts.

5. Set the adaptation of the boost correction in C1583.




Fig. 6.11-2 Adaptation of boost correction

[A] Adaptation of boost correction

— Characteristic when C1583 = 100 % (Lenze setting). The output frequency corresponds to half the rated motor frequency in C0089.

- - - - Characteristic when C1583 = 199.99 %. The output frequency corresponds to the rated motor frequency in C0089.

When C1583 = 0 % the boost correction is deactivated

Enter the output frequency in C1583 until which the boost correction is to have an effect.

- At an output frequency of 0 Hz the boost correction has the influence defined in C0080 and is 100 percent efficient. An increasing output frequency reduces the influence linearly to 0.

Example

A motor connected to a controller has a rated motor voltage of 400 V (C0090 = 400 V). The voltage boost U_{\min} is set to 2 % (C0016 = 2 %).

- At a voltage boost of 2 % and a rated motor voltage of 400 V, $U_{\min} = 8 \text{ V}$.

The voltage boost U_{\min} is to be optimised via C0080:




Fig. 6.11-3 Influence of boost correction

[A] Maximum correction value when the output frequency is 0 Hz

- When $C0080 = 0.5$, the maximum correction value is:
 $3 \times U_{\min} = 3 \times 8 \text{ V} = 24 \text{ V}$
- The maximum voltage boost is:
 $U_{\min} + \text{correction value} = 8 \text{ V} + 24 \text{ V} = 32 \text{ V}$

Commissioning	6
Optimising the operating behaviour	6.11
Motor magnetising current with vector control	6.11.4

6.11.4 Motor magnetising current with vector control

This chapter describes how to optimise the setpoint for the motor magnetising current (C0095) via the codes C0080 and C1583 in case of vector control **without** feedback.

- In case of vector control **with** feedback the setpoint for the motor magnetising current is only determined by C0095. An optimisation is not required. The codes C0080 and C1583 have no effect.

The motor current consists of the exciting and active part. The magnetisation of the motor is determined by the excitation current (magnetising current). To create a torque the motor needs active current.

In the vector control mode (C0006 = 1) a magnetising current is injected into the motor after controller enable. The current level is detected by the controller from the motor data.

If a too low motor magnetising current is injected after controller enable, the following drive behaviour occurs:

- The required torque is not achieved at standstill.
- When a high load is accelerated from standstill, the current overshoots. OC1 can be activated.
- The machine runs irregularly as the motor is underexcited.



Note!

If the motor magnetising current is too low, Lenze recommends to operate the controller with sine-wave modulated switching frequency (C0018 = 0, 1, 4, 5 oder 6) only.

6**Commissioning**

6.11

Optimising the operating behaviour

6.11.4

Motor magnetising current with vector control

Codes for parameter setting

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0080	Vp field CTRL <small>STOP</small>	0.50	0.00	{0.01 }	0.99	Influence on the motor magnetising current selected under C0095 <ul style="list-style-type: none"> ● Not effective with C0006 = 1 and C0025 > 1 at the same time ● Influence is effective from 0 Hz to the frequency selected under C1583 	6.6-1
C0095	Mot Io	→	0.0	{0.1 A}	1000.0	Motor magnetising current → dependent on C0086, C0088 and C0091 <ul style="list-style-type: none"> ● Change of C0086 sets C0095 to the Lenze setting ● Change of C0095 sets C0086 = 0 	6.6-1
C1583	fset high	100.00	0.00	{0.01 %}	199.99	Alterations by Lenze service only! Adaptation of the motor magnetising current set in C0095 (with V/f characteristic control: influence limit of the boost correction; with vector control: influence limit of the field precontrol) <ul style="list-style-type: none"> ● The output frequency is set up to which the motor magnetising current set in C0095 is to have an effect. ● C1583 = 100 % \triangleq half the rated motor frequency in C0089 	6.11-5

Commissioning	6
Optimising the operating behaviour	6.11
Motor magnetising current with vector control	6.11.4

Adjustment



Stop!

A longer operation of the motor in standstill may destroy the motor by overheating, especially in case of small motors.

- ▶ Connect the thermal contact (NC contact), PTC, or KTY of the motor and activate the motor temperature monitoring of the controller.
- ▶ Operate self-ventilated motors with a blower, if required.

Basic setting

1. Enter the motor data of the motor nameplate and execute the motor identification. (6.6-16)
2. For magnetising the motor, consider enough time. The motor is being magnetised between controller enable and motor start.
A delayed start of the motor can be achieved using e.g. the quick stop function:
 - Activate quick stop. Enable the controller and wait until the motor is magnetised sufficiently. Deactivate quick stop for the motor to start.
 The bigger the motor the longer the time for magnetisation. A motor with the power of 90 kW requires up to 2 s.
 If the desired continuous current does not flow, the magnetisation of the motor can be optimised using the codes C0080, C0095 and C1583.

Optimisation

3. If required, select a setpoint for the motor magnetising current in C0095.
 - The value in the Lenze setting has been evaluated by the controller from the entered motor data of the motor nameplate.
4. The influence, the setpoint of the motor magnetising current is to have, can be set in C0080.
 - A P controller which increases or reduces the setpoint can be parameterised via C0080.
 - Increase the value in C0080 step by step and observe the effect on the current injection with an oscilloscope, if required.
 - When C0080 = 0 the P controller is deactivated. No setpoint is selected for the motor magnetising current.
5. Set the adaptation of the setpoint for the motor magnetising current in C1583.




Fig. 6.11-4 Adaptation of the setpoint for the motor magnetising current

- Adaptation of the setpoint
 - Characteristic when C1583 = 100 % (Lenze setting). The output frequency corresponds to half the rated motor frequency in C0089.
 - - - - - Characteristic when C1583 = 199.99 %. The output frequency corresponds to the rated motor frequency in C0089.
- When C1583 = 0 % the adaptation is deactivated. No setpoint is selected for the motor magnetising current.

Select the output frequency in C1583, up to which the setpoint of the motor magnetising current is to have an effect.

- At an output frequency of 0 Hz the setpoint has the influence defined in C0080 and is 100 percent efficient. An increasing output frequency reduces the influence linearly to 0.

7 Parameter setting

Contents

7.1	Important notes	7.1-1
7.2	Parameter setting with the XT EMZ9371BC keypad	7.2-1
7.2.1	General data and operating conditions	7.2-1
7.2.2	Installation and commissioning	7.2-2
7.2.3	Display elements and function keys	7.2-2
7.2.4	Changing and saving parameters	7.2-4
7.2.5	Loading a parameter set	7.2-6
7.2.6	Transferring parameters to other standard devices	7.2-7
7.2.7	Activating password protection	7.2-9
7.2.8	Diagnostics	7.2-10
7.2.9	Menu structure	7.2-11

7.1 Important notes

Adapting the controller functions to the application

The controller functions can be adapted to your applications by means of parameterisation. You can either parameterise via keypad, PC or via the parameter channel of a bus system.

The function library contains a detailed description of the functions, the signal flow diagrams contain all configurable signals.

Parameters and codes

The parameters for the functions are stored in numbered codes:

- ▶ Codes are marked in the text with a "C" (e.g. C0002).
- ▶ The code table provides a quick overview of all codes. The codes are sorted according to their numbers and can be used as reference.
(8.5-1)

Parameter setting via keypad

A quick parameter setting is provided by the keypad XT. Moreover, it serves as status display, error diagnosis and transfer of parameters to other drive controllers.

	Keypad XT EMZ9371BC
Can be used with	8200 vector, 8200 motec, starttec, Drive PLC, 9300 vector, 9300 servo
Operator buttons	8
Plain text display	yes
Menu structure	yes
Configurable menu ("user menu")	yes
Predefined basic configurations	yes
Non-volatile memory for parameter transfer	yes
Password protection	yes
Diagnosis terminal	Keypad XT in handheld design, IP 20 (E82ZBBXC)
Installation in control cabinet	no
Type of protection	IP 20
Detailed description	7.2-1

Parameter setting via PC

You need the parameter setting / operating software »Global Drive Control« (GDC) or »Global Drive Control easy« (GDC easy) and an interface for communication:

- Interface for system bus (CAN) (preset in GDC):
 - PC system bus adapter
- Serial interface for LECOM:
 - Communication module LECOM-A/B (RS232/RS485)
EMF2102IB-V001

The parameter setting /operating software of the Global Drive Control family are easy-to-understand and tools for the operation, parameter setting and diagnostics or Lenze drive controllers.


	GDC easy ESP-GDC2-E	GDC ESP-GDC2
Supply	Free download from the internet at www.lenze.com	Program package must be charged for
Operation in interactive mode	yes	yes
Comprehensive help functions	yes	yes
Menu "Short setup"	yes	yes
Monitor windows for displaying operating parameters and for diagnostic purposes	yes	yes
Saving and printing of parameter settings as code list	yes	yes
Loading of parameter files from the controller to the PC	yes	yes
Storing of parameter files from the PC in the controller	yes	yes
Function block editor	no	yes
Technology functions for 9300 Servo	no	yes
Oscilloscope function for 9300 Servo and 9300 vector	no	yes
Detailed description	Online help of the program	Online help of the program

Parameter setting via bus system

Detailed information can be found in the documentation of the corresponding bus system.

7.2 Parameter setting with the XT EMZ9371BC keypad

7.2.1 General data and operating conditions



9371BC011

Feature	Values	
Dimensions		
Width	a	60 mm
Height	b	73.5 mm
Depth	c	15 mm
Environmental conditions		
Climate		
Storage	IEC/EN 60721-3-1	1K3 (-25 ... +60 °C)
Transport	IEC/EN 60721-3-2	2K3 (-25 ... +70 °C)
Operation	IEC/EN 60721-3-3	3K3 (-10 ... +60 °C)
Enclosure	IP 20	

Parameter setting

Parameter setting with the XT EMZ9371BC keypad

Installation and commissioning

7.2.2 Installation and commissioning




Fig. 7.2-1 Installation and commissioning of XT EMZ9371BC keypad or E82ZBBXC diagnosis terminal

- ① Connect keypad to the AIF interface on the front of the standard device.
The keypad can be connected/disconnected during operation.
- ② As soon as the keypad is supplied with voltage, it carries out a short self-test.
- ③ The operation level indicates when the keypad is ready for operation:
 - A** Current state of the standard device
 - B** Memory location 1 of the user menu (C0517):
Code number, subcode number, and current value
 - C** Active fault message or additional status message
 - D** Actual value in % of the status display defined in C0004
- ④ **PRG** must be pressed to leave the operation level

7.2.3

Display elements and function keys




Fig. 7.2-2 Display elements and function keys of the XT EMZ9371BC keypad

Parameter setting

7

Parameter setting with the XT EMZ9371BC keypad

7.2

Display elements and function keys

7.2.3

Displays

	Display	Meaning	Explanation
A Status displays of standard device			
	RDY	Ready for operation	
	IMP	Pulse inhibit is active	Power outputs are inhibited
	I _{max}	Set current limit is exceeded in motor or generator mode	
	M _{max}	Speed controller 1 in its limitation	Drive is torque-controlled (Only active for operation with standard devices of 9300 series)
	Fail	Active fault	
B Parameter acceptance			
	→	Parameter is accepted immediately	Standard device operates immediately with the new parameter value
	SHPRG →	Parameter must be confirmed with SHIFT PRG	Standard device operates with the new parameter value after being confirmed
	SHPRG	When the controller is inhibited the parameter must be confirmed with SHIFT PRG	Standard device operates with the new parameter value after the controller is re-enabled
	None	Display parameter	Change is not possible
C Active level			
	Menu	Menu level is active	Select main menu and submenus
	Code	Code level is active	Select codes and subcodes
	Para	Parameter level is active	Change parameters in the codes or subcodes
	None	Operating level is active	Display operating parameters
D Short text			
	Alphanumeric	Contents of the menus, meaning of the codes and parameters In the operating level C0004 (in %) and the active fault are displayed	
E Number			
	Menu level	With active level: Menu number	Only active for operation with standard devices of 8200 vector or 8200 motec series
	Code level	With active level: Four-digit code number	
F Number			
	Menu level	With active level: Submenu number	Only active for operation with standard devices of 8200 vector or 8200 motec series
	Code level	With active level: Two-digit subcode number	
G Parameter value			
		Parameter value with unit	
H Cursor			
			In the parameter level, the figure above the cursor can be changed directly
I Function keys			
			For description see the following table

Parameter setting

Parameter setting with the XT EMZ9371BC keypad

Changing and saving parameters

Function keys



Note!

Key combinations with **SHIFT**:

Press **SHIFT** and keep it pressed, then press the second key in addition.

Key	Function			
	Menu level	Code level	Parameter level	Operating level
PRG		Change to the parameter level	Change to the operating level	Change to the code level
SHIFT PRG	Load predefined configurations in the menu "Short setup" ¹⁾		Accept parameters when SHPRG ↴ or SHPRG is displayed	
▲ ▼	Change between menu items	Change of code number	Change of figure above cursor	
SHIFT ▲ SHIFT ▼	Quick change between the menu items	Quick change of code number	Quick change of figure above cursor	
► ◀	Change between main menu, submenus and code level		Cursor to the right Cursor to the left	
RUN	Cancel the function of STOP key, the LED in the key is off			
STOP	Inhibit controller, the LED in the key is lit Reset the fault (TRIP reset): 1. Remedy the cause of malfunction 2. Press STOP 3. Press RUN			

¹⁾ Only active for operation with standard devices of 8200 vector or 8200 motec series

7.2.4

Changing and saving parameters



Note!

Your settings have an effect on the current parameters in the main memory. You must save your settings in a parameter set so that they are not lost when the mains are connected.

If you only need one parameter set, save your settings as parameter set 1, since parameter set 1 is loaded automatically after mains connection.

Step	Key sequence	Action
1. Select the menu	▲ ▼ ► ◀	Use the arrow keys to select the desired menu
2. Change to the code level	►	Display of the first code in the menu
3. Select code or subcode	▼ ▲	Display of the current parameter value
4. Change to the parameter level	PRG	
5. When SHPRG is displayed, inhibit the controller	STOP ¹⁾	The drive coasts
6. Change parameter		
	A ► ◀	Move cursor below the figure to be changed
	B ▼ ▲	Change of figure

Step	Key sequence	Action
	SHIFT ▼ SHIFT ▲	Quick change of figure
7. Accept the changed parameter	Display of SHPRG or SHPRG → SHIFT PRG Display → -	Confirm change to accept the parameter Display "OK" The parameter has been accepted immediately
8. Enable the controller, if required	RUN 1)	The drive runs again
9. Change to the code level	A PRG B PRG	Display of the operating level Display of the code with changed parameter
10. Change further parameters		Restart the "loop" with step 1. or 3.
11. Save changed parameters	A ▲▼▶◀ B PRG C ▲ D SHIFT PRG	Select the code C0003 "PAR SAVE" in the menu "Load/Store" Change to the parameter level Display "0" and "READY" Select the parameter set in which the parameters are to be saved permanently Save as parameter set 1: ⇒ Set "1" "Save PS1" Save as parameter set 2: ⇒ Set "2" "Save PS2" Save as parameter set 3: ⇒ Set "3" "Save PS3" Save as parameter set 4: ⇒ Set "4" "Save PS4" When "OK" is displayed, the settings are permanently saved in the selected parameter set.
12. Change to the code level	A PRG B PRG	Display of the operating level Display of C0003 "PAR SAVE"
13. Set parameters for another parameter set		Restart the "loop" with step 1. or 3.

- 1) The function of the **STOP** key can be programmed:
 C0469 = 1: Controller inhibit
 C0469 = 2: Quick stop (Lenze setting)

Parameter setting

Parameter setting with the XT EMZ9371BC keypad

Loading a parameter set

7.2.5 Loading a parameter set

The keypad serves to load a saved parameter set into the main memory when the controller is inhibited. After the controller is enabled, it operates with the new parameters.



Danger!

- ▶ When a new parameter set is loaded, the controller is reinitialised and acts as if it had been connected to the mains:
 - System configurations and terminal assignments can be changed. Make sure that your wiring and drive configuration comply with the settings of the parameter set.
- ▶ Only use terminal X5/28 as source for the controller inhibit! Otherwise the drive may start in an uncontrolled way when switching over to another parameter set.



Note!

- ▶ After switching on the supply voltage, the controller always loads parameter set 1 into the main memory.
- ▶ It is also possible to load other parameter sets into the main memory via the digital inputs or bus commands.

Step	Key sequence	Action
1. Inhibit controller		Terminal X5/28 = LOW
2. Load the saved parameter set into the main memory		
	A	Select the code C0002 "PAR LOAD" in the menu "Load/Store"
	B	Change to the parameter level The active parameter set is displayed, e. g. display "0" and "Load Default" If you want to restore the delivery status, proceed with D
Select the parameter set to be loaded	C	Load parameter set 1: ⇒ Set "1" "Load PS1" Load parameter set 2: ⇒ Set "2" "Load PS2" Load parameter set 3: ⇒ Set "3" "Load PS3" Load parameter set 4: ⇒ Set "4" "Load PS4"
	D	"RDY" goes off. The parameter set is loaded completely into the main memory if "RDY" is displayed again.
3. Change to the code level		
	A	Display of the operating level
	B	Display of C0002 "PAR LOAD"
4. Enable controller		Terminal X5/28 = HIGH The drive is running with the settings of the loaded parameter set

Parameter setting	7
Parameter setting with the XT EMZ9371BC keypad	7.2
Transferring parameters to other standard devices	7.2.6

7.2.6 Transferring parameters to other standard devices

The keypad enables you to copy parameter settings from one standard device to another.

For this purpose use the "Load/Store" menu:



Danger!

During the transfer of the parameters from the keypad to the controller, the control terminals may adopt undefined states!

Therefore be absolutely sure to disconnect the connectors X5 and X6 from the controller prior to the transfer. Like this you will ensure that the drive controller is inhibited and all control terminals are in the defined "LOW" state.

Copying parameter sets from the standard device to the keypad



Note!

After the parameter sets are copied to the keypad XT (C0003 = 11), the parameter set last loaded using C0002 is always activated.

So the actual parameters remain active also after copying:

- Prior to copying, save the actual parameters in the parameter set and load this parameter set into the drive controller using C0002.

Step	Key sequence	Action
1. Connect keypad to controller 1		
2. Inhibit controller		Terminal X5/28 = LOW The drive coasts.
3. On the "Load/Store" menu select C0003	Ⓐ Ⓛ Ⓜ Ⓝ	On the "Load/Store" menu select code C0003 "PAR SAVE" using the arrow keys.
4. Change to the parameter level	PRG	Display "0" and "READY"
5. Copy all parameter sets to the keypad		The settings stored in the keypad are overwritten. Ⓐ Set "11" "Save extern"
6. Start copying	SHIFT PRG	The "RDY" status display goes off. "BUSY" is indicated as parameter value. When "BUSY" goes off after approx. one minute, all parameter sets have been copied to the keypad. The "RDY" status display illuminates.
7. Change to the code level	A PRG B PRG	Display of the operating level Display of C0003 and "PAR SAVE"
8. Enable controller		Terminal X5/28 = HIGH
9. Remove keypad from controller 1		

Copying parameter sets from the keypad to the standard device

Step	Key sequence	Action
1. Connect keypad to controller 2		
2. Inhibit controller		Terminal X5/28 = LOW The "IMP" status display illuminates. The drive coasts
3. Disconnect connectors X5 and X6		All control terminals have the defined "LOW" state.
4. On the "Load/Store" menu select C0002	Ⓐ Ⓛ Ⓜ Ⓝ	On the "Load/Store" menu select code C0002 "PAR LOAD" using the arrow keys.
5. Change to the parameter level	PRG	The active parameter set is displayed, e. g. display "0" and "Load Default"
6. Select the correct copy function		The settings stored in the controller are overwritten.
	●	The parameters are not yet active after copying. Select parameter set and load into main memory. 7.2-6
	●	Set "20" "ext -> EEPROM"
	●	Copy parameter set 1: ⇒ Set "11" "Load ext PS1"
		Copy parameter set 2: ⇒ Set "12" "Load ext PS2"
		Copy parameter set 3: ⇒ Set "13" "Load ext PS3"
		Copy parameter set 4: ⇒ Set "14" "Load ext PS4"
7. Start copying	SHIFT PRG	The "RDY" status display goes off. "BUSY" is indicated as parameter value. When "BUSY" goes off, all selected parameter sets have been copied to the controller. The "RDY" status display illuminates.
8. Change to the code level	A PRG	Display of the operating level
	B PRG	Display of C0002 and "PAR LOAD"
9. Save individually copied parameter sets in non-volatile memory	Ⓐ Ⓛ Ⓜ Ⓝ	On the "Load/Store" menu select code C0003 "PAR SAVE" using arrow keys and save contents of the main memory in non-volatile memory.
10. Connect connectors X5 and X6		
11. Enable controller		Terminal X5/28 = HIGH The drive runs with the new settings.

7.2.7 Activating password protection



Note!

- If the password protection is activated (C0094 = 1 ... 9999), you only have free access to the user menu.
- To access the other menus, you must enter the password. By this, the password protection is annulled until you enter a new password.
- Please observe that the password-protected parameters can be overwritten as well when transferring the parameter sets to other standard devices. The password is not transferred.
- Do not forget your password! If you have forgotten your password, it can only be reset via a PC or a bus system!

Activate password protection

Step	Key sequence	Action
1. Select the "USER menu"	▲ □ ▶ ▷	Change to the user menu using the arrow keys
2. Change to the code level	▶	Display of code C0051 "MCTRL-NACT"
3. Select C0094	▲	Display of code C0094 "Password"
4. Change to the parameter level	PRG	Display "0" = no password protection
5. Set password		
	A ▲	Select password (1 ... 9999)
	B SHIFT PRG	Confirm password
6. Change to the code level		
	A PRG	Display of the operating level
	B PRG	Display of C0094 and "Password"
7. Change to the "USER menu"	□ ▶ ▷	

The password protection is active now.

You can only quit the user menu if you re-enter the password and confirm it with SHIFT PRG.

Remove password protection

Step	Key sequence	Action
1. Change to the code level in the user menu	▶	
2. Select C0094	▲	Display of code C0094 "Password"
3. Change to the parameter level	PRG	Display "9999" = password protection is active
4. Enter password		
	A ▽	Set valid password
	B SHIFT PRG	Confirm The password protection is deactivated by entering the password once again.
5. Change to the code level		
	A PRG	Display of the operating level
	B PRG	Display of C0094 and "Password"

The password protection is deactivated now. All menus can be freely accessed again.

Parameter setting

Parameter setting with the XT EMZ9371BC keypad

Diagnostics

7.2.8 Diagnostics

In the "Diagnostic" menu the two submenus "Actual info" and "History" contain all codes for

- monitoring the drive
- fault/error diagnosis

In the operating level, more status messages are displayed. If several status messages are active, the message with the highest priority is displayed.

Priority	Display	Meaning	
1	GLOBAL DRIVE INIT	Initialisation or communication error between keypad and controller	
2	XXX - TRIP	Active TRIP (contents of C0168/1)	
3	XXX - MESSAGE	Active message (contents of C0168/1)	
4	Special device states:	Switch-on inhibit	
5	Source for controller inhibit (the value of C0004 is displayed simultaneously):		
	STP1	9300 servo: ECSxS/P/M/A:	Terminal X5/28 Terminal X6/SI1
	STP3	Operating module or LECOM A/B/LI	
	STP4	INTERBUS or PROFIBUS-DP	
	STP5	9300 servo, ECSxA/E:	System bus (CAN)
		ECSxS/P/M:	MotionBus (CAN)
	STP6	C0040	
6	Source for quick stop (QSP):		
	QSP-term-Ext	The MCTRL-QSP input of the MCTRL function block is on HIGH signal.	
	QSP-C0135	Operating module or LECOM A/B/LI	
	QSP-AIF	INTERBUS or PROFIBUS-DP	
	QSP-CAN	9300 servo, ECSxA:	System bus (CAN)
		ECSxS/P/M:	MotionBus (CAN)
7	XXX - WARNING	Active warning (contents of C0168/1)	
8	xxxx	Value below C0004	

7.2.9 Menu structure

For simple, user-friendly operation, the codes are clearly arranged in function-related menus:

Main menu	Submenus	Description
Display	Display	
User-Menu		Codes defined in C0517
Code list		All available codes
	ALL	All available codes listed in ascending order (C0001 ... C7999)
	PS 1	Codes in parameter set 1 (C0001 ... C1999)
	PS 2	Codes in parameter set 2 (C2001 ... C3999)
	PS 3	Codes in parameter set 3 (C4001 ... C5999)
	PS 4	Codes in parameter set 4 (C6001 ... C7999)
Load/Store		Parameter set management Parameter set transfer, restore delivery status
Diagnostic		Diagnostic
	Actual info	Display codes to monitor the drive
	History	Fault analysis with history buffer
Short setup		Quick configuration of predefined applications Configuration of the user menu The predefined applications depend on the type of the standard device (frequency inverter, servo inverter, position controller, ...)
Main FB		Configuration of the main function blocks
	NSET	Setpoint processing
	NSET-JOG	Fixed setpoints
	NSET-RAMP1	Ramp function generator
	MCTRL	Motor control
	DFSET	Digital frequency processing
	DCTRL	Internal control
Terminal I/O		Connection of inputs and outputs with internal signals
	AIN1 X6.1/2	Analog input 1
	AIN2 X6.3/4	Analog input 2
	AOUT1 X6.62	Analog output 1
	AOUT2 X6.63	Analog output 2
	DIGIN	Digital inputs
	DIGOUT	Digital outputs
	DFIN	Digital frequency input
	DFOUT	Digital frequency output
	State bus	State bus (not with 9300 frequency inverter)
Controller		Configuration of internal control parameters
	Speed	Speed controller
	Current	Current controller or torque controller
	Phase	Phase controller (not with 9300 frequency inverter)
Motor/Feedb.		Input of motor data, configuration of speed feedback
	Motor adj	Motor data
	Feedback	Configuration of feedback systems
Monitoring		Configuration of monitoring functions

Parameter setting

Parameter setting with the XT EMZ9371BC keypad

Menu structure

Main menu	Submenus	Description
Display	Display	
LECOM/AIF		Configuration of operation with communication modules
	LECOM A/B	Serial interface
	AIF interface	Process data
	Status word	Display of status words
System bus		Configuration of system bus (CAN)
	Management	CAN communication parameters
	CAN-IN1	CAN object 1
	CAN-OUT1	
	CAN-IN2	CAN object 2
	CAN-OUT2	
	CAN-IN3	CAN object 3
	CAN-OUT3	
	Status word	Display of status words
	FDO	Free digital outputs
FB config		Configuration of function blocks
Func blocks		Parameterisation of function blocks
		The submenus contain all available function blocks
FCODE		Configuration of free codes
Identify		Identification
	Drive	Software version of standard device
	Op Keypad	Software version of keypad

8**Configuration****Contents**

8.1	Important notes	8.1-1
8.2	Function blocks	8.2-1
8.2.1	Diameter calculator (DCALC)	8.2-1
8.2.2	Master frequency input (DFIN)	8.2-5
8.2.3	Master frequency output (DFOUT)	8.2-8
8.2.4	Master frequency ramp-function generator (DFRG)	8.2-13
8.2.5	Master frequency processing (DFSET)	8.2-18
8.2.6	Internal motor control with V/f characteristic control (MCTRL1)	8.2-25
8.2.7	Internal motor control with vector control (MCTRL2)	8.2-40
8.3	Monitoring	8.3-1
8.3.1	Responses	8.3-1
8.3.2	Monitoring times for process data input objects	8.3-2
8.3.3	Maximum speed	8.3-3
8.3.4	Motor	8.3-3
8.3.5	Controller current load ($I \times t$ monitoring)	8.3-4
8.3.6	Motor temperature	8.3-5
8.3.7	Heatsink temperature	8.3-5
8.3.8	DC-bus voltage	8.3-6
8.3.9	External error (EEr)	8.3-6
8.4	Overview of monitoring functions	8.4-1
8.5	Code table	8.5-1
8.6	Selection lists	8.6-1
8.6.1	Selection list 1: Analog output signals	8.6-1
8.6.2	Selection list 2: Digital output signals	8.6-3
8.6.3	Selection list 3: Angle signals	8.6-6
8.6.4	Selection list 4: Speed signals	8.6-6
8.6.5	Selection list 5: Function blocks	8.6-7
8.7	Table of attributes	8.7-1

8.1 **Important notes**

The "Configuration" chapter consists of two parts.

System Manual

The "Configuration" chapter in the System Manual contains the following:

- ▶ Monitoring
- ▶ Monitoring functions
- ▶ Description of the following function blocks:
 - Diameter calculator (DCALC)
 - Digital frequency input (DFIN)
 - Digital frequency output (DFOUT)
 - Digital frequency ramp function generator (DFRFG)
 - Digital frequency processing (DFSET)
 - Internal motor control with V/f characteristic control (MCTRL1)
 - Internal motor control with vector control (MCTRL2)
- ▶ Code table
- ▶ Selection lists
- ▶ Table of attributes

System Manual (extension)

The "Configuration" chapter in the System Manual (extension) contains the following:

- ▶ Notes on the configuration with Global Drive Control
- ▶ Description of the basic configuration
- ▶ Use of function blocks
- ▶ Description of the other function blocks for the 9300 vector frequency inverter

Configuration	8
Function blocks	8.2
Diameter calculator (DCALC)	8.2.1

8.2 Function blocks

8.2.1 Diameter calculator (DCALC)

Description

The function block calculates the current reel diameter in winding drives.




Fig. 8.2-1 Diameter calculator (DCALC1)

Codes for parameter setting

Code		Possible settings				IMPORTANT
No.	Name	Lenze	Selection			
C1300 STOP	N-motor/ Dmax	300	-32767	{1 rpm}	32767	Motor speed at D _{max} , function block DCALC1 ● Nominal speed of the winding drive
C1301 STOP	N-line max	3000	1	{1 rpm}	32767	Maximum line speed, function block DCALC1 ● Nominal speed of the line drive
C1302	calc cycle	0.1	0.1	{0.1 rev}	100.0	Calculation cycle, function block DCALC1
C1303	time const	0.10	0.01	{0.01 s}	50.00	Filter time constant, function block DCALC1
C1304 STOP	Dmax	500	1	{1 mm}	10000	Maximum diameter, function block DCALC1 ● Nominal winding diameter
C1305	lower D-limit	50	1	{1 mm}	10000	Lower diameter limit, function block DCALC1 ● Minimum winding diameter
C1306	upper D-limit	500	1	{1 mm}	10000	Upper diameter limit, function block DCALC1 ● Maximum winding diameter
C1307	hyst D-limit	1.00	0.00	{0.01 %}	100.0	Hysteresis - diameter limitation, function block DCALC1 ● Hysteresis for D _{min} / D _{max} output
C1308 STOP	arit function	1	0	DCALC1-OUT=D	DCALC1-OUT = diameter	Selection of the arithmetic function, function block DCALC1
				1	DCALC1-OUT=1/D	

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C1309 STOP	Dmin	50	1	{1 mm}	10000	Minimum diameter, function block DCALC1	8.2-1
C1310	DCALC1-Titime	0.000	0.000	{0.001 s}	999.900	Acceleration and deceleration time, function block DCALC1	
C1311	window D-calc	1.00	0.00	{0.01 %}	100.00	Window - diameter calculation, function block DCALC1 ● Window setting for permissible diameter deviation	
C1320 STOP	CFG: SET	1000	FIXED0%		■ Selection list 1	Configuration of analog input signal, function block DCALC1 ● The signal is scaled to the value in C1304 (100 % \triangleq C1304)	8.2-1
C1321 STOP					■ Selection list 2	Configuration of digital input signals, function block DCALC1	
1	CFG: LOAD	1000	FIXED0			● HIGH: initial value at DCALC1-SET is accepted ● DCALC1-LOAD has a higher priority than DCALC1-HOLD	
2	CFG: HOLD	1000	FIXED0			● HIGH = holds the diameter value reached and resets the integrators.	
C1322		-36000	{1 rpm}	36000		Function block DCALC1 ● Display of the signals linked in C1327	8.2-1
1	DIS: N-Line						
2	DIS: N-WIND						
C1325	DIS: SET	-199,99	{0.01 %}	199,99		Function block DCALC1 ● Display of the signal linked in C1320	
C1326		0		1		Function block DCALC1 ● Display of the signals linked in C1321	
1	DIS: LOAD						
2	DIS: HOLD						
C1327 STOP				■ Selection list 3		Configuration of input signals, function block DCALC1	8.2-1
1	CFG: N-Line	1000	FIXED0INC			● Speed signal of the line drive	
2	CFG: N-WIND	1000	FIXED0INC			● Speed signal of the winding drive	
C1328	DIS: D-ACT	-200	{1 mm}	200		Function block DCALC1 ● Display of the current diameter	

Setting the initial value

The signal at DCALC1-Set is set as initial value.

- With DCALC1-LOAD = 1 the initial value is accepted.
- The initial value is accepted unfiltered.

Configuration	8
Function blocks	8.2
Diameter calculator (DCALC)	8.2.1

Calculating the diameter	By division of the speed signals at DCALC1-N-LINE and DCALC1-N-WIND, the current diameter is calculated.
	<ul style="list-style-type: none"> ▶ The signal at DCALC1-N-LINE has to correspond to the circumferential speed of the reel. ▶ The signal at DCALC1-N-WIND has to be proportional to the reel speed. ▶ You have to adapt the signal at DCALC1-N-LINE in C1300 and C1301, so that the value calculated corresponds to the actual diameter. The nominal reel diameter d_{max} is entered in C1304. <ul style="list-style-type: none"> – For operation with the nominal reel diameter d_{max} you have to enter the value at input DCALC1-N-WIND in C1300 and the value at input DCALC1-N-LINE in C1301. ▶ The input signals are integrated cyclically. In C1302 you alter the integration interval (calculation cycle): <ul style="list-style-type: none"> Great value in C1302 \Rightarrow high resolution Low value in C1302 \Rightarrow low resolution ▶ If the integrator overflows, DCALC1-OVFL is set to HIGH. The integrator is reset internally and starts again with the calculation of the last correct value. ▶ A first-order low pass filters the values calculated. The filter time constant is set via C1303.
Displaying the diameter	In C1328 the current diameter is displayed.
	<ul style="list-style-type: none"> ▶ For the conversion of the scaled calculated value to the absolute value [mm], the reference diameter d_{max} has to be entered via C1304. ▶ At DCALC1-D-OUT the current diameter is output. The signal is scaled to the value in C1304.
Maintaining/saving the current value	With DCALC1-HOLD = HIGH the last diameter value calculated is maintained and the integrators are reset.
	<ul style="list-style-type: none"> ▶ When the controller is switched off, the current diameter value is saved. When it is switched on, the last value saved is loaded.
Setting/displaying the diameter	<p>In C1305 the minimum diameter (d_{min}) in [mm] is entered. d_{min} is reached when DCALC1-DMIN switches to HIGH.</p> <p>In C1306 the maximum diameter (d_{max}) in [mm] is entered. d_{max} is reached when DCALC1-DMAX switches to HIGH.</p> <p>In C1307 a hysteresis for resetting the display signal is set. The entry in [%] relates to the absolute values in C1305 and C1306.</p>

Converting the diameter (d) to 1/d

In configurations with a speed forward control it is common to multiply the precontrol signal with the reciprocal value of the diameter (d). This value is output at DCALC1-OUT.

- C1308 = 0: DCALC1-OUT = d
- C1308 = 1: DCALC1-OUT = 1/d

For the conversion to 1/d the reference value for the diameter has to be defined in C1309, for which the signal at DCALC1-OUT is to be 100 %.

- Normally C1309 corresponds to the minimum diameter in C1305 (d_{\min}).

In order to ensure a continuous transition when setting new diameter values, a ramp function generator is activated if C1310 > 0 s.

Web break monitoring

A window comparator compares the corresponding newly calculated value to the value last filtered.

- In C1311 the maximum difference in [%] between the two values is defined.
- DCALC1-I=0 is set to LOW if the maximum difference is exceeded.

Formulas for calculation**Current diameter (C1328)**

$$C1328 \text{ [mm]} = \frac{\text{DCALC1-N-LINE [inc]}}{\text{DCALC1-N-WIND [inc]}} \cdot \frac{\text{C1300 [rpm]}}{\text{C1301 [rpm]}} \cdot \text{C1304 [mm]}$$

Output signal at DCALC1-OUT

For C1308 = 0 (DCALC1-OUT = d):

$$\text{DCALC1-OUT [%]} = \frac{C1328 \text{ [mm]}}{C1304 \text{ [mm]}} \cdot 100 \%$$

For C1308 = 1 (DCALC1-OUT = 1/d):

$$\text{DCALC1-OUT [%]} = \frac{C1304 \text{ [mm]}}{C1328 \text{ [mm]}} \cdot \frac{C1309 \text{ [mm]}}{C1304 \text{ [mm]}} \cdot 100 \%$$

**Note!**

The value at DCALC1-OUT is limited by the maximum reel diameter (C1306) and the minimum reel diameter (C1305).

Configuration	8
Function blocks	8.2
Master frequency input (DFIN)	8.2.2

8.2.2 Master frequency input (DFIN)

Description

The function block calculates a speed signal from the rectangular signals at X9. TTL signals and HTL signals can be connected. The zero track can be selected as an option.

The edge changes are detected every 1 ms and result directly in the output value.




Fig. 8.2-2 Digital frequency input (DFIN)

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0425	DFIN const	3	0	256 inc/rev	Constant of the master frequency input, function block DFIN ● Output signal at the connected encoder or at the upstream controller in the event of a master frequency cascade/master frequency bus	8.2-5
			1	512 inc/rev		
			2	1024 inc/rev		
			3	2048 inc/rev		
			4	4096 inc/rev		
			5	8192 inc/rev		
			6	16384 inc/rev		
C0426	DIS: OUT		-36000	{1 rpm}	36000	Output signal of the master frequency input, function block DFIN ● Display only
C0427	DFIN function	0				Function of the master frequency input, function block DFIN
			0	2-phase		● Phase-displaced signal sequence
			1	A pulse/B dir		● Control of direction of rotation via track B
			2	Pulse A or B		● Control of speed and direction of rotation via track A or track B

Evaluating input signals

In C0427 the different modes for the evaluation of the input signals can be selected.


C0427 = 0 (phase-displaced signal sequence)

Fig. 8.2-3 Phase-displaced signal sequence (CW rotation)

Clockwise Track A leads track B by 90 ° (positive value at DFIN-OUT)
 rotation

Counter-clock Track A lags track B by 90 ° (negative value at DFIN-OUT)
 wise rotation


C0427 = 1 (control of the direction of rotation via track B)

Fig. 8.2-4 Control of direction of rotation via track B

Clockwise Track A transmits the speed
 rotation Track B = LOW (positive value at DFIN-OUT)

Counter-clock Track A transmits the speed
 wise rotation Track B = HIGH (negative value at DFIN-OUT)


C0427 = 2 (control of speed and direction of rotation via track A or track B)

Fig. 8.2-5 Control of speed and direction of rotation via track A or track B

Clockwise Track A transmits the speed and direction of rotation (positive
 rotation value at DFIN-OUT)
 Track B = LOW

Counter-clock Track B transmits the speed and direction of rotation (negative
 wise rotation value at DFIN-OUT)
 Track A = LOW

Configuration	8
Function blocks	8.2
Master frequency input (DFIN)	8.2.2

Adjusting the output signal

In C0425 the output signal can be adapted:

- To the encoder at X9 or
- To the upstream controller with master frequency cascade/master frequency bus.

Transfer function

Calculating the output signal:

$$\text{DFIN-OUT [rpm]} = f [\text{Hz}] \cdot \frac{60}{C0425}$$

Example:

The input frequency amounts to 200 kHz, the number of increments corresponds to 2048 inc/rev. (C0425 = 3).

$$\text{DFIN-OUT [rpm]} = 200000 \text{ Hz} \cdot \frac{60}{2048} = 5859 \text{ rpm}$$

Signal adaptation

Signal adaptations other than by squaring in C0425 can be achieved by connecting a function block.

Example:

The function block CONV3 shall convert the speed signal into a quasi analog signal.

Calculating the output signal at CONV3:

$$\text{CONV3-OUT [%]} = f [\text{Hz}] \cdot \frac{0.4}{C0425} \cdot \frac{C0950}{C0951}$$

Interconnecting function blocks:




Fig. 8.2-6 Digital frequency input (DFIN) with connected converter



Note!

If a master frequency is output to DFOUT-AN-IN or DFOUT-DF (C0540 = 0 or C0540 = 1) and an incremental encoder is evaluated via X8, the function block DFIN cannot be used anymore.

If the input signals at X8 or X9 are output to X10, (C0540 = 4 or C0540 = 5), this restriction does not exist.

8.2.3 Master frequency output (DFOUT)**Description**

The function block creates rectangular signals from an analog signal or speed signal, which are output via X10. Alternatively, you can set the master frequency output to a signal output at X8 or X9.




Fig. 8.2-7 Digital frequency output (DFOUT)

Codes for parameter setting

Code		Possible settings		IMPORTANT	8.2-8
No.	Name	Lenze	Selection		
C0030	DFOUT const	3	0 256 inc/rev 1 512 inc/rev 2 1024 inc/rev 3 2048 inc/rev 4 4096 inc/rev 5 8192 inc/rev 6 16384 inc/rev	Function block DFOUT • Setting of the constant (increments per revolution) for the master frequency output X10	

Configuration	8
Function blocks	8.2
Master frequency output (DFOUT)	8.2.3

Code		Possible settings			IMPORTANT
No.	Name	Lenze	Selection		
C0540 <small>STOP</small>	Function	0			Function selection, function block DFOUT ● Output signal at X10
			0 Analog input	Analog input	Signal at DFOUT-AN-IN is output. Zero track can be input externally.
			1 PH diff input	Phase difference input	Signal at DFOUT-DF-IN is output. Zero track can be input externally.
			2	Not assigned	
			3	Not assigned	
			4 X10 = X9	X9 is output on X10	The input signals are buffered C0030 is without function
C0541 <small>STOP</small>	CFG: AN-IN	5001	MCTRL-NACT	 Selection list 1	Configuration of analog input signal, function block DFOUT ● Signal in [%] of C0011
C0542 <small>STOP</small>	CFG: DF-IN	1000	FIXEDPHI-0	 Selection list 4	Configuration of input signal, function block DFOUT ● Speed signal
C0544 <small>STOP</small>	CFG: SYN-RDY	1000	FIXED0	 Selection list 2	Configuration of digital input signal, function block DFOUT ● DFOUT-SYN-RDY = HIGH: Generating a zero pulse
C0545	PH offset	0	0 {1 inc.}	65535	Phase offset, function block DFOUT ● Displacing the zero pulse generated via DFOUT-SYN-RDY by up to 360 ° ● 1 rev. = 65535 inc (360 °)


Output signals at X10

Fig. 8.2-8 Signal sequence for CW rotation (definition)

- The output signals correspond to the simulation of an incremental encoder:

- Track A and track B and, if required, the zero track and the corresponding inverted tracks are output. The levels are TTL-compatible.
- Positive input values (CW rotation) result in the represented signal sequence.

- With negative input values (CCW rotation) track B leads track A by 90 °.

- The encoder constant of the encoder simulation is set in C0030.

C0540 serves to define which input signal or signal source shall be active. The zero track is output according to the selected setting.

C0540	Signal at X10
0	DFOUT-AN-IN is output to X10. Zero track can be selected externally.
1	DFOUT-DF-IN is output to X10. Zero track can be selected externally.
2	No function
3	No function
4	The signal at input X9 is electrically amplified and directly output (C0030 is without function)
5	The signal at input X8 is electrically amplified and directly output (C0030 is without function)

**Note!**

The settings C0540 = 0 and C0540 = 1 are not possible when a connection to the master frequency input X9 (DFIN) was established and an incremental encoder was connected via X8 (C0025 = 100, 110 ... 113).

Configuration	8
Function blocks	8.2
Master frequency output (DFOUT)	8.2.3

Output of analog signal as frequency

Setting: C0540 = 0

- The analog signal at the input DFOUT-AN-IN is converted into a frequency and output to X10.
- Frequency calculation:

$$f [\text{Hz}] = \text{DFOUT-AN-IN} [\%] \cdot \frac{\text{C0030}}{100} \cdot \frac{\text{C0011}}{60}$$

Example:

The input signal at DFOUT-AN-IN amounts to 50 %, the number of increments corresponds to 2048 inc/rev. (C0030 = 3) and the maximum speed (C0011) is set to 3000 rpm.

$$f [\text{Hz}] = 50 \% \cdot \frac{2048}{100} \cdot \frac{3000}{60} = 51200 \text{ Hz}$$

Generating an index pulse

An artificial index signal can be generated for the output frequency.

1. Set the input DFOUT-SYN-RDY = HIGH.
 - 360° later, a LOW-HIGH edge generates the index pulse.
 - Then a zero pulse is generated every 360 ° according to C0030.
2. If necessary, shift the zero pulse by up to 360 ° (65536 inc = 360 °) via C0545.

Output of the speed signal as frequency

Setting: C0540 = 1

- The speed signal at the input DFOUT-DF-IN is converted into a frequency and output to X10.
- Frequency calculation:

$$f [\text{Hz}] = \text{DFOUT-DF-IN} [\text{rpm}] \cdot \frac{\text{C0030}}{60}$$

Example:

The input signal at DFOUT-DF-IN amounts to 3000 rpm, the number of increments corresponds to 2048 inc/revolution (C0030 = 3).

$$f [\text{Hz}] = 3000 \text{ rpm} \cdot \frac{2048}{60} = 102400 \text{ Hz}$$

Generating a zero pulse

An artificial zero pulse can be generated for the output frequency.

1. Set the input DFOUT-SYN-RDY = HIGH.
 - 360° later, a LOW-HIGH edge generates the zero pulse.
 - Then a zero pulse is generated every 360 ° according to C0030.
2. If necessary, shift the zero pulse by up to 360 ° (65536 inc = 360 °) via C0545.

**Signal at X8 is directly output
at X10**

- ▶ The input signals at X8 are amplified electrically and output directly.
- ▶ The signals depend on the assignment of the input X8.
- ▶ The codes C0030, C0545 and the output DFOUT-OUT have no function.
- ▶ The zero track is only output if it is connected to X8.

**Signal at X9 is directly output
at X10**

- ▶ The input signals at X9 are amplified electrically and output directly.
- ▶ The signals depend on the assignment of the input X9.
- ▶ The codes C0030, C0545 and the output DFOUT-OUT have no function.
- ▶ The zero track is output if it is connected to X9.

Configuration	8
Function blocks	8.2
Master frequency ramp-function generator (DFRFG)	8.2.4

8.2.4 Master frequency ramp-function generator (DFRFG)

Description

The function block creates acceleration and deceleration ramps for the operation with master frequency, thus leading the drive to the master frequency with angular synchronism.




Fig. 8.2-9 Digital frequency ramp function generator (DFRFG1)

Codes for parameter setting

Code		Possible settings				IMPORTANT
No.	Name	Lenze	Selection			
C0751	DFRFG1 Tir	1.000	0.001	{0.001 s}	999.999	Acceleration time T_{ir} , function block DFRFG1 8.2-13
C0752	Max speed	3000	1	{1 rpm}	16000	Maximum speed, function block DFRFG1 <ul style="list-style-type: none"> • Maximum speed-up (speed)
C0753	DFRFG1 QSP	0.000	0.000	{0.001 s}	999.900	Deceleration time T_{if} for quick stop, function block DFRFG1
C0754	PH error	$2 \cdot 10^9$	10	{1}	$2 \cdot 10^9$	Following error, function block DFRFG1 <ul style="list-style-type: none"> • Maximum permissible phase difference between setpoint and actual phase • 1 rev. = 65535 inc
C0755	Syn window	100	0	{1 inc.}	65535	Synchronisation window, function block DFRFG1 <ul style="list-style-type: none"> • 1 rev. = 65535 inc

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0758 STOP	CFG: IN	1000	FIXEDPHI-0	□ Selection list 4	Configuration of input signal, function block DFRFG1 ● Speed/phase setpoint signal	□ 8.2-13
C0759 STOP	CFG: QSP	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block DFRFG1 ● HIGH = quick stop active	
C0760 STOP	CFG: STOP	1000	FIXED0	□ Selection list 2	Configuration of input signal, function block DFRFG1 ● HIGH = Status of the profile generator is maintained, setpoint is saved	
C0761 STOP	CFG: RESET	1000	FIXED0	□ Selection list 2	Configuration of input signal, function block DFRFG1 ● HIGH = resetting the integrators	
C0764		0		1	Function block DFRFG1 ● Display of the signals linked in C0759, C0760 and C0761	
1 DIS: QSP						
2 DIS: STOP						
3 DIS: RESET						
C0765	DIS: IN		-32767 {1 rpm}	32767	Function block DFRFG1 ● Display of the signal linked in C0758	

Configuration	8
Function blocks	8.2
Master frequency ramp-function generator (DFRFG)	8.2.4

Profile generator



Stop!

Do not operate the drive with this function at the torque limitation M_{max} , I_{max} .

The profile generator creates ramps which automatically compensate the resulting phase displacement. If you do not need this compensation, set DFRFG-RESET = HIGH.




Fig. 8.2-10 Synchronisation on DFRFG

- C0751 Setting the deceleration and acceleration time
- C0752 Setting the maximum speed
- C0755 Setting the switching point

When the actual angle has reached its setpoint and the output signal corresponds to the input signal, the drive runs in synchronism and the output DFRG1-SYNC is set to HIGH. At the same time the profile generator is switched to the inactive state.




Fig. 8.2-11 Speed-time diagram DFRFG

The number of increments at DFRG1-IN (master drive) defines the set phase. The set phase can be displayed as a path. The speed-time diagram shows the distance covered (angle) as the area below the speed profile. When synchronisation is reached, master and slave have covered the same distance (phase).

Quick stop (QSP)

Quick stop takes the drive out of the system and brings it to standstill. Setpoints and actual values are continued to be detected.




Fig. 8.2-12 Quick stop DFRFG

C0751 Acceleration and deceleration time of the profile generator
 C0752 Maximum speed
 C0753 Setting the deceleration time T_{if} for QSP

- QSP is activated using DFRG1-QSP = HIGH.
- With DFRG1-QSP = LOW, QSP is deactivated. The setpoint is approached via the profile generator.

Ramp function generator stop

The function "ramp-function generator stop" keeps the state of the profile generator during operation. Setpoints and actual values are continued to be detected.




Fig. 8.2-13 Ramp function generator stop

C0752 Maximum speed

- The function "ramp-function generator stop" is activated with DFRG1-STOP = HIGH.
 - The last status is output at DFRG1-OUT.
- With DFRG1-STOP = LOW the function "ramp-function generator stop" is reset. The setpoint is approached via the profile generator.
- With DFRG1-RESET = HIGH, the profile generator is activated. Internally added-up set phases and actual phases are reset.
- The set phase is detected using a HIGH-LOW signal at DFRG1-RESET.

Reset ramp generator

Configuration	8
Function blocks	8.2
Master frequency ramp-function generator (DFRFG)	8.2.4

Monitoring the phase difference

The profile generator can accept a phase difference between the set phase and the actual phase of up to ± 2140000000 inc (= 32000 revolutions).

- ▶ A limit value can be set for the permissible phase difference via C0754.
- ▶ If the limit value is reached, DFRG1-FAIL is set to HIGH and the value is saved.
- ▶ DFRG1-FAIL is only set to LOW with DFRG1-RESET = HIGH.

8.2.5 Master frequency processing (DFSET)

Description

The function block prepares the master frequency for the controller. You can select values for the stretching and gearbox factor and carry out a speed or phase trimming.




Fig. 8.2-14 Digital frequency processing (DFSET)

Codes for parameter setting

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0033	Gearbox denom	1	1	{1}	32767	Gearbox factor - denominator of the function block DFSET	8.2-18
C0252	Angle offset	0	-245760000	{1 inc.}	245760000	Phase offset for master frequency processing, function block DFSET • Fixed phase offset for digital frequency configuration • 1 rev. = 65536 inc	8.2-18
C0253	Angle n-trim	→	-32767	{1 inc.}	32767	Speed-dependent phase trimming for the master frequency processing, function block DFSET → depending on C0005, C0025, C0490 • Change of C0005, C0025 or C0490 resets C0253 to the corresponding Lenze setting • 1 rev. = 65536 inc • Value in C0253 is reached at 15000 rpm	

Configuration	8
Function blocks	8.2
Master frequency processing (DFSET)	8.2.5

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0520 STOP	CFG: IN	1000	FIXEDPHI-0	Selection list 4	Configuration of input signal, function block DFSET ● Input of speed / phase setpoint signal	8.2-18
C0521 STOP	CFG: VP-DIV	1000	FIXED0%	Selection list 1	Configuration of analog input signal, function block DFSET ● Signal for numerator of stretching factor ● 100 % = 16384 inc	
C0522 STOP	CFG: RAT-DIV	1000	FIXED0%	Selection list 1	Configuration of analog input signal, function block DFSET ● Signal for numerator of gearbox factor ● 100 % = 16384 inc	
C0523 STOP	CFG: A-TRIM	1000	FIXED0%	Selection list 1	Configuration of analog input signal, function block DFSET ● Signal for phase trimming via offset multiplier (C0529) ● 100 % = 16384 inc	
C0524 STOP	CFG: N-TRIM	1000	FIXED0%	Selection list 1	Configuration of analog input signal, function block DFSET ● Signal for speed trimming ● Signal in [%] of C0011	
C0525 STOP	CFG: 0-PULSE	1000	FIXED0	Selection list 2	Configuration of digital input signal, function block DFSET ● Signal for one-time zero pulse activation ● HIGH = release for zero pulse synchronisation	
C0526 STOP	CFG: RESET	1000	FIXED0	Selection list 2	Configuration of digital input signal, function block DFSET ● Signal for reset of integrators ● HIGH sets – Position difference = 0 – DFSET-PSET = 0 – DFSET-PSET2 = 0	
C0527 STOP	CFG: SET	1000	FIXED0	Selection list 2	Configuration of digital input signal, function block DFSET ● HIGH = Set phase integrators to equal values ● LOW-HIGH edge sets DFSET-PSET = 0 ● HIGH-LOW edge sets DFSET-PSET to the current value of MCTRL-PHI-SET ● DFSET-SET has a higher priority than DFSET-RESET	
C0528			-2·10 ⁹	{1}	2·10 ⁹	Function block DFSET ● Display only
1	DIS: 0-pulse A					Phase difference between two zero pulses
2	DIS: Offset					Offset = C0523 × C0529 + C0252

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0529	Multip offset	1	-20000	{1}	20000	Offset multiplier, function block DFSET ● Multiplier for the phase offset (C0252)	8.2-18
C0530	DF evaluation	0	0	with factor	With gearbox factor	Master frequency evaluation, function block DFSET	
			1	no factor	Without gearbox factor	● Evaluation of the setpoint integrator	
C0531	Act 0 div	1	1	{1}	16384	Actual zero pulse divisor, function block DFSET	
C0532	0-pulse/TP	1	1	0-pulse	Index pulse	Zero pulse / touch probe, function block DFSET	
			2	Touch probe	Touch probe	● Zero pulse of the feedback system or touch probe	
C0533	Vp denom	1	1	{1}	32767	Gain factor of denominator V _p , function block DFSET	
C0534	0 pulse fct	0				Zero pulse function, function block DFSET ● Synchronising the drive	8.2-18
			0	inactive	Inactive		
			1	Continuous	Continuous synchronisation, correction in the shortest possible way		
			2	Cont. switch	Continuous synchronisation, correction in the shortest possible way	After a LOW-HIGH signal to DFSET-0-pulse, the zero track is synchronised once	
			10	Once, fast way	One-time synchronisation, correction in the shortest possible way		
			11	Once, CW	One-time synchronisation, correction in direction of rotation to the right		
			12	Once, CCW	One-time synchronisation, correction in direction of rotation to the left		
			13	Once, 2*0-pulse	One-time synchronisation, correction is detected from setpoint pulse and actual pulse and corrected to the corresponding direction		
C0535	Set 0 div	1	1	{1}	16384	Desired zero pulse divisor, function block DFSET	8.2-18

Configuration	8
Function blocks	8.2
Master frequency processing (DFSET)	8.2.5

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0536			-32767	{1}	32767	Function block DFSET ● Display of the signals linked in C0521, C0522 and C0523
1	DIS: VP-DIV					8.2-18
2	DIS: RAT-DIV					
3	DIS: A-TRIM					
C0537	DIS: N-TRIM		-199.99	{0.01 %}	199.99	Function block DFSET ● Display of the signal linked in C0524
C0538			0		1	Function block DFSET ● Display of the signals linked in C0525, C0526 and C0527
1	DIS: 0-pulse					
2	DIS: RESET					
3	DIS: SET					
C0539	DIS: IN		-6000	{1 rpm}	6000	Function block DFSET ● Display of the signal linked in C0520
C0546	Min inc/rev	1000	1	{1 inc.}	2147483647	Masking of the touch probe signal, function block DFSET ● Suppressing interference pulses at X5/E4 (actual pulse of touch probe signal) ● The size of the masking window between two actual pulses is set

Setpoint conditioning with stretching and gearbox factor**Stretching factor**

The stretching factor defines the ratio with which the drive is to run faster or slower than the setpoint.

The setpoint at DFSET-IN is evaluated. The result is output to DFSET-POUT.

$$\text{DFSET-POUT} = \text{DFSET-IN} \cdot \frac{\text{DFSET-VP-DIV}}{\text{C0533}}$$

The stretching factor results from numerator and denominator.

- ▶ The numerator (DFSET-VP-DIV) can be defined as a variable from the analog signal source or as a fixed value from a code.
- ▶ Enter the denominator under C0533.

**Note!**

When calculating the stretching factor, the input signal at DFSET-VP-DIV is not processed in a scaled mode. A signal of 100 % corresponds to a count value of 16384.

Gearbox factor

The gearbox factor defines the ratio by means of which the drive speed can be changed additionally.

The setpoint at DFSET-IN, multiplied by the stretching factor, is evaluated. The result is output at DFSET-NOUT [in % of n_{max} (C0011)].

$$\text{DFSET-NOUT} = \text{DFSET-IN} \cdot \frac{\text{DFSET-VP-DIV}}{\text{C0533}} \cdot \frac{\text{DFSET-RAT-DIV}}{\text{C0033}}$$

The gearbox factor results from numerator and denominator.

- ▶ The numerator (DFSET-RAT-DIV) can be defined as a variable from the analog signal source or as a fixed value from a code.
- ▶ Enter the denominator under C0033.

**Note!**

When calculating the gearbox factor, the input signal at DFSET-RAT-DIV is not processed in a scaled mode. A signal of 100 % corresponds to a count value of 16384.

Configuration	8
Function blocks	8.2
Master frequency processing (DFSET)	8.2.5

Processing of correction values

Speed trimming

The speed trimming serves to add correction values, e. g. by a superimposed control loop. This enables the drive to accelerate or decelerate.

- At the speed trimming, an analog value at DFSET-N-TRIM is added to the speed setpoint.

Phase trimming

The phase trimming adds a setpoint at DFSET-A-TRIM to the phase setpoint and changes the rotor position to the setpoint with the number of increments provided in either direction (drive is leading or lagging). The phase is trimmed within a range of ± 32767 increments (corresponds to $\pm \frac{1}{2}$ revolution). Every analog signal can be used as a source.

- The input is done in increments (1 revolution $\triangleq 65536$ increments).
- An analog input signal at DFSET-A-TRIM of 100 % $\triangleq 1/4$ revolution $\triangleq 16384$ increments.
- You can extend the setting range with a multiplier (C0529).

Phase offset

The phase offset (C0252) adds a fixed phase offset to the setpoint of the drive.

Phase adjustment proportional to speed

With a phase adjustment proportional to speed, the phase leads or lags with increasing speed.

- Enter the offset in increments under C0253.
- The set phase offset is reached at 15000 rpm of the drive (linear relationship).



Note!

Phase corrections are only reasonable if the controller is operated with incremental encoder feedback and the calculated following error is used for correcting the speed setpoint. The following error is output to DFSET-PSET.

Synchronising to zero track or touch probe



Stop!

When the synchronisation via the terminals X5/E4 and X5/E5 (C0532 = 2) is activated, these terminals must not contain any other signal connections.

When selecting a basic configuration via C0005, the terminals contain a basic setting.

Selection of synchronisation

C0532 = 1 (zero pulse)

The synchronisation is performed on the zero track of the digital frequency input X9 and the zero track of the feedback system set under C0490.

C0532 = 2 (touch probe)

The synchronisation is performed using the terminals X5/E4 (actual pulse) and X5/E5 (setpoint pulse).

Touch probe initiators can have delay times which cause a speed-dependent phase offset.

Set the correction for the phase offset under C0429.

$$\text{C0429} = 16384 \cdot \text{Correction value}$$

The correction value for the phase offset can be obtained from the data sheet of the initiator, or contact the manufacturer.

Synchronisation modes

C0534	Synchronisation mode	Note
0	Inactive	Function inactive
1	Continuous synchronisation with correction in the shortest possible way	
2	Continuous synchronisation with correction in the shortest possible way	
10	One synchronisation. A phase deviation is corrected in the shortest possible way.	After a LOW-HIGH signal to DFSET-0-pulse, the zero track is synchronised once
11	One synchronisation. A phase deviation is corrected in CW direction.	
12	One synchronisation. A phase deviation is corrected in CCW direction.	
13	Single synchronisation. A phase difference is determined between setpoint pulse and actual pulse and is corrected to the corresponding direction of rotation according to the sign.	

► During synchronisation, DFSET-ACK is set to HIGH.



Note!

Drive synchronisation is only reasonable if the controller is operated with incremental encoder feedback and the calculated following error is used for correcting the speed setpoint. The following error is output to DFSET-PSET.

Configuration	8
Function blocks	8.2
Internal motor control with V/f characteristic control (MCTRL1)	8.2.6

8.2.6 Internal motor control with V/f characteristic control (MCTRL1)

Description

The function block MCTRL1 controls the motor. It is always carried out so that it does not need to be entered into the processing table.

In the Lenze setting, the controller is set to V/f characteristic control (C0006 = 5). Without other settings and with analog setpoint selection via X6/1, X6/2 and connected asynchronous standard motor (50 Hz/400 V) commissioning can be executed immediately.

The V/f characteristic control is suitable for single drives, multi-motor drives, synchronous motors, reluctance motors and asynchronous motors.




Fig. 8.2-15 Internal motor control with V/f characteristic control (MCTRL1)

Codes for parameter setting

Code		Possible settings			IMPORTANT		
No.	Name	Lenze	Selection				
C0006 <small>STOP</small>	Op mode	5			Selection of the operating mode for the motor control		
			1 vector ctrl	Vector control without or with speed feedback	In case of the first selection enter the motor data and identify them with C0148.	6.8-8	
C0010	N _{min}	0	0	{1 rpm}	36000	<ul style="list-style-type: none"> Reference value for the absolute and relative setpoint selection for the acceleration and deceleration times C0059 must be set correctly Set C0010 < C0011 C0010 is only effective in case of analog setpoint selection via AIN1 <p>Important: For parameter setting via interface, major changes in one step should only be made when the controller is inhibited.</p>	Minimum speed 6.10-1
C0011	N _{max}	3000	0	{1 rpm}	36000	Maximum speed	
C0014	V/f charact.	0			Characteristic in the V/f characteristic control mode		8.2-25
			0	Linear	Linear V/f characteristic		
			1	square	Square V/f characteristic		
C0015	Rated freq	50	10	{1 Hz}	5000	V/f-rated frequency In C0015 you can set a base frequency which differs from the rated motor frequency (C0089) <ul style="list-style-type: none"> Lenze setting: C0015 = C0089 Changing C0086 or C0089 overwrites the value in C0015 	8.2-25
C0016	Umin boost	0.00	0.00	{0.01 %}	100.00	U _{min} boost (FCODE) <ul style="list-style-type: none"> C0016 = 1 % corresponds to a boost of 1 % of the rated motor voltage (C0090) Code is freely configurable 	6.8-4

Configuration	8
Function blocks	8.2
Internal motor control with V/f characteristic control (MCTRL1)	8.2.6

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0018	fchop	6				Switching frequency of the inverter
			1	1 kHz sin	loss-optimised	<ul style="list-style-type: none"> General rule: The lower the switching frequency the <ul style="list-style-type: none"> lower the power loss higher the noise generation better the concentricity factor
			2	2 kHz sin	concentricity-optimised	
			3	4 kHz f_top	power-optimised	
			4	4 kHz sin	noise-optimised	
			6	4/2 kHz sin	noise/concentricity-optimised with automatic change-over to low switching frequency	<ul style="list-style-type: none"> Observe derating indications for high switching frequencies The max. output frequency (f_{max}) is: <ul style="list-style-type: none"> $f_{chop} = 4 \text{ kHz} \Rightarrow f_{max} = 300 \text{ Hz}$ $f_{chop} = 2 \text{ kHz} \Rightarrow f_{max} = 150 \text{ Hz}$ $f_{chop} = 1 \text{ kHz} \Rightarrow f_{max} = 150 \text{ Hz}$
C0021	slipcomp	→	-20.00	{0.01 %}	20.00	<p>Slip compensation → Change of C0086, C0087 or C0089 sets C0021 to the calculated rated slip of the motor</p> <ul style="list-style-type: none"> When changing over to the vector control mode, C0021 is set to 0
C0022	I _{max} current	→	0	{0.1 A}	-	<ul style="list-style-type: none"> I_{max} limit in motor mode → depending on C0086
C0023	I _{max} gen.	→	0	{0.1 A}	-	<ul style="list-style-type: none"> I_{max} limit in generator mode → depending on C0086
C0036	DC brk value	0.0	0.0	{0.1 A}	-	<ul style="list-style-type: none"> Set DC braking current → depends on the controller
C0042	DIS: QSP				Quick stop	
					<ul style="list-style-type: none"> Display only 	8.2-25
			0	QSP inactive	Quick stop is not active	8.2-40
			1	QSP active	Quick stop is active	
C0050	MCTRL-NSET2		-100.00	{0.01 %}	100.00	<p>Speed setpoint, function block MCTRL</p> <ul style="list-style-type: none"> Display of the speed in [%] of C0011
C0051	MCTRL-NACT		-36000	{1 rpm}	36000	<p>Actual speed value, function block MCTRL</p> <ul style="list-style-type: none"> Read only
C0052	MCTRL-Umot		0	{1 V}	800	<p>Motor voltage, function block MCTRL</p> <ul style="list-style-type: none"> Read only $MCTRL-VACT = 100 \% = C0090$
C0053	UG-VOLTAGE		0	{1 V}	900	<p>DC-bus voltage, function block MCTRL</p> <ul style="list-style-type: none"> Read only $MCTRL-DCVOLT = 100 \% = 1000 \text{ V}$
C0054	I _{mot}		0.0	{0.1 A}	5000.0	<p>Actual motor current, function block MCTRL</p> <ul style="list-style-type: none"> Read only $MCTRL-IACT = 100 \% = C0022$

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0056	MCTRL-MSET2		-100.00	{0.01 %}	100.00	Read only. The output signal depends on the operating mode: <ul style="list-style-type: none">● Current motor current in case of V/f characteristic control, function block MCTRL1● Torque setpoint in case of vector control, function block MCTRL2
C0058	MCTRL-FACT		-600.0	{0.1 Hz}	600.0	Output frequency <ul style="list-style-type: none">● Display only● MCTRL-FACT = 100.0 % = 1000.0 Hz
C0063	Mot temp		0	{1 °C}	200	Motor temperature <ul style="list-style-type: none">● Read only● Monitoring of the motor temperature must be activated.● KTY at X8/5, X8/8:<ul style="list-style-type: none">– At 150 °C, TRIP OH3 is set– Early warning is possible via OH7, temperature is set in C0121● PTC, thermal contact at T1, T2:<ul style="list-style-type: none">– Release sets TRIP or warning OH8
C0064	Utilization		0	{1 %}	150	Device utilisation lxt <ul style="list-style-type: none">● Read only● Device utilisation of the last 180 s operating time● C0064 > 100 % triggers warning OC5● C0064 > 110 % limits the output current of the controller to 67 % of the maximum current in C0022
C0070	Vp speed CTRL	10.0	0.0	{0.1 }	255.9	Gain of speed controller
C0071	Tn speed CTRL	50	1	{1 ms}	6000	Integral-action time of speed controller C0071 = 6000 ms: No integral-action time
C0074	limit N	10.00	0.00	{0.01 %}	100.00	Limitation of the speed controller <ul style="list-style-type: none">● Influence of the speed controller for V/f characteristic control with feedback● max. setpoint difference in percent
C0075	Vp curr CTRL	0.04	0.00	{0.01 }	0.99	Gain of current controller <ul style="list-style-type: none">● Vector control: Gain of current controller● V/f characteristic control: Maximum current controller
C0076	Tn curr CTRL	10.0	0.1	{0.1 ms}	2000.0	Integral-action time of current controller <ul style="list-style-type: none">● Vector control: integral-action time of current controller● V/f characteristic control: maximum current controller● C0076 = 2000 ms: current controller is switched off

Configuration	8
Function blocks	8.2
Internal motor control with V/f characteristic control (MCTRL1)	8.2.6

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0078	Tn slip CTRL	100	1	{1 ms}	6000	<p>Integral-action time of slip controller</p> <ul style="list-style-type: none"> Filter time for slip compensation (C0021) Only active with V/f characteristic control
						8.2-25
C0086 <small>STOP</small>	Mot type	→		Motor selection list		<p>Motor type selection → depending on the controller used</p> <ul style="list-style-type: none"> Motor selection in C0086 sets the corresponding parameters in C0021, C0022, C0081, C0087, C0088, C0089, C0090, C0091
						6.6-1
C0087 <small>STOP</small>	Mot speed	→	50	{1 rpm}	36000	<p>Rated motor speed → depending on C0086</p> <ul style="list-style-type: none"> Motor selection in C0086 set the corresponding rated motor speed in C0087 Change of C0087 sets C0086 = 0
						6.6-1
C0089 <small>STOP</small>	Mot frequency	→	10	{1 Hz}	5000	<p>Rated motor frequency → depending on C0086</p> <ul style="list-style-type: none"> Motor selection in C0086 sets the corresponding rated motor frequency in C0089 Change of C0089 sets C0086 = 0
						6.6-1
C0090 <small>STOP</small>	Mot voltage	→	0	{1 V}	1000	<p>Rated motor voltage → depending on C0086</p> <ul style="list-style-type: none"> Motor selection in C0086 sets the corresponding rated motor voltage in C0090 Change of C0090 sets C0086 = 0
						6.6-1
C0095 <small>STOP</small>	Mot lo	→	0.0	{0.1 A}	1000.0	<p>Motor magnetising current → dependent on C0086, C0088 and C0091</p> <ul style="list-style-type: none"> Change of C0086 sets C0095 to the Lenze setting Change of C0095 sets C0086 = 0
						6.6-1
C0105	QSP Tif	5.00	0.00	{0.01 s}	999.90	<p>Quick stop deceleration time</p> <ul style="list-style-type: none"> The deceleration time refers to a speed variation of C0011 ... 0
						8.2-25
						8.2-40
C0107	holding time	0.00	0.00	{0.01 s}	9999.90	Hold time for automatic DC injection braking (Auto-GSB)
						8.2-25
						8.2-40
C0143	limit 2 kHz	0.0	0.0	{0.1 Hz}	20.0	<p>Speed-dependent switching threshold</p> <ul style="list-style-type: none"> Threshold for automatic switching frequency reduction The controller changes automatically to 2 kHz when this value falls below the threshold
						8.2-25
						8.2-40

8 Configuration

8.2

Function blocks

8.2.6

Internal motor control with V/f characteristic control (MCTRL1)

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0234	damp value	20	-100	{1 %}	100	Influence of the oscillation damping, function block MCTRL <ul style="list-style-type: none"> Minimising a tendency to oscillation of the drive Influences the tendency to oscillation of the drive When C0025 >1 and C0006 = 1, C0234 is set to 0
C0235	damping	2	1	{1 ms}	600	Filter time of the oscillation damping, function block MCTRL <ul style="list-style-type: none"> Filter time for the internal signal for oscillation damping
C0236	damp limit	1.0	0.0	{0.1 Hz}	20.0	Limit value of oscillation damping, function block MCTRL <ul style="list-style-type: none"> Limit value for the internal signal of oscillation damping
C0890 <small>STOP</small>	CFG: N-SET	5050	NSET-NOUT	 Selection list 1	Configuration of analog input signal, function block MCTRL <ul style="list-style-type: none"> Speed setpoint 	 8.2-25  8.2-40
C0900 <small>STOP</small>	CFG: QSP	10250	R/L/Q-QSP	 Selection list 2	Configuration of digital input signal, function block MCTRL <ul style="list-style-type: none"> HIGH = drive performs quick stop 	 8.2-25  8.2-40
C0903 <small>STOP</small>	CFG: BOOST	5015	MCTRL-BOOST	 Selection list 1	Configuration of analog input signal, function block MCTRL <ul style="list-style-type: none"> Boost of the motor voltage 	 8.2-25
C0904 <small>STOP</small>	CFG: DC-BREAK	1000	FIXED0	 Selection list 2	Configuration of digital input signal, function block MCTRL <ul style="list-style-type: none"> HIGH = Motor is braked 	 8.2-25  8.2-40
C0905	DIS: DC-BREAK		0		1	Function block MCTRL <ul style="list-style-type: none"> Display of the signal linked in C0904
C0906			-199.99	{0.01 %}	199.99	Function block MCTRL <ul style="list-style-type: none"> Display of the signals linked in C0890, C0891, C0892, C0893, C0901 and C0903
1	DIS: N-SET					 8.2-25
2	DIS: M-ADD					 8.2-40
3	DIS: LO-M-LIM					
4	DIS: HI-M-LIM					
5	DIS: I-SET					
6	DIS: BOOST					
C0907			0		1	Function block MCTRL <ul style="list-style-type: none"> Display of the signals linked in C0899, C0900 and C0902
1	reserved					
2	DIS: N/M-SWT					
3	DIS: QSP					
4	DIS: I-LOAD					
C0909	speed limit	1	1	+/- 175 %		Speed limitation, function block MCTRL <ul style="list-style-type: none"> Limitation of direction of rotation for the speed setpoint
			2	0 ... 175 %		 8.2-25
			3	-175 ... 0 %		 8.2-40
C0910 <small>STOP</small>	CFG: VP-ADAPT	1006	FIXED100%	 Selection list 1	Configuration of analog input signal, function block MCTRL <ul style="list-style-type: none"> Gain adaptation of the speed controller If the gain is varying, join to CURVE-OUT of FB CURVE 	 8.2-25  8.2-40
C0911	DIS: VP-ADAPT		-199.99	{0.01 %}	199.99	Function block MCTRL <ul style="list-style-type: none"> Display of the signal linked in C0910

Configuration	8
Function blocks	8.2
Internal motor control with V/f characteristic control (MCTRL1)	8.2.6

- Speed setpoint selection**
- The signal at the input MCTRL-N-SET is the setpoint speed in [%] and always refers to the maximum speed (C0011).
 - In most basic configurations, MCTRL-N-SET is connected to the function block NSET (speed setpoint conditioning).
 - You can also connect MCTRL-N-SET to any other analog output signal of a function block.

- Speed setpoint limitation**
- The speed setpoint at MCTRL-N-SET is always limited to $\pm 100\%$ of the maximum speed n_{max} (C0011).
 - The motor control converts the speed setpoint into a frequency setpoint, which is limited to a maximum output frequency, depending on the switching frequency f_{chop}

Switching frequency f_{chop}	Maximum output frequency
2 kHz	150 Hz
4 kHz	300 Hz

- Setting of the V/f characteristic**
- The motor voltage characteristic is set via the input of the motor ratings. Via the input MCTRL-BOOST the motor voltage can be raised. The input is connected to C0016 (freely configurable) in all basic configurations.
- To adapt the motor voltage boost to your application, you can also connect the input with other function blocks.

- Speed control**
- With feedback operation, a PI controller will control the slip.
- Activating the speed control**
- The speed control is activated when you select an incremental encoder in C0025.

Parameter setting

Code	Function
C0070	Gain V_p
C0071	Integral-action time T_n
C0074	Influence of the speed controller at operation with incremental encoder. Reference is n_{max} (C0011).



Note!

If the speed controller influence is adapted to the motor slip to be expected, the motor cannot accelerate in an uncontrolled way when the incremental encoder fails.

Adaptation of the speed controller

The gain of the speed controller can be changed online via the input MCTRL-VP-N-ADAPT. The set gain in C0070 is the reference value for an input signal of 100 %.

- You can influence the gain (C0070) by adapting a function block (e.g. CURVE) to MCTRL-VP-N-ADAPT.
- The adaptation is switched off in the Lenze default setting.

Limitation of the output current

The limitation of the output current is mainly used for the protection of the controller and the stabilisation of the control.

When the maximum permissible motor load is exceeded, you can adapt the max. output current of the controller accordingly.

Parameter setting

Code	Function
C0022	Maximum current in motor mode
C0023	Maximum current in generator mode

If you select a motor (via C0086), the maximum current of which is clearly lower than the output current of the controller, the maximum motor current (C0022) is limited automatically to 200% of the rated motor current.

Mode of operation

In the V/f characteristic control mode, a PI controller ($V_p = C0075$, $T_n = C0076$) prevents an excess of the max. permissible motor current by reducing (motor overload) or increasing (generator overload) of the output frequency.

The N controller is not active in the V/f characteristic control mode without feedback.

Consequences

- ▶ The motor cannot follow the speed setpoint.
- ▶ MCTRL-IMAX is set to HIGH
- ▶ When selecting the automatic switching frequency setting (C0018 = 0 or 6), the controller switches to a lower switching frequency so that a disconnection is not required.

Automatic speed detection after controller enable - flying restart circuit**Note!**

Due to physical regularities, the operability of the flying restart circuit depends on the application, the motor and the motor power.

- ▶ With EVF9335 ... EVF9338 and EVF9381 ... EVF9383 devices, the operability of the flying restart circuit can therefore not be guaranteed.

Configuration	8
Function blocks	8.2
Internal motor control with V/f characteristic control (MCTRL1)	8.2.6

Quick stop (QSP) After a signal request, the motor is decelerated to standstill when an internal ramp function generator has been activated.

Mode of operation

- Quick stop is active
 - MCTRL-QSP = HIGH
 - The control word DCTRL-QSP is applied
 - DC injection braking (GSB) is not active (GSB has priority over quick stop)
 - If quick stop is active, the motor brakes to standstill with the deceleration time set in C0105. MCTRL-QSP-OUT is set to HIGH.
- Manual DC injection braking**
- After a signal, the motor is braked by injecting a DC current.
 - Braking in generator mode must be used for controlled brake ramps.
 - The hold time (C0107) has no influence. The motor remains braked until MCTRL-GSB is set to LOW.



Note!

Manual DC injection braking has priority over quick stop.

Setting

Selection	Code	Description
DC braking current	C0036	DC braking current with which the motor is braked



Stop!

An excessive DC braking current and braking time can thermally overload the motor. Special care must be taken when using self-ventilated motors.

Activation

The input MCTRL-GSB in the function block MCTRL is triggered with HIGH level.

- MCTRL-GSB = HIGH: Function is activated
- MCTRL-GSB = LOW: Function is not activated

Function procedure




Fig. 8.2-16 Signal sequence with DC injection braking

- [A] Actual speed value of the motor (e. g. MCTRL-NACT)
 - [B] Controller output current (e. g. MCTRL-IACT)
 - [C] Pulse inhibit (e. g. DCTRL-IMP)
 - [D] Activating DC injection braking (MCTRL-GSB)
 - [E] DC injection braking is active (MCTRL-GSB-OUT)
 - MCTRL-GSB-OUT = HIGH: Function is active
 - MCTRL-GSB-OUT = LOW: Function is not active
- ① The motor rotates with the preset speed. The current adjusts itself as a function of the load [E].
- ② DC injection braking is activated with MCTRL-GSB = HIGH. Pulse inhibit **IMP** is set. The motor coasts.
- ③ The pulse inhibit is deactivated and the DC braking current set in C0036 is injected
- ④ DC injection braking is deactivated with MCTRL-GSB = LOW
The motor is accelerated to speed setpoint at the set acceleration ramp and is kept there.

Configuration	8
Function blocks	8.2
Internal motor control with V/f characteristic control (MCTRL1)	8.2.6

Automatic DC injection braking

When the speed falls below a settable speed setpoint threshold, the function "DC injection braking" is activated.



Note!

Automatic DC-injection braking has priority over quick stop.

Setting

Selection	Code	Description
DC braking current	C0036	DC braking current with which the motor is braked
Speed setpoint threshold	C0019	If the values fall below the threshold, DC-injection braking is released
Hold time	C0107	Duration of DC-injection braking. After the hold time, pulse inhibit is set.



Stop!

An excessive DC braking current and braking time can thermally overload the motor. Special care must be taken when using self-ventilated motors.

Function procedure

Automatic DC injection braking provides two function procedures, each with a different reaction of the controller. The parameter setting is identical for both function procedures.

Function procedure 1:

- After the hold time has elapsed (C0107), the controller automatically sets pulse inhibit **IMP**.




Fig. 8.2-17 Signal characteristic with automatic DC injection braking

- Ⓐ Speed setpoint (e. g. AIN-OUT)
- Ⓑ Actual speed value of the motor (e. g. MCTRL-NACT)
- Ⓒ Controller output current (e. g. MCTRL-IACT)
- Ⓓ Pulse inhibit (e. g. DCTRL-IMP)
- Ⓔ DC injection braking is active (MCTRL-GSB-OUT)
MCTRL-GSB-OUT = HIGH: Function is active
MCTRL-GSB-OUT = LOW: Function is not active
- ① The motor rotates with the preset speed. The current adjusts itself as a function of the load Ⓛ.
- ② With a speed setpoint < speed threshold (C0019), DC injection braking is activated. Pulse inhibit **IMP** is set. The motor coasts.
- ③ The pulse inhibit is deactivated and the DC braking current set in C0036 is injected
- ④ After the hold time (C0107) pulse inhibit **IMP** is set

Configuration	8
Function blocks	8.2
Internal motor control with V/f characteristic control (MCTRL1)	8.2.6

Function procedure 2:

- If you define a speed setpoint > speed threshold (C0019) before the hold time elapses, DC-injection braking is deactivated and the drive follows the speed setpoint. If the speed falls below the threshold again, DC-injection braking is reactivated and the hold time is restarted.




Fig. 8.2-18 Signal characteristic with automatic DC injection braking

- [A] Speed setpoint (e. g. AIN-OUT)
- [B] Actual speed value of the motor (e. g. MCTRL-NACT)
- [C] Controller output current (e. g. MCTRL-IACT)
- [D] Pulse inhibit (e. g. DCTRL-IMP)
- [E] DC injection braking is active (MCTRL-GSB-OUT)
MCTRL-GSB-OUT = HIGH: Function is active
MCTRL-GSB-OUT = LOW: Function is not active
- ① The motor rotates with the preset speed. The current adjusts itself as a function of the load [F].
- ② With a speed setpoint < speed threshold (C0019), DC injection braking is activated. Pulse inhibit [IMP] is set. The motor coasts.
- ③ The pulse inhibit is deactivated and the DC braking current set in C0036 is injected
- ④ DC-injection braking is deactivated as soon as the speed setpoint exceeds the speed threshold (C0019). The motor is accelerated to the defined speed setpoint and kept there.

Oscillation damping

Suppressing no-load oscillations in case of:

- ▶ Drives with different rated power of controller and motor, e. g. when operating with high switching frequency and the power derating involved.
- ▶ Operation of higher-pole motors.
- ▶ Operation of three-phase AC drives > 10 kW.

Compensation of resonances in the drive kit:

- ▶ Certain asynchronous motors may show this behaviour above $\frac{1}{3}$ of the rated speed ($\frac{1}{3} \cdot n_n$). This may result in an unstable operation (current and speed variations).

Adjustment

The Lenze setting is designed for power-adapted motors.

Usually, the speed oscillations can be reduced by changing the Lenze setting of the codes C0234 oder C0236 by the factor 2 ... 5.

1. Approach the range with speed oscillations.
 2. Change the influence of the oscillation damping in C0234 (generally, increase it).
 3. Increase the limitation of the oscillation damping in C0236.
 4. Change filter time in C0235 in the range of 1 ... 20 ms, if necessary.
- ▶ These can be indicators for smooth running:
 - Constant motor current characteristic
 - Reduction of the mechanical oscillations in the bearing seat

Configuration	8
Function blocks	8.2
Internal motor control with V/f characteristic control (MCTRL1)	8.2.6

Slip compensation

The speed of an asynchronous machine decreases when being loaded. This load-dependent speed drop is called slip. By setting C0021 the slip can be partly compensated.

In the V/f characteristic control mode the slip compensation is only active at operation without feedback (C0025 = 1).

V/f characteristic control

The slip compensation (C0021) is automatically calculated from the rated motor speed (C0087) and the rated motor frequency (C0089). The entered slip constant [%] is the rated slip of the motor in [%] relating to the synchronous speed of the motor.

► Calculating the slip compensation and entering it into C0021:

$s = \frac{n_{rsyn} - n_r}{n_{rsyn}} \cdot 100 \%$	E Slip constant (C0021) [%]
$n_{rsyn} = \frac{f_r \cdot 60}{p}$	n _{rsyn} Synchronous motor speed [min ⁻¹]
	n _r Rated motor speed according to motor nameplate [min ⁻¹]
	f _r Rated motor frequency according to motor nameplate [Hz]
	p Number of motor pole pairs (1, 2, 3, ...)

► If required, the slip compensation can be adapted manually:

- If C0021 is set too high, the drive may get unstable.
- With cyclic load impulses (e. g. centrifugal pump) a smooth motor characteristic is achieved by smaller values in C0021 (possibly negative values)
- Parameterise C0078 (filter time for the slip compensation) if you want to change the motor response time to load changes (dynamic ↔ slow).

► The actual speed is output as an analog signal (in [%] of n_{max} (C0011)) to MCTRL-NACT.



Note!

When operating synchronous or reluctance motors, C0021 must be set to 0.

Inhibiting the direction of rotation

If the motor may only rotate in one direction, you can limit the output voltage generation to one direction of rotation via C0909.

Code	Description
C0909 = 1	The motor rotates in both directions
C0909 = 2	Motor rotates clockwise, "positive direction of rotation" (View of the motor shaft)
C0909 = 3	Motor rotates counter-clockwise, "negative direction of rotation" (View of the motor shaft)

8.2.7 Internal motor control with vector control (MCTRL2)

Description

The function block MCTRL2 controls the motor. Since it is always executed, it does not need to be entered into the processing table.

Compared with the V/f characteristic control the vector control (C0006 = 1) has a much higher torque efficiency at the same motor current. The motor is monitored and controlled via an internal motor model. This serves to achieve an optimum operating behaviour of the motor at any time.

The vector control can be used for single drives, asynchronous motors and multi-motor drives of the same type with rigid coupling.




Fig. 8.2-19 Internal motor control with vector control (MCTRL2)

Configuration	8
Function blocks	8.2
Internal motor control with vector control (MCTRL2)	8.2.7

Codes for parameter setting

Code		Possible settings			IMPORTANT		
No.	Name	Lenze	Selection				
C0006 <small>STOP</small>	Op mode	5			Selection of the operating mode for the motor control		
			1 vector ctrl	Vector control without or with speed feedback	In case of the first selection enter the motor data and identify them with C0148.	6.8-8	
C0010	N _{min}	0	0	{1 rpm}	36000	<ul style="list-style-type: none"> Reference value for the absolute and relative setpoint selection for the acceleration and deceleration times C0059 must be set correctly Set C0010 < C0011 C0010 is only effective in case of analog setpoint selection via AIN1 <p>Important: For parameter setting via interface, major changes in one step should only be made when the controller is inhibited.</p>	6.10-1
C0011	N _{max}	3000	0	{1 rpm}	36000	Maximum speed	
C0018	fchop	6			Switching frequency of the inverter	6.9-1	
			1 1 kHz sin	loss-optimised	<ul style="list-style-type: none"> General rule: The lower the switching frequency the – lower the power loss – higher the noise generation – better the concentricity factor Observe derating indications for high switching frequencies The max. output frequency (f_{max}) is: <ul style="list-style-type: none"> fchop = 4 kHz \Rightarrow $f_{max} = 300$ Hz fchop = 2 kHz \Rightarrow $f_{max} = 150$ Hz fchop = 1 kHz \Rightarrow $f_{max} = 150$ Hz 		
			2 2 kHz sin	concentricity-optimised			
			3 4 kHz f_top	power-optimised			
			4 4 kHz sin	noise-optimised			
			6 4/2 kHz sin	noise/concentricity-optimised with automatic change-over to low switching frequency			
C0019	Thresh nact=0	0	-36000	{1 rpm}	36000	Operating threshold - automatic DC injection brake (Auto-GSB) <ul style="list-style-type: none"> Falling below the threshold in C0019 activates automatic DC injection braking when the holding time set under C0107 > 0 	8.2-25 8.2-40

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0021	slipcomp	→	-20.00	{0.01 %}	20.00	Slip compensation → Change of C0086, C0087 or C0089 sets C0021 to the calculated rated slip of the motor ● When changing over to the vector control mode, C0021 is set to 0
C0022	I _{max} current	→	0	{0.1 A}	-	I _{max} limit in motor mode → depending on C0086
C0023	I _{max} gen.	→	0	{0.1 A}	-	I _{max} limit in generator mode → depending on C0086
C0025 <small>STOP</small>	Feedback type	1				Speed feedback
	1	no feedback	No feedback			
	100	IT (C420) - X8	Input of the number of increments in C0420			Incremental encoder at X8 ● Incremental encoders with TTL level can only be connected to X8.
	101	IT (C420) - X9	Input of the number of increments in C0420			Incremental encoder at X9 ● Connect incremental encoders with HTL-level on X9 only
			Number of increments:			
	110	IT512-5V	512 inc			
	111	IT1024-5V	1024 inc			
	112	IT2048-5V	2048 inc			
	113	IT4096-5V	4096 inc			
C0036	DC brk value	0.0	0.0	{0.1 A}	-	Set DC braking current → depends on the controller
C0042	DIS: QSP					Quick stop ● Display only
	0	QSP inactive				Quick stop is not active
	1	QSP active				Quick stop is active
C0050	MCTRL-NSET2		-100.00	{0.01 %}	100.00	Speed setpoint, function block MCTRL ● Display of the speed in [%] of C0011
C0051	MCTRL-NACT		-36000	{1 rpm}	36000	Actual speed value, function block MCTRL ● Read only
C0052	MCTRL-Umot		0	{1 V}	800	Motor voltage, function block MCTRL ● Read only ● MCTRL-VACT = 100 % = C0090
C0053	UG-VOLTAGE		0	{1 V}	900	DC-bus voltage, function block MCTRL ● Read only ● MCTRL-DCVOLT = 100 % = 1000 V
C0054	I _{mot}		0.0	{0.1 A}	5000.0	Actual motor current, function block MCTRL ● Read only ● MCTRL-IACT = 100 % = C0022

Configuration 8
Function blocks 8.2
Internal motor control with vector control (MCTRL2) 8.2.7

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0056	MCTRL-MSET2		-100.00	{0.01 %}	100.00	Read only. The output signal depends on the operating mode: <ul style="list-style-type: none"> • Current motor current in case of V/f characteristic control, function block MCTRL1 • Torque setpoint in case of vector control, function block MCTRL2 8.2-25 8.2-40
C0058	MCTRL-FACT		-600.0	{0.1 Hz}	600.0	Output frequency <ul style="list-style-type: none"> • Display only • MCTRL-FACT = 100.0 % = 1000.0 Hz 8.2-25 8.2-40
C0063	Mot temp		0	{1 °C}	200	Motor temperature <ul style="list-style-type: none"> • Read only • Monitoring of the motor temperature must be activated. • KTY at X8/5, X8/8: <ul style="list-style-type: none"> – At 150 °C, TRIP OH3 is set – Early warning is possible via OH7, temperature is set in C0121 • PTC, thermal contact at T1, T2: <ul style="list-style-type: none"> – Release sets TRIP or warning OH8 8.2-25 8.2-40
C0064	Utilization		0	{1 %}	150	Device utilisation lxt <ul style="list-style-type: none"> • Read only • Device utilisation of the last 180 s operating time • C0064 > 100 % triggers warning OC5 • C0064 > 110 % limits the output current of the controller to 67 % of the maximum current in C0022 8.2-25 8.2-40
C0070	Vp speed CTRL	10.0	0.0	{0.1 }	255.9	Gain of speed controller
C0071	Tn speed CTRL	50	1	{1 ms}	6000	Integral-action time of speed controller C0071 = 6000 ms: No integral-action time 8.2-25 8.2-40
C0075	Vp curr CTRL	0.04	0.00	{0.01 }	0.99	Gain of current controller <ul style="list-style-type: none"> • Vector control: Gain of current controller • V/f characteristic control: Maximum current controller 8.2-25 8.2-40
C0076	Tn curr CTRL	10.0	0.1	{0.1 ms}	2000.0	Integral-action time of current controller <ul style="list-style-type: none"> • Vector control: integral-action time of current controller • V/f characteristic control: maximum current controller • C0076 = 2000 ms: current controller is switched off 8.2-25 8.2-40
C0082 <small>STOP</small>	Mot Rr	→	0.0000	{0.0001 Ω}	65.5350	Motor rotor resistance → Value is determined by motor parameter identification from C0087, C0088, C0089, C0090 and C0091 <ul style="list-style-type: none"> • Selection of a motor in C0086 sets the corresponding rotor resistance value 6.6-1 6.6-16

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0084 STOP	Mot Rs	→	0.00	{0.01 mΩ}	100000.00	Motor stator resistance → Value is determined by motor parameter identification (C0148, C0149) 6.6-1 6.6-16
C0086 STOP	Mot type	→		Motor selection list		Motor type selection → depending on the controller used ● Motor selection in C0086 sets the corresponding parameters in C0021, C0022, C0081, C0087, C0088, C0089, C0090, C0091 6.6-1
C0087 STOP	Mot speed	→	50	{1 rpm}	36000	Rated motor speed → depending on C0086 ● Motor selection in C0086 set the corresponding rated motor speed in C0087 ● Change of C0087 sets C0086 = 0 6.6-1
C0088 STOP	Mot current	→	0.5	{0.1 A}	1000.0	Rated motor current → depending on C0086 ● Motor selection in C0086 sets the corresponding rated motor current in C0088 ● Change of C0088 sets C0086 = 0 6.6-1
C0089 STOP	Mot frequency	→	10	{1 Hz}	5000	Rated motor frequency → depending on C0086 ● Motor selection in C0086 sets the corresponding rated motor frequency in C0089 ● Change of C0089 sets C0086 = 0 6.6-1
C0090 STOP	Mot voltage	→	0	{1 V}	1000	Rated motor voltage → depending on C0086 ● Motor selection in C0086 sets the corresponding rated motor voltage in C0090 ● Change of C0090 sets C0086 = 0 6.6-1
C0091 STOP	Mot cos phi	→	0.50	{0.01 }	1.00	Motor cos φ → depending on C0086 ● Motor selection in C0086 sets the corresponding motor cos φ in C0091 ● Change of C0091 sets C0086 = 0 6.6-1
C0092 STOP	Mot Ls	→	0.00	{0.01 mH}	6553.50	Motor stator inductance → Value is determined by motor parameter identification from C0088, C0089, C0090 and C0091 → Motor selection in C0086 sets corresponding stator inductance value in C0092 6.6-1

Configuration 8
Function blocks 8.2
Internal motor control with vector control (MCTRL2) 8.2.7

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0093	Drive ident				Controller identification ● Read only	
				0	Invalid	Defective power section
				1	None	No power section
				14	9335VC 400V	Display of the controller used
				
				20	9383VC 400V	
				21	9334VC 500V	
				
				28	9383VC 500V	
C0094	Password	0	0	{1}	9999	Password ● C0094 = 1 ... 9999: Free access to the user menu only
C0095 <small>STOP</small>	Mot lo	→	0.0	{0.1 A}	1000.0	Motor magnetising current → dependent on C0086, C0088 and C0091 ● Change of C0086 sets C0095 to the Lenze setting ● Change of C0095 sets C0086 = 0
C0105	QSP Tif	5.00	0.00	{0.01 s}	999.90	Quick stop deceleration time ● The deceleration time refers to a speed variation of C0011 ... 0
C0107	holding time	0.00	0.00	{0.01 s}	9999.90	Hold time for automatic DC injection braking (Auto-GSB)
C0143	limit 2 kHz	0.0	0.0	{0.1 Hz}	20.0	Speed-dependent switching threshold ● Threshold for automatic switching frequency reduction ● The controller changes automatically to 2 kHz when this value falls below the threshold
C0234	damp value	20	-100	{1 %}	100	Influence of the oscillation damping, function block MCTRL ● Minimising a tendency to oscillation of the drive ● Influences the tendency to oscillation of the drive ● When C0025 >1 and C0006 = 1, C0234 is set to 0
C0235	damping	2	1	{1 ms}	600	Filter time of the oscillation damping, function block MCTRL ● Filter time for the internal signal for oscillation damping
C0236	damp limit	1.0	0.0	{0.1 Hz}	20.0	Limit value of oscillation damping, function block MCTRL ● Limit value for the internal signal of oscillation damping

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0420 STOP	Encoder const	512	1	{1 inc/rev}	8192	Number of increments for incremental encoder at X8 or X9 <ul style="list-style-type: none"> • Connect incremental encoders with HTL-level on X9 only
C0421 STOP	Enc voltage	5.00	5.00	{0.1 V}	8.00	Supply voltage for the incremental encoder at X8 CAUTION! A wrong entry can destroy the incremental encoder!
C0497	Nact filter	2.0	0.0	{0.1 ms}	50.0	Filter time constant N_{act} for actual speed value, function block MCTRL2 <ul style="list-style-type: none"> • Internal filtering of the speed signal for control • C0497 = 0 ms: Switched off
C0890 STOP	CFG: N-SET	5050	NSET-NOUT	Selection list 1	Configuration of analog input signal, function block MCTRL <ul style="list-style-type: none"> • Speed setpoint 	█ 8.2-25 █ 8.2-40
C0891 STOP	CFG: M-Add	1000	FIXED0%	Selection list 1	Configuration of analog input signal, function block MCTRL <ul style="list-style-type: none"> • Additional torque setpoint or torque setpoint 	█ 8.2-40
C0892 STOP	CFG: Lo-M-LIM	5700	ANEG1-OUT	Selection list 1	Configuration of analog input signal, function block MCTRL <ul style="list-style-type: none"> • Lower torque limit in [%] of C0057 	█ 8.2-40
C0893 STOP	CFG: HI-M-LIM	19523	FCODE-472/3	Selection list 1	Configuration of analog input signal, function block MCTRL <ul style="list-style-type: none"> • Upper torque limit in [%] of C0057 	█ 8.2-40
C0898 STOP	CFG: M-LIM switch	0	M-LIM ON	Reduced torque limit is active	Torque limitation in the field weakening range, function block MCTRL <ul style="list-style-type: none"> • If the torque limit is reduced, the maximum possible torque in the field weakening range is lowered with 1/f. This provides a higher motor stability in the field weakening range 	█ 8.2-40
			1	M-LIM OFF	Reduced torque limit is inactive	
C0899 STOP	CFG: N/M-SWT	1000	FIXED0	Selection list 2	Configuration of digital input signal, function block MCTRL <ul style="list-style-type: none"> • LOW = active speed control • HIGH = active torque control 	█ 8.2-40
C0900 STOP	CFG: QSP	10250	R/L/Q-QSP	Selection list 2	Configuration of digital input signal, function block MCTRL <ul style="list-style-type: none"> • HIGH = drive performs quick stop 	█ 8.2-25 █ 8.2-40
C0901 STOP	CFG: I-SET	1000	FIXED0%	Selection list 1	Configuration of analog input signal, function block MCTRL <ul style="list-style-type: none"> • Setting of integral action component of the speed controller 	█ 8.2-40
C0902 STOP	CFG: I-LOAD	1000	FIXED0	Selection list 2	Configuration of digital input signal, function block MCTRL <ul style="list-style-type: none"> • HIGH = the integral action component at MCTRL-I-SET is accepted by the speed controller 	

Configuration	8
Function blocks	8.2
Internal motor control with vector control (MCTRL2)	8.2.7

Code		Possible settings			IMPORTANT
No.	Name	Lenze	Selection		
C0904 STOP	CFG: DC-BREAK	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block MCTRL • HIGH = Motor is braked □ 8.2-25
C0905	DIS: DC-BREAK		0	1	Function block MCTRL • Display of the signal linked in C0904 □ 8.2-40
C0906		-199.99	{0.01 %}	199.99	Function block MCTRL • Display of the signals linked in C0890, C0891, C0892, C0893, C0901 and C0903 □ 8.2-25 □ 8.2-40
C0907		0		1	Function block MCTRL • Display of the signals linked in C0899, C0900 and C0902
C0909	speed limit	1	1 +/- 175 % 2 0 ... 175 % 3 -175 ... 0 %		Speed limitation, function block MCTRL • Limitation of direction of rotation for the speed setpoint □ 8.2-25 □ 8.2-40
C0910 STOP	CFG: VP-ADAPT	1006	FIXED100%	□ Selection list 1	Configuration of analog input signal, function block MCTRL • Gain adaptation of the speed controller • If the gain is varying, join to CURVE-OUT of FB CURVE □ 8.2-25 □ 8.2-40
C0911	DIS: VP-ADAPT		-199.99	{0.01 %}	199.99 Function block MCTRL • Display of the signal linked in C0910

Speed setpoint selection

- ▶ The signal at the input MCTRL-N-SET is the setpoint speed in [%] and always refers to the maximum speed (C0011).
- ▶ In most basic configurations, MCTRL-N-SET is connected to the function block NSET (speed setpoint conditioning).
 - You can also connect MCTRL-N-SET to any other analog output signal of a function block.

Speed setpoint limitation

- ▶ The speed setpoint at MCTRL-N-SET is always limited to $\pm 100\%$ of the maximum speed n_{max} (C0011).
- ▶ The motor control converts the speed setpoint into a frequency setpoint, which is limited to a maximum output frequency, depending on the switching frequency f_{chop}

Switching frequency f_{chop}	Maximum output frequency
2 kHz	150 Hz
4 kHz	300 Hz

Speed control

A PI controller compares the speed setpoint with the actual speed of the motor model and creates a torque setpoint from the speed variation.

- the actual speed is output as an analog signal (in [%] of n_{\max} (C0011)) to MCTRL-NACT.

Parameter setting

Code	Function
C0070	Gain V_p
C0071	Integral-action time T_n

Operation with speed feedback

To change over to operation with external speed feedback, the incremental encoder must be selected via C0025. The external speed feedback serves to operate the motor in all of the four torque/speed quadrants.

Adaptation of the speed controller

Use the input MCTRL-VP-N-ADAPT to change the gain of the speed controller online. The set gain in C0070 is the reference value for an input signal of 100 %.

- By adapting a function block (e.g. CURVE) to MCTRL-VP-N-ADAPT you can influence the gain (C0070).
- In the Lenze setting the adaptation is deactivated.

Behaviour when speed setpoint = 0

If the speed setpoint = 0 (MCTRL-N-SET = 0) and actual speed value ≈ 0 (MCTRL-NACT ≈ 0), the speed controller is switched off. The motor merely receives its magnetising current.

Behaviour in braking operation at very low speed**Stop!**

A longer-lasting braking operation with very low speed can lead to an unstable vector control. Remedy:

- Passing through the critical speed range more quickly.
- Using speed feedback.

Configuration	8
Function blocks	8.2
Internal motor control with vector control (MCTRL2)	8.2.7

Temperature detection

For motors with temperature detection (KTY83-110) the controller can consider temperature changes in its motor model. The accuracy and stability of the vector control are improved considerably.

► Sensor connection:

- X8/5 = -KTY (rt/ws/bl)
- X8/8 = +KTY (br/gr/sw)



Note!

You can also use the thermal sensor (KTY) without speed feedback.

- When monitoring SD6 (C0594) is activated, temperature feedback is activated at the same time.
- First, activate the temperature feedback and then start the motor identification to consider the motor temperature.
- In addition, you can activate and parameterise the monitoring functions OH3 (C0583) and OH7 (C0584).
- The current motor temperature can be displayed via C0063.

Setting integral action component

To initialise the speed controller with a starting torque, the integral action component of the speed controller can be described via MCTRL-I-SET (starting value) and MCTRL-I-LOAD (control signal).

Input signal	Effect
MCTRL-I-LOAD = HIGH	<ul style="list-style-type: none"> • The speed controller transmits the value at MCTRL-I-SET to its integral action component • The P component is switched off
MCTRL-I-LOAD = LOW	The speed controller is active

Torque limitation in the field weakening range

The function is suitable for applications which also require a constant torque in the field weakening range.

- ▶ With quick stop (QSP) the torque limitation becomes inactive.
- ▶ When the motor torque reaches the defined limit, the drive cannot follow the speed setpoint anymore and the output MCTRL-MMAX is set to HIGH.

External setting of torque limits

If the maximum torque reached in the field weakening operation is too low, the torque limits can be changed via the inputs MCTRL-HI-M-LIM and MCTRL-LO-M-LIM.

- ▶ MCTRL-HI-M-LIM defines the upper torque limit in [%] of the maximum torque displayed in C0057.
Maximum possible input value: 199.99 %
- ▶ MCTRL-LO-M-LIM defines the lower torque limit in [%] of the maximum torque displayed in C0057.
Minimum possible input value: -199.99 %

**Note!**

The maximum possible torque displayed under C0057 refers to the basic speed range (zero speed to rated speed of the motor) and is calculated from the nameplate data and the setting of the maximum motor current under C0022.




Fig. 8.2-20 Torque characteristics when being evaluated with C0898

- A** "Internal limit characteristic" when $C0898 = 1$ and $MCTRL-HI-M-LIM = 199\%$
Boost of the upper torque limit when $MCTRL-HI-M-LIM = 199\%$ and $C0898 = 0$
- B** Torque characteristic when $C0898 = 1$ and $MCTRL-HI-M-LIM = 80\%$
- C** Torque characteristic when $C0898 = 0$ and $MCTRL-HI-M-LIM = 80\%$

Evaluating torque limits using C0898

Code C0898 serves to evaluate the defined torque limits at the inputs MCTRL-LO-M-LIM and MCTRL-HI-M-LIM using the function $1/f_{act}$. This serves to reduce the torque.

Selection	Code	Description
Evaluation of the torque limit in the field weakening range	$C0898 = 0$	Lenze setting The input signals at MCTRL-LO-M-LIM and MCTRL-HI-M-LIM are evaluated with $1/f_{act}$.
	$C0898 = 1$	An "internal limit characteristic" which corresponds to a maximum torque limit of $\pm 199,99\%$ is evaluated with $1/f_{act}$. <ul style="list-style-type: none"> • The torque remains constant until the limit characteristic is reached. This requires that the controller provides a sufficient amount of current and the motor is stable within the required speed range. • The input signals at MCTRL-LO-M-LIM and MCTRL-HI-M-LIM are not evaluated with $1/f_{act}$.

Limitation of the output current

The output current is mainly limited for protecting the controller and stabilising the drive control.

If the maximum permissible motor load is exceeded, the maximum output current of the controller must be adjusted accordingly.

Parameter setting

Code	Function
C0022	Maximum current in motor mode
C0023	Maximum current in generator mode

If you select a motor via C0086 the maximum current of which is much lower than the output current of the controller, the maximum current in motor mode (C0022) is automatically limited to the double rated motor current.

Mode of functioning

In the vector control mode the limit values are complied with by means of the automatic limitation of the speed controller.

The speed controller is limited if the motor current has reached the limit set under C0022 or C0023 (the controller supplies the max. output current). In this status

Consequences

- ▶ The motor cannot follow the speed setpoint.
- ▶ MCTRL-IMAX is set to HIGH.
- ▶ When selecting the automatic chopper frequency setting (C0018 = 0 or 6) a switch-over to a lower chopper frequency is carried out, so that the unit will not be switched off.

Configuration	8
Function blocks	8.2
Internal motor control with vector control (MCTRL2)	8.2.7

Torque control with speed limitation

As an alternative to the speed control, the vector control can be switched to torque control with speed limitation.



Note!

In the basic configurations C0005 = 4xxx the torque control with speed limitation is already set.

- When MCTRL-N/M-SWT = HIGH, the torque control with speed limitation is active.
 - The torque control with torque setpoint selection via MCTRL-M-ADD is active.
 - MCTRL-M-ADD acts as a bipolar torque setpoint.
 - The sign of the speed limitation value at MCTRL-N-SET is automatically created from the sign of the torque setpoint at MCTRL-M-ADD. Thus, the speed limitation value acts in both directions of rotation.
 - The actual torque is output as analog signal (in [%] of M_{max} (C0057)) to MCTRL-MACT.



Stop!

If the motor is to create a holding torque at standstill, the torque setpoint must not fall below a certain limit.

- Depending on the motor type and accuracy of the identified motor parameters, the vector control can become unstable if the torque setpoint <10 % ... 20 %.
- Operate the motor with speed feedback when the required holding torque is within the critical region.

Automatic speed detection after controller enable - flying restart circuit



Note!

Due to physical regularities, the operability of the flying restart circuit depends on the application, the motor and the motor power.

- With EVF9335 ... EVF9338 and EVF9381 ... EVF9383 devices, the operability of the flying restart circuit can therefore not be guaranteed.

Quick stop (QSP)

After a signal, the motor is decelerated to standstill when an internal ramp function generator has been activated.

Mode of operation

- ▶ Quick stop is active
 - MCTRL-QSP = HIGH
 - The control word DCTRL-QSP is applied
 - DC injection braking (GSB) is not active (GSB has priority over quick stop)
- ▶ When quick stop is active:
 - the motor decelerates to standstill with the deceleration time set in C0105,
 - A torque control is deactivated and the motor is controlled by the speed controller.
 - The torque limitations MCTRL-LO-M-LIM and MCTRL-HI-M-LIM are deactivated.
 - MCTRL-QSP-OUT is set to HIGH.

**Note!**

When the motor is at standstill, the field current is injected into the motor.

Configuration	8
Function blocks	8.2
Internal motor control with vector control (MCTRL2)	8.2.7

- Manual DC injection braking**
- After a signal, the motor is braked by injecting a DC current.
 - Braking in generator mode must be used for controlled brake ramps.
 - The hold time (C0107) has no influence. The motor remains braked until MCTRL-GSB is set to LOW.



Note!

Manual DC injection braking has priority over quick stop.

Special features of vector control with feedback

- If the DC braking current (C0036) \leq than the motor magnetising current, the motor magnetising current is injected.
- If the DC braking current (C0036) $>$ than the motor magnetising current, the DC braking current is injected.

Setting

Selection	Code	Description
DC braking current	C0036	DC braking current with which the motor is braked



Stop!

An excessive DC braking current and braking time can thermally overload the motor. Special care must be taken when using self-ventilated motors.

Activation

The input MCTRL-GSB in the function block MCTRL is triggered with HIGH level.

- MCTRL-GSB = HIGH: Function is activated
- MCTRL-GSB = LOW: Function is not activated

Function procedure




Fig. 8.2-21 Signal sequence with DC injection braking

- [A] Actual speed value of the motor (e. g. MCTRL-NACT)
 - [B] Controller output current (e. g. MCTRL-IACT)
 - [C] Pulse inhibit (e. g. DCTRL-IMP)
 - [D] Activating DC injection braking (MCTRL-GSB)
 - [E] DC injection braking is active (MCTRL-GSB-OUT)
 - MCTRL-GSB-OUT = HIGH: Function is active
 - MCTRL-GSB-OUT = LOW: Function is not active
- ① The motor rotates with the preset speed. The current adjusts itself as a function of the load [F].
- ② DC injection braking is activated with MCTRL-GSB = HIGH. Pulse inhibit IMP is set. The motor coasts.
- ③ The pulse inhibit is deactivated and the DC braking current set in C0036 is injected
- ④ DC injection braking is deactivated with MCTRL-GSB = LOW
The motor is accelerated to speed setpoint at the set acceleration ramp and is kept there.

Configuration	8
Function blocks	8.2
Internal motor control with vector control (MCTRL2)	8.2.7

Automatic DC injection braking

When the speed falls below a settable speed setpoint threshold, the function "DC injection braking" is activated.



Note!

Automatic DC-injection braking has priority over quick stop.

Special features of vector control with feedback

- ▶ If the DC braking current (C0036) \leq than the motor magnetising current, the motor magnetising current is injected.
- ▶ If the DC braking current (C0036) $>$ than the motor magnetising current, the DC braking current is injected.

Setting

Selection	Code	Description
DC braking current	C0036	DC braking current with which the motor is braked
Speed setpoint threshold	C0019	If the values fall below the threshold, DC-injection braking is released
Hold time	C0107	Duration of DC-injection braking. After the hold time, pulse inhibit is set.



Stop!


An excessive DC braking current and braking time can thermally overload the motor. Special care must be taken when using self-ventilated motors.

Function procedure

Automatic DC injection braking provides two function procedures, each with a different reaction of the controller. The parameter setting is identical for both function procedures.

Function procedure 1:

- After the hold time has elapsed (C0107), the controller automatically sets pulse inhibit **IMP**.



9300vec090

Fig. 8.2-22 Signal characteristic with automatic DC injection braking

- Ⓐ Speed setpoint (e. g. AIN-OUT)
- Ⓑ Actual speed value of the motor (e. g. MCTRL-NACT)
- Ⓒ Controller output current (e. g. MCTRL-IACT)
- Ⓓ Pulse inhibit (e. g. DCTRL-IMP)
- Ⓔ DC injection braking is active (MCTRL-GSB-OUT)
MCTRL-GSB-OUT = HIGH: Function is active
MCTRL-GSB-OUT = LOW: Function is not active
- ① The motor rotates with the preset speed. The current adjusts itself as a function of the load Ⓛ.
- ② With a speed setpoint < speed threshold (C0019), DC injection braking is activated. Pulse inhibit **IMP** is set. The motor coasts.
- ③ The pulse inhibit is deactivated and the DC braking current set in C0036 is injected
- ④ After the hold time (C0107) pulse inhibit **IMP** is set

Configuration	8
Function blocks	8.2
Internal motor control with vector control (MCTRL2)	8.2.7

Function procedure 2:

- If you define a speed setpoint > speed threshold (C0019) before the hold time elapses, DC-injection braking is deactivated and the drive follows the speed setpoint. If the speed falls below the threshold again, DC-injection braking is reactivated and the hold time is restarted.




Fig. 8.2-23 Signal characteristic with automatic DC injection braking

- [A] Speed setpoint (e. g. AIN-OUT)
- [B] Actual speed value of the motor (e. g. MCTRL-NACT)
- [C] Controller output current (e. g. MCTRL-IACT)
- [D] Pulse inhibit (e. g. DCTRL-IMP)
- [E] DC injection braking is active (MCTRL-GSB-OUT)
MCTRL-GSB-OUT = HIGH: Function is active
MCTRL-GSB-OUT = LOW: Function is not active
- ① The motor rotates with the preset speed. The current adjusts itself as a function of the load [F].
- ② With a speed setpoint < speed threshold (C0019), DC injection braking is activated. Pulse inhibit [IMP] is set. The motor coasts.
- ③ The pulse inhibit is deactivated and the DC braking current set in C0036 is injected
- ④ DC-injection braking is deactivated as soon as the speed setpoint exceeds the speed threshold (C0019). The motor is accelerated to the defined speed setpoint and kept there.

Oscillation damping

Suppressing no-load oscillations in case of:

- ▶ Drives with different rated power of controller and motor, e. g. when operating with high switching frequency and the power derating involved.
- ▶ Operation of higher-pole motors.
- ▶ Operation of three-phase AC drives > 10 kW.

Compensation of resonances in the drive kit:

- ▶ Certain asynchronous motors may show this behaviour above $\frac{1}{3}$ of the rated speed ($\frac{1}{3} \cdot n_n$). This may result in an unstable operation (current and speed variations).

Adjustment

The Lenze setting is designed for power-adapted motors.

Usually, the speed oscillations can be reduced by changing the Lenze setting of the codes C0234 oder C0236 by the factor 2 ... 5.

1. Approach the range with speed oscillations.
 2. Change the influence of the oscillation damping in C0234 (generally, increase it).
 3. Increase the limitation of the oscillation damping in C0236.
 4. Change filter time in C0235 in the range of 1 ... 20 ms, if necessary.
- ▶ These can be indicators for smooth running:
 - Constant motor current characteristic
 - Reduction of the mechanical oscillations in the bearing seat

**Note!****Restricted effect with vector control**

- ▶ The oscillation damping has no influence on the drive behaviour at low tendency to oscillation of the speed controller.
- ▶ Especially for drives > 55 kW with a tendency to oscillation it may be necessary to deactivate the oscillation damping (C0234 = 0 %).
- ▶ For operation with feedback the oscillation damping has no influence.

Configuration	8
Function blocks	8.2
Internal motor control with vector control (MCTRL2)	8.2.7

Slip compensation

Vector control

Use C0021 to change the influence of the rotor resistance (C0082) proportionally:

- ▶ Reduce the value in C0021 at an increasing speed (negative values)
- ▶ Increase the value in C0021 at a decreasing speed



Note!

When setting the vector control mode, the slip compensation (C0021) is automatically set to 0.0 %.

- ▶ When you switch back to the V/f characteristic control mode, the slip compensation must be re-adapted.

Inhibiting the direction of rotation

If the motor may only rotate in one direction, you can limit the output voltage generation to one direction of rotation via C0909.

Code	Description
C0909 = 1	The motor rotates in both directions
C0909 = 2	Motor rotates clockwise, "positive direction of rotation" (View of the motor shaft)
C0909 = 3	Motor rotates counter-clockwise, "negative direction of rotation" (View of the motor shaft)

Configuration	8
Monitoring	8.3
Responses	8.3.1

8.3 Monitoring

Various monitoring functions (§ 8.4-1) protect the drive system against impermissible operating conditions.

If a monitoring function is activated,

- the set response is triggered to protect the drive.
- the fault message is entered at position 1 in the history buffer (§ 9.2-1).

8.3.1 Responses

Depending on the failure, one or more of the following responses are possible:

Response	Effects on the drive and controller		Danger warnings
TRIP (highest priority)	<ul style="list-style-type: none"> ● Switches the power outputs U, V, W to a high resistance until TRIP is reset ● The drive coasts (no control!). ● After TRIP reset, the drive accelerates to its setpoint on the ramps set. 		
Message	<p>Switches the power outputs U, V, W to a high resistance as long as the message is active.</p> <ul style="list-style-type: none"> ● Short-time message ≤ 0.5 s The drive coasts (no control) as long as the message is active. If the message is no longer available, the drive accelerates to its setpoint with maximum torque. ● Longer message > 0.5 s The drive coasts (due to internal controller inhibit) as long as the message is active. If required, restart the drive. 	 Danger! The drive restarts automatically if the message is no longer available.	
Warning	<ul style="list-style-type: none"> ● Only display of the failure. ● The drive operates in a controlled manner. 		 Stop! As these responses have no effect on the drive behaviour, the drive can be destroyed.
Off	<ul style="list-style-type: none"> ● No response on failures! Monitoring is deactivated. 		

8.3.2 Monitoring times for process data input objects

Each process data input object can monitor whether a telegram has been received within a time set. As soon as a telegram arrives, the corresponding monitoring time (C0357) is restarted ("retriggerable monoflop" function).

The following assignments are valid:

Setting the response to the monitoring:

- ▶ C0591 for CAN1_IN ("CE1")
- ▶ C0592 for CAN2_IN ("CE2")
- ▶ C0593 for CAN3_IN ("CE3")

The following can be set:

- ▶ 0 = error (TRIP) - controller sets controller inhibit (CINH)
- ▶ 2 = warning
- ▶ 3 = monitoring is switched off

You can also use the signals as binary output signals, e. g. for the assignment of the output terminal.

Bus off

If the controller disconnects from the CAN bus due to faulty telegrams, the "BusOffState" (CE4) signal is set.

"BusOffState" can trigger an error (TRIP) or warning (like CE1, CE2, CE3). You can also switch the signal off. The response is set via C0595. You can also assign the terminal output.

Reset node

Changes with regard to the baud rates, the CAN node addresses, or the addresses of process data objects are only valid after a reset node.

The reset node can be effected by:

- ▶ A reconnection of the low-voltage supply
- ▶ Reset node via the bus system
- ▶ Reset node via C0358

Configuration	8
Monitoring	8.3
Maximum speed	8.3.3

8.3.3 Maximum speed



Stop!

Destruction of the drive!

- ▶ If the fault is triggered, the drive is without torque.
- ▶ In the event of an actual speed value encoder failure it is not guaranteed that the monitoring responds.

Protective measures:

- ▶ Use a mechanical brake if necessary.
- ▶ Special, system-specific measures are to be taken.

The NMAX fault is triggered if the system speed (MCTRL-NACT)

- ▶ exceeds the value set under C0596 or
- ▶ exceeds the maximum speed n_{\max} (C0011) by twice the max. speed value.

A fault initiates TRIP NMAX. Other responses cannot be set.

8.3.4 Motor

Short circuit in the motor cable (OC1)

The OC1 fault is triggered if the motor current exceeds the rated controller current by more than 2.25 times.

A fault initiates TRIP OC1. Other responses cannot be set.

Earth fault in the motor cable (OC2)

The OC2 fault is triggered if

- ▶ the motor has a short circuit to the frame,
- ▶ one of the phases has a short circuit to the shield,
- ▶ one of the phases has a short circuit to PE,
- ▶ the capacitive charging current of the motor cable is too high.

A fault initiates TRIP OC2. Other responses cannot be set.

Overload during acceleration or deceleration (OC3)

Fault OC3 is activated in the case of a too great load during acceleration. The acceleration times or deceleration times (C0012, C0013, C0105) are set too short in proportion to the load.

If a fault occurs, TRIP OC3 is activated. Other responses cannot be set.

Failure of a motor phase (LP1)

If a current-carrying motor phase fails, a motor winding is broken or the current limit value set in C0599 is too high, the LP1 fault is triggered.

The monitoring is not appropriate for field frequencies > 480 Hz and when synchronous servo motors are used. Deactivate the monitoring at these conditions.

The response to exceeding the thresholds can be set under C0597.

**Note!**

The monitoring can only be activated if the function block MLP1 is entered in the processing table (C0465).


8.3.5 Controller current load ($I \times t$ monitoring)

Fig. 8.3-1 $I \times t$ diagram



I_r Device output current

100 % continuous thermal current at C0022 $\leq 1.5 I_r$

70 % continuous thermal current at C0022 $> 1.5 I_r$

The $I \times t$ monitoring monitors the current load of the controller. The current load is calculated from the mean value of the motor current over the acquisition period of 180 s.

The monitoring is set in such a way that the following operation modes are possible:

- ▶ Continuously with device output current = I_r .
- ▶ ≤ 60 s with device output current $\leq 1.5 \times I_r$.

A fault initiates TRIP OC5. Other responses cannot be set.

Configuration	8
Monitoring	8.3
Motor temperature	8.3.6

8.3.6 Motor temperature

KTY at X7 or X8

The motor temperature is monitored with a KTY temperature sensor. Wire the temperature sensor to the resolver cable at X7 or to the encoder cable at X8.

- ▶ Adjustable warning threshold (OH7) via C0121
 - The reset point is 15° C below the adjusted threshold.
- ▶ Fixed warning threshold (OH3) = 150 °C
 - The reset point is at 135° C.

The response to exceeding the thresholds can be set under:

- ▶ C0584 (adjustable threshold)
- ▶ C0583 (fixed threshold)

Monitoring of the KTY at X7 or X8

The SD6 fault is triggered if there is a short or open circuit between X7/8 and X7/9 or X8/5 and X8/8.

The response can be set under C0594.

PTC thermistor or thermal contact (NC contact) at T1, T2

The motor temperature is monitored with a PTC thermistor or thermal contact. Wire the temperature sensor to T1, T2.

- ▶ Fixed warning threshold (OH8)
 - The switch-off threshold and the hysteresis depend on the temperature sensor (DIN 44081).

The response to exceeding the threshold can be set under C0585.



Stop!

Motor could be destroyed!

- ▶ If the responses "Warning" or "Off" are set, the motor could be destroyed by overload.

Protective measure:

- ▶ Set the response "TRIP".

8.3.7 Heatsink temperature

Via a temperature threshold, the heatsink temperature of the controller can be monitored:

- ▶ Adjustable threshold (OH4) under C0122
 - The reset point is 5° C below the adjusted threshold.
- ▶ Fixed threshold (OH) = 85° C
 - The reset point is at 80° C.

The response for exceeding the adjustable threshold can be set under C0582.

8.3.8 DC-bus voltage

In C0173 the mains voltage and DC-bus voltage are set. From this the switching thresholds for overvoltage and undervoltage result.

EVF9335 ... EVF9338 EVF9381 ... EVF9383	Selection C0173	Mains voltage [V AC]	Operation with brake transistor	Message LU (undervoltage)		Message OU (overvoltage)	
				set [V DC]	reset [V DC]	set [V DC]	reset [V DC]
ExV210 ExV240 ExV270 ExV300	0	< 400	yes / no	285	430	770	755
	1	400	yes / no	285	430	770	755
	2	460	yes / no	328	473	770	755
	3	480	no	342	487	770	755
	4	480	yes	342	487	800	785
	5	500	yes / no	342	487	900	885
Ex ExV060 ExV110	read only	400	yes / no	285	430	700	685

C0173 = 1: Lenze setting

Overvoltage

If the DC-bus voltage exceeds the upper switch-off threshold set in C0173, warning OU is activated.

Undervoltage

If the DC-bus voltage falls below the lower switch-off threshold set in C0173, the LU message is triggered.

- ▶ An undervoltage message > 3 seconds is interpreted as an operating state (e.g. mains switched off) and entered in the history buffer. The entry is, however, deleted as soon as the cause has been eliminated (e.g. mains switched on again).

This operating state can occur if the control module is already supplied externally via terminals X5/39 and X5/59, but the mains voltage is not yet switched on.

- ▶ An undervoltage message < 3 seconds is interpreted as a fault (e.g. mains fault), entered in the history buffer and saved.

8.3.9 External error (EEr)

A HIGH signal at DCTRL-TRIP-SET triggers the EEr fault.

You can, for example, connect the digital input DCTRL-TRIP-SET with an input terminal (X5/Ex). In this way an external encoder can trigger the EEr fault.

The response can be set under C0581.

8.4 Overview of monitoring functions

The responses of monitoring functions can be partly parameterised via codes – in GDC in the parameter menu under **Monitoring** –.

Monitoring				Possible responses				
Error message	Description	Source	CoDe	TRIP	Message	Warning	Off	
0071 CCr	System fault	Internal		●				
x091 EEr	External monitoring (activated via DCTRL)	FWM	C0581	●	✓	✓	✓	
Voltage supply								
2020 OU	Overvoltage in the DC bus (C0173)	MCTRL				●		
1030 LU	Undervoltage in the DC bus (C0173)	MCTRL			●			
0107 H07	Internal fault (power section)	Internal		●				
Communication								
x061 CE0	Communication error on the automation interface (AIF)	AIF	C0126	✓		✓	●	
x062 CE1	Communication error at process data input object CAN1_IN (monitoring time can be set with C0357/1)	CAN1_IN	C0591	✓		✓	●	
x063 CE2	Communication error at process data input object CAN2_IN (monitoring time can be set with C0357/2)	CAN2_IN	C0592	✓		✓	●	
x064 CE3	Communication error at process data input object CAN3_IN (monitoring time can be set with C0357/3)	CAN3_IN	C0593	✓		✓	●	
x065 CE4	BUS-OFF state of the system bus (CAN) (too many faulty telegrams)	CAN	C0595	✓		✓	●	
Temperatures / sensors								
0050 OH	Heatsink temperature > 85° C	MCTRL		●				
x053 OH3	Motor temperature > 150° C	MCTRL	C0583	●			✓	
x054 OH4	Heatsink temperature > C0122	MCTRL	C0582		●	✓		
x057 OH7	Motor temperature > C0121	MCTRL	C0584		●	✓		
x058 OH8	Motor temperature across inputs T1 and T2 is too high. Please note: In the case of "Warning" (C0585 = 2) or "Off" (C0585 = 3), the drive can be destroyed if the fault is not eliminated in time!	MCTRL	C0585	✓		✓	●	
x086 Sd6	Thermal sensor error at motor (X7 or X8)	MCTRL	C0594	✓		✓	●	
x110 H10	Thermal sensor error at heatsink	FWM	C0588	●		1)	1)	
x111 H11	Thermal sensor error in the device interior	FWM	C0588	●		1)	1)	
Motor / feedback system								
0011 OC1	Short circuit of motor cable	MCTRL		●				
0012 OC2	Motor cable earth fault	MCTRL		●				
0013 OC3	Overload at acceleration or deceleration	MCTRL		●				

Monitoring					Possible responses				
Error message		Description		Source	CoDe	TRIP	Message	Warning	Off
0015	OC5	I x t overload		MCTRL		●			
x032	LP1	Motor phase failure (current limit can be set in C0599) Please note: Can only be used for asynchronous motors. The function block MLP1 has to be entered in C0465.		MCTRL	C0597	✓		✓	●
x083	Sd3	Interruption of the digital frequency coupling. The input signal "Lamp Control" at X9/8 is LOW Please note: In the case of "Warning" (C0587 = 2), the drive can be destroyed if the fault is not eliminated in time!		MCTRL	C0587	●		✓	✓
x085	Sd5	At analog input X6/1, X6/2, the input current is < 2 mA Monitoring only possible if C0034 = 1		MCTRL	C0598	✓		✓	●
0140	ID1	Motor data identification - characteristic		MCTRL		●			
0141	ID2	Motor data identification - motor data		MCTRL		●			
Speed									
0200	NMAX	Maximum speed (C0596) has been exceeded.		MCTRL		●			
Time-out / overflow									
0105	H05	Intern fault (memory)		Internal		●			
Parameter setting									
0072	PR1	Checksum error in parameter set 1		Internal		●			
0073	PR2	Checksum error in parameter set 2		Internal		●			
0074	PER	Program error		Internal		●			
0075	PRO	Error in the parameter sets		Internal		●			
0077	PR3	Checksum error in parameter set 3		Internal		●			
0078	PR4	Checksum error in parameter set 4		Internal		●			
0079	PI	Fault during the parameter initialisation		Internal		●			

Representation of the error number:

x 0 = TRIP, 1 = message, 2 = warning

E. g. "2091": An external monitoring has triggered EEr warning

1) Setting only permitted by Lenze service

8.5 Code table

How to read the code table:

Column	Abbreviation		Meaning	
Code	Cxxxx		Code Cxxxx	
	1		Subcode 1 of Cxxxx	● Parameter value of the code can be defined differently in each parameter set
	2		Subcode 2 of Cxxxx	● Parameter value is accepted immediately (ONLINE)
	*			Parameter value of the code is the same in all parameter sets
	ENTER			Changed parameter or the code or subcode is accepted after pressing SHIFT PRG
	STOP			Changed parameter of the code or subcode is accepted after pressing SHIFT PRG, if the controller is inhibited
Name			Name of the code	
Lenze			Lenze setting (value on delivery or after restoring the delivery status with C0002)	
	→		The column "IMPORTANT" contains further information	
Selection	1	{%}	99 min. value {unit} max. value	
IMPORTANT	-		Short, important explanations	

Code	Possible settings			IMPORTANT
No.	Name	Lenze	Selection	
C0002	Par load STOP	1		Loading a parameter set
			0	Restore the delivery status
			1	Load PS1
			2	Load PS2
			3	Load PS3
			4	Load PS4
			11	Load ext PS1
			12	Load ext PS2
			13	Load ext PS3
			14	Load ext PS4
			20	ext -> EEPROM
C0003	Par save ENTER	0		Load all parameter sets from the keypad into the controller
			0	Save parameter set
			1	Saving is completed
			2	Save the parameters loaded in the controller into a parameter set (PS1 PS4)
			3	
			4	
	Op display ENTER	56	0	All parameter sets (PS1 PS4) must be transferred from the controller to the keypad XT
				Operating display
				● Keypad shows selected code in the operating level if no other status messages of C0183 are active

Code		Possible settings				IMPORTANT
No.	Name	Lenze	Selection			
C0005 <small>STOP</small>	Signal CFG					Selection of the basic configuration
			1000	0	Common	Modified basic configuration
				100	CFG: empty	All internal connections are removed
				1000	Speed mode	Speed control
				2000	Step mode	Step control
				3000	Lead screw	Traversing control
				4000	Torque mode	Torque control
				5000	DF master	Digital frequency master
				6000	DF slv bus	Master frequency slave (bar)
				7000	DF slv cas	Digital frequency slave (cascade)
				8000	Dancer ctrl e	Dancer position control with external diameter measurement
				9000	Dancer ctrl i	Dancer position control with internal diameter measurement
C0006 <small>STOP</small>	Op mode	5				Selection of the operating mode for the motor control
						In case of the first selection enter the motor data and identify them with C0148.
						6.8-8
						Commissioning without identification of the motor data is possible <ul style="list-style-type: none">● Advantage of identification with C0148: Improved smooth running at low speeds
C0009	LECOM address	1	1	{1}	99	LECOM controller address <ul style="list-style-type: none">● Bus device number when operated via interface● 10, 20 ... 90 reserved for broadcast to device groups with RS232, RS485, optical fibre

Code		Possible settings				IMPORTANT		
No.	Name	Lenze	Selection					
C0010	N _{min}	0	0	{1 rpm}	36000	<ul style="list-style-type: none"> Reference value for the absolute and relative setpoint selection for the acceleration and deceleration times C0059 must be set correctly Set C0010 < C0011 C0010 is only effective in case of analog setpoint selection via AIN1 <p>Important: For parameter setting via interface, major changes in one step should only be made when the controller is inhibited.</p>	Minimum speed	6.10-1
C0011	N _{max}	3000	0	{1 rpm}	36000		Maximum speed	
C0012	Tir (acc)	5.00	0.00	{0.01 s}	9999.90	Acceleration time T _{ir} of the main setpoint	6.10-3	
						<ul style="list-style-type: none"> Refers to speed change 0 ... C0011 		
C0013	Tif (dec)	5.00	0.00	{0.01 s}	9999.90	Deceleration time T _{if} of the main setpoint		
						<ul style="list-style-type: none"> Refers to speed change 0 ... C0011 		
C0014	V/f charact.	0				Characteristic in the V/f characteristic control mode	8.2-25	
			0	Linear		Linear V/f characteristic		
			1	square		Square V/f characteristic		
C0015	Rated freq	50	10	{1 Hz}	5000	V/f-rated frequency In C0015 you can set a base frequency which differs from the rated motor frequency (C0089)	8.2-25	
						<ul style="list-style-type: none"> Lenze setting: C0015 = C0089 Changing C0086 or C0089 overwrites the value in C0015 		
C0016	Umin boost	0.00	0.00	{0.01 %}	100.00	U _{min} boost (FCODE)	6.8-4	
						<ul style="list-style-type: none"> C0016 = 1 % corresponds to a boost of 1 % of the rated motor voltage (C0090) Code is freely configurable 		
C0017	FCODE (Qmin)	50	-36000	{1 rpm}	36000	Q _{min} -switching threshold (FCODE)		
						<ul style="list-style-type: none"> Programmable speed threshold If the current speed is < C0017, CMP1-OUT is activated. Freely configurable code 		

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0018	fchop	6				Switching frequency of the inverter
			1	1 kHz sin	loss-optimised	<ul style="list-style-type: none"> General rule: The lower the switching frequency the <ul style="list-style-type: none"> lower the power loss higher the noise generation better the concentricity factor
			2	2 kHz sin	concentricity-optimised	<ul style="list-style-type: none"> Observe derating indications for high switching frequencies
			3	4 kHz f_top	power-optimised	<ul style="list-style-type: none"> The max. output frequency (f_{max}) is: <ul style="list-style-type: none"> $f_{chop} = 4 \text{ kHz} \Rightarrow f_{max} = 300 \text{ Hz}$ $f_{chop} = 2 \text{ kHz} \Rightarrow f_{max} = 150 \text{ Hz}$ $f_{chop} = 1 \text{ kHz} \Rightarrow f_{max} = 150 \text{ Hz}$
			4	4 kHz sin	noise-optimised	
			6	4/2 kHz sin	noise/concentricity-optimised with automatic change-over to low switching frequency	
C0019	Thresh nact=0	0	-36000	{1 rpm}	36000	Operating threshold - automatic DC injection brake (Auto-GSB) <ul style="list-style-type: none"> Falling below the threshold in C0019 activates automatic DC injection braking when the holding time set under C0107 > 0
C0020	turn value	100	0	{1 %}	200	Influence on concentricity factor <ul style="list-style-type: none"> Manual influence on the concentricity factor of the motor
C0021	slipcomp	→	-20.00	{0.01 %}	20.00	Slip compensation <ul style="list-style-type: none"> Change of C0086, C0087 or C0089 sets C0021 to the calculated rated slip of the motor When changing over to the vector control mode, C0021 is set to 0
C0022	I _{max} current	→	0	{0.1 A}	-	I _{max} limit in motor mode <ul style="list-style-type: none"> → depending on C0086
C0023	I _{max} gen.	→	0	{0.1 A}	-	I _{max} limit in generator mode <ul style="list-style-type: none"> → depending on C0086
C0025 <small>STOP</small>	Feedback type	1				Speed feedback
			1	no feedback	No feedback	
			100	IT (C420) - X8	Input of the number of increments in C0420	Incremental encoder at X8 <ul style="list-style-type: none"> Incremental encoders with TTL level can only be connected to X8.
			101	IT (C420) - X9	Input of the number of increments in C0420	Incremental encoder at X9 <ul style="list-style-type: none"> Connect incremental encoders with HTL-level on X9 only
					Number of increments:	Incremental encoder at X8
			110	IT512-5V	512 inc	<ul style="list-style-type: none"> Incremental encoders with TTL level can only be connected to X8.
			111	IT1024-5V	1024 inc	
			112	IT2048-5V	2048 inc	
			113	IT4096-5V	4096 inc	

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0026			-199.99	{0.01 %}	199.99	Free control code FCODE 26/1 and FCODE26/2 Offset of AIN1 (X6/1, X6/2) Offset of AIN2 (X6/3, X6/4)
1	FCODE (offset)	0.00				
2	FCODE (offset)	0.00				
C0027			-199.99	{0.01 %}	199.99	Free control code FCODE 27/1 and FCODE27/2 Gain AIN1 (X6/1, X6/2) • 100 % = gain 1 Gain AIN2 (X6/3, X6/4) • 100 % = gain 1
1	FCODE (gain)	100.00				
2	FCODE (gain)	100.00				
C0030	DFOUT const	3	0	256 inc/rev		Function block DFOUT • Setting of the constant (increments per revolution) for the master frequency output X10
			1	512 inc/rev		
			2	1024 inc/rev		
			3	2048 inc/rev		
			4	4096 inc/rev		
			5	8192 inc/rev		
			6	16384 inc/rev		
C0032	FCODE Gearbox	1	-32767	{1}	32767	Gearbox factor - numerator of the function block DFSET • Freely configurable code
C0033	Gearbox denom	1	1	{1}	32767	
C0034	Mst current	0	0	-10 V ... +10 V		Voltage / current range for analog signals at input X6/1, X6/2 • Observe jumper position of X3
			1	4 mA ... 20 mA		
			2	-20 mA ... +20 mA		
C0036	DC brk value	0.0	0.0	{0.1 A}	-	Set DC braking current → depends on the controller
C0037	Set-value rpm	0	-36000	{1 rpm}	36000	Setpoint selection
C0038			0	{1 rpm}	36000	Suppress speed ranges, function block NLIM1 • Speed ranges are only run through dynamically • Static behaviour in the inhibited range is suppressed
1	N 1 start	0				
2	N 1 stop	0				
3	N 2 start	0				
4	N 2 stop	0				
5	N 3 start	0				
6	N 3 stop	0				

Code		Possible settings			IMPORTANT		
No.	Name	Lenze	Selection				
C0039			-36000	{1 rpm}	36000	JOG setpoints for the speed setpoint conditioning, function block NSET <ul style="list-style-type: none"> ● Parameter setting of the fixed speeds (JOG setpoints) ● Activation via binary coding of digital input signals in C0787/1 ... C0787/4 ● For coding see description of function block NSET 	
1	JOG set-value	1500				See System Manual (extension)	
2	JOG set-value	1000					
3	JOG set-value	500					
4	JOG set-value	200					
5	JOG set-value	100					
6	JOG set-value	50					
7	JOG set-value	25					
8	JOG set-value	10					
9	JOG set-value	5					
10	JOG set-value	0					
...					
15	JOG set-value	0					
C0040	Ctrl enable	0			Controller enable <ul style="list-style-type: none"> ● Controller can only be enabled if X5/28 = HIGH 	6.4-1	
		0	Ctrl inhibit		Controller inhibited		
		1	Ctrl enable		Controller enabled		
C0042	DIS: QSP				Quick stop <ul style="list-style-type: none"> ● Display only 	8.2-25	
		0	QSP inactive		Quick stop is not active		
		1	QSP active		Quick stop is active	8.2-40	
C0043	Trip reset	0	0	no/trip reset	Reset actual error		
		1	trip active		There is a TRIP error		
C0045	DIS: act JOG		0	Nset active	Nset is active	Active JOG setpoint for the speed setpoint conditioning, function block NSET <ul style="list-style-type: none"> ● Display of the activated fixed speed 	
		1	JOG1		JOG setpoint 1		
		2	JOG2		JOG setpoint 2		
			
		15	JOG15		JOG setpoint 15		
C0046	DIS: N		-199.99	{0.01 %}	199.99	Main setpoint for the speed setpoint conditioning, function block NSET <ul style="list-style-type: none"> ● Read only 	
C0049	DIS: NADD		-199.99	{0.01 %}	199.99	Additional setpoint, function block NSET <ul style="list-style-type: none"> ● Read only 	See System Manual (extension)
C0050	MCTRL-NSET2		-100.00	{0.01 %}	100.00	Speed setpoint, function block MCTRL <ul style="list-style-type: none"> ● Display of the speed in [%] of C0011 	
C0051	MCTRL-NACT		-36000	{1 rpm}	36000	Actual speed value, function block MCTRL <ul style="list-style-type: none"> ● Read only 	8.2-25 8.2-40
C0052	MCTRL-Umot		0	{1 V}	800	Motor voltage, function block MCTRL <ul style="list-style-type: none"> ● Read only ● MCTRL-VACT = 100 % = C0090 	
C0053	UG-VOLTAGE		0	{1 V}	900	DC-bus voltage, function block MCTRL <ul style="list-style-type: none"> ● Read only ● MCTRL-DCVOLT = 100 % = 1000 V 	8.2-25 8.2-40

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0054	Imot		0.0 {0.1 A}	5000.0	Actual motor current, function block MCTRL <ul style="list-style-type: none"> ● Read only ● MCTRL-IACT = 100 % = C0022 	8.2-25 8.2-40
C0056	MCTRL-MSET2		-100.00 {0.01 %}	100.00	Read only. The output signal depends on the operating mode: <ul style="list-style-type: none"> ● Current motor current in case of V/f characteristic control, function block MCTRL1 ● Torque setpoint in case of vector control, function block MCTRL2 	8.2-25 8.2-40
C0057	Max Torque		0 {1 Nm}	5000	Maximum possible torque of the drive configuration <ul style="list-style-type: none"> ● Display only ● With V/f characteristic control depending on C0022, C0086, C0088 ● With vector control depending on C0022, C0086, C0088, C0091 	
C0058	MCTRL-FACT		-600.0 {0.1 Hz}	600.0	Output frequency <ul style="list-style-type: none"> ● Display only ● MCTRL-FACT = 100.0 % = 1000.0 Hz 	8.2-25 8.2-40
C0059	Mot pole no.		1 {1}	50	Pole pair number of the motor <ul style="list-style-type: none"> ● Display only 	
C0061	Heatsink temp		0 {1 °C}	100	Heatsink temperature <ul style="list-style-type: none"> ● Read only ● If the temperature of the heatsink > 85 °C, the controller sets TRIP OH ● Early warning is possible via OH4, temperature is set in C0122 	See System Manual (extension)
C0063	Mot temp		0 {1 °C}	200	Motor temperature <ul style="list-style-type: none"> ● Read only ● Monitoring of the motor temperature must be activated. ● KTY at X8/5, X8/8: – At 150 °C, TRIP OH3 is set – Early warning is possible via OH7, temperature is set in C0121 ● PTC, thermal contact at T1, T2: – Release sets TRIP or warning OH8 	8.2-25 8.2-40
C0064	Utilization		0 {1 %}	150	Device utilisation Ixt <ul style="list-style-type: none"> ● Read only ● Device utilisation of the last 180 s operating time ● C0064 > 100 % triggers warning OC5 ● C0064 > 110 % limits the output current of the controller to 67 % of the maximum current in C0022 	8.2-25 8.2-40
C0067	Act trip		Selection list 10		Momentary fault message <ul style="list-style-type: none"> ● Display only 	

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0070	Vp speed CTRL	10.0	0.0	{0.1 }	255.9	Gain of speed controller	8.2-25
C0071	Tn speed CTRL	50	1	{1 ms}	6000	Integral-action time of speed controller C0071 = 6000 ms: No integral-action time	8.2-40
C0074	limit N	10.00	0.00	{0.01 %}	100.00	Limitation of the speed controller <ul style="list-style-type: none">● Influence of the speed controller for V/f characteristic control with feedback● max. setpoint difference in percent	8.2-25 8.2-40
C0075	Vp curr CTRL	0.04	0.00	{0.01 }	0.99	Gain of current controller <ul style="list-style-type: none">● Vector control: Gain of current controller● V/f characteristic control: Maximum current controller	8.2-25 8.2-40
C0076	Tn curr CTRL	10.0	0.1	{0.1 ms}	2000.0	Integral-action time of current controller <ul style="list-style-type: none">● Vector control: integral-action time of current controller● V/f characteristic control: maximum current controller● C0076 = 2000 ms: current controller is switched off	8.2-25 8.2-40
C0077	Ti field CTRL	4.0	0.3	{0.1 ms}	6000.0	Integral-action time of field controller <ul style="list-style-type: none">● Only active in case of vector control with feedback	
C0078	Tn slip CTRL	100	1	{1 ms}	6000	Integral-action time of slip controller <ul style="list-style-type: none">● Filter time for slip compensation (C0021)● Only active with V/f characteristic control	8.2-25
C0079	Adapt I-CTRL	100.00	10.00	{0.01 %}	100.00	Adaption of the current controller <ul style="list-style-type: none">● Evaluation for the reset time T_{ni} of the current controller● Effective for setpoint = 0● Is increased automatically to 100 % up to rated speed● C0079 = 100 %: no adaption of the reset time● C0079 < 100 %: – evaluation of the reset time:	8.2-25 8.2-40
C0080	Vp field CTRL	0.50	0.00	{0.01 }	0.99	Influence on the motor magnetising current selected under C0095 <ul style="list-style-type: none">● Not effective with C0006 = 1 and C0025 > 1 at the same time● Influence is effective from 0 Hz to the frequency selected under C1583	6.6-1
C0081 	Mot power	→	0.01	{0.01 kW}	500.00	Rated motor power → Change of C0086 resets value to factory setting <ul style="list-style-type: none">● Change of C0081 sets C0086 = 0	

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0082 STOP	Mot Rr	→	0.0000	{0.0001 Ω}	65.5350	<p>Motor rotor resistance → Value is determined by motor parameter identification from C0087, C0088, C0089, C0090 and C0091</p> <ul style="list-style-type: none"> • Selection of a motor in C0086 sets the corresponding rotor resistance value
C0084 STOP	Mot Rs	→	0.00	{0.01 mΩ}	100000.00	<p>Motor stator resistance → Value is determined by motor parameter identification (C0148, C0149)</p>
C0085 STOP	Mot Lss	→	0.00	{0.01 mH}	6553.50	<p>Motor leakage inductance → Value is determined by motor parameter identification (C0148, C0149)</p>
C0086 STOP	Mot type	→	Motor selection list			<p>Motor type selection → depending on the controller used</p> <ul style="list-style-type: none"> • Motor selection in C0086 sets the corresponding parameters in C0021, C0022, C0081, C0087, C0088, C0089, C0090, C0091
C0087 STOP	Mot speed	→	50	{1 rpm}	36000	<p>Rated motor speed → depending on C0086</p> <ul style="list-style-type: none"> • Motor selection in C0086 set the corresponding rated motor speed in C0087 • Change of C0087 sets C0086 = 0
C0088 STOP	Mot current	→	0.5	{0.1 A}	1000.0	<p>Rated motor current → depending on C0086</p> <ul style="list-style-type: none"> • Motor selection in C0086 sets the corresponding rated motor current in C0088 • Change of C0088 sets C0086 = 0
C0089 STOP	Mot frequency	→	10	{1 Hz}	5000	<p>Rated motor frequency → depending on C0086</p> <ul style="list-style-type: none"> • Motor selection in C0086 sets the corresponding rated motor frequency in C0089 • Change of C0089 sets C0086 = 0
C0090 STOP	Mot voltage	→	0	{1 V}	1000	<p>Rated motor voltage → depending on C0086</p> <ul style="list-style-type: none"> • Motor selection in C0086 sets the corresponding rated motor voltage in C0090 • Change of C0090 sets C0086 = 0
C0091 STOP	Mot cos phi	→	0.50	{0.01 }	1.00	<p>Motor cos φ → depending on C0086</p> <ul style="list-style-type: none"> • Motor selection in C0086 sets the corresponding motor cos φ in C0091 • Change of C0091 sets C0086 = 0

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0092 <small>STOP</small>	Mot Ls	→	0.00	{0.01 mH}	6553.50	Motor stator inductance → Value is determined by motor parameter identification from C0088, C0089, C0090 and C0091 → Motor selection in C0086 sets corresponding stator inductance value in C0092
C0093	Drive ident		0	Invalid		Controller identification ● Read only
			1	None		Defective power section
			14	9335VC 400V		No power section
				Display of the controller used
			20	9383VC 400V		
			21	9334VC 500V		
				
			28	9383VC 500V		
			9321	9321 VC		
				
C0094	Password	0	0	{1}	9999	Password ● C0094 = 1 ... 9999: Free access to the user menu only
C0095 <small>STOP</small>	Mot Io	→	0.0	{0.1 A}	1000.0	Motor magnetising current → dependent on C0086, C0088 and C0091 ● Change of C0086 sets C0095 to the Lenze setting ● Change of C0095 sets C0086 = 0
C0096			0	no protection	No password protection	Parameter access protection ● Extension of the access protection for AIF bus systems and CAN with activated password in C0094
			1	R protection	Read protection	
			2	W protection	Write protection	
			3	R/W protection	Read/write protection	● All codes in the user menu can continued to be accessed.
1	AIF protect.	0				Parameter access protection AIF
2	CAN protect.	0				Parameter access protection CAN
C0099	S/W version		x.y	Main version		Software version ● Read only
			x	Subversion		

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0101			0.00	{0.01 s}	999.90	Additional acceleration times for speed setpoint conditioning, function block NSET See System Manual (extension)
1	add Tir	0.00				• Additional acceleration and deceleration times for the main setpoint
2	add Tir	0.00				• Activation via binary coding of digital input signals in C0788/1 ... C0788/4
...				• For coding see description of function block NSET
15	add Tir	0.00				
C0103			0.00	{0.01 s}	999.90	Additional deceleration times for speed setpoint conditioning, function block NSET See System Manual (extension)
1	add Tif	0.00				• Additional acceleration and deceleration times for the main setpoint
2	add Tif	0.00				• Activation via binary coding of digital input signals in C0788/1 ... C0788/4
...				• For coding see description of function block NSET
15	add Tif	0.00				
C0104	select accel. <small>STOP</small>	0				Selection of acceleration function of the linear ramp function generator of NSET See System Manual (extension)
		0	a = const			Constant acceleration
		1	t = const			Constant time
		2	s = const			Constant path
C0105	QSP Tif	5.00	0.00	{0.01 s}	999.90	Quick stop deceleration time • The deceleration time refers to a speed variation of C0011 ... 0 8.2-25 8.2-40
C0107	holding time	0.00	0.00	{0.01 s}	9999.90	Hold time for automatic DC injection braking (Auto-GSB) 8.2-25 8.2-40
C0108			-199.99	{0.01 %}	199.99	Free control code FCODE108/1 and FCODE108/2 See System Manual (extension)
1	FCODE (gain)	100.00				Gain of analog output signal AOUT1 (X6/62) • 100 % = gain 1
2	FCODE (gain)	100.00				Gain of analog output signal AOUT2 (X6/63) • 100 % = gain 1
C0109			-199.99	{0.01 %}	199.99	Free control code FCODE109/1 and FCODE109/2
1	FCODE (offset)	0.00				Offset of analog output signal AOUT1 (X6/62)
2	FCODE (offset)	0.00				Offset of analog output signal AOUT2 (X6/63)
C0114			0	High active	HIGH level is active	Inversion of digital input signals at X5, function block DIGIN See System Manual (extension)
			1	LOW active	LOW level is active	
1	DIGIN1 pol	0				Terminal X5/E1
2	DIGIN2 pol	0				Terminal X5/E2
3	DIGIN3 pol	0				Terminal X5/E3
4	DIGIN4 pol	1				Terminal X5/E4
5	DIGIN5 pol	0				Terminal X5/E5
5	DIGIN6 (ST) pol	0				Terminal X5/ST

Code		Possible settings			IMPORTANT		
No.	Name	Lenze	Selection				
C0116 <small>STOP</small>				□ Selection list 2	Configuration of free digital outputs (FDO) ● Signals can only be evaluated when being networked with automation interfaced	See System Manual (extension)	
1	CFG: FDO-0	1000	FIXED0				
...				
32	CFG: FDO-31	1000	FIXED0				
C0117 <small>STOP</small>				□ Selection list 2	Configuration of digital inputs signals, function block DIGOUT A change of the basic configuration in C0005 changes the signal assignment!	□ 6.5-3 See System Manual (extension)	
1	CFG: DIGOUT1	15000	DCTRL-TRIP		Terminal X5/A1		
2	CFG: DIGOUT2	10650	CMP1-OUT		Terminal X5/A2		
3	CFG: DIGOUT3	500	DCTRL-RDY		Terminal X5/A3		
4	CFG: DIGOUT4	5003	MCTRL-MMAX		Terminal X5/A4		
C0118		0	High active	HIGH level is active	Inversion of digital output signals, function block DIGOUT		
		1	LOW active	LOW level is active			
1	DIGOUT1 pol	1			Terminal X5/A1		
2	DIGOUT2 pol	1			Terminal X5/A2		
3	DIGOUT3 pol	0			Terminal X5/A3		
4	DIGOUT4 pol	0			Terminal X5/A4	□ 6.6-11 See System Manual (extension)	
C0121	OH7 limit	150	45	{1 °C}	150		
C0122	OH4 limit	80	45	{1 °C}	85	Setting of the operating temperature for monitoring OH7 ● Only for KTY at X8 ● Monitoring OH7 is configured in C0584	See System Manual (extension)
						Configuration of monitoring OH4 ● Monitoring of the heatsink temperature ● Activating monitoring with C0582 ● Temperature in C0122 reached: – Warning OH4 is initiated	
C0125	Baudrate	0	0	9600 baud	LECOM baud rate	● Baud rate for accessory module 2102	
			1	4800 baud			
			2	2400 baud			
			3	1200 baud			
			4	19200 baud			
C0126	MONIT CEO	3	0	TRIP	Configuration of monitoring CEO	See System Manual (extension)	
			2	Warning	● Error message in case of communication error AIF		
			3	Off			
C0130	DIS: act Ti		0	C12/C13	Active T_i times for the speed setpoint conditioning, function block NSET	See System Manual (extension)	
			1	Tir1/Tif1	● Display of the additional acceleration and deceleration times for the main setpoint (C0101, C0103)		
			2	Tir2/Tif2	● Activation via binary coding of C0788/1 ... C0788/4		
					
			14	Tir14/Tif14			
			15	Tir15/Tif15			
C0132 <small>STOP</small>	RFG fly delay				May only be changed by Lenze service personnel!		
C0133 <small>STOP</small>	HLG fly delay				May only be changed by Lenze service personnel!		

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0134	RFG charac	0	0	Linear	linear characteristic	Ramp function generator characteristic, function block NSET ● Characteristic of the main setpoint
			1	S-shaped	S-shaped characteristic	
C0135	Control word	0	Bit	Assignment		Control word, function block AIF ● Decimal control word when networked via automation interface AIF ● 16-bit information, binary coded
			0	reserved		
			1	reserved		
			2	reserved		
			3	Quick stop		
			4	reserved		
			5	reserved		
			6	reserved		
			7	reserved		
			8	Operation inhibited		
			9	Controller inhibit		
			10	TRIP SET		
			11	Trip reset		
			12	reserved		
			13	reserved		
			14	reserved		
			15	reserved		
C0136						Display of the control words in C0135, AIF-IN and CAN-IN1
	1 Ctrl wrd C135					Control word C0135
	2 Ctrl wrd CAN					Control word CAN
	3 Ctrl wrd AIF					Control word AIF
C0141	FCODE (setval)	0.00	-199.9	{0.01 }	199.99	Main setpoint, freely configurable code (FCODE) ● Used as main setpoint in the basic configurations C0005 = xxxx
C0142	Start options					May only be changed by Lenze service personnel!
C0143	limit 2 kHz	0.0	0.0	{0.1 Hz}	20.0	Speed-dependent switching threshold ● Threshold for automatic switching frequency reduction ● The controller changes automatically to 2 kHz when this value falls below the threshold
C0144	OH switch 	1	0	Switch off	Switch-over is not active	Temperature-dependent switching frequency reduction ● If the heatsink temperature set in C0122 is reached (warning OH4), the controller switches to 2 kHz
			1	Switch on	Switch-over is active	
C0145	select ref 					May only be changed by Lenze service personnel!
C0146	fly current					May only be changed by Lenze service personnel!
C0147	fly dt-f					May only be changed by Lenze service personnel!

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0148 	ident run	0	0	WRK stop	Ready	<p>Motor data identification</p> <ol style="list-style-type: none"> Inhibit controller, wait until drive has stopped Enter the correct values of the motor nameplate into C0087, C0088, C0089, C0090, C0091 Set C0148 = 1, confirm with  Enable controller <p>The identification</p> <ul style="list-style-type: none"> starts,  goes off. The motor "whistles" but does not rotate! lasts approx. 1 ... 2 min is completed when  is lit again <p>5. Inhibit controller:</p>	
				1	WRK run	Start identification	
C0149 	Auto ident	0	0	Id inactive	Automatic identification is inactive	<p>Automatic motor data identification</p> <ol style="list-style-type: none"> Inhibit controller, wait until drive has stopped Enter the correct values of the motor nameplate into C0087, C0088, C0089, C0090, C0091 Set C0149 = 1, confirm with  Enable controller <p>The identification</p> <ul style="list-style-type: none"> starts,  goes off. The motor "whistles" but does not rotate! lasts approx. 1 ... 2 min is completed when  is lit again <p>5. Inhibit controller:</p>	
				1	Id active	Automatic identification is active <ul style="list-style-type: none"> The identification starts automatically after controller enable After a faulty identification, the process is restarted after TRIP RESET or mains switching and subsequent controller enable 	
C0150	Status word		Bit00	–	Bit08	Status code	<p>Read only</p> <p>Decimal status word for networking via automation interface (AI)</p> <ul style="list-style-type: none"> Binary interpretation indicates the bit states
			Bit01	IMP	Bit09	Status code	
			Bit02	–	Bit10	Status code	
			Bit03	–	Bit11	Status code	
			Bit04	–	Bit12	Warning	
			Bit05	–	Bit13	Message	
			Bit06	n = 0	Bit14	–	
			Bit07	CINH	Bit15	–	
C0151	DIS: FDO (DW)						<p>Read only</p> <ul style="list-style-type: none"> Free digital outputs (FDO) Hexadecimal representation of the digital output signals configured in C0116 Binary interpretation indicates the bit states
C0155	Status word 2		Bit00	Fail	Bit08	R/L	<p>Display only</p> <ul style="list-style-type: none"> Binary interpretation indicates the bit states
			Bit01	M _{max}	Bit09	–	
			Bit02	I _{max}	Bit10	–	
			Bit03	IMP	Bit11	–	
			Bit04	RDY	Bit12	–	
			Bit05	CINH	Bit13	–	
			Bit06	TRIP	Bit14	–	
			Bit07	Init	Bit15	–	

Code		Possible settings		IMPORTANT
No.	Name	Lenze	Selection	
C0156 STOP				<p>□ Selection list 2</p> <p>Configuration of digital input signals of function block STAT</p> <ul style="list-style-type: none"> Input signals are output as status messages in C0150, AIF status word and CAN1 status word
1	CFG: STAT.B0	2000	DCTRL-PAR*1-O	
2	CFG: STAT.B2	5002	MCTRL-IMAX	
3	CFG: STAT.B3	5003	MCTRL-MMAX	
4	CFG: STAT.B4	5050	NSET-RFG I=O	
5	CFG: STAT.B5	10650	CMP1-OUT	
6	CFG: STAT.B14	505	DCTRL-CW/CCW	
7	CFG: STAT.B15	500	DCTRL-RDY	
C0157		0	No status message	<p>Digital status signal of function block STAT</p> <ul style="list-style-type: none"> Display of the signals linked in C0156
		1	Status message is output	
1	DIS: STAT.B0			
2	DIS: STAT.B2			
3	DIS: STAT.B3			
4	DIS: STAT.B4			
5	DIS: STAT.B5			
6	DIS: STAT.B14			
7	DIS: STAT.B15			
C0161	Act trip			Display of history buffer "Active fault" <ul style="list-style-type: none"> Keypad: LECOM error number
C0167	Reset failmem	0	0 Ready	Clear history buffer
		1	Clear history buffer	• Active fault messages are not cleared
				See System Manual (extension)
				See System Manual (extension)

Code		Possible settings		IMPORTANT
No.	Name	Lenze	Selection	
C0168				<p>Display of the fault messages in the history buffer</p> <ul style="list-style-type: none"> ● Keypad: LECOM error number <p>See System Manual (extension)</p>
	1 Fail no. act			Active fault
	2 Fail no. old1			Last fault
	3 Fail no. old2			Second to last fault
	4 Fail no. old3			Third last fault
	5 Fail no. old4			Fourth-last fault
	6 Fail no. old5			Fifth-last fault
	7 Fail no. old6			Sixth-last fault
	8 Fail no. old7			Last but six fault
C0169		Display in [s]		<p>Displays at what time the fault (C0168) has occurred since mains connection (C0179)</p> <ul style="list-style-type: none"> ● If a fault is followed by another fault for several times, only the time of the last occurrence is stored
	1 Failtime act			Active fault
	2 Failtime old1			Last fault
	3 Failtime old2			Second to last fault
	4 Failtime old3			Third last fault
	5 Failtime old4			Fourth-last fault
	6 Failtime old5			Fifth-last fault
	7 Failtime old6			Sixth-last fault
	8 Failtime old7			Last but six fault
C0170				<p>Displays how many times the fault (C0168) has occurred after the last mains connection</p>
	1 Counter act			Active fault
	2 Counter old1			Last fault
	3 Counter old2			Second to last fault
	4 Counter old3			Third last fault
	5 Counter old4			Fourth-last fault
	6 Counter old5			Fifth-last fault
	7 Counter old6			Sixth-last fault
	8 Counter old7			Last but six fault

Code		Possible settings			IMPORTANT		
No.	Name	Lenze	Selection				
C0173 STOP	UG limit	1			<p>Check during commissioning and adapt, if necessary! All controllers in the system must have the same threshold!</p> <ul style="list-style-type: none"> • Adaptation of UG thresholds • Only display in case of the variants for 400 V mains (EVF93xx-EV, EVF93xx-EVV030, EVF93xx-EVV060, EVF93xx-EVV110): <ul style="list-style-type: none"> – C0173 = 1 – OU = 700 ... 685 V 	12-1 See System Manual (extension)	
			Mains	LU	OU		
		0	< 400 V	285 V	770 ... 755 V	Device with or without brake transistor	
		1	400 V	285 V	770 ... 755 V		
		2	460 V	328 V	770 ... 755 V		
		3	480 V	342 V	770 ... 755 V		
		4	480 V	342 V	800 ... 785 V		
		5	500 V	342 V	900 ... 885 V		
C0174	BR Limit	3			<p>Display of the brake transistor thresholds</p> <p>Check during commissioning and adapt, if necessary! All controllers connected to the bus must have the same threshold!</p>	12-1 See System Manual (extension)	
			Mains	U _{BR}	OU		
		0	400 V	685 V	700 V	Only display in case of the variants for 400 V mains (EVF93xx-EV, EVF93xx-EVV030, EVF93xx-EVV060, EVF93xx-EVV110)	
		1	400 V / 460 V	755 V	770 V	Only in case of the variants for 400 V/500 V mains (EVF93xx-EVV210, EVF93xx-EVV240, EVF93xx-EVV270, EVF93xx-EVV300)	
		2	480 V	785 V	800 V		
		3	500 V	885 V	900 V		
C0178	Op timer			{s}	Display only Total time of the controller enable (X5/28 = HIGH)		
C0179	mainstimer			{s}	Display only Total time of mains "ON"		
C0182	Ti S-shaped	20.00	0.01	{0.01 s}	50.00	Integration time of S-shaped ramp function generator, function block NSET <ul style="list-style-type: none"> • C0182 = 0.00: ramp function generator operates linearly • C0182 > 0.00: ramp function generator operates in an S-shape (without jerk) 	See System Manual (extension)

Code		Possible settings		IMPORTANT	
No.	Name	Lenze	Selection		
C0183	Diagnostics		0 No fault 101 Initialisation 102 TRIP/fault 103 Emergency stop 104 IMP message 105 Power OFF 111 Operation inhibit via C0135 112 Operation inhibit via AIF 113 Operation inhibit via CAN 121 Controller inhibited via X5/28 122 Controller inhibited internally (DCTRL-CINH1) 123 Controller inhibited internally (DCTRL-CINH2) 124 Controller inhibited via STOP at the keypad 125 Controller inhibited via AIF 126 Controller inhibited via CAN 141 Switch-on inhibit 142 Pulse inhibit IMP 151 Quick stop via MCTRL-QSP 152 Quick stop via STOP at the keypad 153 Quick stop via AIF 154 Quick stop via CAN 161 DC injection braking via terminal 162 DC injection braking via C0135 163 DC injection braking via AIF 164 DC injection braking via CAN 170 Motor parameter identification is active 250 Warning is active (C0168)	Diagnostics <ul style="list-style-type: none"> ● Display only ● If several items or fault or status information are to be shown, the information with the smallest number is displayed 	7.2-10
				Function is not supported	
C0190	NSET arit	0	0 OUT = C46 1 C46 + C49 2 C46 - C49 3 C46 * C49 4 C46 / C49 5 C46/(100 - C49)	Arithmetic function, function block NSET Connects main setpoint (C0046) and additional setpoint (C0040)	See System Manual (extension)

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0195	BRK1 T act	99.9	0.0	{0.1 s}	99.9	Brake closing time, function block BRK1 <ul style="list-style-type: none"> ● C0195 = 99.9 s: infinite ● After the time has elapsed in C0195, the status "brake applied" is reached
C0196	BRK1 T release	0.0	0.0	{0.1 s}	60.0	Brake opening time, function block BRK1 <ul style="list-style-type: none"> ● Opening time can be obtained from the technical data of the brake ● After the time has elapsed in C0196, the status "brake released" is reached
C0200	S/W Id	x	Main version		Software ID	
		y	Subversion		● Display only	
		S9300MVxy000			9300 vector 0.37 ... 90 kW	
		S9300MVxy020			9300 vector 110 ... 400 kW	
C0201	S/W date	xxx yy zzzz	xxx = month yy = day zzzz = year		Software creation	
					● Display only	
C0202					Internal identification	
					● Display only	
C0203					Commission number	
					● Display only	
C0204					Serial number	
					● Display only	
C0206	Product date	xx/yy/zz			Date of production	
					● Display only	
					● xx = day, yy = month, zz = year	
C0207	DL info 1				Download info 1	
					● Display only	
C0208	DL info 2				Download info 2	
					● Display only	
C0209	DL info 3				Download info 3	
					● Display only	
C0220	NSET Tir add	2.00	0.00	{0.01 s}	9999.90	Acceleration time T_{ir} for additional setpoint, function block NSET <ul style="list-style-type: none"> ● The acceleration time refers to a speed variation of 0 ... C0011
C0221	NSET Tif add	2.00	0.00	{0.01 s}	9999.90	Deceleration time T_{if} for additional setpoint, function block NSET <ul style="list-style-type: none"> ● The deceleration time refers to a speed variation of C0011 ... 0
C0222	PCTRL Vp	1.0	0.1	{0.1 }	500.0	Gain V_p , function block PCTRL1
C0223	PCTRL1 Tn	400	20	{1 ms}	99999	Integral action component T_n , function block PCTRL1 <ul style="list-style-type: none"> ● C0223 = 99999 ms: no integral action component
C0224	PCTRL1 Kd	0.0	0.0	{0.1 }	5.0	Differential component K_d , function block PCTRL1
C0234	damp value	20	-100	{1 %}	100	Influence of the oscillation damping, function block MCTRL <ul style="list-style-type: none"> ● Minimising a tendency to oscillation of the drive ● Influences the tendency to oscillation of the drive ● When C0025 >1 and C0006 = 1, C0234 is set to 0

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0235	damping	2	1	{1 ms}	600	Filter time of the oscillation damping, function block MCTRL <ul style="list-style-type: none"> ● Filter time for the internal signal for oscillation damping
C0236	damp limit	1.0	0.0	{0.1 Hz}	20.0	Limit value of oscillation damping, function block MCTRL <ul style="list-style-type: none"> ● Limit value for the internal signal of oscillation damping
C0241	Cmp-RFG-l=0	1.00	0.00	{0.01 %}	100.00	Speed threshold in [%] for the digital output NSET-controller enable-l=0, function block NSET <ul style="list-style-type: none"> ● The analog signals NSET-NOUT (without arithmetic and limiting functions) and NSET-controller enable-l are compared ● NSET-controller enable-l=0 = HIGH: the differential signal between NSET-NOUT and NSET-controller enable-l falls below the value in C0241 ● C0241 = 100 %: n_{max}
C0244	BRK1 M set	0.00	0.00	{0.01 %}	100.00	Holding torque, function block BRK1 <ul style="list-style-type: none"> ● C0244 = 100 % = C0057
C0250	FCODE 1 Bit	0	0		1	Free control code FCODE250
C0252	Angle offset	0	-245760000	{1 inc.}	245760000	Phase offset for master frequency processing, function block DFSET <ul style="list-style-type: none"> ● Fixed phase offset for digital frequency configuration ● 1 rev. = 65536 inc
C0253	Angle n-trim	→	-32767	{1 inc.}	32767	Speed-dependent phase trimming for the master frequency processing, function block DFSET → depending on C0005, C0025, C0490 <ul style="list-style-type: none"> ● Change of C0005, C0025 or C0490 resets C0253 to the corresponding Lenze setting ● 1 rev. = 65536 inc ● Value in C0253 is reached at 15000 rpm

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0260	MPOT1 high	100.00	-199.99	{0.01 %}	199.99	Upper limit, function block MPOT1 ● Condition: C0260 > C0261	See System Manual (extension)
C0261	MPOT1 low	-100.0	-199.99	{0.01 %}	199.99	Lower limit, function block MPOT1 ● Condition: C0261 < C0260	
C0262	MPOT1 TIR	10.0	0.1	{0.1 s}	6000.0	Acceleration time T_{ir} , function block MPOT1 ● The set time refers to a change of 0 ... 100 %	
C0263	MPOT1 Tif	10.0	0.1	{0.1 s}	6000.0	Deceleration time T_{if} , function block MPOT1 Motor potentiometer ● The set time refers to a change of 100 ... 0 %	
C0264	MPOT1 on/off	0	0	no change		Deactivation of motor potentiometer, function block MPOT1	
			1	Deceleration with T_{if} to 0%		● Function is executed when MPOT1-INACT = HIGH	
			2	Deceleration with T_{if} to C0261			
			3	Jump with T_{if} = 0 to 0%			
			4	Jump with T_{if} = 0 to C0261			
			5	Acceleration with T_{ir} to C0260			
C0265	MPOT1 init	0	0	Value of MPOT1 when mains fails		Initialisation of motor potentiometer, function block MPOT1	
			1	lower limit of C0261		● Starting value which is to be accepted during mains switching and activated motor potentiometer	
			2	0 %			
C0267 <small>STOP</small>				■ Selection list 2	Configuration of digital input signals, function block MPOT	UP DOWN MPOT1-OUT	See System Manual (extension)
1	CFG: UP	1000	FIXED0			0 0 —	
						0 1 ↓	
						1 0 ↑	
						1 1 —	
2	CFG: DOWN	1000	FIXED0			↑: Output signal runs to the upper limit value ↓: Output signal runs to the lower limit value —: Output signal is unchanged	
C0268 <small>STOP</small>	CFG: INACT	1000	FIXED0	■ Selection list 2	Configuration of digital input signal, function block MPOT	● HIGH: motor potentiometer is not active. Output signal runs to 0	
C0269					Digital input signals, function block MPOT	● Display of the signals linked in C0267 and C0268	
1	DIS: UP						
2	DIS: DOWN						
3	DIS: INACT						

Code		Possible settings			IMPORTANT			
No.	Name	Lenze	Selection					
C0325	Vp2 adapt	1.0	0.1	{0.1 }	500.0	Function block PTCTRL1 ● Adaptation of gain V_{p2}		
C0326	Vp3 adapt	1.0	0.1	{0.1 }	500.0	Function block PTCTRL1 ● Adaptation of gain V_{p3}		
C0327	Set2 adapt	100.00	0.00	{0.01 %}	100.00	Function block PTCTRL1 ● Adaptation of setpoint speed threshold n_{set2} ● Condition: C0327 > C0328		
C0328	Set1 adapt	0.00	0.00	{0.01 %}	100.00	Function block PTCTRL1 ● Adaptation of setpoint speed threshold n_{set1} ● Condition: C0328 < C0327		
C0329	Adapt on/off	0	0	No adaptation of the process controller		Function block PTCTRL1 ● Adaptation On/Off		
			1	External adaptation via input				
			2	Adaptation via setpoint				
			3	Adaptation via control difference				
C0332	PCTRL Tir	0	0	{1 s}	10000	Acceleration time T_{ir} , function block PCTRL1 ● The acceleration time refers to a setpoint change of 0 ... 100 %		
C0333	PCTRL1 Tif	0	0	{1 s}	10000	Deceleration time T_{if} , function block PCTRL1 ● The deceleration time refers to a setpoint change of 100 % ... 0		
C0336	DIS: act Up		0.0	{0.1 }	500.0	Current gain V_p , function block PCTRL1 ● Read only		
C0337	Bi/unipolar	0				Sphere of action, function block PCTRL1		
			0	Bipolar		● Output value is limited to -100 ... 100 %		
			1	Unipolar		● Output value is limited to 0 ... 100 %		
C0338	ARIT1 funct	1	0	OUT = IN1		Selection of function, function block ARIT1		
			1	OUT = IN1 + IN2				
			2	OUT = IN1 - IN2				
			3	OUT = IN1 * IN2				
			4	OUT = IN1 / IN2				
			5	OUT = IN1 / (100 - IN2)				
C0339 <small>STOP</small>				□ Selection list 1		Configuration of analog input signals, function block ARIT1		
1	CFG: IN	1000	FIXED0%			ARIT1-IN1		
2	CFG: IN	1000	FIXED0%			ARIT1-IN2		
C0340			-199.99	{0.01 %}	199.99	Function block ARIT1 ● Display of the signals linked in C0339		
						ARIT1-IN1		
						ARIT1-IN2		
C0350	CAN address	1	1	{1}	63	System bus node address ● Change is effective after "Reset node" command		

Code		Possible settings			IMPORTANT
No.	Name	Lenze	Selection		
C0351	CAN baudrate	0	0	500 kbit/s	System bus baud rate ● Change is effective after "Reset node" command
			1	250 kbit/s	
			2	125 kbit/s	
			3	50 kbit/s	
			4	1000 kbit/s	
C0352	CAN mst	0	0	Slave	Configuration of the system bus nodes ● Change is effective after "Reset node" command
			1	Master	
C0353			0	C0350 is the source	Source of the system bus address
			1	C0354 is the source	
1	CAN addr sel1	0			CAN IN1, CAN-OUT1
2	CAN addr sel2	0			CAN IN2, CAN-OUT2
3	CAN addr sel3	0			CAN IN3, CAN-OUT3
C0354			1	{1}	512 Selective system bus address ● Individual addressing of the system bus process data objects
1	IN1 addr 2	129			CAN-IN1
2	OUT1 addr 2	1			CAN-OUT2
3	IN2 addr 2	257			CAN-IN2
4	OUT2 addr 2	258			CAN-OUT2
5	IN3 addr 2	385			CAN-IN3
6	OUT3 addr 2	386			CAN-OUT3
C0355			0	{1}	2047 System bus identifier ● Read only
1	CAN-IN1 Id				
2	CAN-OUT1 Id				
3	CAN-IN2 Id				
4	CAN-OUT2 Id				
5	CAN-IN3 Id				
6	CAN-OUT3 Id				
C0356		0		{1 ms}	65000 System bus time settings
1	CAN boot-up	3000			Required for CAN interconnection without master
2	OUT2 cycle	0			0 = event-controlled process data transfer >0 = cyclic process data transfer
3	OUT3 cycle	0			
4	CAN delay	20			When the NMT state "Operational" (after "Pre-operational" or "Stopped") has been reached, the delay time "CANdelay" is started. After the delay time has elapsed, the PDO's CAN-OUT2 and CAN-OUT3 are sent for the first time.
C0357		0		{1 ms}	65000 System bus monitoring times ● After a fault message, the CAN objects remain in receive mode
1	CE1monit time	3000			CAN-IN1
2	CE2monit time	3000			CAN-IN2
3	CE3monit time	3000			CAN-IN3
C0358	Reset node	0	0	No function	Set the nodal reset point of the system bus
			1	CAN reset	

Code		Possible settings		IMPORTANT
No.	Name	Lenze	Selection	
C0359	CAN state		0 Operational	System bus status ● Read only
			1 Pre-operational	
			2 Warning	
			3 Bus off	
C0360			0	65535 Telegram counter ● Read only ● For count values > 65535 the counter starts at 0
	1 Message OUT			All telegrams sent
	2 Message IN			All telegrams received
	3 Message OUT1			Telegrams sent on CAN-OUT1
	4 Message OUT2			Telegrams sent on CAN-OUT2
	5 Message OUT3			Telegrams sent on CAN-OUT3
	6 Message POUT1			Telegrams sent on parameter channel1
	7 Message POUT2			Telegrams sent on parameter channel2
	8 Message IN1			Telegrams received from CAN-IN1
	9 Message IN2			Telegrams received from CAN-IN2
	10 Message IN3			Telegrams received from CAN-IN3
	11 Message PIN1			Telegrams received from parameter channel1
	12 Message PIN2			Telegrams received from parameter channel2
C0361			0 {1 %}	100 System bus load ● Read only ● For a perfect operation, the entire bus load (all nodes connected) should be less than 80 %
	1 Load OUT			All telegrams sent
	2 Load IN			All telegrams received
	3 Load OUT1			Telegrams sent on CAN-OUT1
	4 Load OUT2			Telegrams sent on CAN-OUT2
	5 Load OUT3			Telegrams sent on CAN-OUT3
	6 Load POUT1			Telegrams sent on parameter channel1
	7 Load POUT2			Telegrams sent on parameter channel2
	8 Load IN1			Telegrams received from CAN-IN1
	9 Load IN2			Telegrams received from CAN-IN2
	10 Load IN3			Telegrams received from CAN-IN3
	11 Load PIN1			Telegrams received from parameter channel1
	12 Load PIN2			Telegrams received from parameter channel2
C0364 <small>STOP</small>	CFG: CAN activ	1000	FIXED0	■ Selection list 2 Configuration - digital input signal ● Switches the system bus via the external signal from "Pre-Operational" to "Operational"
C0365	DIS:CAN activ		0 Pre-Operational	System bus state ● Display only
			1 Operational	
C0366	Sync Response	1	0 No response	Response to sync telegram of the master
			1 Response	

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0367	Sync Rx ID	128	1	{1}	256	Receipt identifier (Rx) ● Sync Identifier for grouping for data transfer to CAN-IN1
C0368	Sync Tx ID	128	1	{1}	256	Transmission identifier (Tx) ● Identifier for generating a sync telegram
C0369	Sync Tx Time	0	0	{1}	65000	Sync transmission time (Tx) ● Transmission interval for the object set in C0368
C0400	DIS: OUT		-199.99	{0.01 %}	199.99	Analog output signal, function block AIN1 ● Read only
C0402 <small>STOP</small>	CFG: OFFSET	19502	FCODE-26/1	□ Selection list 1		Configuration offset, function block AIN1 ● The offset is added to the input signal at AIN1-IN
C0403 <small>STOP</small>	CFG: GAIN	19504	FCODE-27/1	□ Selection list 1		Configuration of gain, function block AIN1 ● The gain is multiplied by the input signal at AIN1-IN
C0404			-199.99	{0.01 %}	199.99	Function block AIN1 ● Display of the signals linked in C0402 and C0404
1	DIS: OFFSET					
2	DIS: GAIN					
C0405	DIS: OUT		-199.99	{0.01 %}	199.99	Analog output signal, function block AIN2 ● Read only
C0407 <small>STOP</small>	CFG: OFFSET	19503	FCODE-26/2	□ Selection list 1		Configuration of offset, function block AIN2 ● The offset is added to the input signal at AIN2-IN
C0408 <small>STOP</small>	CFG: GAIN	19505	FCODE-27/2	□ Selection list 1		Configuration of gain, function block AIN2 ● The gain is multiplied by the input signal at AIN2-IN
C0409			-199.99	{0.01 %}	199.99	Function block AIN2 ● Display of the signals linked in C0407 and C0408
1	DIS: OFFSET					
2	DIS: GAIN					
C0420 <small>STOP</small>	Encoder const	512	1	{1 inc/rev}	8192	Number of increments for incremental encoder at X8 or X9 ● Connect incremental encoders with HTL-level on X9 only
C0421 <small>STOP</small>	Enc voltage	5.00	5.00	{0.1 V}	8.00	Supply voltage for the incremental encoder at X8 CAUTION! A wrong entry can destroy the incremental encoder!

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0425	DFIN const	3	0	256 inc/rev	Constant of the master frequency input, function block DFIN <ul style="list-style-type: none"> Output signal at the connected encoder or at the upstream controller in the event of a master frequency cascade/master frequency bus 	8.2-5
			1	512 inc/rev		
			2	1024 inc/rev		
			3	2048 inc/rev		
			4	4096 inc/rev		
			5	8192 inc/rev		
			6	16384 inc/rev		
C0426	DIS: OUT		-36000	{1 rpm}	36000	Output signal of the master frequency input, function block DFIN <ul style="list-style-type: none">Display only
C0427	DFIN function	0				Function of the master frequency input, function block DFIN
			0	2-phase		<ul style="list-style-type: none">Phase-displaced signal sequence
			1	A pulse/B dir		<ul style="list-style-type: none">Control of direction of rotation via track B
			2	Pulse A or B		<ul style="list-style-type: none">Control of speed and direction of rotation via track A or track B
C0431 <small>STOP</small>	CFG: IN	5001	MCTRL-NACT	■ Selection list 1	Configuration of analog input signal, function block AOUT1 <ul style="list-style-type: none">Signal at AOUT1-IN is output to terminal X6/62	See System Manual (extension)
C0432 <small>STOP</small>	CFG: OFFSET	19512	FCODE-109/1	■ Selection list 1	Configuration of offset, function block AOUT1 <ul style="list-style-type: none">the offset is added to the input signal at AOUT1-IN	
C0433 <small>STOP</small>	CFG: GAIN	19510	FCODE-108/1	■ Selection list 1	Configuration of gain, function block AOUT1 <ul style="list-style-type: none">The gain is multiplied by the input signal at AOUT1-IN	
C0434			-199.99	{0.01 %}	199.99	Function block AOUT1 <ul style="list-style-type: none">Display of the signals linked in C0431, C0432 and C0433
	1 DIS: IN					
	2 DIS: OFFSET					
	3 DIS: GAIN					
C0436 <small>STOP</small>	CFG: IN	5002	MCTRL-MSET2	■ Selection list 1	Configuration of analog input signal, function block AOUT2 <ul style="list-style-type: none">Signal at AOUT2-IN is output to terminal X6/63	See System Manual (extension)
C0437 <small>STOP</small>	CFG: OFFSET	19513	FCODE-109/2	■ Selection list 1	Configuration of offset, function block AOUT2 <ul style="list-style-type: none">The offset is added to the input signal at AOUT2-IN	
C0438 <small>STOP</small>	CFG: GAIN	19511	FCODE-108/2	■ Selection list 1	Configuration of gain, function block AOUT2 <ul style="list-style-type: none">The gain is multiplied by the input signal at AOUT2-IN	
C0439			-199.99	{0.01 %}	199.99	Function block AOUT2 <ul style="list-style-type: none">Display of the signals linked in C0436, C0437 and C0438
	1 DIS: IN					
	2 DIS: OFFSET					
	3 DIS: GAIN					

Code		Possible settings			IMPORTANT		
No.	Name	Lenze	Selection				
C0443	DIS: DIGIN-OUT		0	{1}	255	Terminal signals, function block DIGIN <ul style="list-style-type: none"> ● Read only ● Binary interpretation of the terminal signals at X5 	
			Bit	Assignment			
			0	DIGIN1	X5/E1		
			1	DIGIN2	X5/E2		
			2	DIGIN3	X5/E3		
			3	DIGIN4	X5/E4		
			4	DIGIN5	X5/E5		
			5	ST-DIGIN6	X5/ST		
			6	DIGIN-CINH	X5/28		
C0444			0	LOW signal	Terminal signals, function block DIGOUT <ul style="list-style-type: none"> ● Read only 	See System Manual (extension)	
			1	HIGH signal			
			DIS: DIGOUT1	Bit	Assignment		
			DIS: DIGOUT2	0	DIGIN1		
			DIS: DIGOUT3	1	DIGIN2		
C0450 <small>STOP</small>	CFG: NX	1000	FIXED0%	 Selection list 1	Configuration of analog input signal, function block BRK1 <ul style="list-style-type: none"> ● Speed threshold, from which the drive may output the signal "Close brake" 	See System Manual (extension)	
C0451 <small>STOP</small>	CFG: SET	1000	FIXED0	 Selection list 2	Configuration of digital input signal, function block BRK1 <ul style="list-style-type: none"> ● HIGH = close brake ● LOW = open brake 		
C0452 <small>STOP</small>	CFG: SIGN	1000	FIXED0%	 Selection list 1	Configuration of analog input signal, function block BRK1 <ul style="list-style-type: none"> ● Direction of torque with which the drive is to create a torque against the brake 		
C0458			-199.99	{0.01 %}	199.99	Function block BRK1 <ul style="list-style-type: none"> ● Display of the signals linked in C0450 and C0452 	See System Manual (extension)
			1				
			2				
C0459	DIS: ON				Function block BRK1 <ul style="list-style-type: none"> ● Display of the signal linked in C0451 		
C0464	Customer I/F		0	original		Customer interface indicates the status of the selected basic configuration <ul style="list-style-type: none"> ● Reassignment of terminals in a basic configuration does not change C0005 and sets C0464 = 1 ● Adding or removing function blocks or changing the signal flow among the function blocks in a basic configuration sets C0005 = 0 and C0464= 1 	
			1	changed			

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0465 <small>STOP</small>		→		□ Selection list 5		
1	FB list	200	DFIN			
2	FB list	0				
3	FB list	50	AIN1			
4	FB list	0				
5	FB list	0				
6	FB list	55	AIN2			
7	FB list	0				
8	FB list	0				
9	FB list	10250	R/L/Q			
10	FB list	0				
...	...	0				
14	FB list	0				
15	FB list	5250	NLIM1			
16	FB list	5050	NSET			
...	...	0				
19	FB list	5700	ANEG1			
...	...	0				
22	FB list	10650	CMP1			
...	...	0				
25	FB list	70	AOUT1			
...	...	0				
28	FB list	75	AOUT2			
...	...	0				
31	FB list	250	DFOUT			
...	...	0				
41	FB list	25000	AIF-OUT			
42	FB list	20000	CAN-OUT			
...				
50	FB list	0				
C0466	CPU T remain				Remaining process time for processing the function blocks	
					● Display only	
C0469 <small>STOP</small>	Fct STP key	2	0	inactive	Inactive	Determines the function which is released when pressing <small>STOP</small> on the keypad
			1	CINH	Inhibit controller:	Changes are only active after mains connection!
			2	qsp	Quick stop	
C0470		0		{1}	255	Configuration of free control codes for digital signals
						● The data words C0470 and C0471 are in parallel and are identical.
1	FCODE 8 Bit	0				FCODE bit 0-7
2	FCODE 8 Bit	0				FCODE bit 8-15
3	FCODE 8 Bit	0				FCODE bit 16-23
4	FCODE 8 Bit	0				FCODE bit 24-31
C0471	Configuration of input FCODE 32 Bit	0	0	{1}	4294967296	Free control code for digital signals
						● The data words C0470 and C0471 are in parallel and are identical.

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0472			-199.99	{0.01 %}	199.99	Configuration of free control codes for analog signals
1	FCODE analog	0.00				
2	FCODE analog	0.00				
3	FCODE analog	100.00				
6	FCODE analog	0.00				
...	...	0.00				
20	FCODE analog	0.00				
C0473			-32767	{1}	32767	Configuration of free control codes for absolute analog signals
1	FCODE abs	1				
2	FCODE abs	1				
3	FCODE abs	0				
...	...	0				
10	FCODE abs	0				
C0474			-2147483647	{1}	2147483647	Configuration of free control codes for phase signals ● 1 rev. = 65536 inc
1	FCODE PH	0				
...	...	0				
5	FCODE PH	0				
C0475			-16000	{1}	16000	Configuration of free control codes for phase difference signals ● 1 rev. = 65536 inc
1	FCODE DF	0				
2	FCODE DF	0				
C0497	Nact filter	2.0	0.0	{0.1 ms}	50.0	Filter time constant N_{act} for actual speed value, function block MCTRL2 ● Internal filtering of the speed signal for control ● C0497 = 0 ms: Switched off
C0510	CFG: IN1 <small>STOP</small>	50	AIN1-OUT	■ Selection list 1		Configuration of analog input signal, function block NLIM1 ● Input for analog speed setpoint
C0511	DIS: IN1		-199.99	{0.01 %}	199.99	Function block NLIM1 ● Display of the input signal configured in C0510

Code		Possible settings			IMPORTANT
No.	Name	Lenze	Selection		
C0517 <small>ENTER</small>			0.00 {0.01 }	1999.00	<ul style="list-style-type: none"> The user menu contains in the Lenze setting the most important codes for commissioning the operating mode "V/f characteristic control" With an active password protection only the codes entered in C0517 can be freely accessed Enter the numbers of the required codes in the subcodes The input is done in the format xxx.yy <ul style="list-style-type: none"> - xxx: Code number - yy: Subcode number It is not checked whether the entered code exists.
1	User menu	51.00	Actual speed value (MCTRL-NACT)		
2	User menu	54.00	Actual motor current (MCTRL-IACT)		
3	User menu	56.00	Torque setpoint (MCTRL-MSET2)		
4	User menu	64.00	Device utilisation Ixt		
5	User menu	183.00	Diagnostics		
6	User menu	168.01	History buffer		
7	User menu	39.01	JOG-setpoints 1 (NSET)		
8	User menu	86.00	Motor type selection		
9	User menu	148.00	Identifying motor parameters		
10	User menu	22.00	I _{max} limit in motor mode		
11	User menu	23.00	I _{max} limit in generator mode		
12	User menu	11.00	Maximum speed N _{max}		
13	User menu	12.00	Acceleration time T _{ir} main setpoint		
14	User menu	13.00	Deceleration time T _{if} main setpoint		
15	User menu	16.00	U _{min} boost		
16	User menu	70.00	Gain V _p speed controller		
17	User menu	71.00	Integral-action time T _n speed controller		
18	User menu	75.00	Gain V _p current controller		
19	User menu	76.00	Integral-action time T _n current controller		
20	User menu	142.00	Starting condition		
21	User menu	92.00	Motor stator inductance		
22	User menu	36.00	DC braking current		
23	User menu	93.00	Controller identification		
24	User menu	99.00	Software version		
...	...	0	Not assigned		
31	User menu	94.00	Password		
32	User menu	3.00	Save parameter set		

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0520 <small>STOP</small>	CFG: IN	1000	FIXEDPHI-0	<input type="checkbox"/> Selection list 4	Configuration of input signal, function block DFSET ● Input of speed / phase setpoint signal	<input type="checkbox"/> 8.2-18
C0521 <small>STOP</small>	CFG: VP-DIV	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block DFSET ● Signal for numerator of stretching factor ● 100 % = 16384 inc	
C0522 <small>STOP</small>	CFG: RAT-DIV	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block DFSET ● Signal for numerator of gearbox factor ● 100 % = 16384 inc	
C0523 <small>STOP</small>	CFG: A-TRIM	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block DFSET ● Signal for phase trimming via offset multiplier (C0529) ● 100 % = 16384 inc	
C0524 <small>STOP</small>	CFG: N-TRIM	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block DFSET ● Signal for speed trimming ● Signal in [%] of C0011	
C0525 <small>STOP</small>	CFG: 0-PULSE	1000	FIXED0	<input type="checkbox"/> Selection list 2	Configuration of digital input signal, function block DFSET ● Signal for one-time zero pulse activation ● HIGH = release for zero pulse synchronisation	
C0526 <small>STOP</small>	CFG: RESET	1000	FIXED0	<input type="checkbox"/> Selection list 2	Configuration of digital input signal, function block DFSET ● Signal for reset of integrators ● HIGH sets – Position difference = 0 – DFSET-PSET = 0 – DFSET-PSET2 = 0	
C0527 <small>STOP</small>	CFG: SET	1000	FIXED0	<input type="checkbox"/> Selection list 2	Configuration of digital input signal, function block DFSET ● HIGH = Set phase integrators to equal values ● LOW-HIGH edge sets DFSET-PSET = 0 ● HIGH-LOW edge sets DFSET-PSET to the current value of MCTRL-PHI-SET ● DFSET-SET has a higher priority than DFSET-RESET	
C0528			-2·10 ⁹	{1}	Function block DFSET ● Display only	<input type="checkbox"/> 8.2-18
1	DIS: 0-pulse A				Phase difference between two zero pulses	
2	DIS: Offset				Offset = C0523 × C0529 + C0252	

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0529	Multip offset	1	-20000	{1}	20000	Offset multiplier, function block DFSET ● Multiplier for the phase offset (C0252)	8.2-18
C0530	DF evaluation	0	0	with factor	With gearbox factor	Master frequency evaluation, function block DFSET ● Evaluation of the setpoint integrator	8.2-18
			1	no factor	Without gearbox factor		
C0531	Act 0 div	1	1	{1}	16384	Actual zero pulse divisor, function block DFSET	
C0532	0-pulse/TP	1	1	0-pulse	Index pulse	Zero pulse / touch probe, function block DFSET ● Zero pulse of the feedback system or touch probe	8.2-18
			2	Touch probe	Touch probe		
C0533	Vp denom	1	1	{1}	32767	Gain factor of denominator V _p , function block DFSET	
C0534	0 pulse fct	0				Zero pulse function, function block DFSET ● Synchronising the drive	8.2-18
			0	inactive	Inactive		
			1	Continuous	Continuous synchronisation, correction in the shortest possible way		
			2	Cont. switch	Continuous synchronisation, correction in the shortest possible way	After a LOW-HIGH signal to DFSET-0-pulse, the zero track is synchronised once	
			10	Once, fast way	One-time synchronisation, correction in the shortest possible way		
			11	Once, CW	One-time synchronisation, correction in direction of rotation to the right		
			12	Once, CCW	One-time synchronisation, correction in direction of rotation to the left		
			13	Once, 2*0-pulse	One-time synchronisation, correction is detected from setpoint pulse and actual pulse and corrected to the corresponding direction		
C0535	Set 0 div	1	1	{1}	16384	Desired zero pulse divisor, function block DFSET	8.2-18

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0536		1 DIS: VP-DIV 2 DIS: RAT-DIV 3 DIS: A-TRIM	-32767	{1}	32767	Function block DFSET ● Display of the signals linked in C0521, C0522 and C0523
C0537	DIS: N-TRIM	1 DIS: 0-pulse 2 DIS: RESET 3 DIS: SET	-199.99	{0.01 %}	199.99	Function block DFSET ● Display of the signal linked in C0524
			0		1	Function block DFSET ● Display of the signals linked in C0525, C0526 and C0527
C0539	DIS: IN	Function <small>STOP</small>	-6000	{1 rpm}	6000	Function block DFSET ● Display of the signal linked in C0520
			0			Function selection, function block DFOUT ● Output signal at X10
			0	Analog input	Analog input	Signal at DFOUT-AN-IN is output. Zero track can be input externally.
			1	PH diff input	Phase difference input	Signal at DFOUT-DF-IN is output. Zero track can be input externally.
			2		Not assigned	
			3		Not assigned	
		4 X10 = X9 5 X10 = X8	4	X10 = X9	X9 is output on X10	The input signals are buffered C0030 is without function
			5	X10 = X8	X8 is output on X10	
C0541	CFG: AN-IN	5001	MCTRL-NACT	□ Selection list 1		Configuration of analog input signal, function block DFOUT ● Signal in [%] of C0011
C0542	CFG: DF-IN	1000	FIXEDPHI-0	□ Selection list 4		Configuration of input signal, function block DFOUT ● Speed signal
C0544	CFG: SYN-RDY	1000	FIXED0	□ Selection list 2		Configuration of digital input signal, function block DFOUT ● DFOUT-SYN-RDY = HIGH: Generating a zero pulse
C0545	PH offset	0	0	{1 inc.}	65535	Phase offset, function block DFOUT ● Displacing the zero pulse generated via DFOUT-SYN-RDY by up to 360 ° ● 1 rev. = 65535 inc (360 °)
C0546	Min inc/rev	1000	1	{1 inc.}	2147483647	Masking of the touch probe signal, function block DFSET ● Suppressing interference pulses at X5/E4 (actual pulse of touch probe signal) ● The size of the masking window between two actual pulses is set

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0547	DIS: AN-IN		-199.99	{0.01 %}	199.99	Function block DFOUT ● Display of the signal linked in C0541
C0548	DIS: SYN-RDY		0		1	Function block DFOUT ● Display of the signal linked in C0544
C0549	DIS: DF-IN		-32767	{1 rpm}	32767	Function block DFOUT ● Display of the signal linked in C0542
C0560			-199.99	{0.01 %}	199.99	Configuration of fixed setpoints, function block FIXSET1 ● Output of the setpoints to FIXSET1-OUT via binary coding of the inputs FIXSET1-IN1 ... FIXSET1-IN4
	1 Fix set-value	100				See System Manual (extension)
	2 Fix set-value	75				
	3 Fix set-value	50				
	4 Fix set-value	25				
	5 Fix set-value	0				
	0				
	15 Fix set-value	0				
C0561 <small>STOP</small>	CFG: AIN	1000	FIXED0%		□ Selection list 1	Configuration of analog input signal, function block FIXSET1 ● The analog input signal is switched to FIXSET1-OUT if all inputs FIXSET-INx = LOW
C0562 <small>STOP</small>					□ Selection list 2	Configuration of digital input signals, function block FIXSET1 ● The number of inputs to be assigned depend on the number of the fixed setpoints required.
	1 CFG: IN	1000	FIXED0			FIXSET1-IN1
	2 CFG: IN	1000	FIXED0			FIXSET1-IN2
	3 CFG: IN	1000	FIXED0			FIXSET1-IN3
	4 CFG: IN	1000	FIXED0			FIXSET1-IN4
C0563	DIS: AIN		-199.99	{0.01 %}	199.99	Function block FIXSET1 ● Display of the signal linked in C0561
C0564			0		1	Function block FIXSET1 ● Display of the signals linked in C0562/1, C0562/2, C0562/3 and C0562/4
	1 DIS: IN					FIXSET1-IN1
	2 DIS: IN					FIXSET1-IN2
	3 DIS: IN					FIXSET1-IN3
	4 DIS: IN					FIXSET1-IN4
C0570 <small>STOP</small>	CFG: IN	1000	FIXED0%		□ Selection list 1	Configuration of analog input signal, function block S&H1
C0571 <small>STOP</small>	CFG: LOAD	1000	FIXED0		□ Selection list 2	Configuration of digital input signal, function block S&H1
C0572	DIS: IN		-199.99	{0.01 %}	199.99	Function block S&H1 ● Display of the signal linked in C0570
C0573	DIS: LOAD		0		1	Function block S&H1 ● Display of the signal linked in C0571
C0581	MONIT EEr	0	0 TRIP 1 Message 2 Warning 3 Off			Configuration monitoring EEr, external fault
						See System Manual (extension)

Code				Possible settings	IMPORTANT	
No.	Name	Lenze	Selection			
C0582	MONIT OH4	2	2	Warning	Configuration monitoring OH4, heatsink temperature ● The operating temperature can be set in C0122	See System Manual (extension)
			3	Off		
C0583	MONIT OH3	3	0	TRIP	Configuration of motor temperature monitoring with fixed operating temperature ● Only for KTY at X8 ● The operating temperature is fixed at 150 °C	6.6-11 See System Manual (extension)
			3	Off		
C0584	MONIT OH7	3	2	Warning	Configuration of monitoring motor temperature with variable operating temperature ● Only for KTY at X8 ● When reaching the temperature set in C0121 the warning OH7 is activated	6.6-11 See System Manual (extension)
			3	Off		
C0585	MONIT OH8	3	0	TRIP	Configuration of motor temperature monitoring ● Temperature monitoring via PTC input (T1, T2)	6.6-9 See System Manual (extension)
			2	Warning		
			3	Off		
C0587	MONIT SD3	3	0	TRIP	Configuration of monitoring SD3, encoder at X9 ● Monitors the voltage supply at X9/pin 8	See System Manual (extension)
			2	Warning		
			3	Off		
C0588	MONIT H10/H11	0	0	TRIP	Configuration of monitoring H10 and H11, thermal sensors in the controller ● H10: Sensor error - heatsink temperature ● H11: Sensor error - interior temperature	See System Manual (extension)
			3	Off		
C0591	MONIT CE1	3	0	TRIP	Configuration of monitoring CE1, communication error at CAN-IN1	See System Manual (extension)
			2	Warning		
			3	Off		
C0592	MONIT CE2	3	0	TRIP	Configuration of monitoring CE2, communication error at CAN-IN2	
			2	Warning		
			3	Off		
C0593	MONIT CE3	3	0	TRIP	Configuration of monitoring CE3, communication error at CAN-IN3	
			2	Warning		
			3	Off		
C0594	MONIT SD6	3	0	TRIP	Activation of the motor temperature monitoring with KTY at X8 ● Use C0594 = 0 or 2 to activate monitoring ● In case of a short circuit or interruption at X8/5 and X8/8 the fault message SD6 is activated ● Configuration of the response when exceeding the motor temperature – Fixed operating temperature in C0583 – Variable operating temperature in C0584	6.6-11 See System Manual (extension)
			2	Warning		
			3	Off		
C0595	MONIT CE4	3	0	TRIP	Configuration of monitoring CE4, BUS-OFF (system bus)	See System Manual (extension)
			2	Warning		
			3	Off		

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0596	NMAX limit	4000	0 {1 rpm}		36000	Configuration of monitoring N _{max} , maximum system speed exceeded	See System Manual (extension)
C0597	MONIT LP1	3	0 TRIP			Configuration of monitoring the motor phases LP1	See System Manual (extension)
			2 Warning				
			3 Off				
C0598	MONIT SD5	3	0 TRIP			Configuration of monitoring SD5, open circuit at analog input X6/1, X6/2	See System Manual (extension)
			2 Warning				
			3 Off				
C0599	Limit LP1	5.0	1.0 {0.1 %}		10.0	Configuration of current limit LP1, current limit value for monitoring the motor phases in C0597	See System Manual (extension)
C0600	Function	1	0 OUT = IN1			Function selection, function block ARIT2	See System Manual (extension)
			1 OUT = IN1 + IN2				
			2 OUT = IN1 - IN2				
			3 OUT = IN1 * IN2				
			4 OUT = IN1 / IN2				
			5 OUT = IN1 / (100 - IN2)				
C0601 <small>STOP</small>			□ Selection list 1			Configuration of analog input signal, function block ARIT2	
1	CFG: IN	1000	FIXED0%			ARIT2-IN1	
2	CFG: IN	1000	FIXED0%			ARIT2-IN2	
C0602			-199.99	{0.01 %}	199.99	Function block ARIT2 ● Display of the signals linked in C0601	
1	DIS: IN					ARIT2-IN1	
2	DIS: IN					ARIT2-IN2	
C0603	Function	1	0 OUT = IN1			Function selection, function block ARIT3	See System Manual (extension)
			1 OUT = IN1 + IN2				
			2 OUT = IN1 - IN2				
			3 OUT = IN1 * IN2				
			4 OUT = IN1 / IN2				
			5 OUT = IN1 / (100 - IN2)				
C0604 <small>STOP</small>			□ Selection list 1			Configuration of analog input signal, function block ARIT3	
1	CFG: IN	1000	FIXED0%			ARIT3-IN1	
2	CFG: IN	1000	FIXED0%			ARIT3-IN2	
C0605			-199.99	{0.01 %}	199.99	Function block ARIT3 ● Display of the signals linked in C0604	
1	DIS: IN					ARIT3-IN1	
2	DIS: IN					ARIT3-IN2	
C0608 <small>STOP</small>	CFG: IN	1000	FIXED0% □ Selection list 1			Configuration of analog input signal, function block SQRT1	See System Manual (extension)
C0609	DIS: IN		-199.99	{0.01 %}	199.99	Function block SQRT1 ● Display of the signal linked in C0608	

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0610 STOP				□ Selection list 1	Configuration of analog input signals, function block ADD1	See System Manual (extension)
1	CFG: IN	1000	FIXED0%		Addition input ADD1-IN1	
2	CFG: IN	1000	FIXED0%		Addition input ADD1-IN2	
3	CFG: IN	1000	FIXED0%		Subtraction input ADD1-IN3	
C0611		-199.99	{0.01 %}	199.99	Function block ADD1 ● Display of the signals linked in C0610	
1	DIS: IN				ADD1-IN1	
2	DIS: IN				ADD1-IN2	
3	DIS: IN				ADD1-IN3	
C0612 STOP				□ Selection list 1	Configuration of analog input signals, function block ADD2	See System Manual (extension)
1	CFG: IN	1000	FIXED0%		Addition input ADD2-IN1	
2	CFG: IN	1000	FIXED0%		Addition input ADD2-IN2	
3	CFG: IN	1000	FIXED0%		Subtraction input ADD2-IN3	
C0613		-199.99	{0.01 %}	199.99	Function block ADD2 ● Display of the signals linked in C0612	
1	DIS: IN				ADD2-IN1	
2	DIS: IN				ADD2-IN2	
3	DIS: IN				ADD2-IN3	
C0620	DB1 gain	1.00	-10.00	{0.01 }	10.00	Gain, function block DB1
C0621	DB1 value	1.00	0.00	{0.01 %}	100.00	Dead band, function block DB1 ● Fault signals around the zero point of the input signal are set to 0
C0622 STOP	CFG: IN	1000	FIXED0%	□ Selection list 1	Configuration of analog input signal, function block DB1	
C0623	DIS: IN	-199.99	{0.01 %}	199.99	Function block DB1 ● Display of the signal linked in C0622	
C0630	Max limit	100.00	-199.99	{0.01 %}	199.99	Upper limit, function block LIM1 ● The analog input signal is limited to the set value
C0631	MiN limit	-100.0	-199.99	{0.01 %}	199.99	Lower limit, function block LIM1 ● The analog input signal is limited to the set value
C0632 STOP	CFG: IN	1000	FIXED0%	□ Selection list 1	Configuration of analog input signal, function block LIM1	
C0633	DIS: IN	-199.99	{0.01 %}	199.99	Function block LIM1 ● Display of the signal linked in C0632	

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0640	Delay T	20.00	0.01	{0.01 s}	50.00	Time constant, function block PT1-1 <ul style="list-style-type: none"> Time period by which the output of analog signal is delayed 	See System Manual (extension)
C0641 <small>STOP</small>	CFG: IN	1000	FIXED0%	■ Selection list 1		Configuration of analog input signal, function block PT1-1	
C0642	DIS: IN		-199.99	{0.01 %}	199.99	Function block PT1-1 <ul style="list-style-type: none"> Display of the signal linked in C0641 	
C0643	Delay T	20.00	0.01	{0.01 s}	50.00	Time constant, function block PT1-2 <ul style="list-style-type: none"> Time period by which the output of analog signal is delayed 	
C0644 <small>STOP</small>	CFG: IN	1000	FIXED0%	■ Selection list 1		Configuration of analog input signal, function block PT1-2	
C0645	DIS: IN		-199.99	{0.01 %}	199.99	Function block PT1-2 <ul style="list-style-type: none"> Display of the signal linked in C0644 	
C0650	DT1-1 gain	1.00	-320.00	{0.01 }	320.00	Gain, function block DT1-1 <ul style="list-style-type: none"> Gain of the analog input signal 	See System Manual (extension)
C0651	Delay T	1.000	0.005	{0.01 s}	5.000	Time constant, function block DT1-1 <ul style="list-style-type: none"> Time period by which the output of analog signal is delayed 	
C0652 <small>STOP</small>	CFG: IN	1000	FIXED0%	■ Selection list 1		Configuration of analog input signal, function block DT1-1	
C0653	Sensibility	1	1	15 bits		Input sensitivity, function block DT1-1 <ul style="list-style-type: none"> According to the setting only the indicated higher-order bits are evaluated 	
			2	14 bits			
			3	13 bits			
			4	12 bits			
			5	11 bits			
			6	10 bits			
			7	9 bits			
C0654	DIS: IN		-199.99	{0.01 %}	199.99	Function block DT1-1 <ul style="list-style-type: none"> Display of the signal linked in C0652 	
C0655	Numerator	1	-32767	{1}	32767	Configuration of conversion factor with numerator and denominator, function block CONV5	See System Manual (extension)
C0656	Denominator	1	1	{1}	32767	$OUT [rpm] = IN [\%] \cdot \frac{15000 \text{ rpm}}{100 \%} \cdot \frac{C0655}{C0656}$	
C0657 <small>STOP</small>	CFG: IN	1000	FIXED0%	■ Selection list 1		Configuration of analog input signal, function block CONV5	
C0658	DIS: IN		-199.99	{0.01 %}	199.99	Function block CONV5 <ul style="list-style-type: none"> Display of the signal linked in C0657 	
C0661 <small>STOP</small>	CFG: IN	1000	FIXED0%	■ Selection list 1		Configuration of analog input signal, function block ABS1 <ul style="list-style-type: none"> Converts bipolar signals into unipolar signals 	See System Manual (extension)
C0662	DIS: IN		-199.99	{0.01 %}	199.99	Function block ABS1 <ul style="list-style-type: none"> Display of the signal linked in C0661 	

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0671	RFG1 Tir	0.00	0.00	{0.01 s}	999.90	Acceleration time T_{ir} and deceleration time T_{if} , function block RFG1 ● Acceleration and deceleration ramp
C0672	RFG1 Tif	0.00	0.00	{0.01 s}	999.90	● Selection of a final value at RFG1-OUT
C0673 <small>STOP</small>	CFG: IN	1000	FIXED0%	□ Selection list 1		Configuration of analog input signal, function block RFG1 ● Selection of a final value at RFG1-OUT
C0674 <small>STOP</small>	CFG: SET	1000	FIXED0%	□ Selection list 1		Configuration of analog input signal, function block RFG1 ● Selection of a starting value at RFG1-OUT
C0675 <small>STOP</small>	CFG: LOAD	1000	FIXED0	□ Selection list 2		Configuration of digital input signal, function block RFG1 ● HIGH: RFG1-OUT is set to the value at RFG1-Set ● LOW: The signal at RFG1-OUT travels along the ramps towards the input value at RFG1-IN
C0676			-199.99	{0.01 %}	199.99	Function block RFG1 ● Display of the signals linked in C0673 and C0674
1	DIS: RFG1					RFG1-IN
2	DIS: RFG1					RFG1-SET
C0677	DIS: LOAD		0		1	Function block RFG1 ● Display of the signal linked in C0675
C0680	Function	1	1	IN1 = IN 2		Function selection, function block CMP1 ● Compare input signals at CMP1-IN1 and CMP1-IN2
			2	IN1 > IN2		
			3	IN1 < IN2		
			4	IN1 IN2		
			5	IN1 IN2		
			6	IN1 IN2		
C0681	Hysteresis	1.00	0.00	{0.01 %}	100.00	Hysteresis, function block CMP1 ● Hysteresis for input signals which are not stable and hence the output oscillates
C0682	Window	1.00	0.00	{0.01 %}	100.00	Window, function block CMP1 ● Set the range in which the signal comparison is to be apply
C0683 <small>STOP</small>				□ Selection list 1		Configuration of analog input signal, function block CMP1
1	CFG: IN	5001	MCTRL-NACT			CMP1-IN1
2	CFG: IN	19500	FCODE-17			CMP1-IN2
C0684			-199.99	{0.01 %}	199.99	Function block CMP1 ● Display of the signals linked in C0683
1	DIS: IN					CMP1-IN1
2	DIS: IN					CMP1-IN2

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0685	Function	1	1	IN1 = IN2	Function selection, function block CMP2 ● Compare input signals at CMP2-IN1 and CMP2-IN2	
			2	IN1 > IN2		
			3	IN1 < IN2		
			4	IN1 N2		
			5	IN1 N2		
			6	IN1 N2		
C0686	Hysteresis	1.00	0.00	{0.01 %}	100.00	Hysteresis, function block CMP2 ● Hysteresis for input signals which are not stable and hence the output oscillates
C0687	Window	1.00	0.00	{0.01 %}	100.00	Window, function block CMP2 ● Set the range in which the signal comparison is to be apply
C0688 <small>STOP</small>				□ Selection list 1		Configuration of analog input signal, function block CMP2
	1	CFG: IN	1000	FIXED0%		CMP2-IN1
	2	CFG: IN	1000	FIXED0%		CMP2-IN2
C0689			-199.99	{0.01 %}	199.99	Function block CMP2 ● Display of the signals linked in C0688
	1	DIS: IN				CMP2-IN1
	2	DIS: IN				CMP2-IN2
C0690	Function	1	1	IN1 = IN 2	Function selection, function block CMP3 ● Compare input signals at CMP3-IN1 and CMP3-IN2	
			2	IN1 > IN2		
			3	IN1 < IN2		
			4	IN1 N2		
			5	IN1 N2		
			6	IN1 < IN2		
C0691	Hysteresis	1.00	0.00	{0.01 %}	100.00	Hysteresis, function block CMP3 ● Hysteresis for input signals which are not stable and hence the output oscillates
C0692	Window	1.00	0.00	{0.01 %}	100.00	Window, function block CMP3 ● Set the range in which the signal comparison is to be apply
C0693 <small>STOP</small>			□ Selection list 1		Configuration of analog input signal, function block CMP3	
	1	CFG: IN	1000	FIXED0%		CMP3-IN1
	2	CFG: IN	1000	FIXED0%		CMP3-IN2
C0694			-199.99	{0.01 %}	199.99	Function block CMP3 ● Display of the signals linked in C0693
	1	DIS: IN				CMP3-IN1
	2	DIS: IN				CMP3-IN2
C0700 <small>STOP</small>	CFG: IN	19523	FCODE-472/3	□ Selection list 1		Configuration of analog input signal, function block ANEG1 ● The value at ANEG1-IN is multiplied by -1 and output
C0701	DIS: IN		-199.99	{0.01 %}	199.99	Function block ANEG1 ● Display of the signal linked in C0700

See System Manual (extension)

See System Manual (extension)

See System Manual (extension)

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0703 STOP	CFG: IN	19523	FCODE-472/3	□ Selection list 1	Configuration of analog input signal, function block ANEG2 ● The value at ANEG2-IN is multiplied by -1 and output	See System Manual (extension)
C0704	DIS: IN		-199.99 {0.01 %}	199.99	Function block ANEG2 ● Display of the signal linked in C0703	
C0705	Function	1	1 IN1 = IN2		Function selection, function block CMP4 ● Compare input signals at CMP4-IN1 and CMP4-IN2	See System Manual (extension)
			2 IN1 > IN2			
			3 IN1 < IN2			
			4 IN1 = IN2			
			5 IN1 > IN2			
			6 IN1 < IN2			
C0706	Hysteresis	1.00	0.00 {0.01 %}	100.00	Hysteresis, function block CMP4 ● Hysteresis for input signals which are not stable and hence the output oscillates	
C0707	Window	1.00	0.00 {0.01 %}	100.00	Window, function block CMP4 ● Set the range in which the signal comparison is to be apply	
C0708 STOP			□ Selection list 1		Configuration of analog input signal, function block CMP4	
1	CFG: IN	1000	FIXED0%		CMP4-IN1	
2	CFG: IN	1000	FIXED0%		CMP4-IN2	
C0709			-199.99 {0.01 %}	199.99	Function block CMP4 ● Display of the signals linked in C0708	See System Manual (extension)
					CMP4-IN1	
					CMP4-IN2	
C0710	Function	0	Rising trans	Rising edge	Function selection, function block TRANS1	See System Manual (extension)
					1. LOW-HIGH edge at TRANS1-IN switches TRANS1-OUT = HIGH 2. After the time has elapsed (C0711), TRANS1-OUT switches to LOW	
					1. HIGH-LOW edge at TRANS1-IN switches TRANS1-OUT = HIGH 2. After the time has elapsed (C0711), TRANS1-OUT switches to LOW	
C0711	Pulse T	0.001	0.001 {0.001 s}	60.000	Pulse duration, function block TRANS1 ● After the time has elapsed, TRANS1-OUT switches to LOW	
C0713 STOP	CFG: IN	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block TRANS1	
C0714	DIS: IN		0	1	Function block TRANS1 ● Display of the signal linked in C0713	

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0715	Function	0			Function selection, function block TRANS2	See System Manual (extension)
			0	Rising trans	Rising edge	1. LOW-HIGH edge at TRANS2-IN switches TRANS2-OUT = HIGH 2. After the time has elapsed (C0716), TRANS2-OUT switches to LOW
			1	Falling trans	Falling edge	1. HIGH-LOW edge at TRANS2-IN switches TRANS2-OUT = HIGH 2. After the time has elapsed (C0716), TRANS2-OUT switches to LOW
C0716	Pulse T	0.001	0.001 {0.001 s}	60.000	Pulse duration, function block TRANS2	<ul style="list-style-type: none"> ● After the time has elapsed, TRANS2-OUT switches to LOW
					Configuration of digital input signal, function block TRANS2	
					Function block TRANS2	
C0718 <small>STOP</small>	CFG: IN	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block TRANS2	
C0719	DIS: IN		0		1	Function block TRANS2 ● Display of the signal linked in C0718
C0720	Function	2			Function selection, function block DIGDEL1	See System Manual (extension)
			0	On delay	On delay	1. LOW-HIGH edge at DIGDEL1-IN starts a timing element 2. After the time has elapsed (C0721), DIGDEL1-OUT switches to HIGH
			1	Off delay	Off delay	1. LOW-HIGH edge at DIGDEL1-IN starts a timing element and sets DIGDEL1-OUT = HIGH 2. After the time has elapsed (C0721), DIGDEL1-OUT switches to LOW
C0721	Delay T	1.000	0.001 {0.001 s}	60.000	Delay time, function block DIGDEL1	
					Configuration of digital input signal, function block DIGDEL1	
					Function block DIGDEL1	
C0723 <small>STOP</small>	CFG: IN	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block DIGDEL1	
C0724	DIS: IN		0		1	Function block DIGDEL1 ● Display of the signal linked in C0723

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0725	Function	2			Function selection, function block DIGDEL2	See System Manual (extension)
			0 On delay	On delay	1. LOW-HIGH edge at DIGDEL2-IN starts a timing element 2. After the time has elapsed (C0726), DIGDEL2-OUT switches to HIGH	
			1 Off delay	Off delay	1. LOW-HIGH edge at DIGDEL2-IN starts a timing element and sets DIGDEL2-OUT = HIGH 2. After the time has elapsed (C0726), DIGDEL2-OUT switches to LOW	
C0726	Delay T	1.000	0.001 {0.001 s}	60.000	Delay time, function block DIGDEL2	
C0728 <small>STOP</small>	CFG: IN	1000	FIXED0	■ Selection list 2	Configuration of digital input signal, function block DIGDEL2	
C0729	DIS: IN		0		1 Function block DIGDEL2 ● Display of the signal linked in C0728	
C0730	Mode	0	0 Stop measurement		Function block OSZ	See System Manual (extension)
			1 Start measurement		● Starting / stopping the measured value recording	
C0731	Status		0 Measurement completed		Oscilloscope function	
			1 Measurement active		● Read only	
			2 Trigger detected		● Current operating status	
			3 Abort			
			4 Abort after trigger			
			5 Read memory			
C0732 <small>STOP</small>				■ Selection list 1	Configuration of analog input signals, function block OSZ Function block OSZ	See System Manual (extension)
	1 OSZ channel 1	1000	FIXED0%			
	2 OSZ channel 2	1000	FIXED0%			
	3 OSZ channel 3	1000	FIXED0%			
	4 OSZ channel 4	1000	FIXED0%			
C0733 <small>STOP</small>				■ Selection list 2	Configuration of digital input signal, function block OSZ	
1	Trigger input	1000	FIXED0			
C0734	Trigger source	1	0 OSZ trigger input		Function block OSZ	See System Manual (extension)
			1 OSZ channel 1		● Configure digital input C0732 or C0733 with desired trigger signal	
			2 OSZ channel 2			
			3 OSZ channel 3			
			4 OSZ channel 4			
C0735	Trigger level	0	-32767 {1}	32767	Function block OSZ ● Trigger level OSZ channel 1 ... OSZ channel 4	
C0736	Trigger edge	0	0 LOW-HIGH edge		Oscilloscope function	
			1 HIGH-LOW edge			
C0737	Trigger Delay	0.0	-100.0 {0.1 %}	999.99	Function block OSZ ● Setting of pretriggering and posttriggering	

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0738	Sampling period	3	3	1 ms	Oscilloscope function ● Time base	See System Manual (extension)
			4	2 ms		
			5	5 ms		
			6	10 ms		
			7	20 ms		
			8	50 ms		
			9	100 ms		
			10	200 ms		
			11	500 ms		
			12	1 s		
			13	2 s		
			14	5 s		
			15	10 s		
			16	20 s		
			17	50 s		
			18	1 min		
			19	2 min		
			20	5 min		
			21	10 min		
C0739	Number of channels	4	1	{1}	4	Function block OSZ ● Switching on/off the channels – 1 = channel 1 – 2 = channel 1 + 2 – 3 = channel 1 ... 3 – 4 = channel 1 ... 4
C0740		0				Oscilloscope function ● Reading data memory
1	Read start position	0	0	{1}	65535	● Provides a pointed access to a storage block
2	Enable/inhibit data reading	0	0	No data reading		
			1	Data reading		
C0741	STATUS	0		1000000000	Function block OSZ ● Read only	See System Manual (extension)
1	Version					
2	Memory size					
3	Data width					
4	Number of channels					
C0742	Data block length	8	0	{1}	65536	Function block OSZ
C0743	Read data block length (OSZ)		0		65535	Function block OSZ ● Read only ● Reading an 8 byte data block
C0744	Memory depth	3	0	512 measured values		Oscilloscope function ● Adapt memory capacity to the measurement task
			1	1024 measured values		
			2	1536 measured values		
			3	2048 measured values		
			4	3072 measured values		
			5	4096 measured values		
			6	8192 measured values		

Code		Possible settings			IMPORTANT		
No.	Name	Lenze	Selection				
C0749		0		65535	Information about storing the measured values, function block OSZ ● Read only	See System Manual (extension)	
	1 Abort index				Measured value no. of the abort time		
	2 Trigger index				Measured value no. of the trigger time		
	3 End index				Measured value no. of the end time		
C0750	Vp denom	16	1	1	Gain V _P of the position controller, function block DFRG1	8.2-13	
			2	1/2			
			4	1/4			
			8	1/8			
			16	1/16			
			32	1/32			
			64	1/64			
			128	1/128			
			256	1/256			
			512	1/512			
			1024	1/1024			
			2048	1/2048			
			4096	1/4096			
			8192	1/8192			
			16384	1/16384			
C0751	DFRFG1 Tir	1.000	0.001	{0.001 s}	999.999	Acceleration time T _{ir} , function block DFRG1	8.2-13
C0752	Max speed	3000	1	{1 rpm}	16000	Maximum speed, function block DFRG1 ● Maximum speed-up (speed)	
C0753	DFRFG1 QSP	0.000	0.000	{0.001 s}	999.900	Deceleration time T _{if} for quick stop, function block DFRG1	
C0754	PH error	2·10 ⁹	10	{1}	2·10 ⁹	Following error, function block DFRG1 ● Maximum permissible phase difference between setpoint and actual phase ● 1 rev. = 65535 inc	
C0755	Syn window	100	0	{1 inc.}	65535	Synchronisation window, function block DFRG1 ● 1 rev. = 65535 inc	

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0758 STOP	CFG: IN	1000	FIXEDPHI-0	□ Selection list 4	Configuration of input signal, function block DFRFG1 • Speed/phase setpoint signal	8.2-13
C0759 STOP	CFG: QSP	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block DFRFG1 • HIGH = quick stop active	
C0760 STOP	CFG: STOP	1000	FIXED0	□ Selection list 2	Configuration of input signal, function block DFRFG1 • HIGH = Status of the profile generator is maintained, setpoint is saved	
C0761 STOP	CFG: RESET	1000	FIXED0	□ Selection list 2	Configuration of input signal, function block DFRFG1 • HIGH = resetting the integrators	
C0764		0		1	Function block DFRFG1	
1 DIS: QSP					• Display of the signals linked in C0759, C0760 and C0761	
2 DIS: STOP						
3 DIS: RESET						
C0765	DIS: IN		-32767 {1 rpm}	32767	Function block DFRFG1 • Display of the signal linked in C0758	
C0770 STOP	CFG: D	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block FLIP1	See System Manual (extension)
C0771 STOP	CFG: CLK	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block FLIP1 • Each LOW-HIGH edge at FLIP1-CLK switches the signal at FLIP1-D to FLIP1-OUT	
C0772 STOP	CFG: CLR	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block FLIP1 • Resets the flip-flop • HIGH: Sets FLIP1-OUT = LOW • Input has highest priority	
C0773		0		1	Function block FLIP1 • Display of the signals linked in C0770, C0771 and C0773	
1 DIS: D						
2 DIS: CLK						
3 DIS: CLR						
C0775 STOP	CFG: D	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block FLIP2	See System Manual (extension)
C0776 STOP	CFG: CLK	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block FLIP2 • Each LOW-HIGH edge at FLIP2-CLK switches the signal at FLIP2-D to FLIP2-OUT	
C0777 STOP	CFG: CLR	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block FLIP2 • Resets the flip-flop • HIGH: sets FLIP2-OUT = LOW • Input has highest priority	
C0778		0		1	Function block FLIP2 • Display of the signals linked in C0775, C0776 and C0777	
1 DIS: D						
2 DIS: CLK						
3 DIS: CLR						

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0780 <small>STOP</small>	CFG: N	5250	NLIM1-OUT	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block NSET <ul style="list-style-type: none"> Main setpoint 	See System Manual (extension)
C0781 <small>STOP</small>	CFG: N-INV	10251	R/L/Q-R/L	<input type="checkbox"/> Selection list 2	Configuration of digital input signal, function block NSET <ul style="list-style-type: none"> HIGH: main setpoint (C0780) is inverted 	
C0782 <small>STOP</small>	CFG: NADD	55	AIN2-OUT	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block NSET <ul style="list-style-type: none"> Additional setpoint 	
C0783 <small>STOP</small>	CFG: NADD-INV	1000	FIXED0	<input type="checkbox"/> Selection list 2	Configuration of digital input signal, function block NSET <ul style="list-style-type: none"> HIGH: additional setpoint (C0783) is inverted 	
C0784 <small>STOP</small>	CFG: CINH-VAL	5001	MCTRL-NACT	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block NSET <ul style="list-style-type: none"> The signal is accepted by the main setpoint integrator when the controller is inhibited 	
C0785 <small>STOP</small>	CFG: SET	5000	MCTRL-nset2	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block NSET <ul style="list-style-type: none"> When NSET-LOAD = HIGH, the signal is accepted by the main setpoint integrator 	
C0786 <small>STOP</small>	CFG: LOAD	5001	MCTRL-QSP-OUT	<input type="checkbox"/> Selection list 2	Configuration of digital input signal, function block NSET <ul style="list-style-type: none"> HIGH: The signal at NSET-SET is accepted by the mains setpoint integrator Control of both ramp function generators in special situations, e.g. quick stop 	
C0787 <small>STOP</small>				<input type="checkbox"/> Selection list 2	Configuration of digital input signals, function block NSET <ul style="list-style-type: none"> Activation of a fixed speed via binary coding of the digital input signals For coding see description of function block NSET Parameter setting of the fixed speeds (JOG setpoints) in C0039 	See System Manual (extension)
1	CFG: JOG	53	DIGIN3		NSET-JOG*1	
2	CFG: JOG	1000	FIXED0		NSET-JOG*2	
3	CFG: JOG	1000	FIXED0		NSET-JOG*4	
4	CFG: JOG	1000	FIXED0		NSET-JOG*8	
C0788 <small>STOP</small>				<input type="checkbox"/> Selection list 2	Configuration of digital input signals, function block NSET <ul style="list-style-type: none"> Activation of additional acceleration and deceleration times for the mains setpoint via binary coding of the digital input signals For coding see description of function block NSET Parameter setting of the times in C0101 and 103 	
1	CFG: TI	1000	FIXED0		NSET-Ti*1	
2	CFG: TI	1000	FIXED0		NSET-Ti*2	
3	CFG: TI	1000	FIXED0		NSET-Ti*4	
4	CFG: TI	1000	FIXED0		NSET-Ti*8	

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0789 <small>STOP</small>	CFG: RFG-0	1000	FIXED0	<input type="checkbox"/> Selection list 2	Configuration of digital input signal, function block NSET <ul style="list-style-type: none"> HIGH: Guides the main setpoint integrator to 0 via the current T_i times 	See System Manual (extension)
C0790 <small>STOP</small>	CFG: RFG-STOP	1000	FIXED0	<input type="checkbox"/> Selection list 2	Configuration of digital input signal, function block NSET <ul style="list-style-type: none"> HIGH: Keeps the main setpoint integrator on its current value 	
C0798			-199.99 1. DIS: CINH-VAL 2. DIS: SET	{0.01 %} 199.99	Function block NSET <ul style="list-style-type: none"> Display of the signals linked in C0783 and C0785 Read only: analog input signals of NSET	See System Manual (extension)
C0799	Input signals		0		1 Function block NSET <ul style="list-style-type: none"> Display of the signals linked in C0781, C0783, C0786, C0787, C0788, C0789 and C0790 	
C0800 <small>STOP</small>	CFG: SET	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block PCTRL <ul style="list-style-type: none"> Input for the process setpoint Value range: $\pm 200\%$ 	See System Manual (extension)
C0801 <small>STOP</small>	CFG: ACT	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block PCTRL <ul style="list-style-type: none"> Configuration of analog input signal of PCTRL1 Input for the actual value Value range: $\pm 200\%$ 	
C0802 <small>STOP</small>	CFG: INFLU	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block PCTRL <ul style="list-style-type: none"> Evaluation (influence) of the output signal Value range: $\pm 200\%$ 	
C0803 <small>STOP</small>	CFG: ADAPT	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block PCTRL <ul style="list-style-type: none"> The gain V_p can be changed via the adaptation input Value range: $\pm 200\%$ 	
C0804 <small>STOP</small>	CFG: INACT	1000	FIXED0	<input type="checkbox"/> Selection list 2	Configuration of digital input signal, function block PCTRL <ul style="list-style-type: none"> HIGH = deactivates the process controller 	
C0805 <small>STOP</small>	CFG: I-OFF	1000	FIXED0	<input type="checkbox"/> Selection list 2	Configuration of digital input signal, function block PCTRL <ul style="list-style-type: none"> HIGH = Switching off integral action component LOW = Switching on integral action component 	

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0808		-199.99 1 DIS: SET 2 DIS: ACT 3 DIS: INFLU 4 DIS: ADAPT	{0.01 %}	199.99	Function block PCTRL	See System Manual (extension)
					● Display of the signals linked in C0801, C0802, C0803 and C0804	
					Function block PCTRL	
					● Display of the signals linked in C0805 and C0806	
C0809		1 DIS: INACT 2 DIS: I-OFF			Configuration of analog input signals, function block ASW1	See System Manual (extension)
					ASW1-IN1	
C0810	<small>STOP</small>			□ Selection list 1	ASW1-IN2	
		1 CFG: IN	1000	FIXED0%	Configuration of digital input signal, function block ASW1	
		2 CFG: IN	1000	FIXED0%	● LOW: signal at ASW1-IN1 is output to ASW1-OUT	See System Manual (extension)
C0811	<small>STOP</small>	CFG: SET	1000	FIXED0	● HIGH: signal at ASW1-IN2 is output to ASW1-OUT	
				□ Selection list 2	Function block ASW1	
					● Display of the signals linked in C0810	
C0812		1 DIS: IN 2 DIS: IN	-199.99	{0.01 %}	199.99	
					ASW1-IN1	
C0813	DIS: SET		0		1 Function block ASW1	See System Manual (extension)
					● Display of the signal linked in C0811	
C0815	<small>STOP</small>			□ Selection list 1	Configuration of analog input signals, function block ASW2	
		1 CFG: IN	1000	FIXED0%	ASW2-IN1	
		2 CFG: IN	1000	FIXED0%	ASW2-IN2	See System Manual (extension)
C0816	<small>STOP</small>	CFG: SET	1000	FIXED0	Configuration of digital input signal, function block ASW2	
				□ Selection list 2	● LOW: signal at ASW2-IN1 is output to ASW2-OUT	
					● HIGH: signal at ASW2-IN2 is output to ASW2-OUT	
C0817		1 DIS: IN 2 DIS: IN	-199.99	{0.01 %}	199.99	
					ASW2-IN1	
C0818	DIS: SET		0		1 Function block ASW2	See System Manual (extension)
					● Display of the signal linked in C0816	
C0820	<small>STOP</small>			□ Selection list 2	Configuration of digital input signals, function block AND1	
		1 CFG: IN	1000	FIXED0	AND1-IN1	
		2 CFG: IN	1000	FIXED0	AND1-IN2	See System Manual (extension)
		3 CFG: IN	1000	FIXED0	AND1-IN3	
C0821		1 DIS: IN 2 DIS: IN 3 DIS: IN	0		1 Function block AND1	
					● Display of the signals linked in C0820	
					AND1-IN1	
					AND1-IN2	
					AND1-IN3	

Code		Possible settings		IMPORTANT	
No.	Name	Lenze	Selection		
C0822 <small>STOP</small>				<input type="checkbox"/> Selection list 2	Configuration of digital input signals, function block AND2 See System Manual (extension)
1	CFG: IN	1000	FIXED0		AND2-IN1
2	CFG: IN	1000	FIXED0		AND2-IN2
3	CFG: IN	1000	FIXED0		AND2-IN3
C0823		0	1	<input type="checkbox"/> Selection list 2	Function block AND2 ● Display of the signals linked in C0822 See System Manual (extension)
1	DIS: IN				AND2-IN1
2	DIS: IN				AND2-IN2
3	DIS: IN				AND2-IN3
C0824 <small>STOP</small>				<input type="checkbox"/> Selection list 2	Configuration of digital input signals, function block AND3 See System Manual (extension)
1	CFG: IN	1000	FIXED0		AND3-IN1
2	CFG: IN	1000	FIXED0		AND3-IN2
3	CFG: IN	1000	FIXED0		AND3-IN3
C0825		0	1	<input type="checkbox"/> Selection list 2	Function block AND3 ● Display of the signals linked in C0824 See System Manual (extension)
1	DIS: IN				AND3-IN1
2	DIS: IN				AND3-IN2
3	DIS: IN				AND3-IN3
C0826 <small>STOP</small>				<input type="checkbox"/> Selection list 2	Configuration of digital input signals, function block AND4 See System Manual (extension)
1	CFG: IN	1000	FIXED0		AND4-IN1
2	CFG: IN	1000	FIXED0		AND4-IN2
3	CFG: IN	1000	FIXED0		AND4-IN3
C0827		0	1	<input type="checkbox"/> Selection list 2	Function block AND4 ● Display of the signals linked in C0826 See System Manual (extension)
1	DIS: IN				AND4-IN1
2	DIS: IN				AND4-IN2
3	DIS: IN				AND4-IN3
C0828 <small>STOP</small>				<input type="checkbox"/> Selection list 2	Configuration of digital input signals, function block AND5 See System Manual (extension)
1	CFG: IN	1000	FIXED0		AND5-IN1
2	CFG: IN	1000	FIXED0		AND5-IN2
3	CFG: IN	1000	FIXED0		AND5-IN3
C0829		0	1	<input type="checkbox"/> Selection list 2	Function block AND5 ● Display of the signals linked in C0828 See System Manual (extension)
1	DIS: IN				AND5-IN1
2	DIS: IN				AND5-IN2
3	DIS: IN				AND5-IN3

Code		Possible settings		IMPORTANT	
No.	Name	Lenze	Selection		
C0830 STOP				□ Selection list 2	Configuration of digital input signals, function block OR1
1	CFG: IN	1000	FIXED0		OR1-IN1
2	CFG: IN	1000	FIXED0		OR1-IN2
3	CFG: IN	1000	FIXED0		OR1-IN3
C0831			0	1	Function block OR1 ● Display of the signals linked in C0830
	1 DIS: IN				OR1-IN1
	2 DIS: IN				OR1-IN2
	3 DIS: IN				OR1-IN3
C0832 STOP				□ Selection list 2	Configuration of digital input signals, function block OR2
1	CFG: IN	1000	FIXED0		OR2-IN1
2	CFG: IN	1000	FIXED0		OR2-IN2
3	CFG: IN	1000	FIXED0		OR2-IN3
C0833			0	1	Function block OR2 ● Display of the signals linked in C0832
	1 DIS: IN				OR2-IN1
	2 DIS: IN				OR2-IN2
	3 DIS: IN				OR2-IN3
C0834 STOP				□ Selection list 2	Configuration of digital input signals, function block OR3
1	CFG: IN	1000	FIXED0		OR3-IN1
2	CFG: IN	1000	FIXED0		OR3-IN2
3	CFG: IN	1000	FIXED0		OR3-IN3
C0835			0	1	Function block OR3 ● Display of the signals linked in C0834
	1 DIS: IN				OR3-IN1
	2 DIS: IN				OR3-IN2
	3 DIS: IN				OR3-IN3
C0836 STOP				□ Selection list 2	Configuration of digital input signals, function block OR4
1	CFG: IN	1000	FIXED0		OR4-IN1
2	CFG: IN	1000	FIXED0		OR4-IN2
3	CFG: IN	1000	FIXED0		OR4-IN3
C0837			0	1	Function block OR4 ● Display of the signals linked in C0836
	1 DIS: IN				OR4-IN1
	2 DIS: IN				OR4-IN2
	3 DIS: IN				OR4-IN3

Code		Possible settings		IMPORTANT	
No.	Name	Lenze	Selection		
C0838 <small>STOP</small>				□ Selection list 2	Configuration of digital input signals, function block OR5 See System Manual (extension)
1	CFG: IN	1000	FIXED0		OR5-IN1
2	CFG: IN	1000	FIXED0		OR5-IN2
3	CFG: IN	1000	FIXED0		OR5-IN3
C0839			0	1	Function block OR5 ● Display of the signals linked in C0838
1	DIS: IN				OR5-IN1
2	DIS: IN				OR5-IN2
3	DIS: IN				OR5-IN3
C0840 <small>STOP</small>	CFG: IN	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block NOT1 See System Manual (extension)
C0841	DIS: IN		0	1	Function block NOT1 ● Display of the signal linked in C0841
C0842 <small>STOP</small>	CFG: IN	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block NOT2 See System Manual (extension)
C0843	DIS: IN		0	1	Function block NOT2 ● Display of the signal linked in C0842
C0844 <small>STOP</small>	CFG: IN	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block NOT3 See System Manual (extension)
C0845	DIS: IN		0	1	Function block NOT3 ● Display of the signal linked in C0844
C0846 <small>STOP</small>	CFG: IN	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block NOT4 See System Manual (extension)
C0847	DIS: IN		0	1	Function block NOT4 ● Display of the signal linked in C0846
C0848 <small>STOP</small>	CFG: IN	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block NOT5 See System Manual (extension)
C0849	DIS: IN		0	1	Function block NOT5 ● Display of the signal linked in C0848
C0850 <small>STOP</small>				□ Selection list 1	Configuration of analog input signals, function block AIF-OUT See System Manual (extension)
1	CFG: OUT.W1	1000	FIXED0%		Process output word 1 ● 100% = 16384 ● Signal is output via byte 3 and byte 4 to X1
2	CFG: OUT.W2	1000	FIXED0%		Process output word 2 ● 100% = 16384
3	CFG: OUT.W3	1000	FIXED0%		Process output word 3 ● 100% = 16384
C0851 <small>STOP</small>	CFG: OUT.D1	1000	FIXED0INC	□ Selection list 3	Configuration of phase input signal, function block AIF ● 32-bit phase signal

Code		Possible settings			IMPORTANT		
No.	Name	Lenze	Selection				
C0852	Type OUT.W2	0			Output of the signal type, function block AIF	See System Manual (extension)	
			0 analog	Analog signal	AIF-OUT.W2 (C0850/2) is output to X1		
			1 digital 0-15	Digital signal via bit 0 ... bit 15	FDO-00 ... FDO-15 (LOW word, C0116/1 ... C0116/15) are output to X1		
			2 low phase	Low phase	AIF-OUT.D1 (LOW word, C0851) is output to X1		
C0853	Type OUT.W3	0			Output of the signal type, function block AIF	See System Manual (extension)	
			0 analog	Analog signal	AIF-OUT.W3 (C0850/3) is output to X1		
			1 digital 16-31	Digital signal via bit 16 ... bit 31	FDO-16 ... FDO-31 (HIGH word, C0116/16 ... C0116/31) are output to X1		
			2 high phase	High phase	AIF-OUT.D1 (HIGH word, C0851) is output to X1		
C0855			0	FFFF	Process input words, function block AIF-IN ● Read only	See System Manual (extension)	
	1 DIS: IN (0 ... 15)				Bit 0 ... bit 15 (via byte 5 and byte 6)		
	2 DIS: IN (16 ... 31)				Bit 16 ... bit 31 (via byte 7 and byte 8)		
C0856			-199.99	{0.01 %}	199.99	Process input words, function block AIF-IN ● Read only ● 100% = 16384	See System Manual (extension)
						Input via byte 3 and byte 4	
						Input via byte 5 and byte 6	
						Input via byte 7 and byte 8	
C0857	DIS: IN.D1		-2147483648	{1}	2147483647	32-bit phase signal, function block AIF-IN ● Read only ● 65536 = 1 rev.	See System Manual (extension)
C0858			-199.99	{0.01 %}	199.99	Process output words, function block AIF-OUT ● Display of the signals linked in C0850 ● 100% = 16384	See System Manual (extension)
						● Display of the signals linked in C0850	
						● 100% = 16384	
C0859	DIS: OUT.D1		-2147483648	{1}	2147483647	32-bit phase signal, function block AIF-OUT ● Display of the signal linked in C0851 ● 1 rev. = 65536	See System Manual (extension)

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0860 <small>STOP</small>				<input type="checkbox"/> Selection list 1		
1	CFG: OUT1.W1	1000	FIXED0%			
2	CFG: OUT1.W2	1000	FIXED0%			
3	CFG: OUT1.W3	1000	FIXED0%			
4	CFG: OUT2.W1	1000	FIXED0%			
5	CFG: OUT2.W2	1000	FIXED0%			
6	CFG: OUT2.W3	1000	FIXED0%			
7	CFG: OUT2.W4	1000	FIXED0%			
8	CFG: OUT3.W1	1000	FIXED0%			
9	CFG: OUT3.W2	1000	FIXED0%			
10	CFG: OUT3.W3	1000	FIXED0%			
11	CFG: OUT3.W4	1000	FIXED0%			
C0861 <small>STOP</small>				<input type="checkbox"/> Selection list 3		
1	CFG: OUT1.D1	1000	FIXED0INC			
2	CFG: OUT2.D1	1000	FIXED0INC			
3	CFG: OUT3.D1	1000	FIXED0INC			
C0863			0	FFFF	Process input words, function block CAN-IN <ul style="list-style-type: none"> ● Read only ● Bit 0 ... bit 15 (via byte 5 and byte 6) ● Bit 16 ... bit 31 (via byte 7 and byte 8) 	See System Manual (extension)
1	DIS: IN1 dig0				CAN-IN1, bit 0 ... bit 15	
2	DIS: IN1 dig16				CAN-IN1, bit 16 ... bit 31	
3	DIS: IN2 dig0				CAN-IN2, bit 0 ... bit 15	
4	DIS: IN2 dig16				CAN-IN2, bit 16 ... bit 31	
5	DIS: IN3 dig0				CAN-IN3, bit 0 ... bit 15	
6	DIS: IN3 dig16				CAN-IN3, bit 16 ... bit 31	
C0864					Output of the signal type, function block CAN-OUT	See System Manual (extension)
1	TYPEOUT1.W2	0	0	analog	Analog signal	CAN-OUTx.Wx (C0860) is output to X4
2	TYPEOUT2.W1	0	1	digital 0-15	Digital signal bit 0 ... bit 15	FDO-00 ... FDO-15 (LOW word, C0116/1 ... C0116/15) are output to X4
3	TypeOUT3.W1	0	2	low phase	Low phase	CAN-OUTx.D1 (LOW word, C0861) is output to X4
C0865					Output of the signal type, function block CAN-OUT	
1	TYPEOUT1.W3	0	0	analog	Analog signal	CAN-OUTx.Wx (C0860) is output to X4
2	TYPEOUT2.W2	0	1	digital 16-31	Digital signal bit 16 ... bit 31	FDO-16 ... FDO-31 (HIGH word, C0116/16 ... C0116/31) are output to X1
3	TYPEOUT3.W2	0	2	high phase	High phase	CAN-OUTx.D1 (HIGH word, C0861) is output to X4

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0866		1 DIS: IN1.W1 2 DIS: IN1.W2 3 DIS: IN1.W3 4 DIS: IN2.W1 5 DIS: IN2.W2 6 DIS: IN2.W3 7 DIS: IN2.W4 8 DIS: IN3.W1 9 DIS: IN3.W2 10 DIS: IN3.W3 11 DIS: IN3.W4	-32768.00	{0.01 %}	32767.00	Process input words, function block CAN-IN ● Read only ● 100% = 16384
						CAN-IN1
						CAN-IN2
						CAN-IN3
C0867			-2147483648	{1}	2147483647	32-bit phase signal, function block CAN-IN ● Read only ● 1 rev. = 65536
C0868			-199.99	{0.01 %}	199.99	Process output words, function block CAN-OUT ● Display of the signals linked in C0860 ● 100% = 16384
C0869			-2147483648	{1}	2147483647	32-bit phase information, function block CAN-OUT ● Display of the signals linked in C0861 ● 1 rev. = 65536
C0870 <small>STOP</small>				□ Selection list 2		Configuration of digital input signals, function block DCTRL
1	CFG: CINH	1000	FIXED0			DCTRL-CINH1 HIGH = Controller inhibit
2	CFG: CINH	1000	FIXED0			DCTRL-CINH2 HIGH = Controller inhibit
C0871 <small>STOP</small>	CFG: TRIP-SET	54	DIGIN4	□ Selection list 2		Configuration of digital input signal, function block DCTRL ● HIGH = fault message EEr
C0876 <small>STOP</small>	CFG: TRIP-RES	55	DIGIN5	□ Selection list 2		Configuration of digital input signal, function block DCTRL ● LOW-HIGH edge = TRIP reset
C0878		1 DIS: CINH1 2 DIS: CINH2 3 DIS: TRIP-SET 4 DIS: TRIP-RES				Function block DCTRL ● Display of the signals linked in C0870, C0871 and C0876

Code		Possible settings				IMPORTANT					
No.	Name	Lenze	Selection								
C0879	1 Reset C135	0	0	Ready			Resetting control words • C0879 = 1 performs one reset				
	2 Reset AIF	0	1	Reset							
	3 Reset CAN	0									
C0880 <small>STOP</small>					■ Selection list 2		See System Manual (extension)				
	1 CFG: PAR*1	1000	FIXED0	C0880/1	C0880/2	Selected parameter set					
	2 CFG: PAR*2	1000	FIXED0	0	0	Parameter set 1					
				0	1	Parameter set 2					
				1	0	Parameter set 3					
				1	1	Parameter set 4					
C0881 <small>STOP</small>	CFG: PAR-LOAD	1000	FIXED0				■ Selection list 2	Configuration of digital input signal, function block DCTRL • LOW-HIGH edge = Load selected parameter set into C0880	See System Manual (extension)		
C0884	1 DIS: PAR*1					Function block DCTRL • Display of the signals linked in C0880 and C0881		See System Manual (extension)			
	2 DIS: PAR*2										
	3 DIS: PAR-LOAD										
C0885 <small>STOP</small>	CFG: R	51	DIGIN1				■ Selection list 2	Configuration of digital input signals, function block R/L/Q • Truth table: Inputs Outputs R L R/L QSP 0 0 0/1 1 1 0 0 0 0 1 1 0 1 1 — — — State is unchanged	See System Manual (extension)		
C0886 <small>STOP</small>	CFG: L	52	DIGIN2				■ Selection list 2				
	1 DIS: R			0		1	Function block R/L/Q • Display of the signals linked in C0885 and C0886				
C0889 <small>STOP</small>	2 DIS: L										
C0890 <small>STOP</small>	CFG: N-SET	5050	NSET-NOUT				■ Selection list 1	Configuration of analog input signal, function block MCTRL • Speed setpoint	8.2-25 8.2-40		
C0891 <small>STOP</small>	CFG: M-Add	1000	FIXED0%				■ Selection list 1	Configuration of analog input signal, function block MCTRL • Additional torque setpoint or torque setpoint	8.2-40		
C0892 <small>STOP</small>	CFG: Lo-M-LIM	5700	ANEGL1-OUT				■ Selection list 1	Configuration of analog input signal, function block MCTRL • Lower torque limit in [%] of C0057			
C0893 <small>STOP</small>	CFG: HI-M-LIM	19523	FCODE-472/3				■ Selection list 1	Configuration of analog input signal, function block MCTRL • Upper torque limit in [%] of C0057			
C0898 <small>STOP</small>	CFG: M-LIM switch	0	0	M-LIM ON	Reduced torque limit is active			Torque limitation in the field weakening range, function block MCTRL • If the torque limit is reduced, the maximum possible torque in the field weakening range is lowered with 1/f. This provides a higher motor stability in the field weakening range	8.2-40		
				1	M-LIM OFF	Reduced torque limit is inactive					

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0899 <small>STOP</small>	CFG: N/M-SWT	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block MCTRL ● LOW = active speed control ● HIGH = active torque control	□ 8.2-40
C0900 <small>STOP</small>	CFG: QSP	10250	R/L/Q-QSP	□ Selection list 2	Configuration of digital input signal, function block MCTRL ● HIGH = drive performs quick stop	□ 8.2-25 □ 8.2-40
C0901 <small>STOP</small>	CFG: I-SET	1000	FIXED0%	□ Selection list 1	Configuration of analog input signal, function block MCTRL ● Setting of integral action component of the speed controller	□ 8.2-40
C0902 <small>STOP</small>	CFG: I-LOAD	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block MCTRL ● HIGH = the integral action component at MCTRL-I-SET is accepted by the speed controller	
C0903 <small>STOP</small>	CFG: BOOST	5015	MCTRL-BOOST	□ Selection list 1	Configuration of analog input signal, function block MCTRL ● Boost of the motor voltage	□ 8.2-25
C0904 <small>STOP</small>	CFG: DC-BREAK	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block MCTRL ● HIGH = Motor is braked	□ 8.2-25
C0905	DIS: DC-BREAK		0	1	Function block MCTRL ● Display of the signal linked in C0904	□ 8.2-40
C0906			-199.99 {0.01 %}	199.99	Function block MCTRL ● Display of the signals linked in C0890, C0891, C0892, C0893, C0901 and C0903	□ 8.2-25 □ 8.2-40
1	DIS: N-SET					
2	DIS: M-ADD					
3	DIS: LO-M-LIM					
4	DIS: HI-M-LIM					
5	DIS: I-SET					
6	DIS: BOOST					
C0907			0	1	Function block MCTRL ● Display of the signals linked in C0899, C0900 and C0902	
1	reserved					
2	DIS: N/M-SWT					
3	DIS: QSP					
4	DIS: I-LOAD					
C0909	speed limit	1	1 +/- 175 % 2 0 ... 175 % 3 -175 ... 0 %		Speed limitation, function block MCTRL ● Limitation of direction of rotation for the speed setpoint	□ 8.2-25 □ 8.2-40
C0910 <small>STOP</small>	CFG: VP-ADAPT	1006	FIXED100%	□ Selection list 1	Configuration of analog input signal, function block MCTRL ● Gain adaptation of the speed controller ● If the gain is varying, join to CURVE-OUT of FB CURVE	□ 8.2-25 □ 8.2-40
C0911	DIS: VP-ADAPT		-199.99 {0.01 %}	199.99	Function block MCTRL ● Display of the signal linked in C0910	
C0912	OV delay time	→	- {1 ms}	-	Delay time of the pulse release after an OU message The default value can be changed by the factor 0.5 ... 2 → depending on the type	□ 8.2-25 □ 8.2-40

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0940	Numerator	1	-32767	{1}	32767	Configuration of conversion factor with numerator and denominator, function block CONV1 OUT [%] = IN [%] · $\frac{C0940}{C0941}$
C0941	Denominator	1	1	{1}	32767	
C0942	CFG: IN <small>STOP</small>	1000	FIXED0%	□ Selection list 1		Configuration of analog input signal, function block CONV1
C0943	DIS: IN		-199.99	{0.01 %}	199.99	Function block CONV1 ● Display of the signal linked in C0942
C0945	Numerator	1	-32767	{1}	32767	Configuration of conversion factor with numerator and denominator, function block CONV2 OUT [%] = IN [%] · $\frac{C0945}{C0946}$
C0946	Denominator	1	1	{1}	32767	
C0947	CFG: IN <small>STOP</small>	1000	FIXED0%	□ Selection list 1		Configuration of analog input signal, function block CONV2
C0948	DIS: IN		-199.99	{0.01 %}	199.99	Function block CONV2 ● Display of the signal linked in C0947
C0950	Numerator	1	-32767	{1}	32767	Configuration of conversion factor with numerator and denominator, function block CONV3 OUT [%] = IN [rpm] · $\frac{100 \%}{15000 \text{ rpm}} \cdot \frac{C0950}{C0951}$
C0951	Denominator	1	1	{1}	32767	
C0952	CFG: IN <small>STOP</small>	1000	FIXED0%	□ Selection list 1		Configuration of analog input signal, function block CONV3
C0953	DIS: IN		-199.99	{0.01 %}	199.99	Function block CONV3 ● Display of the signal linked in C0952
C0955	Numerator	1	-32767	{1}	32767	Configuration of conversion factor with numerator and denominator, function block CONV4 OUT [%] = IN [rpm] · $\frac{100 \%}{15000 \text{ rpm}} \cdot \frac{C0955}{C0956}$
C0956	Denominator	1	1	{1}	32767	
C0957	CFG: IN <small>STOP</small>	1000	FIXED0%	□ Selection list 1		Configuration of analog input signal, function block CONV4
C0958	DIS: IN		-199.99	{0.01 %}	199.99	Function block CONV4 ● Display of the signal linked in C0957
C0960	Function	1				Function selection, function block CURVE1
			1	Function 1		Characteristic with two base points
			2	Function 2		Characteristic with three base points
			3	Function 3		Characteristic with four base points

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0961	y0	0.00	0.00	{0.01 %}	199.99	Configuration of base point y0, function block CURVE1 ● Ordinate of the value pair (x = 0 % / y0)	See System Manual (extension)
C0962	y1	50.00	0.00	{0.01 %}	199.99	Configuration of base point y1, function block CURVE1 ● Ordinate of the value pair (x1 / y1)	
C0963	y2	75.00	0.00	{0.01 %}	199.99	Configuration of base point y2, function block CURVE1 ● Ordinate of the value pair (x2 / y2)	
C0964	y100	100.0	0.00	{0.01 %}	199.99	Configuration of base point y100, function block CURVE1 ● Ordinate of the value pair (x 100 % / y100)	
C0965	x1	50.00	0.01	{0.01 %}	99.99	Configuration of base point x1, function block CURVE1 ● Abscissa of the pair (x1 / y1)	
C0966	x2	75.00	0.01	{0.01 %}	99.99	Configuration of base point x2, function block CURVE1 ● Abscissa of the pair (x2 / y2)	
C0967 <small>STOP</small>	CFG: IN	1000	FIXED0%	 Selection list 1		Configuration of analog input signal, function block CURVE1	See System Manual (extension)
C0968	DIS: IN		-199.99	{0.01 %}	199.99	Function block CURVE1 ● Display of the signal linked in C0967	

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0970 <small>STOP</small>	CFG: SET	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block MFAIL <ul style="list-style-type: none"> Starting value for the controlled deceleration in [%] of C0011 	See System Manual (extension)
C0971 <small>STOP</small>	CFG: FAULT	1000	FIXED0	<input type="checkbox"/> Selection list 2	Configuration of digital input signal, function block MFAIL <ul style="list-style-type: none"> HIGH = activates mains failure control 	
C0972 <small>STOP</small>	CFG: RESET	1000	FIXED0	<input type="checkbox"/> Selection list 2	Configuration of digital input signal, function block MFAIL <ul style="list-style-type: none"> HIGH = resets mains failure control 	
C0973 <small>STOP</small>	CFG: ADAPT	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block MFAIL <ul style="list-style-type: none"> Dynamic adaptation of the proportional gain of UGsetl controller in [%] of C0980 	
C0974 <small>STOP</small>	CFG: CONST	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block MFAIL <ul style="list-style-type: none"> Proportional gain of UGset controller in [%] of C0980 	
C0975 <small>STOP</small>	CFG: THRESHLD	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block MFAIL <ul style="list-style-type: none"> Restart protection when the value falls below the speed threshold Restart threshold in [%] of C0011 	
C0976 <small>STOP</small>	CFG: NACT	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block MFAIL <ul style="list-style-type: none"> Comparison value for the restart threshold in [%] of C0011 Start for V₂ controller 	
C0977 <small>STOP</small>	CFG: SET	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block MFAIL <ul style="list-style-type: none"> Speed starting value for the deceleration in [%] of C0011 	
C0978 <small>STOP</small>	CFG: DC-SET	1000	FIXED0%	<input type="checkbox"/> Selection list 1	Configuration of analog input signal, function block MFAIL <ul style="list-style-type: none"> Setting of the voltage setpoint on which the DC-bus voltage is to be kept (100 % = 1000 V) 	
C0980	MFAIL V _p	0.500	0.001	{0.001}	31.000	Gain V _p , function block MFAIL
C0981	MFAIL T _n	100	20	{1 ms}	2000	Integral-action time T _n , function block MFAIL
C0982	MFAIL T _{ir}	2.000	0.001	{0.001 s}	16.000	Acceleration time T _{ir} , function block MFAIL
C0983	Retrigger T	1.000	0.001	{0.001 s}	60.000	Retrigger time, function block MFAIL <ul style="list-style-type: none"> After the time has elapsed, the mains failure control is terminated

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0988	Input signals	1 2 3 4 5 6 7	-199.99	{0.01 %}	199.99	Function block MFAIL
	1 DIS: N-SET					● Display of the signals linked in C0970, C0973, C0974, C0975, C0976, C0977 and C0978
	2 DIS: ADAPT					
	3 DIS: CONST					
	4 DIS: THRESHLD					
	5 DIS: NACT					
	6 DIS: SET					
	7 DIS: DC-SET					
C0989		1 2	0		1	Function block MFAIL
	1 DIS: FAULT					● Display of the signals linked in C0971 and C0972
	2 DIS: RESET					
C1000	DIVISION	1	0	{1}	31	Part factor, function block CONVPHA1
						● Calculate output signal: $OUT [\%] = IN [\%] \cdot \frac{100 \%}{2^{14} \cdot 2^{C1000}}$
C1001 <small>STOP</small>	CFG: IN	1000	FIXED0INC	□ Selection list 3		Configuration of input signal, function block CONVPHA1
C1002	DIS: IN		-2147483648	{1}	2147483647	Function block CONVPHA1
						● Display of the signal linked in C1001
C1040	Acceleration	100.00 0	0.001	{0.001 }	5000.000	Acceleration, function block SRFG1
						● Max. acceleration
C1041	Jerk	0.200	0.001	{0.001 s}	999.999	Jerk, function block SRFG1
						● S-ramp time
C1042 <small>STOP</small>	CFG: IN	1000	FIXED0%	□ Selection list 1		Configuration of analog input signal, function block SRFG1
C1043 <small>STOP</small>	CFG: SET	1000	FIXED0%	□ Selection list 1		Configuration of analog input signal, function block SRFG1
						● Starting value for the ramp function generator
						● Starting value is accepted when SRFG1-LOAD = HIGH
C1044 <small>STOP</small>	CFG: LOAD	1000	FIXED0	□ Selection list 2		Configuration of digital input signal, function block SRFG1
						● HIGH = accepts the value at SRFG1-SET and outputs it to SRFG1-OUT. SRFG1-DIFF remains on 0 %
C1045		1 2	-199.99	{0.01 %}	199.99	Function block SRFG1
	DIS: IN					● Display of the signals linked in C1042 and C1043
C1046	DIS: LOAD		0		1	Function block SRFG1
						● Display of the signal linked in C1044
C1090	Output signal		-2147483648	{1}	2147483647	Function block FEVAN1
						● Display of the converted signal
C1091	Code	141	2	{1}	2000	Code, function block FEVAN1
						● Selection of the target code in which the calculated value is to be written
C1092	Subcode	0	0	{1}	255	Subcode, function block FEVAN1
						● Selection of the target subcode in which the calculated value is to be written

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C1093	Numerator	1.0000	0.0001	{0.0001}	100000.0000	Numerator, function block FEVAN1 ● Scaling of the input signal	See System Manual (extension)
C1094	Denominator	0.0001	0.0001	{0.0001}	100000.0000	Denominator, function block FEVAN1 ● Scaling of the input signal	
C1095	Offset	0	0	{1}	1000000000	Offset, function block FEVAN1 ● An offset can be added to the converted signal	
C1096 <small>STOP</small>	CFG: IN	1000	FIXED0%	□ Selection list 1		Configuration of analog input signal, function block FEVAN1	See System Manual (extension)
C1097 <small>STOP</small>	CFG: LOAD	1000	FIXED0	□ Selection list 2		Configuration of digital input signal, function block FEVAN1 ● A LOW-HIGH edge transmits the converted signal to the target code	
C1098	DIS: IN		-32768	{1}	32767	Function block FEVAN1 ● Display of the signal linked in C1096	See System Manual (extension)
C1099	DIS: LOAD					Function block FEVAN1 ● Display of the signal linked in C1097	
C1100	Function	1				Function selection, function block FCNT1	See System Manual (extension)
		1	Return			At counter content ≥ FCNT1-CMP-Val FCNT1-EQUAL is set to HIGH for 1 ms	
		2	Hold if >=			At counter content ≥ FCNT1-CMP-Val the counter stops	
		3	Hold if =			At counter content = FCNT1-CMP-Val the counter stops	
C1101 <small>STOP</small>				□ Selection list 1		Configuration of analog input signals, function block FCNT1	See System Manual (extension)
1	CFG: LD-VAL	1000	FIXED0%			● Starting value	
2	CFG: CMP-VAL	1000	FIXED0%			● Comparison value	
C1102 <small>STOP</small>				□ Selection list 2		Configuration of digital input signals, function block FCNT1	See System Manual (extension)
1	CFG: CLKUP	1000	FIXED0			LOW-HIGH edge counts upwards by one	
2	CFG: CLKDWN	1000	FIXED0			LOW-HIGH edge counts downwards by one	
3	CFG: LOAD	1000	FIXED0			● HIGH = accepts starting value ● Input signal has highest priority	
C1103			-32768	{1}	32768	Function block FCNT1 ● Display of the signals linked in C1101	See System Manual (extension)
1	DIS: LD-VAL						
2	DIS: CMP-VAL						
C1104			0		1	Function block FCNT1 ● Display of the signals linked in C1102	
1	DIS: CLKUP						
2	DIS: CLKDWN						
3	DIS: LOAD						

Code		Possible settings			IMPORTANT		
No.	Name	Lenze	Selection				
C1160 <small>STOP</small>				□ Selection list 1	Configuration of analog input signals, function block ASW3	See System Manual (extension)	
1	CFG: IN	1000	FIXED0%		ASW3-IN1		
2	CFG: IN	1000	FIXED0%		ASW3-IN2		
C1161 <small>STOP</small>	CFG: SET	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block ASW3 <ul style="list-style-type: none"> ● LOW: signal at ASW3-IN1 is output to ASW3-OUT ● HIGH: signal at ASW3-IN2 is output to ASW3-OUT 		
C1162			-199.99	{0.01 %}	199.99	Function block ASW3 <ul style="list-style-type: none"> ● Display of the signals linked in C1060 	
1	DIS: IN					ASW3-IN1	
2	DIS: IN					ASW3-IN2	
C1163	DIS: SET					Function block ASW3 <ul style="list-style-type: none"> ● Display of the signal linked in C1061 	
C1190	Motor PTC selection	0			Temperature characteristic for PTC thermistors <ul style="list-style-type: none"> ● Selection of the characteristic for PTC thermistors at X7 or X8 for detecting the motor temperature 	6.6-11	
		0	Standard		Characteristic for PTC thermistors in Lenze motors		
		1	Characteristic		Characteristic for application-specific PTC thermistors		
C1191	Temperature characteristic	0		{1 °C}	255	Temperature range for PTC thermistors <ul style="list-style-type: none"> ● Define temperature points on the characteristic for PTC thermistors 	
1	Temperature 1	100				Temperature point 1	
2	Temperature 2	150				Temperature point 2	
C1192	Resistance characteristic	0		{1 Ω}	3000	Resistance characteristic for PTC thermistors <ul style="list-style-type: none"> ● Define resistance points on the characteristic for PTC thermistors 	
1	Resistance 1	1670				Resistance point 1	
2	Resistance 2	2225				Resistance point 2	
C1300 <small>STOP</small>	N-motor/ Dmax	300	-32767	{1 rpm}	32767	Motor speed at D _{max} , function block DCALC1 <ul style="list-style-type: none"> ● Nominal speed of the winding drive 	8.2-1
C1301 <small>STOP</small>	N-line max	3000	1	{1 rpm}	32767	Maximum line speed, function block DCALC1 <ul style="list-style-type: none"> ● Nominal speed of the line drive 	
C1302	calc cycle	0.1	0.1	{0.1 rev}	100.0	Calculation cycle, function block DCALC1	
C1303	time const	0.10	0.01	{0.01 s}	50.00	Filter time constant, function block DCALC1	

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C1304 <small>STOP</small>	Dmax	500	1	{1 mm}	10000	Maximum diameter, function block DCALC1 <ul style="list-style-type: none"> ● Nominal winding diameter 	8.2-1
C1305	lower D-limit	50	1	{1 mm}	10000	Lower diameter limit, function block DCALC1 <ul style="list-style-type: none"> ● Minimum winding diameter 	
C1306	upper D-limit	500	1	{1 mm}	10000	Upper diameter limit, function block DCALC1 <ul style="list-style-type: none"> ● Maximum winding diameter 	
C1307	hyst D-limit	1.00	0.00	{0.01 %}	100.0	Hysteresis - diameter limitation, function block DCALC1 <ul style="list-style-type: none"> ● Hysteresis for D_{\min} / D_{\max} output 	
C1308 <small>STOP</small>	arit function	1	0	DCALC1-OUT=D	DCALC1-OUT = diameter	Selection of the arithmetic function, function block DCALC1	8.2-1
			1	DCALC1-OUT=1/D	DCALC1-OUT = 1/diameter		
C1309 <small>STOP</small>	Dmin	50	1	{1 mm}	10000	Minimum diameter, function block DCALC1	8.2-1
C1310	DCALC1-Titime	0.000	0.000	{0.001 s}	999.900	Acceleration and deceleration time, function block DCALC1	
C1311	window D-calc	1.00	0.00	{0.01 %}	100.00	Window - diameter calculation, function block DCALC1 <ul style="list-style-type: none"> ● Window setting for permissible diameter deviation 	
C1320 <small>STOP</small>	CFG: SET	1000	FIXED0%	Selection list 1		Configuration of analog input signal, function block DCALC1 <ul style="list-style-type: none"> ● The signal is scaled to the value in C1304 (100 % \triangleq C1304) 	8.2-1
C1321 <small>STOP</small>				Selection list 2		Configuration of digital input signals, function block DCALC1	
1	CFG: LOAD	1000	FIXED0	<ul style="list-style-type: none"> ● HIGH: initial value at DCALC1-SET is accepted ● DCALC1-LOAD has a higher priority than DCALC1-HOLD 			
2	CFG: HOLD	1000	FIXED0	<ul style="list-style-type: none"> ● HIGH = holds the diameter value reached and resets the integrators. 			
C1322			-36000	{1 rpm}	36000	Function block DCALC1 <ul style="list-style-type: none"> ● Display of the signals linked in C1327 	8.2-1
1	DIS: N-Line						
2	DIS: N-WIND						
C1325	DIS: SET		-199,99	{0.01 %}	199,99	Function block DCALC1 <ul style="list-style-type: none"> ● Display of the signal linked in C1320 	
C1326			0		1	Function block DCALC1 <ul style="list-style-type: none"> ● Display of the signals linked in C1321 	
1	DIS: LOAD						
2	DIS: HOLD						
C1327 <small>STOP</small>				Selection list 3		Configuration of input signals, function block DCALC1	8.2-1
1	CFG: N-Line	1000	FIXED0INC	<ul style="list-style-type: none"> ● Speed signal of the line drive 			
2	CFG: N-WIND	1000	FIXED0INC	<ul style="list-style-type: none"> ● Speed signal of the winding drive 			
C1328	DIS: D-ACT		-200	{1 mm}	200	Function block DCALC1 <ul style="list-style-type: none"> ● Display of the current diameter 	

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C1330	PCTRL2 Tir	1.0	0.1	{0.1 s}	6000.0	<p>Acceleration time t_{ir}, function block PCTRL2</p> <ul style="list-style-type: none"> • Acceleration time for the setpoint • The acceleration time refers to a setpoint change of 0 ... 100 %
C1331	PCTRL2 Tif	1.0	0.1	{0.1 s}	6000.0	<p>Deceleration time t_{if}, function block PCTRL2</p> <ul style="list-style-type: none"> • Deceleration time for the setpoint • The deceleration time refers to a setpoint change of 100 % ... 0
C1332	PCTRL2 Vp	1.0	0.1	{0.1 }	500.0	Gain V_p , function block PCTRL2
C1333	PCTRL2 Tn	400	20	{1 ms}	99999	<p>Integral-action time T_n, function block PCTRL2</p> <p>Setting of reset time T_n of PCTRL2</p>
C1334	PCTRL2 Kd	0.0	0.0	{0.1 }	5.0	Differential component K_d , function block PCTRL2
C1335	bipolar/ unipolar	0				Sphere of action, function block PCTRL2
			0	Bipolar		<ul style="list-style-type: none"> • Output value is limited to -100 ... 100 %
			1	Unipolar		<ul style="list-style-type: none"> • Output value is limited to 0 ... 100 %
C1336	Tir overlay	1.0	0.1	{0.1 s}	6000.0	<p>Fade-in time, function block PCTRL2</p> <ul style="list-style-type: none"> • Acceleration time of the ramp generator • Controls the influence of the process controller
C1337	Tif overlay	1.0	0.1	{0.1 s}	6000.0	<p>Fade-out time, function block PCTRL2</p> <ul style="list-style-type: none"> • Deceleration time of the ramp generator • Controls the influence of the process controller
C1340 				□ Selection list 1	Configuration of analog input signals, function block PCTRL2	
1	CFG: RFG-SET	1000	FIXED0%		<ul style="list-style-type: none"> • The process setpoint is shown at PCTRL2-SET with a starting value via a ramp generator • PCTRL-RFG-LOAD = HIGH activates the function 	
2	CFG: SET	1000	FIXED0%		<ul style="list-style-type: none"> • Input for process value • Value range: ±200 % 	
3	CFG: ACT	1000	FIXED0%		<ul style="list-style-type: none"> • Input for actual value • Value range: ±200 % 	
4	CFG: INFL	1000	FIXED0%		<ul style="list-style-type: none"> • Evaluation (influence) of the output signal • Value range: ±200 % 	

Code		Possible settings			IMPORTANT		
No.	Name	Lenze	Selection				
C1341 <small>STOP</small>				<input type="checkbox"/> Selection list 2			
1	CFG: RFG-LOAD	1000	FIXED0			Configuration of digital input signals, function block PCTRL2	
2	CFG: I-OFF	1000	FIXED0			<ul style="list-style-type: none"> • HIGH = function of PCTRL2-RFG-SET is active • HIGH = Switches of integral action component • LOW = switches on integral action component 	
3	CFG: INACT	1000	FIXED0			<ul style="list-style-type: none"> • HIGH = deactivates process controller 	
4	CFG: OVERLAY	1000	FIXED0			<ul style="list-style-type: none"> • HIGH = Shows influence • LOW = hides influence 	
C1344				-199.99	{0.01 %}	199.99	Function block PCTRL2
1	DIS: RFG-SET						<ul style="list-style-type: none"> • Display of the signals linked in C1340
2	DIS: SET						
3	DIS: ACT						
4	DIS: INFL						
C1345				0		1	Function block PCTRL2
1	DIS: RFG-LOAD						<ul style="list-style-type: none"> • Display of the signals linked in C1341
2	DIS: I-OFF						
3	DIS: INACT						
4	DIS: OVERLAY						
C1350	INT1 function	0					Function selection, function block INT1
			0	PHI >= REF			If INT1-IN \geq INT1-REF, INT1-DOUT is set to HIGH
			1	PHI >= REF			If INT1-IN \geq INT1-REF , INT1-DOUT is set to HIGH
C1351	INT1 scaling	65536 00	65536	{1}	1000000000		Scaling factor, function block INT1
							$INT1 - AOUT [\%] = \frac{INT1 - IN [inc]}{C1351} \cdot 100 \%$
C1354 <small>STOP</small>	CFG: REF	1000	FIXED0INC	<input type="checkbox"/> Selection list 3			Input signal configuration
							<ul style="list-style-type: none"> • Reference value
C1355 <small>STOP</small>	CFG: IN	1000	FIXEDPHI-0	<input type="checkbox"/> Selection list 4			Configuration of input signal, function block INT1
							<ul style="list-style-type: none"> • Angle of rotation
C1356 <small>STOP</small>	CFG: RESET	1000	FIXED0	<input type="checkbox"/> Selection list 2			Configuration of digital input signal, function block INT1
							<ul style="list-style-type: none"> • HIGH = Sets the integrator to 0
C1357	DIS: REF		-2000000000	{1 inc}	2000000000		Function block INT1
							<ul style="list-style-type: none"> • Display of the signal linked in C13554
C1358	DIS: IN		-32767	{1 rpm}	32767		Function block INT1
							<ul style="list-style-type: none"> • Display of the signal linked in C1355
C1359	DIS: RESET		0			1	Function block INT1
							<ul style="list-style-type: none"> • Display of the signal linked in C1356
C1360	INT2 function	0					Function selection, function block INT2
			0	PHI >= REF			If INT2-IN \geq INT2-REF, INT2-DOUT is set to HIGH
			1	PHI >= REF			If INT2-IN \geq INT2-REF , INT2-DOUT is set to HIGH
C1361	INT2 scaling	65536 00	65536	{1}	1000000000		Scaling factor, function block INT2
							$INT2 - AOUT [\%] = \frac{INT2 - IN [inc]}{C1361} \cdot 100 \%$

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C1364 STOP	CFG: REF	1000	FIXED0INC	□ Selection list 3	Input signal configuration ● Reference value	See System Manual (extension)
C1365 STOP	CFG: IN	1000	FIXEDPHI-0	□ Selection list 4	Configuration of input signal, function block INT2 ● Angle of rotation	
C1366 STOP	CFG: RESET	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block INT2 ● HIGH = Sets the integrator to 0	
C1367	DIS: REF		-2000000000	{1 inc}	2000000000	Function block INT2 ● Display of the signal linked in C13564
C1368	DIS: IN		-32767	{1 rpm}	32767	Function block INT2 ● Display of the signal linked in C1365
C1369	DIS: RESET		0		1	Function block INT2 ● Display of the signal linked in C1366
C1370	FOLL max	100.00	0.00	{0.01 %}	199.99	Upper limit, function block FOLL1 ● Upper limit of the ramp function generator
C1371	FOLL min	-100.0 0	-199.99	{0.01 %}	0.00	Lower limit, function block FOLL1 ● Lower limit of the ramp function generator
C1372	FOLL Tir	10.0	0.1	{0.1 s}	6000.0	Acceleration time T_{ir} and deceleration time T_{if} of the ramp function generator, function block FOLL1
C1373	FOLL Tif	10.0	0.1	{0.1 s}	6000.0	
C1375 STOP				□ Selection list 1	Configuration of analog input signals, function block FOLL1	See System Manual (extension)
1	CFG: SIGN	1000	FIXED0%		● Negative value: signal characteristic at FOLL1-OUT is opposed to the one at FOLL1-IN ● Positive value: signal characteristic at FOLL1-OUT is the same as at FOLL1-IN	
2	CFG: IN	1000	FIXED0%		If FOLL1-IN > FOLL1-REF, the ramp function generator starts	
3	CFG: REF	1000	FIXED0%		Reference value	
4	CFG: LOAD	1000	FIXED0%		Initial value for the ramp function generator	
C1376 STOP	CFG: SET	1000	FIXED0	□ Selection list 2	Configuration of digital input signal, function block FOLL1 ● HIGH: initial value at FOLL1-LOAD is accepted	
C1377			-199.99	{0.01 %}	199.99	Function block FOLL1 ● Display of the signals linked in C1375
1	DIS: SIGN					See System Manual (extension)
2	DIS: IN					
3	DIS: REF					
4	DIS: LOAD					
C1378	DIS: SET		0		1	Function block FOLL1 ● Display of the signal linked in C1376

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C1583	fset high	100.00	0.00	{0.01 %}	199.99	Alterations by Lenze service only! Adaptation of the motor magnetising current set in C0095 (with V/f characteristic control: influence limit of the boost correction; with vector control: influence limit of the field precontrol)	6.11-5
C1751 		0		{1}	65535	Inverter compensation characteristic (WRK) ● During the motor parameter identification, the characteristic is calculated from the measured motor stator resistance and saved in C1751/1 ... C1751/17	6.6-16
	1	0					
					
	17	0					
C1753 		0	Data are not o. k.			Internal data are o. k. ● Motor data identification for the inverter compensation characteristic has been completed successfully	
		1	Data are o. k.				
C1754 		0	Data are not o. k.			Internal data are o. k. ● Motor data identification for the motor leakage inductance has been completed successfully	
		1	Data are o. k.				
C1755 		100	0	{1}	65535	Image of inverter compensation characteristic (WRK) on the maximum current range	

Configuration	8
Selection lists	8.6
Selection list 1: Analog output signals	8.6.1

8.6 Selection lists

8.6.1 Selection list 1: Analog output signals

Parameter	Analog output signal (O)
000050	AIN1-OUT
000055	AIN2-OUT
000100	DFSET-NOUT
001000	FIXED0%
001006	FIXED100%
001007	FIXED-100%
005000	MCTRL-nset2
005001	MCTRL-NACT
005002	MCTRL-MSET2
005003	MCTRL-MACT
005004	MCTRL-IACT
005005	MCTRL-DCVOLT
005006	MCTRL-VACT
005007	MCTRL-FACT
005008	MCTRL-IxT
005009	MCTRL-PHI-ACT
005010	MCTRL-M-TEMP
005015	MCTRL-BOOST
005050	NSET-NOUT
005051	NSET-RFG-I
005052	NSET-C10-C11
005100	MPOT1-OUT
005150	PCTRL1-OUT
005250	NLIM1-OUT
005500	ARIT1-OUT
005505	ARIT2-OUT
005510	ARIT3-OUT
005540	SQRT1-OUT
005550	ADD1-OUT
005555	ADD2-OUT
005600	RFG1-OUT
005610	SRFG1-OUT
005611	SRFG1-DIFF
005650	ASW1-OUT
005655	ASW2-OUT
005660	ASW3-OUT

Parameter	Analog output signal (O)
005700	ANEG1-OUT
005705	ANEG2-OUT
005750	FIXSET1-OUT
005800	LIM1-OUT
005850	ABS1-OUT
005900	PT1-1-OUT
005905	PT1-2-OUT
005950	DT1-1-OUT
006100	MFAIL-NOUT
006150	DB1-OUT
006200	CONV1-OUT
006205	CONV2-OUT
006210	CONV3-OUT
006215	CONV4-OUT
006230	CONVPH1-OUT
006300	S&H1-OUT
006350	CURVE1-OUT
006400	FCNT1-OUT
010000	BRK1-M-SET
011000	DCALC1-D-OUT
011001	DCALC1-OUT
011050	PCTRL2-OUT
011100	INT1-AOUT
011105	INT2-AOUT
011150	FOLL1-OUT
019500	FCODE-17
019502	FCODE-26/1
019503	FCODE-26/2
019504	FCODE-27/1
019505	FCODE-27/2
019506	FCODE-32
019507	FCODE-37
019510	FCODE-108/1
019511	FCODE-108/2
019512	FCODE-109/1

Parameter	Analog output signal (O)
019513	FCODE-109/2
019515	FCODE-141
019521	FCODE-472/1
019522	FCODE-472/2
019523	FCODE-472/3
019524	FCODE-472/4
019525	FCODE-472/5
019526	FCODE-472/6
019527	FCODE-472/7
019528	FCODE-472/8
019529	FCODE-472/9
019530	FCODE-472/10
019531	FCODE-472/11
019532	FCODE-472/12
019533	FCODE-472/13
019534	FCODE-472/14
019535	FCODE-472/15
019536	FCODE-472/16
019537	FCODE-472/17
019538	FCODE-472/18
019539	FCODE-472/19
019540	FCODE-472/20
019551	FCODE-473/1

Parameter	Analog output signal (O)
019552	FCODE-473/2
019553	FCODE-473/3
019554	FCODE-473/4
019555	FCODE-473/5
019556	FCODE-473/6
019557	FCODE-473/7
019558	FCODE-473/8
019559	FCODE-473/9
019560	FCODE-473/10
020101	CAN-IN1.W1
020102	CAN-IN1.W2
020103	CAN-IN1.W3
020201	CAN-IN2.W1
020202	CAN-IN2.W2
020203	CAN-IN2.W3
020204	CAN-IN2.W4
020301	CAN-IN3.W1
020302	CAN-IN3.W2
020303	CAN-IN3.W3
020304	CAN-IN3.W4
025101	AIF-IN.W1
025102	AIF-IN.W2
025103	AIF-IN.W3

Configuration	8
Selection lists	8.6
Selection list 2: Digital output signals	8.6.2

8.6.2 Selection list 2: Digital output signals

Parameter	Digital output signal (□)
000051	DIGIN1
000052	DIGIN2
000053	DIGIN3
000054	DIGIN4
000055	DIGIN5
000056	DIGIN6(ST)
000065	DIGIN-CINH
000100	DFSET-ACK
000500	DCTRL-RDY
000501	DCTRL-CINH
000502	DCTRL-INIT
000503	DCTRL-IMP
000504	DCTRL-NACT=0
000505	DCTRL-CW/CCW
001000	FIXED0
001001	FIXED1
002000	DCTRL-PAR*1
002001	DCTRL-PAR*2
002002	DCTRL-PAR-BUSY
005001	MCTRL-QSP-OUT
005002	MCTRL-IMAX
005003	MCTRL-MMAX
005006	MCTRL-GSB-OUT
005050	NSET-rfg-i=0
006000	DFRFG1-FAIL
006001	DFRFG1-SYNC
006100	MFAIL-STATUS
006101	MFAIL-I-RESET
006400	FCNT1-EQUAL
010000	BRK1-OUT
010001	BRK1-CINH
010002	BRK1-QSP
010003	BRK1-M-STORE
010250	R/L/Q-QSP
010251	R/L/Q-R/L
010500	AND1-OUT
010505	AND2-OUT
010510	AND3-OUT
010515	AND4-OUT

Parameter	Digital output signal (□)
010520	AND5-OUT
010550	OR1-OUT
010555	OR2-OUT
010560	OR3-OUT
010565	OR4-OUT
010570	OR5-OUT
010600	NOT1-OUT
010605	NOT2-OUT
010610	NOT3-OUT
010615	NOT4-OUT
010620	NOT5-OUT
010650	CMP1-OUT
010655	CMP2-OUT
010660	CMP3-OUT
010665	CMP4-OUT
010700	DIGDEL1-OUT
010705	DIGDEL2-OUT
010750	TRANS1-OUT
010755	TRANS2-OUT
010900	FLIP1-OUT
010905	FLIP2-OUT
011000	DCALC1-DMAX
011001	DCALC1-DMIN
011002	DCALC1-I=0
011003	DCALC1-OVFL
011100	INT1-DOUT
011105	INT2-DOUT
013000	FEVAN1-BUSY
013001	FEVAN1-FAIL
015000	DCTRL-TRIP
015001	DCTRL-MESS
015002	DCTRL-WARN
015003	DCTRL-FAIL
015010	MONIT-LU
015011	MONIT-OU
015012	MONIT-EER
015013	MONIT-OC1
015014	MONIT-OC2
015015	MONIT-LP1
015016	MONIT-OH
015017	MONIT-OH3

Parameter	Digital output signal (□)
015018	MONIT-OH4
015019	MONIT-OH7
015020	MONIT-OH8
015022	MONIT-Sd3
015026	MONIT-CEO
015027	MONIT-NMAX
015028	MONIT-OC5
015029	MONIT-SD5
015030	MONIT-SD6
015032	MONIT-H07
015033	MONIT-H10
015034	MONIT-H11
015040	MONIT-CE1
015041	MONIT-CE2
015042	MONIT-CE3
015043	MONIT-CE4
015044	MONIT-OC3
015045	MONIT-ID1
015046	MONIT-ID2
019500	FCODE-250
019521	FCODE-471.B0
019522	FCODE-471.B1
019523	FCODE-471.B2
019524	FCODE-471.B3
019525	FCODE-471.B4
019526	FCODE-471.B5
019527	FCODE-471.B6
019528	FCODE-471.B7
019529	FCODE-471.B8
019530	FCODE-471.B9
019531	FCODE-471.B10
019532	FCODE-471.B11
019533	FCODE-471.B12
019534	FCODE-471.B13
019535	FCODE-471.B14
019536	FCODE-471.B15
019537	FCODE-471.B16
019538	FCODE-471.B17
019539	FCODE-471.B18
019540	FCODE-471.B19
019541	FCODE-471.B20
019542	FCODE-471.B21
019543	FCODE-471.B22
019544	FCODE-471.B23

Parameter	Digital output signal (□)
019545	FCODE-471.B24
019546	FCODE-471.B25
019547	FCODE-471.B26
019548	FCODE-471.B27
019549	FCODE-471.B28
019550	FCODE-471.B29
019551	FCODE-471.B30
019552	FCODE-471.B31
019751	FCODE-135.B0
019752	FCODE-135.B1
019753	FCODE-135.B2
019755	FCODE-135.B4
019756	FCODE-135.B5
019757	FCODE-135.B6
019758	FCODE-135.B7
019763	FCODE-135.B12
019764	FCODE-135.B13
019765	FCODE-135.B14
019766	FCODE-135.B15
020001	CAN-CTRL.B0
020002	CAN-CTRL.B1
020003	CAN-CTRL.B2
020005	CAN-CTRL.B4
020006	CAN-CTRL.B5
020007	CAN-CTRL.B6
020008	CAN-CTRL.B7
020013	CAN-CTRL.B12
020014	CAN-CTRL.B13
020015	CAN-CTRL.B14
020016	CAN-CTRL.B15
020101	CAN-IN1.B0
020102	CAN-IN1.B1
020103	CAN-IN1.B2
020104	CAN-IN1.B3
020105	CAN-IN1.B4
020106	CAN-IN1.B5
020107	CAN-IN1.B6
020108	CAN-IN1.B7
020109	CAN-IN1.B8
020110	CAN-IN1.B9
020111	CAN-IN1.B10
020112	CAN-IN1.B11

Configuration	8
Selection lists	8.6
Selection list 2: Digital output signals	8.6.2

Parameter	Digital output signal (□)
020113	CAN-IN1.B12
020114	CAN-IN1.B13
020115	CAN-IN1.B14
020116	CAN-IN1.B15
020117	CAN-IN1.B16
020118	CAN-IN1.B17
020119	CAN-IN1.B18
020120	CAN-IN1.B19
020121	CAN-IN1.B20
020122	CAN-IN1.B21
020123	CAN-IN1.B22
020124	CAN-IN1.B23
020125	CAN-IN1.B24
020126	CAN-IN1.B25
020127	CAN-IN1.B26
020128	CAN-IN1.B27
020129	CAN-IN1.B28
020130	CAN-IN1.B29
020131	CAN-IN1.B30
020132	CAN-IN1.B31
020201	CAN-IN2.B0
020202	CAN-IN2.B1
020203	CAN-IN2.B2
020204	CAN-IN2.B3
020205	CAN-IN2.B4
020206	CAN-IN2.B5
020207	CAN-IN2.B6
020208	CAN-IN2.B7
020209	CAN-IN2.B8
020210	CAN-IN2.B9
020211	CAN-IN2.B10
020212	CAN-IN2.B11
020213	CAN-IN2.B12
020214	CAN-IN2.B13
020215	CAN-IN2.B14
020216	CAN-IN2.B15
020217	CAN-IN2.B16
020218	CAN-IN2.B17
020219	CAN-IN2.B18
020220	CAN-IN2.B19
020221	CAN-IN2.B20
020222	CAN-IN2.B21

Parameter	Digital output signal (□)
020223	CAN-IN2.B22
020224	CAN-IN2.B23
020225	CAN-IN2.B24
020226	CAN-IN2.B25
020227	CAN-IN2.B26
020228	CAN-IN2.B27
020229	CAN-IN2.B28
020230	CAN-IN2.B29
020231	CAN-IN2.B30
020232	CAN-IN2.B31
020301	CAN-IN3.B0
020302	CAN-IN3.B1
020303	CAN-IN3.B2
020304	CAN-IN3.B3
020305	CAN-IN3.B4
020306	CAN-IN3.B5
020307	CAN-IN3.B6
020308	CAN-IN3.B7
020309	CAN-IN3.B8
020310	CAN-IN3.B9
020311	CAN-IN3.B10
020312	CAN-IN3.B11
020313	CAN-IN3.B12
020314	CAN-IN3.B13
020315	CAN-IN3.B14
020316	CAN-IN3.B15
020317	CAN-IN3.B16
020318	CAN-IN3.B17
020319	CAN-IN3.B18
020320	CAN-IN3.B19
020321	CAN-IN3.B20
020322	CAN-IN3.B21
020323	CAN-IN3.B22
020324	CAN-IN3.B23
020325	CAN-IN3.B24
020326	CAN-IN3.B25
020327	CAN-IN3.B26
020328	CAN-IN3.B27
020329	CAN-IN3.B28
020330	CAN-IN3.B29
020331	CAN-IN3.B30
020332	CAN-IN3.B31

8

Configuration

8.6

Selection lists

8.6.3

Selection list 3: Angle signals

Parameter	Digital output signal (□)
020400	CAN-SYNC-OUT
025001	AIF-CTRL.B0
025002	AIF-CTRL.B1
025003	AIF-CTRL.B2
025005	AIF-CTRL.B4
025006	AIF-CTRL.B5
025007	AIF-CTRL.B6
025008	AIF-CTRL.B7
025013	AIF-CTRL.B12
025014	AIF-CTRL.B13
025015	AIF-CTRL.B14
025016	AIF-CTRL.B15
025101	AIF-IN.B0
025102	AIF-IN.B1
025103	AIF-IN.B2
025104	AIF-IN.B3
025105	AIF-IN.B4
025106	AIF-IN.B5
025107	AIF-IN.B6
025108	AIF-IN.B7
025109	AIF-IN.B8
025110	AIF-IN.B9

Parameter	Digital output signal (□)
025111	AIF-IN.B10
025112	AIF-IN.B11
025113	AIF-IN.B12
025114	AIF-IN.B13
025115	AIF-IN.B14
025116	AIF-IN.B15
025117	AIF-IN.B16
025118	AIF-IN.B17
025119	AIF-IN.B18
025120	AIF-IN.B19
025121	AIF-IN.B20
025122	AIF-IN.B21
025123	AIF-IN.B22
025124	AIF-IN.B23
025125	AIF-IN.B24
025126	AIF-IN.B25
025127	AIF-IN.B26
025128	AIF-IN.B27
025129	AIF-IN.B28
025130	AIF-IN.B29
025131	AIF-IN.B30
025132	AIF-IN.B31

8.6.3 Selection list 3: Angle signals

Parameter	Phase signal (▲)
000100	DFSET-PSET
001000	FIXED0INC
005000	MCTRL-PHI-ANG
011100	INT1-POUT
011105	INT2-POUT

Parameter	Phase signal (▲)
019521	FCODE-474/1
019522	FCODE-474/2
020103	CAN-IN1.D1
020201	CAN-IN2.D1
020301	CAN-IN3.D1
025103	AIF-IN.D1

8.6.4 Selection list 4: Speed signals

Parameter	Speed signal (Δ)
000050	DFIN-OUT
000100	DFSET-POUT
000250	DFOUT-OUT
001000	FIXEDPHI-0

Parameter	Speed signal (Δ)
005000	MCTRL-PHI-ACT
006000	DFRFG-OUT
006220	CONV5-OUT
019521	FCODE-475/1
019522	FCODE-475/2

Configuration	8
Selection lists	8.6
Selection list 5: Function blocks	8.6.5

8.6.5 Selection list 5: Function blocks

Parameter	Function block
000000	empty
000050	AIN1
000055	AIN2
000070	AOUT1
000075	AOUT2
000100	DFSET
000200	DFIN
000250	DFOUT
005050	NSET
005100	MPOT1
005150	PCTRL1
005250	NLIM1
005500	ARIT1
005505	ARIT2
005510	ARIT3
005540	SQRT1
005550	ADD1
005555	ADD2
005600	RFG1
005610	SRFG1
005650	ASW1
005655	ASW2
005660	ASW3
005700	ANEG1
005705	ANEG2
005750	FIXSET1
005800	LIM1
005850	ABS1
005900	PT1-1
005905	PT1-2
005950	DT1-1
006000	DFRFG1
006100	MFAIL
006150	DB1
006200	CONV1
006205	CONV2
006210	CONV3
006215	CONV4
006220	CONV5
006230	CONVPHA1

Parameter	Function block
006300	S&H1
006350	CURVE1
006400	FCNT1
010000	BRK1
010250	R/L/Q
010500	AND1
010505	AND2
010510	AND3
010515	AND4
010520	AND5
010550	OR1
010555	OR2
010560	OR3
010565	OR4
010570	OR5
010600	NOT1
010605	NOT2
010610	NOT3
010615	NOT4
010620	NOT5
010650	CMP1
010655	CMP2
010660	CMP3
010665	CMP4
010700	DIGDEL1
010705	DIGDEL2
010750	TRANS1
010755	TRANS2
010900	FLIP1
010905	FLIP2
011000	DCALC1
011050	PCTRL2
011100	INT1
011105	INT2
011150	FOLL1
013000	FEVAN1
013100	OSZ
015100	MLP1
020000	CAN-OUT
025000	AIF-OUT

8.7 Table of attributes

The attribute table describes the properties of the codes used. It enables you to create your own communication programs for the controller.

How to read the table of attributes

Column		Abbreviation	Meaning	
Code		Cxxxx	Name of the Lenze code	
Index	dec	24575 - Lenze code number	Index under which the parameter is addressed	Is only required for control via INTERBUS, PROFIBUS DP or system bus (CAN)
	hex	5FFFh - Lenze code number	The subindex of array variables corresponds to the Lenze subcode number	
Data	DS	E	Data structure	Single variable (only one parameter element)
		A		Array variable (several parameter elements)
DT	DA	xx	Number of array elements (subcodes)	
	B8		Data type	1 byte bit-coded
	B16			2 bytes bit-coded
	B32			4 bytes bit-coded
	FIX32			32-bit value with sign; decimal with four decimal places
	I32			4 bytes with sign
	U32			4 bytes without sign
	VS			ASCII string
Format	VD		LECOM format (see also Operating Instructions of the bus module)	ASCII decimal format
	VH			ASCII hexadecimal format
	VS			String format
	VO			Octet string format for data blocks
Access	DL		Data length in byte	The column "Important" contains further information
	LCM-R/W	Ra	Access authorisation for LECOM	Reading is always permitted
		Wa		Writing is always permitted
		W		Writing is restricted
	Condition	CINH	Condition for writing	Writing permitted only when controller is inhibited

Code	Controller		Index dec	Index hex	Data		DA	DT	Format	DL	Access	
	EVF9321 ... EVF9333	EVF9335 ... EVF9383			DS						LCM-R/W	Condition
C0002	♦	♦	24573	5FFD	E	1	FIX32	VD	4	Ra/W	CINH	
C0003	♦	♦	24572	5FFC	E	1	FIX32	VD	4	Ra/Wa		
C0004	♦	♦	24571	5FFB	E	1	FIX32	VD	4	Ra/Wa		
C0005	♦	♦	24570	5FFA	E	1	FIX32	VD	4	Ra/W	CINH	
C0006	♦	♦	24569	5FF9	E	1	FIX32	VD	4	Ra/W	CINH	
C0009	♦	♦	24566	5FF6	E	1	FIX32	VD	4	Ra/Wa		
C0010	♦	♦	24565	5FF5	E	1	FIX32	VD	4	Ra/Wa		
C0011	♦	♦	24564	5FF4	E	1	FIX32	VD	4	Ra/Wa		
C0012	♦	♦	24563	5FF3	E	1	FIX32	VD	4	Ra/Wa		
C0013	♦	♦	24562	5FF2	E	1	FIX32	VD	4	Ra/Wa		
C0014	♦	♦	24561	5FF1	E	1	FIX32	VD	4	Ra/Wa		
C0015	♦	♦	24560	5FF0	E	1	FIX32	VD	4	Ra/Wa		
C0016	♦	♦	24559	5FsF	E	1	FIX32	VD	4	Ra/Wa		
C0017	♦	♦	24558	5FEE	E	1	FIX32	VD	4	Ra/Wa		
C0018	♦	♦	24557	5FED	E	1	FIX32	VD	4	Ra/Wa		
C0019	♦	♦	24556	5FEC	E	1	FIX32	VD	4	Ra/Wa		
C0020	♦	♦	24555	5FEB	E	1	FIX32	VD	4	Ra/Wa		
C0021	♦	♦	24554	5FEA	E	1	FIX32	VD	4	Ra/Wa		
C0022	♦	♦	24553	5FE9	E	1	FIX32	VD	4	Ra/Wa		
C0023	♦	♦	24552	5FE8	E	1	FIX32	VD	4	Ra/Wa		
C0025	♦	♦	24550	5FE6	E	1	FIX32	VD	4	Ra/W	CINH	
C0026	♦	♦	24549	5FE5	A	2	FIX32	VD	4	Ra/Wa		
C0027	♦	♦	24548	5FE4	A	2	FIX32	VD	4	Ra/Wa		
C0030	♦	♦	24545	5FE1	E	1	FIX32	VD	4	Ra/Wa		
C0032	♦	♦	24543	5FDF	E	1	FIX32	VD	4	Ra/Wa		
C0033	♦	♦	24542	5FDE	E	1	FIX32	VD	4	Ra/Wa		
C0034	♦	♦	24541	5FDD	E	1	FIX32	VD	4	Ra/Wa		
C0036	♦	♦	24539	5FDB	E	1	FIX32	VD	4	Ra/Wa		
C0037	♦	♦	24538	5FDA	E	1	FIX32	VD	4	Ra/Wa		
C0038	♦	♦	24537	5FD9	A	6	FIX32	VD	4	Ra/Wa		
C0039	♦	♦	24536	5FD8	A	15	FIX32	VD	4	Ra/Wa		
C0040	♦	♦	24535	5FD7	E	1	FIX32	VD	4	Ra/Wa		
C0042	♦	♦	24533	5FD5	E	1	FIX32	VD	4	Ra		
C0043	♦	♦	24532	5FD4	E	1	FIX32	VD	4	Ra/Wa		
C0045	♦	♦	24530	5FD2	E	1	FIX32	VD	4	Ra		
C0046	♦	♦	24529	5FD1	E	1	FIX32	VD	4	Ra		
C0049	♦	♦	24526	5FCE	E	1	FIX32	VD	4	Ra		
C0050	♦	♦	24525	5FCD	E	1	FIX32	VD	4	Ra		
C0051	♦	♦	24524	5FCC	E	1	FIX32	VD	4	Ra		
C0052	♦	♦	24523	5FCB	E	1	FIX32	VD	4	Ra		
C0053	♦	♦	24522	5FCA	E	1	FIX32	VD	4	Ra		
C0054	♦	♦	24521	5FC9	E	1	FIX32	VD	4	Ra		
C0056	♦	♦	24519	5FC7	E	1	FIX32	VD	4	Ra		
C0057	♦	♦	24518	5FC6	E	1	FIX32	VD	4	Ra		
C0058	♦	♦	24517	5FC5	E	1	FIX32	VD	4	Ra		

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C0059	♦	♦	24516	5FC4	E	1	FIX32	VD	4	Ra	
C0061	♦	♦	24514	5FC2	E	1	FIX32	VD	4	Ra	
C0063	♦	♦	24512	5FC0	E	1	FIX32	VD	4	Ra	
C0064	♦	♦	24511	5FBF	E	1	FIX32	VD	4	Ra	
C0067	♦	♦	24508	5FBC	E	1	FIX32	VD	4	Ra	
C0070	♦	♦	24505	5FB9	E	1	FIX32	VD	4	Ra/Wa	
C0071	♦	♦	24504	5FB8	E	1	FIX32	VD	4	Ra/Wa	
C0074	♦	♦	24501	5FB5	E	1	FIX32	VD	4	Ra/Wa	
C0075	♦	♦	24500	5FB4	E	1	FIX32	VD	4	Ra/Wa	
C0076	♦	♦	24499	5FB3	E	1	FIX32	VD	4	Ra/Wa	
C0077	♦	♦	24498	5FB2	E	1	FIX32	VD	4	Ra/Wa	
C0078	♦	♦	24497	5FB1	E	1	FIX32	VD	4	Ra/Wa	
C0079	♦	♦	24496	5FB0	E	1	FIX32	VD	4	Ra/Wa	
C0080	♦	♦	24495	5FAF	E	1	FIX32	VD	4	Ra/Wa	
C0081	♦	♦	24494	5FAE	E	1	FIX32	VD	4	Ra/W	CINH
C0082	♦	♦	24493	5FAD	E	1	FIX32	VD	4	Ra/W	CINH
C0084	♦	♦	24491	5FAB	E	1	FIX32	VD	4	Ra/W	CINH
C0085	♦	♦	24490	5FAA	E	1	FIX32	VD	4	Ra/W	CINH
C0086	♦	♦	24489	5FA9	E	1	FIX32	VD	4	Ra/W	CINH
C0087	♦	♦	24488	5FA8	E	1	FIX32	VD	4	Ra/W	CINH
C0088	♦	♦	24487	5FA7	E	1	FIX32	VD	4	Ra/W	CINH
C0089	♦	♦	24486	5FA6	E	1	FIX32	VD	4	Ra/W	CINH
C0090	♦	♦	24485	5FA5	E	1	FIX32	VD	4	Ra/W	CINH
C0091	♦	♦	24484	5FA4	E	1	FIX32	VD	4	Ra/W	CINH
C0092	♦	♦	24483	5FA3	E	1	FIX32	VD	4	Ra/W	CINH
C0093	♦	♦	24482	5FA2	E	1	FIX32	VD	4	Ra	
C0094	♦	♦	24481	5FA1	E	1	FIX32	VD	4	Ra/Wa	
C0095	♦	♦	24480	5FA0	E	1	FIX32	VD	4	Ra/W	CINH
C0096	♦	♦	24479	5F9F	A	2	FIX32	VD	4	Ra/Wa	
C0099	♦	♦	24476	5F9C	E	1	FIX32	VD	4	Ra	
C0101	♦	♦	24474	5F9A	A	15	FIX32	VD	4	Ra/Wa	
C0103	♦	♦	24472	5F98	A	15	FIX32	VD	4	Ra/Wa	
C0104	♦	♦	24471	5F97	E	1	FIX32	VD	4	Ra/W	CINH
C0105	♦	♦	24470	5F96	E	1	FIX32	VD	4	Ra/Wa	
C0107	♦	♦	24478	5F94	E	1	FIX32	VD	4	Ra/Wa	
C0108	♦	♦	24467	5F93	A	2	FIX32	VD	4	Ra/Wa	
C0109	♦	♦	24466	5F92	A	2	FIX32	VD	4	Ra/Wa	
C0114	♦	♦	24461	5F8D	A	6	FIX32	VD	4	Ra/Wa	
C0116	♦	♦	24459	5F8B	A	32	FIX32	VD	4	Ra/W	CINH
C0117	♦	♦	24458	5F8A	A	4	FIX32	VD	4	Ra/W	CINH
C0118	♦	♦	24457	5F89	A	4	FIX32	VD	4	Ra/Wa	
C0121	♦	♦	24454	5F86	E	1	FIX32	VD	4	Ra/Wa	
C0122	♦	♦	24453	5F85	E	1	FIX32	VD	4	Ra/Wa	
C0125	♦	♦	24450	5F82	E	1	FIX32	VD	4	Ra/Wa	
C0126	♦	♦	24449	5F81	E	1	FIX32	VD	4	Ra/Wa	

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C0130	♦	♦	24445	5F7D	E	1	FIX32	VD	4	Ra	
C0132	♦	♦	24443	5F7B	E	1	FIX32	VD	4	Ra/W	CINH
C0133	♦	♦	24442	5F7A	E	1	FIX32	VD	4	Ra/W	CINH
C0134	♦	♦	24441	5F79	E	1	FIX32	VD	4	Ra/Wa	
C0135	♦	♦	24440	5F78	E	1	B16	VH	2		
C0136	♦	♦	24439	5F77	A	3	B16	VH	2	Ra	
C0140	♦		24435	5F73	E	1	FIX32	VD	4	Ra/Wa	
C0141	♦	♦	24434	5F72	E	1	FIX32	VD	4	Ra/Wa	
C0142	♦	♦	24433	5F71	E	1	FIX32	VD	4	Ra/Wa	
C0143	♦	♦	24432	5F70	E	1	FIX32	VD	4	Ra/Wa	
C0144	♦	♦	24431	5F6F	E	1	FIX32	VD	4	Ra/W	CINH
C0145	♦	♦	24430	5F6E	E	1	FIX32	VD	4	Ra/W	CINH
C0146	♦	♦	24429	5F6D	E	1	FIX32	VD	4	Ra/Wa	
C0147	♦	♦	24428	5F6C	E	1	FIX32	VD	4	Ra/Wa	
C0148	♦	♦	24427	5F6B	E	1	FIX32	VD	4	Ra/W	CINH
C0149	♦	♦	24426	5F6A	E	1	FIX32	VD	4	Ra/W	CINH
C0150	♦	♦	24425	5F69	E	1	B16	VH	2	Ra	
C0151	♦	♦	24424	5F68	E	1	B32	VH	4	Ra	
C0155	♦	♦	24420	5F64	E	1	B16	VH	2	Ra	
C0156	♦	♦	24419	5F63	A	7	FIX32	VD	4	Ra/W	CINH
C0157	♦	♦	24418	5F62	A	7	FIX32	VD	4	Ra	
C0161	♦	♦	24414	5F5E	E	1	FIX32	VD	4	Ra	
C0167	♦	♦	24408	5F58	E	1	FIX32	VD	4	Ra/Wa	
C0168	♦	♦	24407	5F57	A	8	FIX32	VD	4	Ra	
C0169	♦	♦	24406	5F56	A	8	U32	VH	4	Ra	
C0170	♦	♦	24405	5F55	A	8	FIX32	VD	4	Ra	
C0173	♦	♦	24402	5F52	E	1	FIX32	VD	4	Ra/Wa	
C0174		♦	24401	5F51	E	1	FIX32	VD	4	Ra/Wa	
C0178	♦	♦	24397	5F4D	E	1	U32	VH	4	Ra	
C0179	♦	♦	24396	5F4C	E	1	U32	VH	4	Ra	
C0182	♦	♦	24393	5F49	E	1	FIX32	VD	4	Ra/Wa	
C0183	♦	♦	24392	5F48	E	1	FIX32	VD	4	Ra	
C0190	♦	♦	24385	5F41	E	1	FIX32	VD	4	Ra/Wa	
C0195	♦	♦	24380	5F3C	E	1	FIX32	VD	4	Ra/Wa	
C0196	♦	♦	24379	5F3B	E	1	FIX32	VD	4	Ra/Wa	
C0200	♦	♦	24375	5F37	E	1	VS	VS	14	Ra	
C0201	♦	♦	24374	5F36	E	1	VS	VS	20	Ra	
C0202	♦	♦	24373	5F35	E	1	VS	VS	20	Ra	
C0203	♦	♦	24372	5F34	E	1	VS	VS	20	Ra	
C0204	♦	♦	24371	5F33	E	1	VS	VS	20	Ra	
C0206	♦	♦	24369	5F31	E	1	VS	VS	20	Ra	
C0207	♦	♦	24368	5F30	E	1	VS	VS	20	Ra	
C0208	♦	♦	24367	5F2F	E	1	VS	VS	20	Ra	
C0209	♦	♦	24366	5F2E	E	1	VS	VS	20	Ra	
C0220	♦	♦	24355	5F23	E	1	FIX32	VD	4	Ra/Wa	

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C0221	♦	♦	24354	5F22	E	1	FIX32	VD	4	Ra/Wa	
C0222	♦	♦	24353	5F21	E	1	FIX32	VD	4	Ra/Wa	
C0223	♦	♦	24352	5F20	E	1	FIX32	VD	4	Ra/Wa	
C0224	♦	♦	24351	5F1F	E	1	FIX32	VD	4	Ra/Wa	
C0234	♦	♦	24341	5F15	E	1	FIX32	VD	4	Ra/Wa	
C0235	♦	♦	24340	5F14	E	1	FIX32	VD	4	Ra/Wa	
C0236	♦	♦	24339	5F13	E	1	FIX32	VD	4	Ra/Wa	
C0241	♦	♦	24334	5F0E	E	1	FIX32	VD	4	Ra/Wa	
C0244	♦	♦	24331	5F0B	E	1	FIX32	VD	4	Ra/Wa	
C0250	♦	♦	24325	5F05	E	1	FIX32	VD	4	Ra/Wa	
C0252	♦	♦	24323	5F03	E	1	I32	VH	4	Ra/Wa	
C0253	♦	♦	24322	5F02	E	1	FIX32	VD	4	Ra/Wa	
C0260	♦	♦	24315	5EFB	E	1	FIX32	VD	4	Ra/Wa	
C0261	♦	♦	24314	5EFA	E	1	FIX32	VD	4	Ra/Wa	
C0262	♦	♦	24313	5EF9	E	1	FIX32	VD	4	Ra/Wa	
C0263	♦	♦	24312	5EF8	E	1	FIX32	VD	4	Ra/Wa	
C0264	♦	♦	24311	5EF7	E	1	FIX32	VD	4	Ra/Wa	
C0265	♦	♦	24310	5EF6	E	1	FIX32	VD	4	Ra/Wa	
C0267	♦	♦	24308	5EF4	A	2	FIX32	VD	4	Ra/W	CINH
C0268	♦	♦	24307	5EF3	E	1	FIX32	VD	4	Ra/W	CINH
C0269	♦	♦	24306	5EF2	A	3	FIX32	VD	4	Ra	
C0325	♦	♦	24250	5EBA	E	1	FIX32	VD	4	Ra/Wa	
C0326	♦	♦	24249	5EB9	E	1	FIX32	VD	4	Ra/Wa	
C0327	♦	♦	24248	5EB8	E	1	FIX32	VD	4	Ra/Wa	
C0328	♦	♦	24247	5EB7	E	1	FIX32	VD	4	Ra/Wa	
C0329	♦	♦	24246	5EB6	E	1	FIX32	VD	4	Ra/Wa	
C0332	♦	♦	24243	5EB3	E	1	FIX32	VD	4	Ra/Wa	
C0333	♦	♦	24242	5EB2	E	1	FIX32	VD	4	Ra/Wa	
C0336	♦	♦	24239	5EAF	E	1	FIX32	VD	4	Ra	
C0337	♦	♦	24238	5EAE	E	1	FIX32	VD	4	Ra/Wa	
C0338	♦	♦	24237	5EAD	E	1	FIX32	VD	4	Ra/Wa	
C0339	♦	♦	24236	5EAC	A	2	FIX32	VD	4	Ra/W	CINH
C0340	♦	♦	24235	5EAB	A	2	FIX32	VD	4	Ra	
C0350	♦	♦	24225	5EA1	E	1	FIX32	VD	4	Ra/Wa	
C0351	♦	♦	24224	5EA0	E	1	FIX32	VD	4	Ra/Wa	
C0352	♦	♦	24223	5E9F	E	1	FIX32	VD	4	Ra/Wa	
C0353	♦	♦	24222	5E9E	A	3	FIX32	VD	4	Ra/Wa	
C0354	♦	♦	24221	5E9D	A	6	FIX32	VD	4	Ra/Wa	
C0355	♦	♦	24220	5E9C	A	6	FIX32	VD	4	Ra	
C0356	♦	♦	24219	5E9B	A	4	FIX32	VD	4	Ra/Wa	
C0357	♦	♦	24218	5E9A	A	3	FIX32	VD	4	Ra/Wa	
C0358	♦	♦	24217	5E99	E	1	FIX32	VD	4	Ra/Wa	
C0359	♦	♦	24216	5E98	E	1	FIX32	VD	4	Ra	
C0360	♦	♦	24215	5E97	A	12	FIX32	VD	4	Ra	
C0361	♦	♦	24214	5E96	A	12	FIX32	VD	4	Ra	

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C0364	♦	♦	24211	5E93	E	1	FIX32	VD	4	Ra/W	CINH
C0365	♦	♦	24210	5E92	E	1	FIX32	VD	4	Ra	
C0366	♦	♦	24209	5E91	E	1	FIX32	VD	4	Ra/Wa	
C0367	♦	♦	24208	5E90	A	1	FIX32	VD	4	Ra/Wa	
C0368	♦	♦	24207	5E8F	E	1	FIX32	VD	4	Ra/Wa	
C0369	♦	♦	24206	5E8E	E	1	FIX32	VD	4	Ra/Wa	
C0400	♦	♦	24175	5E6F	E	1	FIX32	VD	4	Ra	
C0402	♦	♦	24173	5E6D	E	1	FIX32	VD	4	Ra/W	CINH
C0403	♦	♦	24172	5E6C	E	1	FIX32	VD	4	Ra/W	CINH
C0404	♦	♦	24171	5E6B	A	2	FIX32	VD	4	Ra	
C0405	♦	♦	24170	5E6A	E	1	FIX32	VD	4	Ra	
C0407	♦	♦	24168	5E68	E	1	FIX32	VD	4	Ra/W	CINH
C0408	♦	♦	24167	5E67	E	1	FIX32	VD	4	Ra/W	CINH
C0409	♦	♦	24166	5E66	A	2	FIX32	VD	4	Ra	
C0420	♦	♦	24155	5E5B	E	1	FIX32	VD	4	Ra/W	CINH
C0421	♦	♦	24154	5E5A	E	1	FIX32	VD	4	Ra/W	CINH
C0425	♦	♦	24150	5E56	E	1	FIX32	VD	4	Ra/Wa	
C0426	♦	♦	24149	5E55	E	1	FIX32	VD	4	Ra	
C0427	♦	♦	24148	5E54	E	1	FIX32	VD	4	Ra/Wa	
C0429	♦	♦	24146	5E52	E	1	FIX32	VD	4	Ra/Wa	
C0431	♦	♦	24144	5E50	E	1	FIX32	VD	4	Ra/W	CINH
C0432	♦	♦	24143	5E4F	E	1	FIX32	VD	4	Ra/W	CINH
C0433	♦	♦	24142	5E4E	E	1	FIX32	VD	4	Ra/W	CINH
C0434	♦	♦	24141	5E4D	A	3	FIX32	VD	4	Ra	
C0436	♦	♦	24139	5E4B	E	1	FIX32	VD	4	Ra/W	CINH
C0437	♦	♦	24138	5E4A	E	1	FIX32	VD	4	Ra/W	CINH
C0438	♦	♦	24137	5E49	E	1	FIX32	VD	4	Ra/W	CINH
C0439	♦	♦	24136	5E48	A	3	FIX32	VD	4	Ra	
C0443	♦	♦	24132	5E44	E	1	B8	VH	1	Ra	
C0444	♦	♦	24131	5E43	A	4	FIX32	VD	4	Ra	
C0450	♦	♦	24125	5E3D	E	1	FIX32	VD	4	Ra/W	CINH
C0451	♦	♦	24124	5E3C	E	1	FIX32	VD	4	Ra/W	CINH
C0452	♦	♦	24123	5E3B	E	1	FIX32	VD	4	Ra/W	CINH
C0458	♦	♦	24117	5E35	A	2	FIX32	VD	4	Ra	
C0459	♦	♦	24116	5E34	E	1	FIX32	VD	4	Ra	
C0464	♦	♦	24111	5E2F	E	1	FIX32	VD	4	Ra	
C0465	♦	♦	24110	5E2E	A	50	FIX32	VD	4	Ra/W	CINH
C0466	♦	♦	24109	5E2D	E	1	FIX32	VD	4	Ra	
C0469	♦	♦	24106	5E2A	E	1	FIX32	VD	4	Ra/W	CINH
C0470	♦	♦	24105	5E29	A	4	B8	VH	1	Ra/Wa	
C0471	♦	♦	24104	5E28	E	1	B32	VH	4	Ra/Wa	
C0472	♦	♦	24103	5E27	A	20	FIX32	VD	4	Ra/Wa	
C0473	♦	♦	24102	5E26	A	10	FIX32	VD	4	Ra/Wa	
C0474	♦	♦	24101	5E25	A	2	I32	VH	4	Ra/Wa	
C0475	♦	♦	24100	5E24	A	2	FIX32	VD	4	Ra/Wa	

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C0497	♦	♦	24078	5E0E	E	1	FIX32	VD	4	Ra/Wa	
C0510	♦	♦	24065	5E01	E	1	FIX32	VD	4	Ra/W	CINH
C0511	♦	♦	24064	5E00	E	1	FIX32	VD	4	Ra/Wa	
C0517	♦	♦	24058	5DFA	A	32	FIX32	VD	4	Ra/Wa	
C0520	♦	♦	24055	5DF7	E	1	FIX32	VD	4	Ra/W	CINH
C0521	♦	♦	24054	5DF6	E	1	FIX32	VD	4	Ra/W	CINH
C0522	♦	♦	24053	5DF5	E	1	FIX32	VD	4	Ra/W	CINH
C0523	♦	♦	24052	5DF4	E	1	FIX32	VD	4	Ra/W	CINH
C0524	♦	♦	24051	5DF3	E	1	FIX32	VD	4	Ra/W	CINH
C0525	♦	♦	24050	5DF2	E	1	FIX32	VD	4	Ra/W	CINH
C0526	♦	♦	24049	5DF1	E	1	FIX32	VD	4	Ra/W	CINH
C0527	♦	♦	24048	5DFO	E	1	FIX32	VD	4	Ra/W	CINH
C0528	♦	♦	24047	5DEF	A	2	I32	VH	4	Ra	
C0529	♦	♦	24046	5DEE	E	1	FIX32	VD	4	Ra/Wa	
C0530	♦	♦	24045	5DED	E	1	FIX32	VD	4	Ra/Wa	
C0531	♦	♦	24044	5DEC	E	1	FIX32	VD	4	Ra/Wa	
C0532	♦	♦	24043	5DEB	E	1	FIX32	VD	4	Ra/Wa	
C0533	♦	♦	24042	5DEA	E	1	FIX32	VD	4	Ra/Wa	
C0534	♦	♦	24041	5DE9	E	1	FIX32	VD	4	Ra/Wa	
C0535	♦	♦	24040	5DE8	E	1	FIX32	VD	4	Ra/Wa	
C0536	♦	♦	24039	5DE7	A	3	FIX32	VD	4	Ra	
C0537	♦	♦	24038	5DE6	E	1	FIX32	VD	4	Ra	
C0538	♦	♦	24037	5DE5	A	3	FIX32	VD	4	Ra	
C0539	♦	♦	24036	5DE4	E	1	FIX32	VD	4	Ra	
C0540	♦	♦	24035	5DE3	E	1	FIX32	VD	4	Ra/W	CINH
C0541	♦	♦	24034	5DE2	E	1	FIX32	VD	4	Ra/W	CINH
C0542	♦	♦	24033	5DE1	E	1	FIX32	VD	4	Ra/W	CINH
C0544	♦	♦	24031	5DDF	E	1	FIX32	VD	4	Ra/W	CINH
C0545	♦	♦	24030	5DDE	E	1	FIX32	VD	4	Ra/Wa	
C0546	♦	♦	24029	5DDD	E	1	U32	VH	4	Ra/Wa	
C0547	♦	♦	24028	5DDC	E	1	FIX32	VD	4	Ra	
C0548	♦	♦	24027	5DDB	E	1	FIX32	VD	4	Ra	
C0549	♦	♦	24026	5DDA	E	1	FIX32	VD	4	Ra	
C0560	♦	♦	24015	5DCF	A	15	FIX32	VD	4	Ra/Wa	
C0561	♦	♦	24014	5DCE	E	1	FIX32	VD	4	Ra/W	CINH
C0562	♦	♦	24013	5DCD	A	4	FIX32	VD	4	Ra/W	CINH
C0563	♦	♦	24012	5DCC	E	1	FIX32	VD	4	Ra	
C0564	♦	♦	24011	5DCB	A	4	FIX32	VD	4	Ra	
C0570	♦	♦	24005	5DC5	E	1	FIX32	VD	4	Ra/W	CINH
C0571	♦	♦	24004	5DC4	E	1	FIX32	VD	4	Ra/W	CINH
C0572	♦	♦	24003	5DC3	E	1	FIX32	VD	4	Ra	
C0573	♦	♦	24002	5DC2	E	1	FIX32	VD	4	Ra	
C0574	♦		24001	5DC1	E	1	FIX32	VD	4	Ra/Wa	
C0581	♦	♦	23994	5DBA	E	1	FIX32	VD	4	Ra/Wa	
C0582	♦	♦	23993	5DB9	E	1	FIX32	VD	4	Ra/Wa	

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C0583	♦	♦	23992	5DB8	E	1	FIX32	VD	4	Ra/Wa	
C0584	♦	♦	23991	5DB7	E	1	FIX32	VD	4	Ra/Wa	
C0585	♦	♦	23990	5DB6	E	1	FIX32	VD	4	Ra/Wa	
C0587	♦	♦	23988	5DB4	E	1	FIX32	VD	4	Ra/Wa	
C0588	♦	♦	23987	5DB3	E	1	FIX32	VD	4	Ra/Wa	
C0591	♦	♦	23984	5DB0	E	1	FIX32	VD	4	Ra/Wa	
C0592	♦	♦	23983	5DAF	E	1	FIX32	VD	4	Ra/Wa	
C0593	♦	♦	23982	5DAE	E	1	FIX32	VD	4	Ra/Wa	
C0594	♦	♦	23981	5DAD	E	1	FIX32	VD	4	Ra/Wa	
C0595	♦	♦	23980	5DAC	E	1	FIX32	VD	4	Ra/Wa	
C0596	♦	♦	23979	5DAB	E	1	FIX32	VD	4	Ra/Wa	
C0597	♦	♦	23978	5DAA	E	1	FIX32	VD	4	Ra/Wa	
C0598	♦	♦	23977	5DA9	E	1	FIX32	VD	4	Ra/Wa	
C0599	♦	♦	23976	5DA8	E	1	FIX32	VD	4	Ra/Wa	
C0600	♦	♦	23975	5DA7	E	1	FIX32	VD	4	Ra/Wa	
C0601	♦	♦	23974	5DA6	A	2	FIX32	VD	4	Ra/W	CINH
C0602	♦	♦	23973	5DA5	A	2	FIX32	VD	4	Ra	
C0603	♦	♦	23972	5DA4	E	1	FIX32	VD	4	Ra/Wa	
C0604	♦	♦	23971	5DA3	A	2	FIX32	VD	4	Ra/W	CINH
C0605	♦	♦	23970	5DA2	A	2	FIX32	VD	4	Ra	
C0608	♦	♦	23967	5D9F	E	1	FIX32	VD	4	Ra/W	CINH
C0609	♦	♦	23966	5D9E	E	1	FIX32	VD	4	Ra	
C0610	♦	♦	23965	5D9D	A	3	FIX32	VD	4	Ra/W	CINH
C0611	♦	♦	23964	5D9C	A	3	FIX32	VD	4	Ra	
C0612	♦	♦	23963	5D9B	A	3	FIX32	VD	4	Ra/W	CINH
C0613	♦	♦	23962	5D9A	A	3	FIX32	VD	4	Ra	
C0620	♦	♦	23955	5D93	E	1	FIX32	VD	4	Ra/Wa	
C0621	♦	♦	23954	5D92	E	1	FIX32	VD	4	Ra/Wa	
C0622	♦	♦	23953	5D91	E	1	FIX32	VD	4	Ra/W	CINH
C0623	♦	♦	23952	5D90	E	1	FIX32	VD	4	Ra	
C0630	♦	♦	23945	5D89	E	1	FIX32	VD	4	Ra/Wa	
C0631	♦	♦	23944	5D88	E	1	FIX32	VD	4	Ra/Wa	
C0632	♦	♦	23943	5D87	E	1	FIX32	VD	4	Ra/W	CINH
C0633	♦	♦	23942	5D86	E	1	FIX32	VD	4	Ra	
C0640	♦	♦	23935	5D7F	E	1	FIX32	VD	4	Ra/Wa	
C0641	♦	♦	23934	5D7E	E	1	FIX32	VD	4	Ra/W	CINH
C0642	♦	♦	23933	5D7D	E	1	FIX32	VD	4	Ra	
C0643	♦	♦	23932	5D7C	E	1	FIX32	VD	4	Ra/Wa	
C0644	♦	♦	23931	5D7B	E	1	FIX32	VD	4	Ra/W	CINH
C0645	♦	♦	23930	5D7A	E	1	FIX32	VD	4	Ra	
C0650	♦	♦	23925	5D75	E	1	FIX32	VD	4	Ra/Wa	
C0651	♦	♦	23924	5D74	E	1	FIX32	VD	4	Ra/Wa	
C0652	♦	♦	23923	5D73	E	1	FIX32	VD	4	Ra/W	CINH
C0653	♦	♦	23922	5D72	E	1	FIX32	VD	4	Ra/Wa	
C0654	♦	♦	23921	5D71	E	1	FIX32	VD	4	Ra	

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C0655	♦	♦	23920	5D70	E	1	FIX32	VD	4	Ra/Wa	
C0656	♦	♦	23919	5D6F	E	1	FIX32	VD	4	Ra/Wa	
C0657	♦	♦	23918	5D6E	E	1	FIX32	VD	4	Ra/W	CINH
C0658	♦	♦	23917	5D6D	E	1	FIX32	VD	4	Ra	
C0661	♦	♦	23914	5D6A	E	1	FIX32	VD	4	Ra/W	CINH
C0662	♦	♦	23913	5D69	E	1	FIX32	VD	4	Ra	
C0671	♦	♦	23904	5D60	E	1	FIX32	VD	4	Ra/Wa	
C0672	♦	♦	23903	5D5F	E	1	FIX32	VD	4	Ra/Wa	
C0673	♦	♦	23902	5D5E	E	1	FIX32	VD	4	Ra/W	CINH
C0674	♦	♦	23901	5D5D	E	1	FIX32	VD	4	Ra/W	CINH
C0675	♦	♦	23900	5D5C	E	1	FIX32	VD	4	Ra/W	CINH
C0676	♦	♦	23899	5D5B	A	2	FIX32	VD	4	Ra	
C0677	♦	♦	23898	5D5A	E	1	FIX32	VD	4	Ra	
C0680	♦	♦	23895	5D57	E	1	FIX32	VD	4	Ra/Wa	
C0681	♦	♦	23894	5D56	E	1	FIX32	VD	4	Ra/Wa	
C0682	♦	♦	23893	5D55	E	1	FIX32	VD	4	Ra/Wa	
C0683	♦	♦	23892	5D54	A	2	FIX32	VD	4	Ra/W	CINH
C0684	♦	♦	23891	5D53	A	2	FIX32	VD	4	Ra	
C0685	♦	♦	23890	5D52	E	1	FIX32	VD	4	Ra/Wa	
C0686	♦	♦	23889	5D51	E	1	FIX32	VD	4	Ra/Wa	
C0687	♦	♦	23888	5D50	E	1	FIX32	VD	4	Ra/Wa	
C0688	♦	♦	23887	5D4F	A	2	FIX32	VD	4	Ra/W	CINH
C0689	♦	♦	23886	5D4E	A	2	FIX32	VD	4	Ra	
C0690	♦	♦	23885	5D4D	E	1	FIX32	VD	4	Ra/Wa	
C0691	♦	♦	23884	5D4C	E	1	FIX32	VD	4	Ra/Wa	
C0692	♦	♦	23883	5D4B	E	1	FIX32	VD	4	Ra/Wa	
C0693	♦	♦	23882	5D4A	A	2	FIX32	VD	4	Ra/W	CINH
C0694	♦	♦	23881	5D49	A	2	FIX32	VD	4	Ra	
C0700	♦	♦	23875	5D43	E	1	FIX32	VD	4	Ra/W	CINH
C0701	♦	♦	23874	5D42	E	1	FIX32	VD	4	Ra	
C0703	♦	♦	23872	5D40	E	1	FIX32	VD	4	Ra/W	CINH
C0704	♦	♦	23871	5D3F	E	1	FIX32	VD	4	Ra	
C0705	♦	♦	23870	5D3E	E	1	FIX32	VD	4	Ra/Wa	
C0706	♦	♦	23869	5D3D	E	1	FIX32	VD	4	Ra/Wa	
C0707	♦	♦	23868	5D3C	E	1	FIX32	VD	4	Ra/Wa	
C0708	♦	♦	23867	5D3B	A	2	FIX32	VD	4	Ra/W	CINH
C0709	♦	♦	23866	5D3A	A	2	FIX32	VD	4	Ra	
C0710	♦	♦	23865	5D39	E	1	FIX32	VD	4	Ra/Wa	
C0711	♦	♦	23864	5D38	E	1	FIX32	VD	4	Ra/Wa	
C0713	♦	♦	23862	5D36	E	1	FIX32	VD	4	Ra/W	CINH
C0714	♦	♦	23861	5D35	E	1	FIX32	VD	4	Ra	
C0715	♦	♦	23860	5D34	E	1	FIX32	VD	4	Ra/Wa	
C0716	♦	♦	23859	5D33	E	1	FIX32	VD	4	Ra/Wa	
C0718	♦	♦	23857	5D31	E	1	FIX32	VD	4	Ra/W	CINH
C0719	♦	♦	23856	5D30	E	1	FIX32	VD	4	Ra	

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C0720	♦	♦	23855	5D2F	E	1	FIX32	VD	4	Ra/Wa	
C0721	♦	♦	23854	5D2E	E	1	FIX32	VD	4	Ra/Wa	
C0723	♦	♦	23852	5D2C	E	1	FIX32	VD	4	Ra/W	CINH
C0724	♦	♦	23851	5D2B	E	1	FIX32	VD	4	Ra	
C0725	♦	♦	23850	5D2A	E	1	FIX32	VD	4	Ra/Wa	
C0726	♦	♦	23849	5D29	E	1	FIX32	VD	4	Ra/Wa	
C0728	♦	♦	23847	5D27	E	1	FIX32	VD	4	Ra/W	CINH
C0729	♦	♦	23846	5D26	E	1	FIX32	VD	4	Ra	
C0730	♦	♦	23845	5D25	E	1	FIX32	VD	4	Ra/Wa	
C0731	♦	♦	23844	5D24	E	1	FIX32	VD	4	Ra	
C0732	♦	♦	23843	5D23	A	4	FIX32	VD	4	Ra/W	CINH
C0733	♦	♦	23842	5D22	E	1	FIX32	VD	4	Ra/W	CINH
C0734	♦	♦	23841	5D21	E	1	FIX32	VD	4	Ra/Wa	
C0735	♦	♦	23840	5D20	E	1	FIX32	VD	4	Ra/Wa	
C0736	♦	♦	23839	5D1F	E	1	FIX32	VD	4	Ra/Wa	
C0737	♦	♦	23838	5D1E	E	1	FIX32	VD	4	Ra/Wa	
C0738	♦	♦	23837	5D1D	E	1	FIX32	VD	4	Ra/Wa	
C0739	♦	♦	23836	5D1C	E	1	FIX32	VD	4	Ra/Wa	
C0740	♦	♦	23835	5D1B	A	2	FIX32	VD	4	Ra/Wa	
C0741	♦	♦	23834	5D1A	A	4	FIX32	VD	4	Ra	
C0742	♦	♦	23833	5D19	E	1	FIX32	VD	4	Ra	
C0743	♦	♦	23832	5D18	E	1	FIX32	VD	4	Ra	
C0744	♦	♦	23831	5D17	E	1	FIX32	VD	4	Ra/Wa	
C0749	♦	♦	23826	5D12	A	3	FIX32	VD	4	Ra	
C0750	♦	♦	23825	5D11	E	1	FIX32	VD	4	Ra/Wa	
C0751	♦	♦	23824	5D10	E	1	FIX32	VD	4	Ra/Wa	
C0752	♦	♦	23823	5D0F	E	1	FIX32	VD	4	Ra/Wa	
C0753	♦	♦	23822	5D0E	E	1	FIX32	VD	4	Ra/Wa	
C0754	♦	♦	23821	5D0D	E	1	U32	VH	4	Ra/Wa	
C0755	♦	♦	23820	5D0C	E	1	FIX32	VD	4	Ra/Wa	
C0756	♦	♦	23819	5D0B	E	1	I32	VH	4	Ra/Wa	
C0757	♦	♦	23818	5D0A	E	1	FIX32	VD	4	Ra/Wa	
C0758	♦	♦	23817	5D09	E	1	FIX32	VD	4	Ra/W	CINH
C0759	♦	♦	23816	5D08	E	1	FIX32	VD	4	Ra/W	CINH
C0760	♦	♦	23815	5D07	E	1	FIX32	VD	4	Ra/W	CINH
C0761	♦	♦	23814	5D06	E	1	FIX32	VD	4	Ra/W	CINH
C0764	♦	♦	23811	5D03	A	3	FIX32	VD	4	Ra	
C0765	♦	♦	23810	5D02	E	1	FIX32	VD	4	Ra	
C0770	♦	♦	23805	5CFD	E	1	FIX32	VD	4	Ra/W	CINH
C0771	♦	♦	23804	5CFC	E	1	FIX32	VD	4	Ra/W	CINH
C0772	♦	♦	23803	5CFB	E	1	FIX32	VD	4	Ra/W	CINH
C0773	♦	♦	23802	5CFA	A	3	FIX32	VD	4	Ra	
C0775	♦	♦	23800	5CF8	E	1	FIX32	VD	4	Ra/W	CINH
C0776	♦	♦	23799	5CF7	E	1	FIX32	VD	4	Ra/W	CINH
C0777	♦	♦	23798	5CF6	E	1	FIX32	VD	4	Ra/W	CINH

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C0778	♦	♦	23797	5CF5	A	3	FIX32	VD	4	Ra	
C0780	♦	♦	23795	5CF3	E	1	FIX32	VD	4	Ra/W	CINH
C0781	♦	♦	23794	5CF2	E	1	FIX32	VD	4	Ra/W	CINH
C0782	♦	♦	23793	5CF1	E	1	FIX32	VD	4	Ra/W	CINH
C0783	♦	♦	23792	5CF0	E	1	FIX32	VD	4	Ra/W	CINH
C0784	♦	♦	23791	5CEF	E	1	FIX32	VD	4	Ra/W	CINH
C0785	♦	♦	23790	5CEE	E	1	FIX32	VD	4	Ra/W	CINH
C0786	♦	♦	23789	5CED	E	1	FIX32	VD	4	Ra/W	CINH
C0787	♦	♦	23788	5CEC	A	4	FIX32	VD	4	Ra/W	CINH
C0788	♦	♦	23787	5CEB	A	4	FIX32	VD	4	Ra/W	CINH
C0789	♦	♦	23786	5CEA	E	1	FIX32	VD	4	Ra/W	CINH
C0790	♦	♦	23785	5CE9	E	1	FIX32	VD	4	Ra/W	CINH
C0798	♦	♦	23777	5CE1	A	2	FIX32	VD	4	Ra	
C0799	♦	♦	23776	5CEO	A	13	FIX32	VD	4	Ra	
C0800	♦	♦	23775	5CDF	E	1	FIX32	VD	4	Ra/W	CINH
C0801	♦	♦	23774	5CDE	E	1	FIX32	VD	4	Ra/W	CINH
C0802	♦	♦	23773	5CDD	E	1	FIX32	VD	4	Ra/W	CINH
C0803	♦	♦	23772	5CDC	E	1	FIX32	VD	4	Ra/W	CINH
C0804	♦	♦	23771	5CDB	E	1	FIX32	VD	4	Ra/W	CINH
C0805	♦	♦	23770	5CDA	E	1	FIX32	VD	4	Ra/W	CINH
C0808	♦	♦	23767	5CD7	A	4	FIX32	VD	4	Ra	
C0809	♦	♦	23766	5CD6	A	2	FIX32	VD	4	Ra	
C0810	♦	♦	23765	5CD5	A	2	FIX32	VD	4	Ra/W	CINH
C0811	♦	♦	23764	5CD4	E	1	FIX32	VD	4	Ra/W	CINH
C0812	♦	♦	23763	5CD3	A	2	FIX32	VD	4	Ra	
C0813	♦	♦	23762	5CD2	E	1	FIX32	VD	4	Ra	
C0815	♦	♦	23760	5CD0	A	2	FIX32	VD	4	Ra/W	CINH
C0816	♦	♦	23759	5CCF	E	1	FIX32	VD	4	Ra/W	CINH
C0817	♦	♦	23758	5CCE	A	2	FIX32	VD	4	Ra	
C0818	♦	♦	23757	5CCD	E	1	FIX32	VD	4	Ra	
C0820	♦	♦	23755	5CCB	A	3	FIX32	VD	4	Ra/W	CINH
C0821	♦	♦	23754	5CCA	A	3	FIX32	VD	4	Ra	
C0822	♦	♦	23753	5CC9	A	3	FIX32	VD	4	Ra/W	CINH
C0823	♦	♦	23752	5CC8	A	3	FIX32	VD	4	Ra	
C0824	♦	♦	23751	5CC7	A	3	FIX32	VD	4	Ra/W	CINH
C0825	♦	♦	23750	5CC6	A	3	FIX32	VD	4	Ra	
C0826	♦	♦	23749	5CC5	A	3	FIX32	VD	4	Ra/W	CINH
C0827	♦	♦	23748	5CC4	A	3	FIX32	VD	4	Ra	
C0828	♦	♦	23747	5CC3	A	3	FIX32	VD	4	Ra/W	CINH
C0829	♦	♦	23746	5CC2	A	3	FIX32	VD	4	Ra	
C0830	♦	♦	23745	5CC1	A	3	FIX32	VD	4	Ra/W	CINH
C0831	♦	♦	23744	5CC0	A	3	FIX32	VD	4	Ra	
C0832	♦	♦	23743	5CBF	A	3	FIX32	VD	4	Ra/W	CINH
C0833	♦	♦	23742	5CBE	A	3	FIX32	VD	4	Ra	
C0834	♦	♦	23741	5CBD	A	3	FIX32	VD	4	Ra/W	CINH

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C0835	♦	♦	23740	5CBC	A	3	FIX32	VD	4	Ra	
C0836	♦	♦	23739	5CBB	A	3	FIX32	VD	4	Ra/W	CINH
C0837	♦	♦	23738	5CBA	A	3	FIX32	VD	4	Ra	
C0838	♦	♦	23737	5CB9	A	3	FIX32	VD	4	Ra/W	CINH
C0839	♦	♦	23736	5CB8	A	3	FIX32	VD	4	Ra	
C0840	♦	♦	23735	5CB7	E	1	FIX32	VD	4	Ra/W	CINH
C0841	♦	♦	23734	5CB6	E	1	FIX32	VD	4	Ra	
C0842	♦	♦	23733	5CB5	E	1	FIX32	VD	4	Ra/W	CINH
C0843	♦	♦	23732	5CB4	E	1	FIX32	VD	4	Ra	
C0844	♦	♦	23731	5CB3	E	1	FIX32	VD	4	Ra/W	CINH
C0845	♦	♦	23730	5CB2	E	1	FIX32	VD	4	Ra	
C0846	♦	♦	23729	5CB1	E	1	FIX32	VD	4	Ra/W	CINH
C0847	♦	♦	23728	5CB0	E	1	FIX32	VD	4	Ra	
C0848	♦	♦	23727	5CAF	E	1	FIX32	VD	4	Ra/W	CINH
C0849	♦	♦	23726	5CAE	E	1	FIX32	VD	4	Ra	
C0850	♦	♦	23725	5CAD	A	3	FIX32	VD	4	Ra/W	CINH
C0851	♦	♦	23724	5CAC	E	1	FIX32	VD	4	Ra/W	CINH
C0852	♦	♦	23723	5CAB	E	1	FIX32	VD	4	Ra/Wa	
C0853	♦	♦	23722	5CAA	E	1	FIX32	VD	4	Ra/Wa	
C0855	♦	♦	23720	5CA8	A	2	B16	VH	2	Ra	
C0856	♦	♦	23719	5CA7	A	3	I32	VH	4	Ra	
C0857	♦	♦	23718	5CA6	E	1	I32	VH	4	Ra	
C0858	♦	♦	23717	5CA5	A	3	I32	VH	4	Ra	
C0859	♦	♦	23716	5CA4	E	1	I32	VH	4	Ra	
C0860	♦	♦	23715	5CA3	A	11	FIX32	VD	4	Ra/W	CINH
C0861	♦	♦	23714	5CA2	A	3	FIX32	VD	4	Ra/W	CINH
C0863	♦	♦	23712	5CA0	A	6	B32	VH	4	Ra	
C0864	♦	♦	23711	5C9F	A	3	FIX32	VD	4	Ra/Wa	
C0865	♦	♦	23710	5C9E	A	3	FIX32	VD	4	Ra/Wa	
C0866	♦	♦	23709	5C9D	A	11	I32	VH	4	Ra	
C0867	♦	♦	23708	5C9C	A	3	I32	VH	4	Ra	
C0868	♦	♦	23707	5C9B	A	11	I32	VH	4	Ra	
C0869	♦	♦	23706	5C9A	A	3	I32	VH	4	Ra	
C0870	♦	♦	23705	5C99	A	2	FIX32	VD	4	Ra/W	CINH
C0871	♦	♦	23704	5C98	E	1	FIX32	VD	4	Ra/W	CINH
C0876	♦	♦	23699	5C93	E	1	FIX32	VD	4	Ra/W	CINH
C0878	♦	♦	23697	5C91	A	4	FIX32	VD	4	Ra	
C0879	♦	♦	23696	5C90	A	3	FIX32	VD	4	Ra/Wa	
C0880	♦	♦	23695	5C8F	A	2	FIX32	VD	4	Ra/W	CINH
C0881	♦	♦	23694	5C8E	E	1	FIX32	VD	4	Ra/W	CINH
C0884	♦	♦	23691	5C8B	A	3	FIX32	VD	4	Ra	
C0885	♦	♦	23690	5C8A	E	1	FIX32	VD	4	Ra/W	CINH
C0886	♦	♦	23689	5C89	E	1	FIX32	VD	4	Ra/W	CINH
C0889	♦	♦	23686	5C86	A	2	FIX32	VD	4	Ra	
C0890	♦	♦	23685	5C85	E	1	FIX32	VD	4	Ra/W	CINH

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C0891	♦	♦	23684	5C84	E	1	FIX32	VD	4	Ra/W	CINH
C0892	♦	♦	23683	5C83	E	1	FIX32	VD	4	Ra/W	CINH
C0893	♦	♦	23682	5C82	E	1	FIX32	VD	4	Ra/W	CINH
C0899	♦	♦	23676	5C7C	E	1	FIX32	VD	4	Ra/W	CINH
C0900	♦	♦	23675	5C7B	E	1	FIX32	VD	4	Ra/W	CINH
C0901	♦	♦	23674	5C7A	E	1	FIX32	VD	4	Ra/W	CINH
C0902	♦	♦	23673	5C79	E	1	FIX32	VD	4	Ra/W	CINH
C0903	♦	♦	23672	5C78	E	1	FIX32	VD	4	Ra/W	CINH
C0904	♦	♦	23671	5C77	E	1	FIX32	VD	4	Ra/W	CINH
C0905	♦	♦	23670	5C76	E	1	FIX32	VD	4	Ra	
C0906	♦	♦	23669	5C75	A	6	FIX32	VD	4	Ra	
C0907	♦	♦	23668	5C74	A	4	FIX32	VD	4	Ra	
C0909	♦	♦	23666	5C72	E	1	FIX32	VD	4	Ra/Wa	
C0910	♦	♦	23665	5C71	E	1	FIX32	VD	4	Ra/W	CINH
C0911	♦	♦	23664	5C70	E	1	FIX32	VD	4	Ra	
C0912	♦	♦	23663	5C6F	E	1	FIX32	VD	4	Ra	
C0913	♦		23662	5C6E	E	1	FIX32	VD	4	Ra/Wa	
C0940	♦	♦	23635	5C53	E	1	FIX32	VD	4	Ra/Wa	
C0941	♦	♦	23634	5C52	E	1	FIX32	VD	4	Ra/Wa	
C0942	♦	♦	23633	5C51	E	1	FIX32	VD	4	Ra/W	CINH
C0943	♦	♦	23632	5C50	E	1	FIX32	VD	4	Ra	
C0945	♦	♦	23630	5C4E	E	1	FIX32	VD	4	Ra/Wa	
C0946	♦	♦	23629	5C4D	E	1	FIX32	VD	4	Ra/Wa	
C0947	♦	♦	23628	5C4C	E	1	FIX32	VD	4	Ra/W	CINH
C0948	♦	♦	23627	5C4B	E	1	FIX32	VD	4	Ra	
C0950	♦	♦	23625	5C49	E	1	FIX32	VD	4	Ra/Wa	
C0951	♦	♦	23624	5C48	E	1	FIX32	VD	4	Ra/Wa	
C0952	♦	♦	23623	5C47	E	1	FIX32	VD	4	Ra/W	CINH
C0953	♦	♦	23622	5C46	E	1	FIX32	VD	4	Ra	
C0955	♦	♦	23620	5C44	E	1	FIX32	VD	4	Ra/Wa	
C0956	♦	♦	23619	5C43	E	1	FIX32	VD	4	Ra/Wa	
C0957	♦	♦	23618	5C42	E	1	FIX32	VD	4	Ra/W	CINH
C0958	♦	♦	23617	5C41	E	1	FIX32	VD	4	Ra	
C0960	♦	♦	23615	5C3F	E	1	FIX32	VD	4	Ra/Wa	
C0961	♦	♦	23614	5C3E	E	1	FIX32	VD	4	Ra/Wa	
C0962	♦	♦	23613	5C3D	E	1	FIX32	VD	4	Ra/Wa	
C0963	♦	♦	23612	5C3C	E	1	FIX32	VD	4	Ra/Wa	
C0964	♦	♦	23611	5C3B	E	1	FIX32	VD	4	Ra/Wa	
C0965	♦	♦	23610	5C3A	E	1	FIX32	VD	4	Ra/Wa	
C0966	♦	♦	23609	5C39	E	1	FIX32	VD	4	Ra/Wa	
C0967	♦	♦	23608	5C38	E	1	FIX32	VD	4	Ra/W	CINH
C0968	♦	♦	23607	5C37	E	1	FIX32	VD	4	Ra	
C0970	♦	♦	23605	5C35	E	1	FIX32	VD	4	Ra/W	CINH
C0971	♦	♦	23604	5C34	E	1	FIX32	VD	4	Ra/W	CINH
C0972	♦	♦	23603	5C33	E	1	FIX32	VD	4	Ra/W	CINH

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C0973	♦	♦	23602	5C32	E	1	FIX32	VD	4	Ra/W	CINH
C0974	♦	♦	23601	5C31	E	1	FIX32	VD	4	Ra/W	CINH
C0975	♦	♦	23600	5C30	E	1	FIX32	VD	4	Ra/W	CINH
C0976	♦	♦	23599	5C2F	E	1	FIX32	VD	4	Ra/W	CINH
C0977	♦	♦	23598	5C2E	E	1	FIX32	VD	4	Ra/W	CINH
C0978	♦	♦	23597	5C2D	E	1	FIX32	VD	4	Ra/W	CINH
C0980	♦	♦	23595	5C2B	E	1	FIX32	VD	4	Ra/Wa	
C0981	♦	♦	23594	5C2A	E	1	FIX32	VD	4	Ra/Wa	
C0982	♦	♦	23593	5C29	E	1	FIX32	VD	4	Ra/Wa	
C0983	♦	♦	23592	5C28	E	1	FIX32	VD	4	Ra/Wa	
C0988	♦	♦	23587	5C23	A	7	FIX32	VD	4	Ra	
C0989	♦	♦	23586	5C22	A	2	FIX32	VD	4	Ra	
C1000	♦	♦	23575	5C17	E	1	FIX32	VD	4	Ra/Wa	
C1001	♦	♦	23574	5C16	E	1	FIX32	VD	4	Ra/W	CINH
C1002	♦	♦	23573	5C15	E	1	I32	VH	4	Ra/Wa	
C1040	♦	♦	23535	5BEF	E	1	FIX32	VD	4	Ra/Wa	
C1041	♦	♦	23534	5BEE	E	1	FIX32	VD	4	Ra/Wa	
C1042	♦	♦	23533	5BED	E	1	FIX32	VD	4	Ra/W	CINH
C1043	♦	♦	23532	5BEC	E	1	FIX32	VD	4	Ra/W	CINH
C1044	♦	♦	23531	5BEB	E	1	FIX32	VD	4	Ra/W	CINH
C1045	♦	♦	23530	5BEA	A	2	FIX32	VD	4	Ra	
C1046	♦	♦	23529	5BE9	E	1	FIX32	VD	4	Ra	
C1090	♦	♦	23485	5BBD	E	1	I32	VH	4	Ra	
C1091	♦	♦	23484	5BBC	E	1	FIX32	VD	4	Ra/Wa	
C1092	♦	♦	23483	5BBB	E	1	FIX32	VD	4	Ra/Wa	
C1093	♦	♦	23482	5BBA	E	1	FIX32	VD	4	Ra/Wa	
C1094	♦	♦	23481	5BB9	E	1	FIX32	VD	4	Ra/Wa	
C1095	♦	♦	23480	5BB8	E	1	FIX32	VD	4	Ra/Wa	
C1096	♦	♦	23479	5BB7	E	1	FIX32	VD	4	Ra/W	CINH
C1097	♦	♦	23478	5BB6	E	1	FIX32	VD	4	Ra/W	CINH
C1098	♦	♦	23477	5BB5	E	1	FIX32	VD	4	Ra	
C1099	♦	♦	23476	5BB4	E	1	FIX32	VD	4	Ra	
C1100	♦	♦	23475	5BB3	E	1	FIX32	VD	4	Ra/Wa	
C1101	♦	♦	23474	5BB2	A	2	FIX32	VD	4	Ra/W	CINH
C1102	♦	♦	23473	5BB1	A	3	FIX32	VD	4	Ra/W	CINH
C1103	♦	♦	23472	5BBO	A	2	FIX32	VD	4	Ra	
C1104	♦	♦	23471	5BAF	A	3	FIX32	VD	4	Ra	
C1160	♦	♦	23418	5B7A	E	1	FIX32	VD	4	Ra/W	CINH
C1161	♦	♦	23417	5B79	E	1	FIX32	VD	4	Ra/W	CINH
C1162	♦	♦	23416	5B78	E	1	FIX32	VD	4	Ra	
C1163	♦	♦	23415	5B77	E	1	FIX32	VD	4	Ra	
C1190		♦	23388	5B5C	E	1	FIX32	VD	4	Ra/Wa	
C1191		♦	23387	5B5B	A	2	FIX32	VD	4	Ra/Wa	
C1192		♦	23386	5B5A	A	2	FIX32	VD	4	Ra/Wa	
C1300	♦	♦	23278	5AEE	E	1	FIX32	VD	4	Ra/Wa	

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C1301	♦	♦	23277	5AED	E	1	FIX32	VD	4	Ra/Wa	
C1302	♦	♦	23276	5AEC	E	1	FIX32	VD	4	Ra/Wa	
C1303	♦	♦	23275	5AEB	E	1	FIX32	VD	4	Ra/Wa	
C1304	♦	♦	23274	5AEA	E	1	VS	VS	20	Ra	
C1305	♦	♦	23273	5AE9	E	1	VS	VS	20	Ra	
C1306	♦	♦	23272	5AE8	E	1	FIX32	VD	4	Ra/Wa	
C1307	♦	♦	23271	5AE7	E	1	FIX32	VD	4	Ra/Wa	
C1308	♦	♦	23270	5AE6	E	1	FIX32	VD	4	Ra/Wa	
C1309	♦	♦	23269	5AE5	E	1	FIX32	VD	4	Ra/Wa	
C1310	♦	♦	23268	5AE4	E	1	FIX32	VD	4	Ra/Wa	
C1311	♦	♦	23267	5AE3	E	1	FIX32	VD	4	Ra/Wa	
C1320	♦	♦	23258	5ADA	E	1	FIX32	VD	4	Ra/W	CINH
C1321	♦	♦	23257	5AD9	A	2	FIX32	VD	4	Ra/W	CINH
C1322	♦	♦	23256	5AD8	A	2	FIX32	VD	4	Ra	
C1325	♦	♦	23253	5AD5	E	1	FIX32	VD	4	Ra	
C1326	♦	♦	23252	5AD4	A	2	FIX32	VD	4	Ra	
C1327	♦	♦	23251	5AD3	A	2	FIX32	VD	4	Ra/W	CINH
C1328	♦	♦	23250	5AD2	E	1	FIX32	VD	4	Ra	
C1330	♦	♦	23248	5AD0	E	1	FIX32	VD	4	Ra/Wa	
C1331	♦	♦	23247	5ACF	E	1	FIX32	VD	4	Ra/Wa	
C1332	♦	♦	23246	5ACE	E	1	FIX32	VD	4	Ra/Wa	
C1333	♦	♦	23245	5ACD	E	1	FIX32	VD	4	Ra/Wa	
C1334	♦	♦	23244	5ACC	E	1	FIX32	VD	4	Ra/Wa	
C1335	♦	♦	23243	5ACB	E	1	FIX32	VD	4	Ra/Wa	
C1336	♦	♦	23242	5ACA	E	1	FIX32	VD	4	Ra/Wa	
C1337	♦	♦	23241	5AC9	E	1	FIX32	VD	4	Ra/Wa	
C1340	♦	♦	23238	5AC6	A	4	FIX32	VD	4	Ra/W	CINH
C1341	♦	♦	23237	5AC5	A	4	FIX32	VD	4	Ra/W	CINH
C1344	♦	♦	23234	5AC2	A	4	FIX32	VD	4	Ra	
C1345	♦	♦	23233	5AC1	A	4	FIX32	VD	4	Ra	
C1350	♦	♦	23228	5ABC	E	1	FIX32	VD	4	Ra/Wa	
C1351	♦	♦	23227	5ABB	E	1	FIX32	VD	4	Ra/Wa	
C1354	♦	♦	23224	5AB8	E	1	FIX32	VD	4	Ra/W	CINH
C1355	♦	♦	23223	5AB7	E	1	FIX32	VD	4	Ra/W	CINH
C1356	♦	♦	23222	5AB6	E	1	FIX32	VD	4	Ra/W	CINH
C1357	♦	♦	23221	5AB5	E	1	FIX32	VD	4	Ra	
C1358	♦	♦	23220	5AB4	E	1	FIX32	VD	4	Ra	
C1359	♦	♦	23219	5AB3	E	1	FIX32	VD	4	Ra	
C1360	♦	♦	23218	5AB2	E	1	FIX32	VD	4	Ra/Wa	
C1361	♦	♦	23217	5AB1	E	1	FIX32	VD	4	Ra/Wa	
C1364	♦	♦	23214	5AAE	E	1	FIX32	VD	4	Ra/W	CINH
C1365	♦	♦	23213	5AAD	E	1	FIX32	VD	4	Ra/W	CINH
C1366	♦	♦	23212	5AAC	E	1	FIX32	VD	4	Ra/W	CINH
C1367	♦	♦	23211	5AAB	E	1	FIX32	VD	4	Ra	
C1368	♦	♦	23210	5AAA	E	1	FIX32	VD	4	Ra	

Code	Controller		Index		Data				Access		
	EVF9321 ... EVF9333	EVF9335 ... EVF9383	dec	hex	DS	DA	DT	Format	DL	LCM-R/W	Condition
C1369	♦	♦	23209	5AA9	E	1	FIX32	VD	4	Ra	
C1370	♦	♦	23208	5AA8	E	1	FIX32	VD	4	Ra/Wa	
C1371	♦	♦	23207	5AA7	E	1	FIX32	VD	4	Ra/Wa	
C1372	♦	♦	23206	5AA6	E	1	FIX32	VD	4	Ra/Wa	
C1373	♦	♦	23205	5AA5	E	1	FIX32	VD	4	Ra/Wa	
C1375	♦	♦	23203	5AA3	E	4	FIX32	VD	4	Ra/W	CINH
C1376	♦	♦	23202	5AA2	E	1	FIX32	VD	4	Ra/W	CINH
C1377	♦	♦	23201	5AA1	A	4	FIX32	VD	4	Ra	
C1378	♦	♦	23200	5AA0	E	1	FIX32	VD	4	Ra	
C1583	♦	♦	22995	59D3	E	1	FIX32	VD	4	Ra/Wa	
C1751	♦	♦	22827	592B	A	17	FIX32	VD	4	Ra/W	CINH
C1753	♦	♦	22825	5929	E	1	FIX32	VD	4	Ra/W	CINH
C1754	♦	♦	22824	5928	E	1	FIX32	VD	4	Ra/W	CINH
C1755	♦	♦	22823	5927	E	1	FIX32	VD	4	Ra/W	CINH

9 Troubleshooting and fault elimination

Contents

9.1	Display of operating data, diagnostics	9.1-1
9.1.1	Display of operating data	9.1-1
9.1.2	Diagnostics	9.1-2
9.2	Troubleshooting	9.2-1
9.2.1	Status display via LEDs at the controller	9.2-1
9.2.2	Fault analysis with the history buffer	9.2-1
9.3	Drive behaviour in the event of faults	9.3-1
9.4	Fault elimination	9.4-1
9.4.1	Drive errors	9.4-1
9.4.2	Controller in clamp operation	9.4-2
9.4.3	Behaviour in case of overvoltage in the DC bus (OU message)	9.4-3
9.5	System error messages	9.5-1
9.5.1	General error messages	9.5-1
9.5.2	Resetting system error messages	9.5-5

Troubleshooting and fault elimination

9

Display of operating data, diagnostics

9.1

Display of operating data

9.1.1

9.1 Display of operating data, diagnostics

9.1.1 Display of operating data

Description

Important operating parameters are measured by the controller. They can be displayed with the keypad or PC.

Some operating data can be calibrated to be displayed or selected directly with the unit of the process quantity (e.g. pressure, temperature, speed).



Note!

The calibration always affects all specified codes simultaneously.

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0051	MCTRL-NACT		-36000	{1 rpm}	36000	Actual speed value, function block MCTRL ● Read only 8.2-25 8.2-40
C0052	MCTRL-Umot		0	{1 V}	800	Motor voltage, function block MCTRL ● Read only ● MCTRL-VACT = 100 % = C0090 8.2-25 8.2-40
C0053	UG-VOLTAGE		0	{1 V}	900	DC-bus voltage, function block MCTRL ● Read only ● MCTRL-DCVOLT = 100 % = 1000 V 8.2-25 8.2-40
C0054	Imot		0.0	{0.1 A}	5000.0	Actual motor current, function block MCTRL ● Read only ● MCTRL-IACT = 100 % = C0022 8.2-25 8.2-40
C0061	Heatsink temp		0	{1 °C}	100	Heatsink temperature ● Read only ● If the temperature of the heatsink > 85 °C, the controller sets TRIP OH ● Early warning is possible via OH4, temperature is set in C0122 See System Manual (extension)
C0063	Mot temp		0	{1 °C}	200	Motor temperature ● Read only ● Monitoring of the motor temperature must be activated. ● KTY at X8/5, X8/8: – At 150 °C, TRIP OH3 is set – Early warning is possible via OH7, temperature is set in C0121 ● PTC, thermal contact at T1, T2: – Release sets TRIP or warning OH8 8.2-25 8.2-40

9 Troubleshooting and fault elimination

9.1 Display of operating data, diagnostics

9.1.2 Diagnostics

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0064	Utilization		0	{1 %}		150	Device utilisation limit <ul style="list-style-type: none"> • Read only • Device utilisation of the last 180 s operating time • C0064 > 100 % triggers warning OC5 • C0064 > 110 % limits the output current of the controller to 67 % of the maximum current in C0022
C0150	Status word		Bit00	–	Bit08	Status code	Read only Decimal status word for networking via automation interface (AIF) <ul style="list-style-type: none"> • Binary interpretation indicates the bit states
			Bit01	IMP	Bit09	Status code	
			Bit02	–	Bit10	Status code	
			Bit03	–	Bit11	Status code	
			Bit04	–	Bit12	Warning	
			Bit05	–	Bit13	Message	
			Bit06	n = 0	Bit14	–	
			Bit07	CINH	Bit15	–	

9.1.2 Diagnostics

Description Display codes for diagnostics

Codes for parameter setting

Code		Possible settings				IMPORTANT	
No.	Name	Lenze	Selection				
C0093	Drive ident		0	Invalid		Controller identification	
			1	None		• Read only	
			14	9335VC 400V		Defective power section	
				No power section	
			20	9383VC 400V		Display of the controller used	
			21	9334VC 500V			
					
			28	9383VC 500V			
			9321	9321 VC			
					
			9333	9333VC			
C0099	S/W version		x.y	Main version		Software version	
			x	Subversion		• Read only	
			y				

Troubleshooting and fault elimination	9
Troubleshooting	9.2
Status display via LEDs at the controller	9.2.1

9.2 Troubleshooting

Detecting breakdowns	A breakdown can be detected quickly via the LEDs at the controller or via the status information at the keypad.
Analysing errors	Analyse the error using the history buffer. The list of fault messages gives you advice how to remove the fault. (9.5-1)

9.2.1 Status display via LEDs at the controller

During operation, the operating status of the controller is indicated by means of two LEDs.

LED		Operating status
Red ①	Green ②	
Off	On	Controller is enabled
On	On	Mains is switched on and automatic start is inhibited
Off	Blinking slowly	Controller is inhibited
Off	On	Motor data identification is being performed
Blinking quickly	Off	Undervoltage
Blinking slowly	Off	Active fault



The image shows a close-up of a Lenze motor label. The label includes the following information:

- Size: Str. 1
- Location: Aerzen
- Version: 1A1F
- Part No.: 1234
- Power: 0/240V
- Certifications: UL LISTED 1D74

Two callout lines with circles point to specific LEDs on the motor housing:

- ① Points to the red LED located on the left side of the label.
- ② Points to the green LED located above the red LED.

9.2.2 Fault analysis with the history buffer

Retracing faults Faults can be retraced via the history buffer. Fault messages are stored in the 8 memory locations in the order of their appearance. The memory locations can be retrieved via codes.

9 Troubleshooting and fault elimination

9.2 Troubleshooting

9.2.2 Fault analysis with the history buffer

Structure of the history buffer

Code	Memory location	Entry	Note
C0168/1	C0169/1	Memory location 1	Active fault
C0168/2	C0169/2	C0170/2	Memory location 2
C0168/3	C0169/3	C0170/3	Memory location 3
C0168/4	C0169/4	C0170/4	Memory location 4
C0168/5	C0169/5	C0170/5	Memory location 5
C0168/6	C0169/6	C0170/6	Memory location 6
C0168/7	C0169/7	C0170/7	Memory location 7
C0168/8	C0169/8	C0170/8	Memory location 8

Explanations regarding the codes

C0168	Fault indication and response <ul style="list-style-type: none">The entry is effected as a LECOM error numberIf several faults with different responses occur at the same time:<ul style="list-style-type: none">Only the fault with the highest priority response is entered (1. TRIP, 2. message, 3. warning).If several faults with the same response (e.g. 2 messages) occur at the same time:<ul style="list-style-type: none">Only the fault which occurred first is entered.
C0169	Time of fault occurrence <ul style="list-style-type: none">The reference time is provided by the power-on time meter (C0179).If the same fault occurs several times in succession, only the time of the last occurrence is stored.
C0170	Fault frequency <ul style="list-style-type: none">Only the time of the last occurrence is stored.

Clear history buffer

Set C0167 = 1 to clear the history buffer.

9.3 Drive behaviour in the event of faults

The controller responds differently to the three possible fault types TRIP, message, or warning:

TRIP

TRIP (display in keypad XT:)

- ▶ Switches the power outputs U, V, W to a high-resistance state until TRIP reset is executed.
- ▶ The fault indication is entered into the history buffer as "current fault" in C0168/1.
- ▶ The drive coasts without any control!
- ▶ After TRIP reset (参见 9.5-5):
 - The drive travels along the ramps to its setpoint.
 - The fault indication is moved to C0168/2 as "last fault".

Messages

Message (display in keypad XT:)

- ▶ Switches the power outputs U, V, W to a high-resistance state.
- ▶ The fault indication is entered into the history buffer as "current fault" in C0168/1.
- ▶ In case of a fault ≤ 5 s:
 - The drive coasts without any control as long as the message is active!
 - If the message is not active anymore, the drive travels to its setpoint with maximum torque.
- ▶ In case of a fault > 5 s:
 - The drive coasts without any control as long as the message is active!
 - If the message is not active anymore, the drive travels to its setpoint along the adjusted ramps.
- ▶ If the message is not active anymore, the fault indication is moved to C0168/2 as "last fault".

Warnings

"Heatsink overtemperature" (keypad XT:)

- ▶ The drive continues to travel in a controlled way!
- ▶ The warning signal goes off when the fault is not active anymore.

"Error in motor phase" (keypad XT:)

"PTC monitoring" (keypad XT:)

- ▶ The drive continues to travel in a controlled way!
- ▶ The fault indication is entered into the history buffer as "current fault" in C0168/1.
- ▶ After TRIP reset, the fault indication is moved to C0168/2 as "last fault".

9.4 Fault elimination

9.4.1 Drive errors

Malfunction	Cause	Remedy
An asynchronous motor with feedback rotates in an uncontrolled manner and with low speed	<p>The motor phases are reversed so that the rotating field of the motor is not identical with the rotating field of the feedback system. The drive shows the following behaviour:</p> <ul style="list-style-type: none"> ● V/f characteristic control (C0006 = 5) <ul style="list-style-type: none"> – The motor rotates faster than the speed setpoint by the value set in C0074 (influence of the speed controller, Lenze setting 10 % of n_{\max}). After the controller is enabled, it does not stop at zero speed setpoint or quick stop (QSP). – The final motor current depends, among other things, on the set value of the V_{\min} boost (C0016) and can rise to I_{\max} (C0022). This may activate the fault message OC5. ● Vector control (C0006 = 1) <ul style="list-style-type: none"> – The motor rotates slowly with maximum slip speed (depending on motor data and maximum current) and does not react to a speed setpoint. The direction of rotation, however, is determined by the sign of the speed setpoint. – The motor current rises up to I_{\max} (C0022). This may activate the fault message OC5 with a time delay. 	<ul style="list-style-type: none"> ● Check motor cable for correct phase relation. ● If possible, operate the motor with deactivated feedback (C0025 = 1) and check the direction of rotation of the motor.
Motor does not rotate although the controller is enabled (IMP is off) and a speed setpoint has been specified.	The two terminal strips X5 are reversed. Since X5/A1 and X5/28 face each other, the controller can be enabled if the control terminals are internally supplied. All other connections, however, are assigned incorrectly so that the motor cannot start.	<p>Check the position of the terminal strips:</p> <ul style="list-style-type: none"> ● If you look at the connection unit in reading direction, the left terminal strip X5 must be connected with the input signals and the right terminal strip X5 must be connected with the output signals.
The monitoring of the motor phases (LP1) does not respond if a motor phase is interrupted, although C0597 = 0 or 2	The function block MLP1 is not entered into the processing table.	Enter the function block MLP1 into the processing table. The function block MLP1 requires 30 μ s of calculating time.
If during high speeds DC-injection braking (GSB) is activated, the fault OC1 (TRIP) or OU (TRIP) occurs	During DC-injection braking the controller sets pulse inhibit for a short time (DCTRL-IMP) to reduce the magnetisation in the motor before a DC voltage is injected into the motor. At high speeds (e. g. in case of mid-frequency motors) the residual voltage which develops from the residual magnetism and high speed can generate such a high motor current that OC1 or OU are activated.	<p>Prolong the duration of the pulse inhibit:</p> <ul style="list-style-type: none"> ● Connect the output signal DCTRL-IMP to the function block TRANSx and adjust the desired switch-off time there (usually 500 ms). If DCTRL-CINH1 is set to HIGH, the duration of the pulse inhibit is prolonged by the time adjusted.

9.4.2 Controller in clamp operation

The clamp operation is a permissible operating mode. But since, however, pulse inhibit is set again and again, the controller cannot provide the optimum power. Moreover, the fault OC3 (TRIP) can be activated.

If the output power is optimal, the output current mainly is right below the clamp threshold.




Fig. 9.4-1 Output current when starting a motor with high load (shown with the oscilloscope in GDC)

- A Clamp threshold
- B Output current

Function

1. When the output current reaches $2.25 \times I_r$, a software clamp is activated.
2. The controller sets pulse inhibit for a short time. The motor current decreases as a function of the inductance in the motor circuit.
 - An internal counter is increased by the value one.
3. After max. 250 µs the pulse inhibit is deactivated.
4. If a software clamp reoccurs within 2 s, the internal counter is again increased by the value one. Otherwise the counter is set to zero.
 - If the counter reaches the value 4300, OC3 (TRIP) is activated.

Troubleshooting and fault elimination	9
Fault elimination	9.4
Behaviour in case of overvoltage in the DC bus (OU message)	9.4.3

9.4.3 Behaviour in case of overvoltage in the DC bus (OU message)

Description	If the DC-bus voltage (U_{DC}) exceeds the switch-off threshold OU, pulse inhibit will be set. At the same time, an internal timer for a delay time (C0912) will be started. Pulse inhibit will be reset, if the voltage falls below the switch-on threshold OU and the delay time has elapsed.
-------------	--

Types EVF93xx-EVV210, EVF93xx-EVV240, EVF93xx-EVV270 and EVF93xx-EVV300				
Mains voltage range		C0173	Switch-off threshold OU	Switch-on threshold OU
< 400 V	Operation with or without brake transistor	0	770 V	755 V
400 V	Operation with or without brake transistor	1 *	770 V	755 V
460 V	Operation with or without brake transistor	2	770 V	755 V
480 V	Brake transistor	3	770 V	755 V
480 V	Brake transistor	4	800 V	785 V
500 V	Operation with or without brake transistor	5	900 V	885 V

* Lenze setting

Types EVF93xx-EV, EVF93xx-EVV060 and EVF93xx-EVV110

Types EVF93xx-EV, EVF93xx-EVV060 and EVF93xx-EVV110				
Mains voltage range		C0173	Switch-off threshold OU	Switch-on threshold OU
400 V	Operation with or without brake transistor	Read only	700 V	685 V

Codes for parameter setting

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0912	OV delay time	→	-	{1 ms}	- Delay time of the pulse enable after an OU message → Depending on C0082, C0086, C0087, C0088, C0089, C0090, C0091, C0092 A change of one of the codes resets C0912 to the time of the selected motor ● The time is derived from the double rotor time constant	8.2-25 8.2-40 9.4-3


Adjustment

Fig. 9.4-2 Influence of the delay time (C0912)

① Switch-off threshold OU

② Switch-on threshold OU

A The period of time between exceeding the switch-off threshold OU and undershooting the switch-on threshold OU equals or is higher than the delay time set in C0912.

After undershooting the switch-on threshold OU, the pulse inhibit is deactivated.

B The period of time between exceeding the switch-off threshold OU and undershooting the switch-on threshold OU is lower than the delay time set in C0912.

The pulse inhibit is deactivated after the delay time in C0912 has elapsed.

- In C0912 the delay time is set in [ms]. The Lenze setting can be changed by the factor 0.5 ... 2.

9.5 System error messages

9.5.1 General error messages



Note!

If the system error is retrieved via the system bus (CAN), the error messages are displayed as numbers (see column "Error message – No." of the below table).

Fault message		Description	Cause	Remedy
No.	Display			
---	---	No fault	-	-
0011	OC1	Short circuit of motor cable	Short circuit	<ul style="list-style-type: none"> Search for cause of short circuit. Check motor cable.
			Excessive capacitive charging current in the motor cable.	Use motor cable which is shorter or of lower capacitance.
0012	OC2	Motor cable earth fault	One of the motor phases has earth contact.	<ul style="list-style-type: none"> Search for cause of short circuit. Check motor cable.
0013	OC3	Overload during acceleration.	Too short acceleration or deceleration times in proportion to the load (C0012, C0013, C0105).	<ul style="list-style-type: none"> Increase the gain (P component) of the current controller (C0075). Reduce the reset time (integral action component) of the I_{max} controller (C0076). Increase ramp times. 9.4-2, "controller in clamp operation (fault OC3)"
0015	OC5	$I \times t$ overload	<ul style="list-style-type: none"> Frequent and too long acceleration with overcurrent Continuous overload with $I_{motor} > 1.05 \times I_{rx}$. 	Check drive dimensioning.
2020	OU	Overvoltage in the DC bus	Braking energy is too high. (DC-bus voltage is higher than set in C0173.)	<ul style="list-style-type: none"> Use a braking unit or regenerative module. Check dimensioning of the brake resistor.
1030	LU	Undervoltage in the DC bus	DC bus voltage is lower than specified in C0173.	<ul style="list-style-type: none"> Check mains voltage Check supply cable
x032	LP1	Motor phase failure	A current-carrying motor phase has failed.	<ul style="list-style-type: none"> Check motor. Check motor cable. Switch off monitoring (C0597 = 3).
			The current limit value is set too low.	<ul style="list-style-type: none"> Set higher current limit value via C0599.
0050	OH	Heatsink temperature $> +90^{\circ}\text{C}$	Ambient temperature $T_u > +40^{\circ}\text{C}$ or $> +50^{\circ}\text{C}$	<ul style="list-style-type: none"> Allow module to cool and ensure better ventilation. Check ambient temperature in the control cabinet.
			Heatsink is very dirty.	Clean heatsink.
			Wrong mounting position	Change mounting position.

Fault message		Description	Cause	Remedy
No.	Display			
x053	OH3	Motor temperature > +150 °C threshold (temperature detection via resolver or incremental value encoder)	Motor is thermally overloaded due to:	<ul style="list-style-type: none"> • Impermissible continuous current • Frequent or too long acceleration processes
			No PTC/temperature contact connected.	<ul style="list-style-type: none"> • Check drive dimensioning. • Switch off monitoring (C0583 = 3).
x054	OH4	Heatsink temperature > C0122	Ambient temperature $T_u > +40$ °C or > +50 °C	<ul style="list-style-type: none"> • Allow module to cool and ensure better ventilation. • Check ambient temperature in the control cabinet. • Switch off monitoring (C0582 = 3).
			Heatsink is very dirty.	Clean heatsink
			Wrong mounting position	Change mounting position.
			The value specified under C0122 is set too low.	Enter a higher value under C0122.
x057	OH7	Motor temperature > C0121 (temperature detection via resolver or incremental value encoder)	Motor is thermally overloaded due to:	<ul style="list-style-type: none"> • Impermissible continuous current • Frequent or too long acceleration processes
			No PTC/temperature contact connected.	Correct wiring.
			The value specified under C0121 is set too low.	Enter a higher value in C0121.
x058	OH8	Motor temperature via inputs T1 and T2 is too high.	Motor is thermally overloaded due to:	<ul style="list-style-type: none"> • Impermissible continuous current • Frequent or too long acceleration processes
			Terminals T1 and T2 are not connected	Connect PTC/temperature contact.
x061	CE0	Automation interface (AIF) communication error	Faulty transfer of control commands via AIF.	<ul style="list-style-type: none"> • Plug in the communication module/keypad XT firmly, screw down, if necessary. • Switch off monitoring (C0126 = 3).
x062	CE1	Communication error on the process data input object CAN1_IN	CAN1_IN object receives faulty data or communication is interrupted.	<ul style="list-style-type: none"> • Check wiring at X4. • Check sender. • Increase monitoring time under C0357/1, if necessary. • Switch off monitoring (C0591 = 3).
x063	CE2	Communication error on the process data input object CAN2_IN	CAN2_IN object receives faulty data or communication is interrupted.	<ul style="list-style-type: none"> • Check wiring at X4. • Check sender. • Increase monitoring time under C0357/2, if necessary. • Switch off monitoring (C0592 = 3).
x064	CE3	Communication error on the process data input object CAN3_IN	CAN3_IN object receives faulty data or communication is interrupted.	<ul style="list-style-type: none"> • Check wiring at X4. • Check sender. • Increase monitoring time under C0357/3, if necessary. • Switch off monitoring (C0593 = 3).

Troubleshooting and fault elimination

9

System error messages

9.5

General error messages

9.5.1

Fault message		Description	Cause	Remedy
No.	Display			
x065	CE4	BUS-OFF state of system bus (CAN)	The controller has received too many faulty telegrams via the system bus (CAN) and has disconnected from the bus.	<ul style="list-style-type: none"> ● Check wiring at X4: Is the bus correctly terminated? ● Check shield connection of the cables. ● Check PE connection. ● Check bus load, reduce the baud rate if necessary. (Observe the cable length!) ● Switch off the monitoring (C0595 = 3).
0071	CCr	System failure	Strong interference injection on the control cables	Screen control cables
			Ground or earth loops in the wiring	<ul style="list-style-type: none"> ● Check wiring ● Check PE connection
				After troubleshooting: Deenergise the device completely (disconnect 24 V supply, discharge DC bus)!
0072	PR1	Checksum error in parameter set 1 CAUTION: The Lenze setting is loaded automatically!	<ul style="list-style-type: none"> ● Fault when loading a parameter set. ● Interruption while transmitting the parameter set via keypad. 	<ul style="list-style-type: none"> ● Set the required parameters and store them under C0003 = 1. ● As to PLC devices, check the use of pointers.
			The stored parameters are incompatible with the loaded software version.	Store the parameter set under C0003 = 1 first to allow for a faults reset.
0073	PR2	Checksum error in parameter set 2 PLEASE NOTE: The Lenze setting is loaded automatically!	<ul style="list-style-type: none"> ● Fault while loading a parameter set. ● Interruption during the transfer of the parameter set via keypad. 	<ul style="list-style-type: none"> ● Set the required parameters and save them with C0003 = 2.
			The parameters saved do not comply with the software version loaded.	In order to be able to acknowledge the error, first save the parameter set with C0003 = 2.
0074	PEr	Program error	Error in the program flow	Send the parameter set (on floppy disk/CD-ROM) with a detailed description of the problem to Lenze. After troubleshooting: Deenergise the device completely (disconnect 24 V supply, discharge DC bus)!
0075	PRO	Error in parameter set.	The operating system software has been updated.	Storage of the Lenze setting C0003 = 1. After troubleshooting: Deenergise the device completely (disconnect 24 V supply, discharge DC bus)!
0077	PR3	Checksum error in parameter set 3 PLEASE NOTE: The Lenze setting is loaded automatically!	<ul style="list-style-type: none"> ● Fault while loading a parameter set. ● Interruption during the transfer of the parameter set via keypad. 	<ul style="list-style-type: none"> ● Set the required parameters and save them with C0003 = 3.
			The parameters saved do not comply with the software version loaded.	In order to be able to acknowledge the error, first save the parameter set with C0003 = 3.
0078	PR4	Checksum error in parameter set 4 PLEASE NOTE: The Lenze setting is loaded automatically!	<ul style="list-style-type: none"> ● Fault while loading a parameter set. ● Interruption during the transfer of the parameter set via keypad. 	<ul style="list-style-type: none"> ● Set the required parameters and save them with C0003 = 4.
			The parameters saved do not comply with the software version loaded.	In order to be able to acknowledge the error, first save the parameter set with C0003 = 4.

Fault message		Description	Cause	Remedy
No.	Display			
0079	PI	Fault during parameter initialisation	<ul style="list-style-type: none"> An error has been detected during the parameter set transfer between two devices. The parameter set does not match the controller, e.g. if data has been transferred from a higher-power controller to a lower-power controller. 	<ul style="list-style-type: none"> Correct parameter set. Send parameter set (on floppy disk/CD-ROM) and a detailed description of the problem to Lenze.
x083	Sd3	Encoder error at X9	<p>Cable interrupted.</p> <p>Pin X9/8 not connected.</p>	<p>Check cable for open circuit.</p> <p>Apply 5 V to pin X9/8 or switch off monitoring (C0587 = 3).</p>
x085	Sd5	Encoder error at X6/1 and X6/2 (C0034 = 1)	Current signal at X6/1 X6/2 < 2mA.	<ul style="list-style-type: none"> Check cable for open circuit. Check current signal encoder. Switch off monitoring (C0598 = 3).
x086	Sd6	Motor temperature sensor error (X7 or X8)	Encoder for detecting the motor temperature at X7 or X8 indicates undefined values.	<ul style="list-style-type: none"> Check cable for firm connection. Switch off the monitoring (C0594 = 3).
x091	EEr	External monitoring has been triggered via DCTRL.	A digital signal assigned to the TRIP-SET function has been activated.	<ul style="list-style-type: none"> Check external encoder. Switch off the monitoring (C0581 = 3).
0105	H05	Internal fault (memory)		Contact Lenze.
0107	H07	Internal fault (power stage)	During initialisation of the controller, an incorrect power stage was detected.	Contact Lenze.
x110	H10	Heatsink temperature sensor error	Sensor for detecting the heatsink temperature indicates undefined values.	<ul style="list-style-type: none"> Contact Lenze. Switch off the monitoring (C0588 = 3).
x111	H11	Temperature sensor error: Temperature inside the controller	Sensor for detecting the internal temperature indicates undefined values.	<ul style="list-style-type: none"> Contact Lenze. Switch off the monitoring (C0588 = 3).
0140	ID1	Error during motor data identification.	No motor connected.	Check motor connection.
			Stator resistance too high.	Check entered motor data.
			Controller inhibited externally.	Enable controller and repeat motor data identification. The controller enable must be pending continuously until the end of the identification process.

Troubleshooting and fault elimination

9

System error messages

9.5

Resetting system error messages

9.5.2

Fault message		Description	Cause	Remedy
No.	Display			
0141	ID2	Error during motor data identification.	Motor too small.	<ul style="list-style-type: none"> Check entered motor data. For parameterisation with Global Drive Control, use the input assistant for motor data. The measurements for the inverter error characteristic and the stator resistance are correct (save measured values in C0003). For the operating mode V/f characteristic control the motor data identification can be completed.
			Controller inhibited externally.	Enable controller and repeat motor data identification. The controller enable must be pending continuously until the end of the identification process.
x200	Nmax	Maximum speed (C0596) has been exceeded.	<ul style="list-style-type: none"> Active load (e.g. for hoists) is too high Drive is not speed-controlled, torque is excessively limited. 	<ul style="list-style-type: none"> Check drive dimensioning. Possibly increase torque limit. Switch off monitoring (C0607 = 3).

Representation of the error number:

x 0 = TRIP, 1 = message, 2 = warning

E.g. "2091": An external monitoring function has triggered EEr warning

9.5.2 Resetting system error messages

Response	Measures for resetting the fault message	
TRIP	 Note! If a TRIP source is still active, the pending TRIP cannot be reset.	Resetting the TRIP can be effected by: <ul style="list-style-type: none"> Pressing the keypad XT EMZ9371 BC \Rightarrow STOP. Then press RUN to re-enable the controller. Setting code C0043 = 0. Control word C0135, bit 11 Control word AIF Control word of system bus (CAN) After resetting the TRIP, the drive remains at standstill.
Message	 Danger! After elimination of the fault, the fault message is cancelled automatically and the drive restarts automatically.	
Warning		After elimination of the fault, the fault message is cancelled automatically.

10 DC-bus operation**Contents**

10.1	Function	10.1-1
10.2	Conditions for trouble-free DC-bus operation	10.2-1
10.2.1	Possible combinations of Lenze controllers in a network of several drives	10.2-1
10.3	Mains chokes for DC-bus operation	10.3-1
10.4	Fuses and cable cross-sections	10.4-1
10.4.1	Mains supply	10.4-1
10.4.2	DC supply	10.4-2
10.5	Basic dimensioning	10.5-1
10.5.1	Conditions	10.5-1
10.5.2	Calculation of the additional DC supply input	10.5-1
10.5.3	Dimensioning examples	10.5-2
10.6	Distributed supply (several supply points)	10.6-1
10.7	Braking operation in the network	10.7-1

10.1**Function**

- ▶ DC-bus connections of drive systems enable the exchange of energy between connected controllers.
- ▶ If one or more controllers operate in generator mode (braking operation), the energy will be fed into the shared DC-voltage bus. The energy will then be available to the controllers which operate in motor mode.
- ▶ The use of brake units and supply units can be reduced.
- ▶ The energy consumption from the three-phase AC mains can be reduced.
- ▶ The number of mains supplies and the related expenses (e.g. wiring) can be perfectly adapted to your application.

DC-bus operation	10
Conditions for trouble-free DC-bus operation	10.2
Possible combinations of Lenze controllers in a network of several drives	10.2.1

10.2 Conditions for trouble-free DC-bus operation



Stop!

- ▶ Only connect controllers with the same ranges for mains voltage or DC-bus voltage.
- ▶ Adapt switching threshold of braking unit or brake transistor.
- ▶ Operate all input modules only with the mains choke specified (§ 10.3-1)!

10.2.1 Possible combinations of Lenze controllers in a network of several drives

- ▶ Use the controllers EVx9335 ... EVx9338 and EVx9381 ... EVx9383 in variants V210, V240, V270 and V300. They are suitable for DC-bus operation.



Note!

For the subject "DC-bus operation", read the documentations of the other devices used within the interconnection.

Controller	In DC-bus connection with	Important requirements
EVx9335 ... EVx9338 EVx9381 ... EVx9383	EVx9335 ... EVx9338 EVx9381 ... EVx9383	<ul style="list-style-type: none"> ● Only supply the controller in a decentralised manner. ● Only operate the controller with the mains choke assigned. ● Set the mains voltage or DC-bus voltage in C0173. ● Adapt the switching thresholds of the brake transistors in C0174.
	EVx9321 ... EVx9333 8200 8200 vector ECSxA004C4B ... ECSx064C4B	<ul style="list-style-type: none"> ● Only central supply via EVx9335 ... EVx9338 or EVx9381 ... EVx9383 permitted <ul style="list-style-type: none"> – A mains supply for EVx9321 ... EVx9333, 8200 and 8200 vector is not permitted. – If required, use additional 9360 DC power supply units for a sufficient DC power. ● Set the mains voltage or DC-bus voltage in C0173. <ul style="list-style-type: none"> – For EVx9335 ... EVx9338 and EVx9381 ... EVx9383 never set C0173 = 5. ● Adapt the switching thresholds of the brake transistors in C0174.
	9340	<ul style="list-style-type: none"> ● The use of 9340 regenerative power supply modules is not possible.

10.3 Mains chokes for DC-bus operation



Note!

In DC-bus operation mains chokes in front of every input module are a basic precondition for trouble-free operation.

Mains chokes specified for the input modules in DC-bus operation:

Controller		Mains choke		
Type	Rated mains current [A]	Rated current [A]	Inductance [mH]	Order No.
EVx9335	200	200	0.14	ELN3-0014H200
EVx9336	238	270	0.11	ELN3-0011H270
EVx9337	285	300	0.09	ELN3-0009H300
EVx9338	356	370	0.09	ELN3-0009H370
EVx9381	475	2 × 270	2 × 0.11	2 × ELN3-0011H270
EVx9382	570	2 × 300	2 × 0.09	2 × ELN3-0009H300
EVx9383	713	2 × 370	2 × 0.09	2 × ELN3-0009H370

DC-bus operation	10
Fuses and cable cross-sections	10.4
Mains supply	10.4.1

10.4 Fuses and cable cross-sections

10.4.1 Mains supply

For fusing the mains supply you can use the following fuses (gRL) and cable cross-sections:

9300 vector	Installation in accordance with EN 60204-1					
	Fuse	Cable cross-sections				
		[A]	L1, L2, L3 [mm ²]	PE [mm ²]		
EVF9335-EV EVF9335-EVVxxx	250		150 2 × 50 ¹⁾		95	
EVF9336-EV EVF9336-EVVxxx	315		150 2 × 50 ¹⁾		95	
EVF9337-EV EVF9337-EVVxxx	315		150 2 × 50 ¹⁾		95	
EVF9338-EV EVF9338-EVVxxx	400		240 2 × 95 ¹⁾		150	
	Master	Slave	Master	Slave	Master	Slave
EVF9381-EV EVF9381-EVVxxx	315	315	150 2 × 50 ¹⁾	150 2 × 50 ¹⁾	95	95
EVF9382-EV EVF9382-EVVxxx	315	315	150 2 × 50 ¹⁾	150 2 × 50 ¹⁾	95	95
EVF9383-EV EVF9383-EVVxxx	400	400	240 2 × 95 ¹⁾	240 2 × 95 ¹⁾	150	150

¹⁾ Multiple conductor; both conductors must have the same cross-section



Note!

We recommend to use semiconductor fuses (gRL).

10.4.2 DC supply

A DC supply is only possible for the variants V210, V240, V270, V300.



Stop!

- Only use semiconductor fuses (gRL).
- On principle, fuse DC cables as 2-pole ($+U_G$, $-U_G$).

9300 vector	Installation in accordance with EN 60204-1					
	Type	Fuse		Cable cross-sections		
		[A]		$+U_G$, $-U_G$ [mm 2]		PE [mm 2]
EVF9335-EVV2xx EVF9335-EVV300		315		150 2 x 50 1)		95
EVF9336-EVV2xx EVF9336-EVV300		350		150 2 x 50 1)		95
EVF9337-EVV2xx EVF9337-EVV300		400		240 2 x 95 1)		95
EVF9338-EVV2xx EVF9338-EVV300		500		240 2 x 95 1)		150
	Master	Slave	Master	Slave	Master	Slave
EVF9381-EVV2xx EVF9381-EVV300	350	350	150 2 x 50 1)	150 2 x 50 1)	95	95
EVF9382-EVV2xx EVF9382-EVV300	400	400	240 2 x 95 1)	240 2 x 95 1)	95	95
EVF9383-EVV2xx EVF9383-EVV300	500	500	240 2 x 95 1)	240 2 x 95 1)	150	150

1) Multiple conductor; both conductors must have the same cross-section

DC-bus operation	10
Basic dimensioning	10.5
Conditions	10.5.1

10.5 Basic dimensioning

10.5.1 Conditions

The input powers specified in the tables are only valid if the following requirements for DC-bus operation are observed:

- ▶ Central supply only via EVx9335 ... EVx9338, EVx9381 ... EVx9383, or 9360 DC power supply unit.
- ▶ Connection to the three-phase system only via mains chokes specified.

10.5.2 Calculation of the additional DC supply input

EVx9321 ... EVx9333,
8200 vector

Required DC power depending on the rated motor power:

P _V [kW]	P _{DC} [kW]	P _V [kW]	P _{DC} [kW]
0.37	0.7	15	18
0.55	0.9	18.5	21
0.75	1.1	22	25
1.1	1.6	30	33
1.5	2.1	37	41
2.2	3.1	45	50
3.0	4.1	55	61
4.0	5.0	75	82
5.5	6.7	90	98
7.5	9.0	110	120
11	12.5		

P_V Rated motor power

If the rated power of the motor used is settled between two values, the higher value is to be adopted

P_{DC} DC power required

ECSxAxxxC4B axis modules

Required DC power relating to the maximum current of the ECS axis modules:

Type	P _{DC} [kW]	Type	P _{DC} [kW]
ECSxA004C4B	1.5	ECSxA032C4B	12
ECSxA008C4B	3.0	ECSxA048C4B	18
ECSxA016C4B	6.0	ECSxA064C4B	24

P_{DC} DC power required

How to calculate the input power required:

1. If devices EVx9321 ... EVx9333 or 8200 vector are used in the drive system:
 Look for the rated powers of the connected motors in the table and write down the corresponding powers P_{DC} .
2. If devices ECSxAxxxC4B are used in the drive system:
 Look for the connected axis modules in the table and write down the corresponding powers P_{DC} .
3. If required, determine the power P_{DC} additionally available for the devices EVx9335 ... EVx9338, EVx9381 ... EVx9383 in the drive system by means of a rough estimate:
 Device power – rated power of the motor connected
4. Add all powers P_{DC} from steps 1. and 2. and subtract the power P_{DC} that is additionally available.
 – The result is the input power required.
5. Select the 9360 DC power supply units to provide the input power.

10.5.3 Dimensioning examples

Drive data			Determined power P_{DC}	
Controller		Motor		
Drive	Type	Power		
Drive 1	E82EV113K4C	11 kW	12.5 kW	from table
Drive 2	E82EV453K4B	37 kW	41 kW	
Drive 3	EVS9332	75 kW	82 kW	
Drive 4	ECSxA048C4B		18 kW	
Drive 5 (input module)	EVV9336 (132 kW)	110 kW	-22 kW	rough estimate

1. Determine the required DC power:

$$P_{DC} = 12.5 \text{ kW} + 41 \text{ kW} + 82 \text{ kW} + 18 \text{ kW} - 22 \text{ kW} = 131.5 \text{ kW}$$

2. Determine the required 9360 DC power supply units:

If 1×9364 (50 kW) and 1×9365 (100 kW) are used, a sufficient DC power is provided with 150 kW.

10.6 Distributed supply (several supply points)

Block diagram




Fig. 10.6-1 Controller with decentralised supply in the drive system

- F1...F6 Mains fuses (§ 10.4-1)
- F7 ... F14 Fuses on DC level (§ 10.4-2)
- Z1 Mains choke (§ 10.3-1)
- Z2 Mains choke for 9360 DC power supply units
9364: ELN3-0038H085
9365: ELN3-0017H170
- Z3 DC choke
9364: 0.75 mH, 90 A
9365: 2 × 0.75 mH, 90 A (switched parallel)
- K10 Mains contactor
- S1 Mains "ON"
- S2 Mains "OFF"

10.7 Braking operation in the network

- ▶ Controllers EVx9335 ... EVx9383 in variants V270 and V300 are equipped with an integrated brake transistor.
- ▶ Controllers EVx9381 ... EVx9383 in variants V270 and V300 consist of a master and a slave. Both master and slave contain one brake transistor, respectively. The braking energy is normally dissipated in equal shares via master and slave.
- ▶ In the DC-bus connection you have to set the switching thresholds of the brake transistors for all controllers of variants V270 and V300 to the same value (C0174).
- ▶ When the braking energy is low (e. g. operation in generator mode), you can also use 9352 brake choppers. A simultaneous braking operation with a 9352 brake chopper and an integrated brake resistor is not possible due to the different switching thresholds.

11 Safety engineering

Contents

11.1	Important notes	11.1-1
11.2	Method of functioning	11.2-1
11.3	Safety relay KSR	11.3-1
11.4	Functional test	11.4-1
11.4.1	Important notes	11.4-1
11.4.2	Manual safety function check	11.4-2
11.4.3	Monitoring the safety function with a PLC	11.4-3

11.1

Important notes



Stop!

In the case of the devices EVF9335 ... EVF9383 of variants V060, V110, V270, and V300, the integrated brake transistor is deactivated if the "Safe torque off" function is active.

The controllers support the safety functions "Safe torque off" (former designation "Safe standstill"), "Protection against unexpected start-up", in accordance with the requirements of control category 3 of ISO 13849-1 (former EN 954-1). Depending on the external interconnection, a standard up to "category 3" in accordance with ISO 13849-1 is achieved.



Note!

In order to comply with control category 3 in accordance with ISO 13849-1 (former EN 954-1), the two methods "Pulse inhibit via safety relay K_{SR}" **and** "Controller inhibit", which are independent of each other, have to be used.

- ▶ Only qualified personnel may install and commission the "Safe torque off" function.
- ▶ All control components (switches, relays, PLC, ...) and the control cabinet have to comply with the requirements of ISO 13849-1 (former EN 954-1) and ISO 13849-2. These include:
 - Control cabinet, switches, relays in enclosure IP54!
 - Gather all further requirements from ISO 13849-1 and ISO 13849-2!
- ▶ The wiring with insulated wire end ferrules or rigid cables is absolutely required.
- ▶ Be absolutely sure to install all safety-relevant cables (e. g. control cable for the safety relay, feedback contact) outside of the control cabinet in a protected manner, e. g. within the cable duct. In doing this, ensure that short circuits between the individual cables cannot occur!
- ▶ With the "Safe torque off" function no emergency stop can be effected without additional measures:
 - Between the motor and controller there is not isolation, no service switch, or maintenance switch!
 - For an emergency stop, the isolation of the cable path to the motor is required, e. g. by a central mains contactor with an emergency stop wiring.
- ▶ If in the case of the "Safe torque off" a force effect is to be expected from outside, (e. g. sagging of hanging loads), additional measures are required (e. g. mechanical brakes).

- After the installation the operator has to check the function of the "Safe torque off" circuit.
 - The functional test has to be repeated at regular intervals.
 - Basically the time intervals to be selected depend on the application and the corresponding risk analysis and the system as a whole (inspection interval). The inspection intervals should not exceed 1 year.

11.2 Method of functioning




Fig. 11.2-1 Internal connection of the "Safe torque off" function with 3 electrically isolated circuits

- Area ①: Pulse inhibit via safety relay K_{SR} ; forcibly guided feedback for monitoring the safety relay
- Area ②: Controller inhibit (X5/28), optional feedback via a digital output (DIGOUT)
- Area ③: Power output stage

Activating "Safe torque off"

The "Safe torque off" status is activated via two different disconnecting paths which are independent of each other:

1. disconnecting path: Pulse inhibit via safety relay K_{SR} (terminal X11/33, X11/34)

- ▶ In the case of LOW level at terminals X11/33, X11/34, the safety relay K_{SR} is deactivated. The driver supply of the power section drivers is interrupted. The inverter no longer receives pulses.
- ▶ The disconnection of the safety relay K_{SR} has to be monitored externally, so that a failure of this disconnecting path can be detected. X11/K31, X11/K32 is a forcibly guided break contact, i. e. if the safety relay K_{SR} has been deactivated ("Safe torque off" activated), the contact is closed.

2. disconnecting path: Controller inhibit by input signal at terminal X5/28

- ▶ The input signal at X5/28 is fed to the microcontroller system and the PWM unit. In the case of LOW level at terminal X5/28, the output of pulses to the inverter is inhibited in the microcontroller system.
- ▶ The disconnecting path "Controller inhibit" can be evaluated optionally via a digital output. Further information can be gathered from the chapter "Functional test" (□ 11.4-1).

"Safe torque off" is activated if **both disconnecting paths are on LOW level**.

Deactivating "Safe torque off"

An AND operation of the disconnecting paths prevents the drive from restarting if only one disconnecting path is enabled.

"Safe torque off" is deactivated if **both disconnecting paths are on HIGH level**.

11.3 Safety relay K_{SR}

Technical data

Terminal	Description	Field	Values
X11/K32	Safety relay K _{SR} 1st disconnecting path	Coil voltage at +20 °C	DC 24 V (20 ... 30 V)
X11/K31		Coil resistance at +20 °C	823 Ω ±10 %
X11/33		Rated coil power	Approx. 700 mW
X11/34		Max. switching voltage	AC 250 V, DC 250 V (0.45 A)
		Max. AC switching capacity	1500 VA
		Max. switching current (ohmic load)	AC 6 A (250 V), DC 6 A (50 V)
		Recommended minimum load	> 50 mW
		Max. switching rate	6 switchings per minute
		Mechanical service life	10 ⁷ switching cycles
		Electrical service life at 250 V AC (ohmic load)	10 ⁵ switching cycles at 6 A 10 ⁶ switching cycles at 1 A 10 ⁷ switching cycles at 0.25 A
		at 24 V DC (ohmic load)	6 × 10 ³ switching cycles at 6 A 10 ⁶ switching cycles at 3 A 1.5 × 10 ⁶ switching cycles at 1 A 10 ⁷ switching cycles at 0.1 A

Terminal data

Regulation for wiring of the terminals X11/34, X11/33, X11/K32, X11/K31, X5/28:

Cable type	Wire end ferrule	Cable cross-section	Tightening torque	Stripping length
 Rigid	–	2.5 mm ² (AWG 14)	0.5 ... 0.6 Nm (4.4 ... 5.3 lb-in)	5 mm
 Flexible	With plastic sleeve	2.5 mm ² (AWG 14)		

Wiring

**Danger!****Faulty operation in case of earth faults possible**


The correct functioning of the safety function is not ensured if an earth fault occurs.

Possible consequences:

- A failure of the safety function can lead to death, severe injuries or damage to material.

Protective measures:

The electrical reference point for the coil of the safety relay K_{SR} must be connected to the PE conductor system (EN 60204-1, paragraph 9.4.3)!

Fig. 11.3-1 Safety relay K_{SR}

Terminal	Function Bold print = Lenze setting	Level / state	Electrical data
X11/K32 X11/K31	Safety relay K _{SR} 1st disconnecting path	Feedback - pulse inhibit	Open contact: Pulse inhibit is inactive (operation) Closed contact: Pulse inhibit is active
X11/33		- coil of safety relay K _{SR}	Coil is not carrying any current: pulse inhibit is active
X11/34		+ coil of safety relay K _{SR}	Coil is carrying current: pulse inhibit is inactive (operation)
X5/28	Controller inhibit (DCTRL-CINH) 2nd disconnecting path	Controller enable/inhibit	LOW: Controller inhibited HIGH: Controller enabled LOW: 0 ... +3 V HIGH: +12 ... +30 V Input current at +24 V: 8 mA Reading and processing the input signals - 1/ms (mean value)

11.4 Functional test

11.4.1 Important notes



Danger!

Unexpected start-up of the machine possible

The "Safe torque off" safety function provides protection against an unexpected start-up of the drive and therefore is an important item within the safety concept for a machine. It has to be ensured that this function works correctly.

Possible consequences:

- ▶ Death, severe injury, or damage to material assets, when the safety function fails.

Protective measures:

After the installation and at regular intervals, the operator has to check the function of the "Safe torque off" circuit.

- ▶ When doing this, check both disconnecting paths separately with regard to their disconnection capability.
- ▶ The functional test can be carried out manually or automatically via the PLC.
- ▶ Basically the inspection interval depends on the application and the corresponding risk analysis, as well as on the system as a whole. It should not exceed 1 year.
- ▶ If the functional test shows impermissible states,
 - the drive or the machine has to be shut down immediately.
 - commissioning is not permitted until the safety function operates correctly.

11.4.2 Manual safety function check

For the functional test, check both disconnecting paths **separately**.

1. disconnecting path: Pulse inhibit via safety relay K_{SR}

How to proceed during the test:

1. Alternately apply LOW and HIGH level to input X11/34 and check the states given in the table below.

Individual test	Specification		Correct status
	Input relay activation (X11/34)	Output feedback (X11/K31)	
Pulse inhibit	LOW	HIGH	
Pulse enable	HIGH	LOW	

The individual tests are passed if the correct states given in the table result.

2. disconnecting path: Controller inhibit

Requirement for the test:

- "Quickstop" (QSP) function deactivated
- "Automatic DC injection brake" deactivated (C0019 = 0)
- Pulses enabled by the safety relay K_{SR} (X11/34 = HIGH)

How to proceed during the test:

1. Set controller inhibit (X5/28 = LOW).
2. Define a setpoint $n_{set} > 0$.
3. Check that the motor is not rotating.

The individual test is passed if the motor does not rotate.

Functional test not passed

If an individual test results in an impermissible status, the functional test is not passed.

- The drive or machine has to be shut down immediately.
- Commissioning is not permitted until the safety function operates correctly.

11.4.3 Monitoring the safety function with a PLC




Fig. 11.4-1 Circuit diagram for monitoring the safety function with a PLC

S1, S2	Separate disconnection options of the two disconnecting paths
K _{SR}	Safety relay
X11/34	Safety relay control
X11/33	Safety relay control (GND)
X11/K32	Forcibly guided feedback contact (24 V)
X11/K31	Forcibly guided feedback contact
DIGOUT	Digital output for evaluating the motor current
X5/28	Controller inhibit
Z1	Programmable logic controller (PLC)
IN 1 - 4	Digital inputs

Requirements

The following conditions must be met:

- ▶ The PLC must be programmed such that the complete system is set to a safe state immediately when the function check leads to an impermissible state.
- ▶ The parameter setting of a digital output must be such that you can conclude to the output current I_{motor} of the drive (see parameterisation example).

11 Safety engineering

11.4

Functional test

11.4.3

Monitoring the safety function with a PLC

Example: Parameterising a digital output

In the following we will show you a possibility of parameterising a digital output, so that a conclusion with regard to the motor current is provided.

Sequence	Parameter	Note
1. Configure function block CMP3 (comparator)		
<ul style="list-style-type: none">● Connect CMP3-IN1 to MCTRL-IACT● Connect CMP3-IN2 to FCODE-472/1● Configure the function IN1 < IN2	C0693/1 = 5004 C0693/2 = 19521 C0690 = 3	
2. Configure output signal of CMP3	C0117/4 = 10660	
<ul style="list-style-type: none">● Connect DIGOUT4 to CMP3-OUT		
3. Enter function block CMP3 in the processing table		
<ul style="list-style-type: none">● Select a free space in the processing table In the Lenze setting, for instance space 2 of the processing table is free	C0465/2 = 10660	
4. Set the current threshold	C0472/1 = 2.00	$I_{Motor} = 0 \rightarrow DIGOUT4 = HIGH$
<ul style="list-style-type: none">● Set the current threshold for I_{rated_Fl} to 2 %		$I_{Motor} \neq 0 \rightarrow DIGOUT4 = LOW$

Functional test within the inspection interval

For the functional test, check both disconnecting paths **separately**.

1. disconnecting path: Pulse inhibit via safety relay K_{SR}

The individual tests are passed if the correct states given in the table result.

Individual test	Specification		Correct status
	Input relay activation (X11/34)	Output feedback (X11/K31)	
Pulse inhibit	LOW		HIGH
Pulse enable	HIGH		LOW

2. disconnecting path: Controller inhibit

Requirement for the test:

- ▶ "Quickstop" (QSP) function deactivated
- ▶ "Automatic DC injection brake" deactivated (C0019 = 0)
- ▶ Pulses enabled by the safety relay K_{SR} (X11/34 = HIGH)

The individual tests are passed if the correct states given in the table result.

Individual test	Specification		Correct status
	X5/28	Setpoint	Output DIGOUT
Controller inhibit	LOW	n _{set} > 0	HIGH
Controller enable	HIGH		LOW

Functional test not passed

If an individual test results in an impermissible status, the functional test is not passed.

- ▶ The drive or machine has to be shut down immediately.
- ▶ Commissioning is not permitted until the safety function operates correctly.

12 Braking operation

Contents

12.1	Brake operation with external brake resistor	12.1-1
12.1.1	Selection of the brake resistors	12.1-1
12.2	Lenze brake resistors	12.2-1
12.2.1	Rated data	12.2-1
12.2.2	Dimensions	12.2-2
12.2.3	Selection	12.2-2
12.2.4	Connection of external brake resistor	12.2-3
12.3	Rated data of the integrated brake transistor	12.3-1
12.4	Braking operation in the network	12.4-1
12.4.1	Selection	12.4-2

Braking operation	12
Brake operation with external brake resistor	12.1
Selection of the brake resistors	12.1.1

12.1 Brake operation with external brake resistor

Larger moments of inertia or longer generator-mode operation require an external brake resistor. It converts mechanical brake energy into heat.

The brake transistor integrated into the controller switches the external brake resistor in addition when the DC-bus voltage exceeds a threshold. It can thus be avoided that the controller sets pulse inhibit in the event of an "overvoltage" and forces the drive to coast to standstill. External brake resistors ensure braking operation at any time.

12.1.1 Selection of the brake resistors

The suitable brake resistor must meet the following criteria:

Brake resistor	Application	
	with active load	with passive load
Continuous braking power [W]	$\geq P_{\max} \cdot \eta_e \cdot \eta_m \cdot \frac{t_1}{t_{zykl}}$	$\geq \frac{P_{\max} \cdot \eta_e \cdot \eta_m}{2} \cdot \frac{t_1}{t_{zykl}}$
Thermal capacity [Ws]	$\geq P_{\max} \cdot \eta_e \cdot \eta_m \cdot t_1$	$\geq \frac{P_{\max} \cdot \eta_e \cdot \eta_m}{2} \cdot t_1$
Resistance [Ω]	$R_{\min} \leq R \leq \frac{U_{DC}^2}{P_{\max} \cdot \eta_e \cdot \eta_m}$	

Field	Description
Active load	Can move without being influenced by the controller (e.g. unwinders)
Passive load	Decelerates to standstill without influence of the controller (e.g. horizontal traversing drives, centrifuges, fans)
V_{DC} [V]	Threshold for brake transistor
P_{\max} [W]	Max. brake power determined by the application IMPORTANT: With EVF9381-EV, EVF9382-EV, EVF9383-EV only calculate with $P_{\max}/2$ since these devices dissipate the brake energy evenly via master and slave. If the brake power is lower, the brake energy can also be dissipated via the master or the slave; use P_{\max} for the calculation.
η_e	Electrical efficiency (controller + motor) Guide value: 0.94
η_m	Mechanical efficiency (gearbox, machine)
t_1 [s]	Braking time
t_{cycl} [s]	Cycle time = time between two braking processes (= $t_1 + \text{break}$)
R_{\min} [Ω]	Lowest permissible brake resistance (see rated data for the integrated brake transistor)

Braking operation	12
Lenze brake resistors	12.2
Rated data	12.2.1

12.2 Lenze brake resistors

12.2.1 Rated data

Field	Data
Resistance R	15 Ω
Continuous power ¹⁾	4.0 kW
Thermal capacity	600.0 kWs
Switch-on cycle	Braking for max. 19/15/14/11 s, then at least 131/135/136/139 s break ²⁾
Cable cross-section to be connected	6 mm ² AWG 10
Mass	12.5 kg
Order No.	ERBD015R04K0

Observe the national and regional legislation

- 1) The continuous power is a reference value for the selection of brake resistors. Braking at peak brake power (V_{DC}^2/R).
- 2) More information on the switching threshold V_{DC} (685 V, 755 V, 785 V, 885 V) of the brake transistor can be found in chapter 12.1



Note!

As standard the brake resistor is equipped with a temperature switch (NC contact max. AC 250 V, 0.5 A).

12

Braking operation

12.2

Lenze brake resistors

12.2.2

Dimensions

12.2.2 Dimensions




Fig. 12.2-1 Dimensions of the ERBD015R04K0 brake resistor

Type	a	a1	a2	a3	a4	b	b1	c	c1	c2	c3	e	e1
ERBD015R04K0	273	266	240	152	64	233	229	640	550	526	66.5	51	53

All values in [mm]

12.2.3 Selection



Stop!

The value must not fall below the lowest permissible resistance.

Connect several brake resistors of type ERBD015R04K0 in parallel to get the brake resistance that matches your application.

The number of resistors to be connected in parallel is calculated with $1/4 \times$ of the required continuous power (round the result).

Braking operation	12
Lenze brake resistors	12.2
Connection of external brake resistor	12.2.4

12.2.4 Connection of external brake resistor




Fig. 12.2-2 Brake resistor connection

RB1, RB2 Controller terminals for connecting the brake resistor

Z1 Brake resistor

PES HF-shield end by PE connection through shield bracket.

Important notes

- ▶ Brake resistors can get hot and under certain conditions a brake resistor can even burn down. For this reason, the brake resistors must be mounted so that the possibly high temperatures cannot cause any damage.
- ▶ Provide a safety shutdown in the event the brake resistor overheats.
- ▶ Use the thermal contacts of the brake resistor (e.g. T1 / T2) as control contacts to disconnect the controller from the cable! <U Info: Graphikrahmen Beginn>
- ▶ Only use shielded brake resistor cables.
- ▶ Connect the shield close to the controller and close to the brake resistor with a surface as large as possible to the mounting plate by using a shield clamp.
- ▶ The shield of the control cables for digital signals (temperature monitoring T1 / T2) must be connected at both sides (controller and brake resistor).
- ▶ Unshielded cables between shield clamp and connection terminals must not be longer than 40 mm.

12.3 Rated data of the integrated brake transistor

Rated data for types EVF93xx-EVV060 and EVF93xx-EVV110 at 400 V rated mains voltage

Brake transistor		9300 vector			
		EVF9335-EVV060 EVF9335-EVV110	EVF9336-EVV060 EVF9336-EVV110	EVF9337-EVV060 EVF9337-EVV110	EVF9338-EVV060 EVF9338-EVV110
Threshold V_{DC}	[V DC]	685			
Peak brake current	[A DC]	315	375	450	560
Max. continuous current	[A DC]	210	250	300	375
Lowest permissible brake resistance ¹⁾	[Ω]	2.2	1.8	1.5	1.2
Current derating		Derate the peak brake current by 2.5 %/ $^{\circ}C$ above 40 $^{\circ}C$ Derate the peak brake current by 5 %/1000 m above 1000 m a.m.s.l.			
Switch-on cycle ³⁾		max. 60 s braking at peak brake power, followed by min. 30 s break			

Brake transistor		9300 vector		
		EVF9381-EVV060 ²⁾ EVF9381-EVV110 ²⁾	EVF9382-EVV060 ²⁾ EVF9382-EVV110 ²⁾	EVF9383-EVV060 ²⁾ EVF9383-EVV110 ²⁾
Threshold V_{DC}	[V DC]	685		
Peak brake current	[A DC]	2 × 375	2 × 450	2 × 560
Max. continuous current	[A DC]	2 × 250	2 × 300	2 × 375
Lowest permissible brake resistance ¹⁾	[Ω]	1.8	1.5	1.2
Current derating		Derate the peak brake current by 2.5 %/ $^{\circ}C$ above 40 $^{\circ}C$ Derate the peak brake current by 5 %/1000 m above 1000 m a.m.s.l.		
Switch-on cycle ³⁾		max. 60 s braking at peak brake power, followed by min. 30 s break		

- ¹⁾ Please consider the cable resistance if you use longer connection cables. The cable resistance must be added to the brake resistance and has therefore a considerable influence on the total resistance.
- ²⁾ Device consists of master and slave connected in parallel. Usually, the brake energy is dissipated evenly via master and slave.
- ³⁾ Please see the switch-on cycle of the brake resistor used.

Rated data for types EVF93xx-EVV270 and EVF93xx-EVV300 at 400 V or 460 V rated mains voltage

Brake transistor		9300 vector			
		EVF9335-EVV270 EVF9335-EVV300	EVF9336-EVV270 EVF9336-EVV300	EVF9337-EVV270 EVF9337-EVV300	EVF9338-EVV270 EVF9338-EVV300
Threshold V _{DC}	[V DC]	755			
Peak brake current	[A DC]	315	375	450	560
Max. continuous current	[A DC]	210	250	300	375
Lowest permissible brake resistance ¹⁾	[Ω]	2.5	2.1	1.8	1.4
Current derating		Derate the peak brake current by 2.5 %/°C above 40 °C Derate the peak brake current by 5 %/1000 m above 1000 m a.m.s.l.			
Switch-on cycle ³⁾		max. 60 s braking at peak brake power, followed by min. 30 s break			

Brake transistor		9300 vector		
		EVF9381-EVV270 ²⁾ EVF9381-EVV300 ²⁾	EVF9382-EVV270 ²⁾ EVF9382-EVV300 ²⁾	EVF9383-EVV270 ²⁾ EVF9383-EVV300 ²⁾
Threshold V _{DC}	[V DC]	755		
Peak brake current	[A DC]	2 × 375	2 × 450	2 × 560
Max. continuous current	[A DC]	2 × 250	2 × 300	2 × 375
Lowest permissible brake resistance ¹⁾	[Ω]	2.1	1.8	1.4
Current derating		Derate the peak brake current by 2.5 %/°C above 40 °C Derate the peak brake current by 5 %/1000 m above 1000 m a.m.s.l.		
Switch-on cycle ³⁾		max. 60 s braking at peak brake power, followed by min. 30 s break		

- 1) Please consider the cable resistance if you use longer connection cables. The cable resistance must be added to the brake resistance and has therefore a considerable influence on the total resistance.
- 2) Device consists of master and slave connected in parallel. Usually, the brake energy is dissipated evenly via master and slave.
- 3) Please see the switch-on cycle of the brake resistor used.

Rated data for types EVF93xx-EVV270 and EVF93xx-EVV300 at 480 V rated mains voltage

Brake transistor		9300 vector			
		EVF9335-EVV270 EVF9335-EVV300	EVF9336-EVV270 EVF9336-EVV300	EVF9337-EVV270 EVF9337-EVV300	EVF9338-EVV270 EVF9338-EVV300
Threshold V _{DC}	[V DC]	785			
Peak brake current	[A DC]	315	375	450	560
Max. continuous current	[A DC]	210	250	300	375
Lowest permissible brake resistance ¹⁾	[Ω]	2.5	2.1	1.8	1.4
Current derating		Derate the peak brake current by 2.5 %/°C above 40 °C Derate the peak brake current by 5 %/1000 m above 1000 m a.m.s.l.			
Switch-on cycle ³⁾		max. 60 s braking at peak brake power, followed by min. 30 s break			

Brake transistor		9300 vector		
		EVF9381-EVV270 ²⁾ EVF9381-EVV300 ²⁾	EVF9382-EVV270 ²⁾ EVF9382-EVV300 ²⁾	EVF9383-EVV270 ²⁾ EVF9383-EVV300 ²⁾
Threshold V _{DC}	[V DC]	785		
Peak brake current	[A DC]	2 × 375	2 × 450	2 × 560
Max. continuous current	[A DC]	2 × 250	2 × 300	2 × 375
Lowest permissible brake resistance ¹⁾	[Ω]	2.1	1.8	1.4
Current derating		Derate the peak brake current by 2.5 %/°C above 40 °C Derate the peak brake current by 5 %/1000 m above 1000 m a.m.s.l.		
Switch-on cycle ³⁾		max. 60 s braking at peak brake power, followed by min. 30 s break		

- ¹⁾ Please consider the cable resistance if you use longer connection cables. The cable resistance must be added to the brake resistance and has therefore a considerable influence on the total resistance.
- ²⁾ Device consists of master and slave connected in parallel. Usually, the brake energy is dissipated evenly via master and slave.
- ³⁾ Please see the switch-on cycle of the brake resistor used.

Rated data for types EVF93xx-EVV270 and EVF93xx-EVV300 at 500 V rated mains voltage

Brake transistor		9300 vector			
		EVF9335-EVV270 EVF9335-EVV300	EVF9336-EVV270 EVF9336-EVV300	EVF9337-EVV270 EVF9337-EVV300	EVF9338-EVV270 EVF9338-EVV300
Threshold V _{DC}	[V DC]	885			
Peak brake current	[A DC]	315	375	450	560
Max. continuous current	[A DC]	210	250	300	375
Lowest permissible brake resistance ¹⁾	[Ω]	2.8	2.3	1.9	1.6
Current derating		Derate the peak brake current by 2.5 %/°C above 40 °C Derate the peak brake current by 5 %/1000 m above 1000 m a.m.s.l.			
Switch-on cycle ³⁾		max. 60 s braking at peak brake power, followed by min. 30 s break			

Brake transistor		9300 vector		
		EVF9381-EVV270 ²⁾ EVF9381-EVV300 ²⁾	EVF9382-EVV270 ²⁾ EVF9382-EVV300 ²⁾	EVF9383-EVV270 ²⁾ EVF9383-EVV300 ²⁾
Threshold V _{DC}	[V DC]	885		
Peak brake current	[A DC]	2 × 375	2 × 450	2 × 560
Max. continuous current	[A DC]	2 × 250	2 × 300	2 × 375
Lowest permissible brake resistance ¹⁾	[Ω]	2.3	1.9	1.6
Current derating		Derate the peak brake current by 2.5 %/°C above 40 °C Derate the peak brake current by 5 %/1000 m above 1000 m a.m.s.l.		
Switch-on cycle ³⁾		max. 60 s braking at peak brake power, followed by min. 30 s break		

- 1) Please consider the cable resistance if you use longer connection cables. The cable resistance must be added to the brake resistance and has therefore a considerable influence on the total resistance.
- 2) Device consists of master and slave connected in parallel. Usually, the brake energy is dissipated evenly via master and slave.
- 3) Please see the switch-on cycle of the brake resistor used.

12.4 Braking operation in the network

Basic circuit diagram




Fig. 12.4-1 Controller with decentralised supply in DC-bus operation and with brake resistor

F1...F6	Mains fuses (§ 3.7-1)
F7 ... F14	Fuses on DC level (§ 3.7-2)
Z1, Z2	Mains choke (§ 10.3-1)
Z3	Brake resistor
K10	Mains contactor
S1	Mains "ON"
S2	Mains "OFF"

12

Braking operation

12.4

Braking operation in the network

12.4.1

Selection

12.4.1 Selection



Stop!

- ▶ Set the DC-bus voltage thresholds of the controllers to the same value under C0173.
- ▶ Set the brake transistor thresholds for the controllers under C0174.

Code		Possible settings			IMPORTANT	
No.	Name	Lenze	Selection			
C0173 	UG limit	1			<p>Check during commissioning and adapt, if necessary! All controllers in the system must have the same threshold!</p> <ul style="list-style-type: none"> ● Adaptation of UG thresholds ● Only display in case of the variants for 400 V mains (EVF93xx-EV, EVF93xx-EVV030, EVF93xx-EVV060, EVF93xx-EVV110): <ul style="list-style-type: none"> – C0173 = 1 – OU = 700 ... 685 V 	12-1 See System Manual (extension)
			Mains LU OU			
		0	< 400 V 285 V 770 ... 755 V		Device with or without brake transistor	
		1	400 V 285 V 770 ... 755 V			
		2	460 V 328 V 770 ... 755 V			
		3	480 V 342 V 770 ... 755 V		Device without brake transistor	
		4	480 V 342 V 800 ... 785 V		Device with brake transistor	
		5	500 V 342 V 900 ... 885 V			
C0174	BR Limit	3			<p>Display of the brake transistor thresholds Check during commissioning and adapt, if necessary! All controllers connected to the bus must have the same threshold!</p>	12-1 See System Manual (extension)
			Mains U_{BR} OU			
		0	400 V 685 V 700 V		Only display in case of the variants for 400 V mains (EVF93xx-EV, EVF93xx-EVV030, EVF93xx-EVV060, EVF93xx-EVV110)	
		1	400 V / 460 V 755 V 770 V		Only in case of the variants for 400 V/500 V mains (EVF93xx-EVV210, EVF93xx-EVV240, EVF93xx-EVV270, EVF93xx-EVV300)	
		2	480 V 785 V 800 V			
		3	500 V 885 V 900 V			

Important notes

- Provide a safety switch-off in the event of overheating if you use a brake resistor. Use the temperature switches of the brake resistor to
- ▶ disconnect all controllers from the mains.
 - ▶ set controller inhibit in all controllers (terminal X528 = LOW).

13 Accessories (overview)**Contents**

13.1 General accessories	13.1-1
13.2 Type-specific accessories	13.2-1

13.1 General accessories

Accessories	Designation	Order number
Communication modules	LECOM-LI (optical fibre)	EMF2102IBCV003
	LECOM-B (RS485)	EMF2102IBCV002
	LECOM-A/B (RS232/485)	EMF2102IBCV001
	LON	EMF2141IB
	INTERBUS	EMF2113IB
	INTERBUS-Loop	EMF2112IB
	PROFIBUS-DP	EMF2133IB
	DeviceNet/CANopen	EMF2175IB
	Operating module keypad XT	EMZ9371BC
	Diagnosis terminal (keypad XT in handheld design, IP20) ¹⁾	E82ZBBXC
Other	Connecting cable	2.5 m 5 m 10 m
	Parameterisation/operating software »Global Drive Control« (GDC)	ESP-GDC2
	PC system bus adapter (Voltage supply via DIN connection)	EMF2173IB
	PC system bus adapter (Voltage supply via PS2 connection)	EMF2173IB-V002
	PC system bus adapter (Voltage supply via PS2 connection, electrical isolation)	EMF2173IB-V003
	PC system bus adapter USB	EMF2177IB
	CAN repeater	EMF2176IB
	PC system cable RS232	5 m 10 m
	Optical fibre adapter (standard output power)	EMF2125IB
	Optical fibre adapter (increased output power)	EMF2126IB
	Power supply unit for optical fibre adapter	EJ0013
	Optical fibre, single-core, black PE sheath (basic protection), sold by the meter	EWZ0007
	Optical fibre, single-core, red PUR sheath (reinforced protection), sold by the meter	EWZ0006
	Setpoint potentiometer	ERPD0010k0001W
	Rotary knob for setpoint potentiometer	ERZ0001
	Scale for setpoint potentiometer	ERZ0002
	Digital display	EPD203
	Encoder cable	2.5 m 5.0 m 10.0 m 15.0 m 20.0 m 25.0 m 30.0 m 35.0 m 40.0 m 45.0 m 50.0 m
	Connecting cable for digital frequency coupling	2.5 m EWLD002GGBS93

¹⁾ Additional connecting cable required

**Tip!**

Current documentation and software updates concerning Lenze products can be found on the Internet in the "Services & Downloads" area under

<http://www.Lenze.com>

13.2 Type-specific accessories

Accessories	9300 vector			
	EVF9335	EVF9336	EVF9337	EVF9338
Motor choke	ELM3-003H275	ELM3-003H275	ELM3-002H320	ELM3-002H410
Air lock	E93ZWL			
Brake resistor	ERBD015R04K0			

Accessories	9300 vector		
	EVF9381	EVF9382	EVF9383
Motor choke	2 × ELM3-003H275	2 × ELM3-002H320	2 × ELM3-002H410
Air lock	E93ZWL2		
Brake resistor	ERBD015R04K0		

14 Appendix

Contents

14.1 Glossary	14.1-1
14.1.1 Terminology and abbreviations used	14.1-1
14.2 Index	14.2-1

Appendix	14
Glossary	14.1
Terminology and abbreviations used	14.1.1

14.1 Glossary

14.1.1 Terminology and abbreviations used

	Cross-reference to a chapter and the corresponding page number
AC	Alternating current or alternating voltage
AIF	Automation interface AIF interface, interface for communication modules
CE	Communauté Européenne (European Community)
Controller	Any frequency inverter, servo inverter or DC speed controller
Cxxxx/y	Subcode y of code Cxxxx (e.g. C0404/2 = subcode 2 of code C0404)
DC	Direct current or direct voltage
DIN	Deutsches Institut für Normung (German Institute for Standardization)
Drive	Lenze controller combined with a geared motor, three-phase AC motor and other Lenze drive components
EMC	Electromagnetic compatibility
EN	Europäische Norm (European standard)
f_r [Hz]	Rated motor frequency
IEC	International Electrotechnical Commission
I_{mains} [A]	Mains current
I_{max} [A]	Maximum output current
IP	International Protection Code
IPC	Industrial PC
I_{PE} [mA]	Leakage current
I_r [A]	Rated output current
L [mH]	Inductance
M_r [Nm]	Rated motor torque
NEMA	National Electrical Manufacturers Association
P_{DC} [kW]	Power which can additionally be drawn from the DC bus at operation with power-adapted motor
PLC	Programmable logic controller
P_r [kW]	Rated motor power
P_V [W]	Inverter power loss

$R [\Omega]$	Resistance
$S_r [kVA]$	Output power of the controller
$U_{DC} [V]$	DC supply voltage
UL	Underwriters Laboratories
$U_M [V]$	Output voltage
$U_{mains} [V]$	Mains voltage
VDE	Verband deutscher Elektrotechniker (Association of German Electrotechnical Engineers)
Xk/y	Terminal y on terminal strip Xk (e.g. X5/28 = terminal 28 on terminal strip X5)

14.2 Index**A****Acceleration, 6.10-1****Acceleration time T_{ir} , additional setpoint of NSET, 8.5-19****Accessories, 13-1**

- external brake resistor, 12.1-1

- General, 13.1-1

- Type-specific, 13.2-1

Activating the incremental encoder, 6.7-1**Actual motor current, 8.2-27 , 8.2-42 , 8.5-7 , 9.1-1****Actual motor voltage, 8.2-27 , 8.2-42 , 8.5-6 , 9.1-1****Actual speed value, 8.2-27 , 8.2-42 , 8.5-6 , 9.1-1****Additional setpoint, 8.5-6****Ambient conditions**

- climatic, 3.1-2

- electrical, 3.1-2

- mechanical, 3.1-2

Analog inputs

- setting input range with jumper X3, 5.6-7

- Signals, 6.5-4

- terminal assignment, 5.6-7

Analog outputs

- Configuration, 6.5-6

- Signals, 6.5-6

- terminal assignment, 5.6-7

Application, as directed, 1.2-1**Application as directed, 1.2-1****Application datum, Display, 9.1-1****B****Basic function, 8.5-2****Brake operation, with external brake resistor, 12.1-1****Brake resistors, Selection, 12.1-1****Brake transistor, 12.3-1****Braking, 6.10-1 , 12-1****Braking operation, 12-1**

- in the network, 10.7-1 , 12.4-1

Bus off, 8.3-2**C****Cable**

- For control connections, 5.2-3

- For motor connection, 5.2-2

Cable cross-sections, 3.7-1**Cable resistance, 5.7-1****Cable type, 5.7-1****Calibration, Application datum, 9.1-1****CAN bus identifier, 8.5-23****Capacitance per unit length, 5.7-1****CE conformity, 1.2-1****CE-typical drive system, 5.3-1 , 5.4-1****Changing parameters, Keypad EMZ9371BC, 7.2-4 , 7.2-6 , 7.2-7 , 7.2-8 , 7.2-9****Changing the direction of rotation, 6.10-5****Clamp operation, 9.4-2****Code, 7.1-1****Code table, 8.5-1****Commissioning, 6-1**

- before switching on, 6.1-1

- Entry of motor data, 6.6-1

Communication modules, 5.10-1

Configuration, 8-1

- Analog input signals, 6.5-4
- Analog output signals, 6.5-6
- Analog outputs, 6.5-6
- changing the direction of rotation, 6.10-5
- Code table, 8.5-1
- Controller inhibit (DCTRL1-CINH), 6.4-1
- Current limits, 6.6-15
- Digital input signals, 6.5-1
- Digital output signals, 6.5-3
- Digital outputs, 6.5-3
- Display functions, 9.1-1
- Maximum field frequency, 6.10-1
- Minimum field frequency, 6.10-1
- Monitoring
 - Current load of controller (Ixt monitoring), 8.3-4
 - Heatsink temperature, 8.3-5
 - Monitoring times for process data input objects, 8.3-2
 - Motor temperature, 8.3-5
- monitoring, 8.3-1
 - bus off, 8.3-2
 - DC-bus voltage, 8.3-6
 - reset node, 8.3-2
- monitoring functions
 - overview, 8.4-1
 - responses, 8.3-1
- motor data collection, 6.6-16
- Oscillation damping, 6.11-3
- Quick stop (QSP), 6.10-4
- Relay output, 6.5-3
- Slip compensation, 6.11-1
- switching frequency of inverter, 6.9-1
- Table of attributes, 8.7-1
- Umin boost, 6.8-6

Conformity, 1.2-1**Control cable, 5.2-3****Control cables, connection between master and slave, 5.4-5****Control terminals, 5.6-1**

- Changing the assignment of X5, 6.5-1
- Changing the assignment of X6, 6.5-1

Control word (AIF), 8.5-13**Controller**

- application as directed, 1.2-1
- in clamp operation, 9.4-2
- labelling, 1.2-1

Controller inhibit, Drive behaviour, 6.4-1**Current limits, 6.6-15****Current load of controller, Ixt monitoring, 8.3-4****D****DC bus**

- Cable cross-sections for the, 5.3-5 , 5.4-9
- Cable selection, 3.7-3
- connection to the, 5.3-5 , 5.4-9
- Fuses for the, 5.3-5 , 5.4-9

DC busbars, installation between master and slave, 5.4-4**DC injection braking (GSB)**

- automatic, 8.2-35 , 8.2-57
- manual, 8.2-33 , 8.2-55

DC supply, 5.2-1**DC-bus cable, shielding, 5.3-5 , 5.4-9****DC-bus connection**

- Distributed supply, 10.6-1
- Possible combinations, 10.2-1

DC-bus operation, 10-1

- Braking operation in, 10.7-1 , 12.4-1
- Conditions, 10.2-1
- Several drives, 10-1

DC-bus voltage, 8.2-27 , 8.2-42 , 8.3-6 , 8.5-6 , 9.1-1

- monitoring, 8.3-6
- overvoltage, 8.3-6
- Undervoltage, 8.3-6

Deceleration, 6.10-1**Deceleration time Tif, additional setpoint of NSET, 8.5-19****Definition of notes used, 2.4-1****Definitions, Terms, 14.1-1****Derating, 6.6-16 , 6.9-1 , 6.11-3 , 8.2-38 , 8.2-60****device control, 8.5-2****Device protection, 2.3-1****Diagnostics, 7.2-10 , 9.1-1 , 9.1-2****Diameter calculator (DCALC1), 8.2-1****Digital frequency input, connection to X9, 5.9-1****Digital frequency output, connection to X10, 5.9-1****Digital input signals, 6.5-1****Digital inputs, Terminal assignment, 5.6-7****Digital inputs/outputs, Terminal assignment, 11.3-2****Digital output signals, 6.5-3****Digital outputs**

- Configuration, 6.5-3
- terminal assignment, 5.6-7

Dimensions, 4.2-1 , 4.3-1 , 12.2-2**Direction of rotation, inhibiting, 8.2-39 , 8.2-61**

Display

- Application datum, 9.1-1
- Operating status, 9.2-1

Display functions, 9.1-1

- Possible values, 9.1-1

Display of operating data, 9.1-1**Display values, 9.1-1**

- Calibration, 9.1-1

Disposal, 2.1-3**Distributed supply, 10.6-1****Drive behaviour**

- Controller inhibit, 6.4-1
- in the event of faults, 9.3-1

Drive errors, 9.4-1**E****Earth fault in motor cable (OC2), 8.3-3****Electrical installation, system bus (CAN), 5.7-1****EMC, what to do in case of interferences, 5.2-6****Emergency-off, Controller inhibit, 6.4-1****Entry of motor data, 6.6-1****Error analysis, Via history buffer, 9.2-1****Error messages, 9.5-1**

- causes and remedies, 9.5-1
- configuration, 8.4-1
- General, 9.5-1
- Resetting, 9.5-5

Exceeding of the maximum speed (NMAX), 8.3-3**Explanations, Code table, 8.5-1****External brake resistors, 12.2-1****External error (EEr), 8.3-6****F****Failure of a motor phase, 8.3-4****Fan connection EVx9335 ... EVx9383**

- Controller is supplied via the DC bus, 5.3-6 , 5.4-10
- controller is supplied with mains voltage, 5.3-5 , 5.4-10

Fault analysis, Via history buffer, 9.2-1**Fault elimination, 9.4-1****Fault messages**

- causes and remedies, 9.5-1
- OC3 in clamp operation, 9.4-2

Feedback system, wiring, 5.8-1**Field controller, 6.8-8 , 8.5-8****Field frequency**

- maximum, 6.10-1
- Minimum, 6.10-1

Free mounting spaces, 4.1-1**Function blocks, 8.2-1**

- diameter calculator (DCALC1), 8.2-1
- internal motor control, vector control (MCTRL2), 8.2-40
- master frequency input (DFIN), 8.2-5
- master frequency output (DFOUT), 8.2-8
- master frequency processing (DFSET), 8.2-18
- master frequency ramp-function generator (DFRFG1), 8.2-13

Functional test, safety function, 11.4-2 , 11.4-5**G****gases, aggressive, 4.1-1****General accessories, 13.1-1****General data, 3.1-1 , 7.2-1****H****Heatsink temperature, monitoring, 8.3-5****History buffer, 9.2-1**

- Assembly, 9.2-2
- clear, 9.2-2

I**I_{max} limit in generator mode, in generator mode, 6.6-15 , 8.2-27 , 8.2-42 , 8.5-4****I_{max} limit in motor mode, 6.6-15 , 8.2-27 , 8.2-42 , 8.5-4****Incremental encoder**

- At X8, 5.8-2 , 6.7-2
- at X9, 5.8-3 , 6.7-3
- operation with, 8.2-48
- with HTL level, 5.8-3 , 6.7-3
- With TTL level, 5.8-2 , 6.7-2

Input signals

- Analog, Configuration, 6.5-4
- Digital, Configuration, 6.5-1

Inputs

- Digital, Response times, 6.5-1
- KTY, 6.6-11
- PTC, 6.6-9

Interferences, eliminating EMC interferences, 5.2-6

Internal motor control

- V/f characteristic control (MCTRL1), setting of V/f characteristic, 8.2-31
- with vector control (MCTRL2)
 - torque control with speed limitation, 8.2-53
 - torque limitation, 8.2-50

Internal motor control (MCTRL)

- inhibiting the direction of rotation, 8.2-39 , 8.2-61
- limiting output current, 8.2-52
- limiting the output current, 8.2-32
- limiting the speed setpoint, 8.2-31 , 8.2-47
- quick stop (QSP), 8.2-33 , 8.2-54
- speed control, 8.2-31 , 8.2-48
- speed setpoint selection, 8.2-31 , 8.2-47
- with vector control (MCTRL2), 8.2-40

J**JOG setpoint, 8.5-6**

Jumper X3, for input range of analog setpoint selection, 5.6-7

K

Keypad EMZ9371BC, Changing parameters, 7.2-4 , 7.2-6 , 7.2-7 , 7.2-8 , 7.2-9

KTY motor monitoring, 6.6-11

L

Labelling, controller, 1.2-1

LED display, 9.2-1

LEDs, 9.2-1

Legal regulations, 1.2-1

Liability, 1.2-2

M

Mains cable, Selection of, 3.7-3

Mains connection, 5.2-1

- fuses for the, 5.3-3 , 5.3-4 , 5.4-7 , 5.4-8

mains connection, cable cross-sections for the, 5.3-3 , 5.3-4 , 5.4-7 , 5.4-8

Mains supply, 3.7-1 , 10.4-1

Manufacturer, 1.2-1

Master frequency input (DFIN), 8.2-5

Master frequency output (DFOU), 8.2-8

Master frequency processing (DFSET), 8.2-18

Master frequency ramp-function generator (DFRG1), 8.2-13

Master/slave

- Connecting control cables between the devices, 5.4-5
- installing the DC busbars, 5.4-4

Maximum speed, 6.10-1 , 8.2-26 , 8.2-41 , 8.5-3

Menu structure, XT EMZ9371BC keypad, 7.2-11

Message, 8.3-1

Minimum speed, 6.10-1 , 8.2-26 , 8.2-41 , 8.5-3

Monitoring, 8.3-1

- bus off, 8.3-2
- configuring, 8.4-1
- Current load of controller, Ixt monitoring, 8.3-4
- DC-bus voltage, 8.3-6
- Earth fault in motor cable (OC2), 8.3-3
- Exceeding of the maximum speed (NMAX), 8.3-3
- External error (EEr), 8.3-6
- Failure of a motor phase (LP1), 8.3-4
- Heatsink temperature, 8.3-5
- Monitoring times for process data input objects, 8.3-2
- Motor temperature, 8.3-5
- overload acceleration, deceleration (OC3), 8.3-3
- possible responses, 8.4-1
- reset node, 8.3-2
- responses, 8.3-1
 - message, 8.3-1
 - TRIP, 8.3-1
 - warning, 8.3-1
- Short circuit in motor cable (OC1), 8.3-3

Monitoring functions

- Overview, 8.4-1
- responses, 8.3-1

Monitoring times for process data input objects, 8.3-2

Motor, thermal monitoring, with PTC thermistor, 6.6-9 , 6.6-11

Motor cable, 5.2-2

- length, 3.1-2
- Selection of, 3.7-3
- shielding, 5.3-7 , 5.4-12

Motor connection, 5.4-13

Motor cos phi, 6.6-2 , 6.6-17 , 6.8-9 , 8.2-44 , 8.5-9

Motor data, identification, 6.6-16

Motor data collection, 6.6-16

Motor leakage inductance, 8.5-9

Motor magnetising current, optimising in case of vector control, 6.11-9

Motor potentiometer

- acceleration time Tir, 8.5-21
- deceleration time Tif, 8.5-21

Motor protection, 2.3-1

Motor rotor resistance, 8.2-43 , 8.5-9
Motor stator inductance, 6.6-17 , 6.8-9 , 8.2-44 , 8.5-10
Motor stator resistance, 6.6-17 , 8.2-44 , 8.5-9
Motor temperature, monitoring, 8.3-5
Motor temperature monitoring, connection, 5.3-8 , 5.4-14
Mounting conditions
- free spaces, 3.1-2
- mounting place, 3.1-2
- mounting position, 3.1-2

N

Nameplate, 1.1-3 , 1.1-4
Network of several drives
- Basic dimensioning, 10.5-1
- Function, 10.1-1
Noise optimised operation, 6.9-1
Notes, definition, 2.4-1

O

Operating behaviour
- Optimise, 6.8-1
- Optimising, 6.11-1
Operating conditions, 3.1-2 , 7.2-1
- ambient conditions
 climatic, 3.1-2
 electrical, 3.1-2
 mechanical, 3.1-2
- mounting conditions
 free spaces, 3.1-2
 mounting place, 3.1-2
 mounting position, 3.1-2

Operating mode
- for standard applications, 6.1-2 , 6.8-3
- Select, 6.8-1
- select, 6.1-1 , 6.8-1
- V/f characteristic control, 6.8-4
 commissioning example, 6.3-1
- vector control, 6.8-8
 commissioning example, 6.3-5

Operating status, Display, 9.2-1

Operation, noise optimised, 6.9-1

Oscillation damping, 6.11-3 , 8.2-38 , 8.2-60
- Reduction of speed oscillations, 6.11-3

Output current, limiting, 8.2-32 , 8.2-52

Output signals

- Analog, Configuration, 6.5-6
- Digital, Configuration, 6.5-3

Outputs
- Analog, 6.5-6
- Digital, 6.5-3
Overload acceleration, deceleration (OC3), 8.3-3
Overspeeds, 2.3-1
Overview, Accessories, 13-1
Overvoltage threshold, DC-bus voltage, 8.3-6

P

Parameter setting, 7-1
- code, 7.1-1
- with bus system, 7.1-2
- With XT EMZ9371BC keypad, 6.3-1 , 7.2-1
Password, 8.2-45 , 8.5-10
Pollution, 3.1-2
Power system, 3.1-2
Protection against unexpected start-up, 11.1-1
- operating mode, 11.2-2
- safety relay, 3.4-1 , 11.3-1
Protection of persons, 2.3-1
PTC motor monitoring, 6.6-9

Q

QSP (quick stop), 8.2-33 , 8.2-54
Quick stop, 6.10-4
Quick stop (QSP), 8.2-33 , 8.2-54
Quick stop deceleration time, 6.10-4 , 8.2-29 , 8.2-45 , 8.5-11

R

Rated data, 12.2-1
- for 400 V mains voltage, 3.6-1
- for 500 V mains voltage, 3.6-2
- integrated brake transistor, 12.3-1
Rated motor current, 6.6-1 , 6.6-17 , 6.8-9 , 8.2-44 , 8.5-9
Rated motor frequency, 6.6-1 , 6.6-17 , 6.8-9 , 8.2-29 , 8.2-44 , 8.5-9
Rated motor power, 6.6-1 , 6.8-8 , 8.5-8
Rated motor speed, 6.6-1 , 6.6-17 , 6.8-9 , 8.2-29 , 8.2-44 , 8.5-9
Rated motor voltage, 6.6-2 , 6.6-17 , 6.8-5 , 6.8-9 , 8.2-29 , 8.2-44 , 8.5-9
Reaction times of digital inputs, 6.5-1
Relay output, Configuration, 6.5-3

Residual hazards, 2.3-1

Responses, 8.3-1

- message, 8.3-1
- TRIP, 8.3-1
- warning, 8.3-1

Running optimisation, 6.11-1

S

Safe standstill, 11.1-1

Safe torque off, 11.1-1

- Function deactivated, 5.6-5
- functional test, 11.4-2 , 11.4-5
- operating mode, 11.2-2
- safety relay, 3.4-1 , 11.3-1

Safe torque off, Function active, 5.6-2

Safety, safety engineering, 11-1

Safety engineering, 11-1

Safety function

- functional test, 11.4-2 , 11.4-5
- Safe torque off, 11.1-1

Safety instructions, 2-1

- Definition, 2.4-1
- Structure, 2.4-1

Safety relay, 3.4-1 , 11.3-1

- Connector X11
- Terminal assignment, 11.3-2
- Wiring, 11.3-2

Safety relay KSR, Terminal assignment, 5.6-7 , 11.3-2

Selecting the operating mode, speed mode, setting acceleration and deceleration times, 6.10-3

Selection, operating mode, 6.1-1 , 6.8-1

Selection of motor type, 6.6-1 , 8.2-29 , 8.2-44 , 8.5-9

Selection of the feedback system, 6.7-1 , 8.2-42 , 8.5-4

Setting integral action component, 8.2-49

Setting the acceleration time, 6.10-3

Setting the deceleration time, 6.10-3

Setting the feedback system, 6.7-1

Setting the speed feedback, 6.7-1

Shielding

- DC-bus cable, 5.3-5 , 5.4-9
- motor cable, 5.3-7 , 5.4-12

Short circuit in motor cable (OC1), 8.3-3

Site altitude, 3.1-2

Slip compensation, 6.11-1 , 8.2-39 , 8.2-61

Speed control, 8.2-31 , 8.2-48

- adapting the speed controller, 8.2-48
- at vector control (MCTRL2), adapting the speed controller, 8.2-31
- with vector control (MCTRL2)
 - setting integral action component, 8.2-49
 - speed feedback, 8.2-48
 - temperature detection, 8.2-49

Speed feedback, 8.2-48

Speed mode, setting acceleration and deceleration times, 6.10-3

Speed oscillations, 6.11-3

Speed setpoint limitation, 8.2-31 , 8.2-47

Speed setpoint selection, 8.2-31 , 8.2-47

Stability, of the motor, 8.2-50

Status word AIF, 8.5-14 , 9.1-2

Stopping, 6.10-1

Supply forms / electrical supply conditions, 5.1-4

Switching frequency, automatic current-dependent change-over, 6.9-2 , 8.2-27 , 8.2-41 , 8.5-4

Switching frequency of inverter, 6.9-1

- noise optimised, 6.9-1

Switching frequency reduction, 6.9-2

switching on, check before switching on, 6.1-1

System bus (CAN), wiring, 5.7-1

System error messages, 9.5-1

- configuration, 8.4-1
- General, 9.5-1
- Resetting, 9.5-5

T

Table of attributes, 8.7-1

Technical data, 3-1

Temperature detection, 8.2-49

Terminal assignment

- analog inputs, 5.6-7
- analog outputs, 5.6-7
- digital inputs, 5.6-7
- Digital inputs/outputs, 11.3-2
- digital outputs, 5.6-7
- Safety relay KSR, 5.6-7 , 11.3-2

Terminal data, 5.6-2 , 11.3-1

Terminology

- Controller, 14.1-1
- Drive, 14.1-1

Terms, Definitions, 14.1-1

Thermal monitoring, motor, with PTC thermistor, 6.6-9 , 6.6-11

Tn current controller, 6.8-8 , 8.2-28 , 8.2-43 , 8.5-8

Tn slip controller, 6.11-1 , 8.2-29 , 8.5-8

Tn speed controller, 8.2-28 , 8.2-43 , 8.5-8

Torque control with speed limitation, in case of vector control (MCTRL2), 8.2-53

Torque limitation in the field weakening range, with vector control (MCTRL2), 8.2-50

TRIP, 8.3-1

Troubleshooting and fault elimination, monitoring, DC-bus voltage, 8.3-6

Troubleshooting, 9.2-1

- Drive behaviour in the event of faults, 9.3-1

- Drive errors, 9.4-1

Troubleshooting and fault elimination, 9-1

- Monitoring, 8.3-1

 Current load of controller (lxt monitoring), 8.3-4

 DC-bus voltage, 8.3-6

 Heatsink temperature, 8.3-5

 Monitoring times for process data input objects, 8.3-2

 Motor temperature, 8.3-5

- monitoring

 bus off, 8.3-2

 reset node, 8.3-2

 responses, 8.3-1

Type-specific accessories, 13.2-1

U

Umin boost, 6.8-6

Undervoltage threshold, DC-bus voltage, 8.3-6

V

V/f characteristic, setting of, 8.2-31

V/f characteristic control, 6.8-4

- boost correction, 6.11-5

- commissioning example, 6.3-1

Vector control, 6.8-8

- commissioning example, 6.3-5

- optimising motor magnetising current, 6.11-9

Voltage boost, optimising via boost correction, 6.11-5

Voltage drop, 3.7-1

Voltage supply, Via internal voltage source, 5.6-3 , 5.6-5

Preface, 1-1

Vp current controller, 6.8-8 , 8.2-28 , 8.2-43 , 8.5-8

VP field precontrol, 6.11-5 , 6.11-10 , 8.5-8

Vp speed controller, 8.2-28 , 8.2-43 , 8.5-8

W

Warning, 8.3-1

Warranty, 1.2-2

Wiring

- digital frequency input to X9, 5.9-1

- digital frequency output to X10, 5.9-1

- system bus (CAN), 5.7-1

Wiring according to EMC, 5.3-1 , 5.4-1

X

XT EMZ9371BC keypad

- Menu structure, 7.2-11

- Parameter setting, 6.3-1 , 7.2-1

CE

Lenze Drive Systems GmbH
Hans-Lenze-Straße 1
D-31855 Aerzen
Germany

EDSVF9383V
EN 5.0-05/2008
© 08/2008
TD19

 +49 (0) 51 54 82-0
 Service 00 80 00 24 4 68 77 (24 h helpline)
 Service +49 (0) 51 54 82-1112
E-Mail Lenze@Lenze.de
Internet www.Lenze.com