

**Operating Instructions** 

# **Global Drive**



Servo motors MDXK, MDFQA, MCS, MCA Three-phase AC motors MDXMA



### Nameplates for MCS, MCA compact servo motors

		мс						
		Туре	TT					
B		Design ———						
C	Motor	me size, length						
D	Tacho	o generator, phase angle sensor						
E		Brake ————						
F	l ru	Design, shaft, true nning, vibrational severity						
G	Elec protec	ctrical connection, tion type, cooling, ————————————————————————————————————						
H	Tempe elec co	erature protection, tronic nameplate,						
		Miscellaneous						
Lege	nd for na MC	ameplates of MCS, MCA compact servo motors Servo motor						
B	А	Asynchronous						
	S	Synchronous						
C	06	Square dimension 62mm	17	Square dimension 165mm				
	09	Square dimension 89mm	19	Square dimension 192mm				
	10	Square dimension 102mm	21	Square dimension 214mm				
	12	Square dimension 116mm	C X	Overall length				
	13	Square dimension 130mm	XX	Speed in 100min <sup>-1</sup>				
	14	Square dimension 142mm						
_								
D	RSO	Resolver p=1						
	SRS	Singleturn absolute value encoder with Sin-Co	os signals, Hiperf	ace				
	SRM	Multiturn absolute value encoder with Sin-Co	os signals, Hiperfa	ace				
	ECN	Singleturn absolute value encoder with Sin-Co	os signals, Endat					
	EQN	Multiturn absolute value encoder with Sin-Co	os signals, Endat					
	EQI	Multiturn absolute value encoder with Sin-Co	os signals, Endat					
	CXX	Incremental encoder TTL with commutation s	ignals UVW					
	ТХХ	Incremental encoder TTL						
	HXX	Incremental encoder HTL						
NNO No encoder								

Lege	nd for na	meplates of MCS, MCA compact servo motors						
E	BO	Without brake	P1	PM brake 24V-DC				
	F1	Spring-operated brake 24V-DC	P2	PM-brake 24V-DC, reinforced				
	F2	Spring-operated brake 24V-DC, reinforced	P5	PM brake 205V-DC				
	F5	Spring-operated brake 205V-DC	P6	PM brake 205V-DC, reinforced				
	F6	Spring-operated brake 205V-DC, reinforced	-					
F	Α	Standard flange form A/FF with through hole, cyl.	shaft with	out featherkey				
	В	Standard flange form A/FF with through hole, cyl	. shaft with	n featherkey				
	С	Standard flange form C/FT with through hole, cyl.	shaft with	out featherkey				
	Ν	Standard flange form C/FT with through hole, cyl. shaft with featherkey (standard add-on)						
	F	Identical to design A but with large flange						
	G	Identical to design B but with large flange						
	U	Identical to design C but with large flange						
	V	Identical to design N but with large flange						
	11	Shaft 11x23 (MCS06)	24	Shaft 24x50 (MCS14; MCA14, 17)				
	14	Shaft 14x30 (MCS09; MCA 10)	28	Shaft 28x60 (MCS19; MCA19)				
	19	Shaft 19x40 (MCS12; MCA13)	38	Shaft 38x80 (MCA21)				
	N or R	True running/vibrational severity						
	ZOX	Direct gearbox attachment: motor without pinior gearbox attachment without intermediate cover,	n for mount with taper	ting on open gearbox with pinion; flange for direct ed hollow shaft; tapered shaft MCS06 19				
	YOX	Direct gearbox attachment: motor without pinio gearbox attachment with intermediate cover, wit	n for moun h tapered ł	ting on open gearbox with pinion; flange for direct nollow shaft; tapered shaft MCA10 21				
	ст			and the second				
G	51	Separate circular connector for power/brake, encoder/temperature, fan						
	SŲ	Shared rectangular connector for power, encoder						
		lerminal box for power/brake, encoder/temperature, fan						
	E	IPE 4 without chaft coaling ring (avcont direct goal	whow attack	on encouer/temperature				
	5	IP54 without shart sealing ring	DOX ALLACI	imenty				
	0	IP64 (A flange without chaft cealing ring) / IP65						
	P	IP64 with chaft coaling ring (A hearing oil tight)						
	D C	IP54 with shaft sealing ring double lin (A lag dust	araaf					
		IP54 with shaft sealing ring double lip (A lag dust	51001)					
	500	IP65 with shaft sealing ring, double lip						
	300	Self-ventiliation / without fan						
	F10	Internal cooling						
	N	Separate ran 2007; AC; IN Without load flywhool						
	J	With additional mass inertia						
H	0	Standard nameplate						
	2	Second nameplate provided unattached						
	S	Colour: black						
	0	Specification - Standard						
	R	Temperature protection KTY sensor						
	U	Specification - UL design, approval UR						
	E	Temperature protection KTY sensor: electronic namenlate						
П	Miscella	Miscellaneous						

### Nameplates for MDXK servo motors and MDXMA three-phase AC motors

	MD -	
A	Type —	
B	Cooling method, ventilation ————	
C	Design, housing	
D	Machine type	
E	Built-on accessories	
F	Frame size	
G	Overall length	
H	Number of pole pairs	ļ

Lege	nd for na	meplates of MDXK servo motors and MDXMA three-p	hase AC r	motors		
A	D	Three-phase AC current				
В	F	Forced ventilated				
	S	Natural ventilation (cooling by convection and radiation	tion)			
	E	Self-ventilated				
C M Modular three-phase AC motor						
	К	Compact servo motor with square housing and cooli	ng ribs			
	Q	IP23 servo motor with square housing				
_						
D	A	Asynchronous machine				
	S	Synchronous machine				
	10	A bealute value and day				
AU     ADSolute Value encoder				lo opcodor		
	DA PC	Brake and Sill-Cos absolute value encoder of SSI abso	Jule vail			
		Drake, resolver and incremental encoder				
	DI	brake and incremental encoder (pulse encoder)				
		Brake				
		Brake receiver and absolute value encoder				
		Brake, resolver and absolute value encouer				
		Na hvaka angadar proparad		Motor for direct goarboy attachment with shaft in		
		No brake, encoder prepared	11/V	acc. with module n (n = 1, 2,)		
		Ino brake, no encoder	DI	Deschuse and in summarial an as day		
		Incremental encoder (puise encoder)		Resolver and incremental encoder		
	ĸА	Resolver and absolute value encoder	кS	Resolver		
F		036-056-071-080-000-100-112-132-160-180				
•		050, 050, 071, 000, 050, 100, 112, 152, 100, 180				
G		0:1:2:3				
_						
H		1; 2; 3				

### Lenze

### Nameplates of MCS, MCA, MDXKS, MDXKA, MDFQA and MDXMA motors

#### MDXKA, MCA asynchronous servo motors

Lenz	Hans-Lenze-Strasse 1 D-31855 Aerzen http://www.Lenze.com
2)3~MOT	Тур (3)
(4) V~	5 kW 6 Nm 7 Hz 8 1/min
(9) A	(10) HP Mo (11) Nm $\cos \varphi$ (12) C86: (13)
	IP (14) I.CL. (15) Ta (16) (25)
Geber Feedback	(17) C416: (18) Id.Nr. (19)
Bremse Brake (20)	V- A Nm
SN (21)	

#### MDXKS, MCS synchronous servo motors

Lenz	Hans-L D-3185 http://v	enze-Strass 5 Aerzen www.Lenze.	se 1 com E	DNo <b>FI</b> (	E Made in Germany
2 3~MOT	Тур (3	)			
(4) V~	(5)	kW (6	) Nm	(7) Hz	(8)/min
(9) A	(10)	HP Mo (	11) Nm	U <sub>in</sub> (22) V	C86: (13)
max (23) A	IP(14)	I.CL.	(15)	Ta (16)	(25)
Geber Feedback	17)	C416:(18	3)	ld.Nr. (19)	0
Bremse Brake (20)	V-	Α	Nm		
SN (21)					

IP23 MDFQA asynchronous servo motors			MDXM modular three-phase AC motors		
$\begin{array}{c c c c c c c c c c c c c c c c c c c $			$\begin{array}{c c c c c c c c c c c c c c c c c c c $		
No.	Explanation	No.	Explanation		
1	Valid conformities and approvals	13	Selection number for operation with servo inverters		
2	Motor type: three-phase AC motor	14	Type of protection		
3	Lenze motor type	15	Thermal class		
4	Rated voltage U <sub>N</sub> [V]	16	Ambient and rated temperature		
5	Rated power P <sub>N</sub> [kW]	17	Encoder labelling		
6	Rated torque M <sub>N</sub> [Nm]	18	Resolver adjustment value; entry in code C0416 in the case of 9300 servo inverters		
7	Rated frequency f <sub>N</sub> [Hz]	19	ID no. / Serial no. 16 digits; first 8 digits = ID no.		
8	Rated speed n <sub>N</sub> [min-1]	20	Data on holding brake: voltage, current, torque		
9	Rated current I <sub>N</sub> [A]	21	Motor no.		
10	Rated power P <sub>N</sub> [HP]	22	Induced voltage (conductor-conductor) at nominal speed and 150°C		
11	Continuous standstill torque M <sub>0</sub> [Nm]	23	Maximum current I <sub>max</sub> [A]		
12	Rated power factor $\cos \phi$	24	Production data		
		25	Temperature sensor		

For operation with servo inverters:

enter the provided selection number in C0086 to automatically optimise the control characteristic.

#### What is new / what has changed in the Operating Instructions?

Material number	Edition	Important	Contents
00 408 498	1.0 03/99 TD09	1st edition	First printing
00 465 520	1.0 03/03 TD09	1st edition replaces 408 498	Completely revised
13055270	2.0 06/05 TD09	1st edition replaces 465 520	Supplement: Gearbox and brake data; Connection of incremental encoder; Example for function block interconnection

	Safety instructions
<u>/</u>	Hazardous voltage on the power connections even when disconnected from mains: residual voltage >60 V! When carrying out work on the power connections always disconnect the controller from the mains and wait until the motor is at standstill (voltage at the contacts when the motor is rotating).
	Danger of burning! During operation, surfaces temperatures of up to 140 °C are possible.Protect against contact!
	Danger of injury through rotating shaft! Before working on motor, ensure motor is at standstill.
	Never disconnect from mains when energised! Otherwise, plug can be destroyed. Inhibit controller before disconnecting from the mains.
	Mounting
	Read these operating instructions before you start!
	<ul> <li>Use an appropriate means of transport and lifting equipment!</li> <li>The shaft must not be exposed to knocks or bumps! Motor can be destroyed! Drive elements must be mounted on the motor shaft via the threading. An extracting device must be used when dismounting. Fasten coupling securely.</li> <li>Fasten motor and ensure unimpeded ventilation</li> <li>If necessary, open condensation drain holes</li> <li>Tighten coupling ring of connector</li> </ul>
	<ul> <li>Motor must be carefully earthed, check cabling</li> <li>Extensive shielding of motor cable on motor and controller</li> </ul>
	<ul> <li>Maintenance interval for shaft sealing ring: approx. 2500 h</li> <li>Maintenance interval for ball bearings: approx. 15000 h</li> <li>Remove dirt at regular intervals</li> </ul>

### Tip!

Current documentation and software updates for Lenze products can be found on the Internet in the "Downloads" area under **http://www.Lenze.com** 

© 2005 Lenze Drive Systems GmbH, Hans-Lenze-Straße 1, D-31855 Aerzen

No part of this documentation may be reproduced or made accessible to third parties without written consent by Lenze Drive Systems GmbH.

All information given in this documentation has been selected carefully and complies with the hardware and software described. Nevertheless, deviations cannot be ruled out. We do not take any responsibility or liability for damages which might possibly occur. Necessary corrections will be included in subsequent editions.

i

1	Prefa	ace and g	general information	9			
	1.1	About t	hese Operating Instructions	9			
	1.2	Termin	ology used	9			
	1.3	Scope o	of supply	9			
	1.4	Legal re	egulations	10			
2	Safet	tv instruc	ctions	11			
-	21	Genera	I safety and application instructions for Lenze motors	11			
	2.1	Cenera	I safety and application notes for Lenze controllers	12			
	2.2	Decidua		16			
	2.5			10			
	2.4	Definiti	ion of notes used	1/			
3	Tech	nical dat	a	18			
	3.1	Genera	l data/operating conditions	18			
	3.2	Rated d	lata	19			
	3.3	Sound p	pressure level	20			
	3.4	Holding	z brake (option)	21			
		3.4.1	Permanent magnet holding brakes	22			
		3.4.2	Spring-operated brakes	23			
4	Mecl	hanical ir	nstallation	24			
	4.1	Transpo	ort. storage and installation	24			
	4.2	Assemt	bly of built-on accessories	24			
	1.2	Mounting of motors on gearboxes with mounting flange (drive and version N)					
	4.5	431	Important notes	25			
		4.3.2	Installation data	26			
		4.3.3	Tightening torques	27			
		4.3.4	Mounting the standard hub / clamping hub	27			
		4.3.5	Mounting the clamping ring hub	28			
		4.3.6	Dismounting the clamping ring hub	28			
5	Elect	rical inst	allation	29			
	5.1	Importa	ant notes	30			
		5.1.1	EMC-compliant wiring	32			
	5.2	Motor o	connection	32			
		5.2.1	Servo motors MDXK 036 090, MDXK 100 112, MCS 06 19, MCA 10 21	32			
		5.2.2	Power connection	33			
		5.2.3	Servo motors MDFQA 100/112/132/160, three-phase AC motors MDXMA	34			



### Contents

	5.4	Feedba	ck connection	36
		5.4.1	Resolver connection	36
		5.4.2	Resolver connection	37
		5.4.3	Sin-Cos absolute value encoder	37
		5.4.4	Connection incremental encoder / SinCos encoder	38
		5.4.5	Sin-Cos absolute value encoder with EnDat interface	39
6	Com	missionir	ng	40
	6.1	Before s	witching on	40
	6.2	Parame	ter setting	41
		6.2.1	Servo controller 9300	41
		6.2.2	Servo controller ECS	42
		6.2.3	Parameter setting of motor temperature detection	42
		6.2.4	Parameterisation of the temperature sensor 9300 / ECS	42
	6.3	Functio	n block interconnection servo inverter 9300	43
	6.4	Parame	terisation of function block interconnection	44
	6.5	Functio	nal test	45
7	Duri	ng operat	tion	46
8	Trou	bleshoot	ing and fault elimination	47
9	Mair	itenance,	/repair	49
	9.1	Mainte	nance intervals	49
	9.2	Mainte	nance operations	49
		9.2.1	Adjustment of the resolver using synchronous servo motors/rotor position adjustment	50
		9.2.2	Temperature control for servo motors	50
	9.3	Repair	- ,	51
10				-
TO	Note	5	•••••••••••••••••••••••••••••	52

### **1** Preface and general information

#### **1.1** About these Operating Instructions

- These operating instructions serve to enhance safety when working on and with MDXK / MDFQA / MCS / MCA servo motors and MDXMA modular three-phase AC motors. They contain safety instructions which must be observed.
- All persons working on or with the stated servo motors or modular three-phase AC motors must have access to these operating instructions and observe the instructions and notes relevant for their work.
- The operating instructions must always be complete and in a perfectly readable state.
- If the information and notes provided in these operating instructions do not meet your requirements, please refer to the operating instructions for the controller and/or gearbox.

#### 1.2 Terminology used

Term	Describes the following
Motor	Servo motor type MDXK, type MDFQA, type MCS, type MCA modular three-phase AC motor type MDXMA
Controller	Any servo inverter of the series 9300, ECS, 9400, 94, 940 Any frequency inverter in the series 8200
Drive system	Drive systems with servo motors type MDXK / MDFQA / MCS / MCA, with modular three-phase AC motors type MDXMA and with other Lenze drive components

#### 1.3 Scope of supply

The drive systems are individually grouped. On delivery, check immediately whether it corresponds with the accompanying papers. Lenze does not grant any warranty for subsequent claims.

Claim for

- ▶ visible transport damages immediately to the forwarder.
- visible deficiencies / incomplete deliveries immediately to your Lenze representative.

1

### 1.4 Legal regulations

Labelling	Nameplate	CE designation	Manufacturer			
	Lenze motors are uniquely designated by the content of the nameplate.	Conforming to EC "Low-Voltage Directive"	Lenze Drive Systems GmbH Postfach 10 13 52 D-31763 Hameln			
Application as directed	<ul> <li>MDXK / MDFQA / MCS / MCA servo motors, MDXMA modular three-phase AC motors</li> <li>can only be operated under the conditions described in these operating instructions.</li> <li>are components: <ul> <li>for use as small drives.</li> <li>for installation in a machine.</li> <li>used for assembly together with other components to form a machine.</li> </ul> </li> <li>comply with the requirements of the EC Low-Voltage Directive.</li> <li>are not machines within the sense of the EC Machine Directive.</li> <li>are not to be used as domestic appliances but exclusively as components for industrial applications.</li> </ul> <li>Drive systems with MDXK / MDFQA / MCS / MCA servo motors, with MDXMA modular three-phase AC motors</li> <li>comply with the EC Directive "Electromagnetic Compatibility" if they are installed in accordance with the guidelines for CE-typical drive systems.</li> <li>can be used: <ul> <li>on public and non-public mains.</li> <li>in industrial as well as residential and commercial premises.</li> </ul> </li> <li>The responsibility for ensuring that the application is in compliance with the EC Directive lies with the user.</li>					
Liability	<ul> <li>The information, data, and notes in these instructions were up to date at the time of printing. Claims referring to motors which have already been supplied cannot be derived from the information, illustrations and descriptions.</li> <li>The process-related notes and circuit sections used in these instructions are suggestions whose suitability for the respective application must be checked. Lenze assumes no guarantee for the suitability of the listed procedures and circuit samples.</li> <li>These operating instructions describe the product features without guaranteeing them.</li> <li>No liability shall be accepted for damage and downtimes resulting from: <ul> <li>non-observance of the operating instructions</li> <li>unauthorised changes or modifications to the motors</li> <li>operating errors</li> <li>improper work on and with the motors.</li> </ul> </li> </ul>					
Warranty	<ul> <li>Terms of warranty: see terms of sa</li> <li>Warranty claims must be made to</li> <li>The warranty is void in all cases in</li> </ul>	ales and delivery of Lenze Drive Syster Lenze immediately after detecting th which liability claims cannot be mad	ms GmbH ne deficiency or fault. e.			

Lenze

### 2 Safety instructions

#### 2.1 General safety and application instructions for Lenze motors

(according to Low-Voltage Directive 73/23/EEC)

#### General

Low-voltage machines have hazardous live and rotating parts and possibly also hot surfaces.

Synchronous machines induce voltages at open terminals during operation.

All operations concerning transport, connections, commissioning and maintenance must be carried out by qualified, skilled personnel (EN 50110-1 (VDE 0105-100) and IEC 60364 must be observed). Inappropriate use creates the risk of severe injury to persons and damage to material assets.

Low-voltage machines may only be operated under the conditions that are indicated in the section "Application as directed".

The conditions at the place of installation must comply with the data given on the nameplate and in the documentation.

#### **Application as directed**

Low-voltage machines are intended for commercial installations. They comply with the harmonised standards of the series EN 60034 (VDE 0530). Their use in potentially explosive atmospheres is prohibited unless they are expressly intended for such use (follow additional instructions).

Low-voltage machines are components for installation into machines as defined in the Machinery Directive 98/37/EC. Commissioning is prohibited until the conformity of the end product with this directive has been established (follow i. a. EN 60204-1)

Low-voltage machines with IP23 protection or less are only intended for outdoor use when applying special protective features.

The integrated brakes must not be used as safety brakes. It cannot be ruled out that factors which cannot be influenced, such as oil ingress due to a defective A-side shaft seal, cause a brake torque reduction.

#### Transport, storage

Damages must be reported immediately upon receipt to the forwarder; if required, commissioning must be excluded. Tighten screwed-in ring bolts before transport. They are designed for the weight of the low-voltage machines, do not apply extra loads. If necessary, use suitable and adequately dimensioned means of transport (e.g. rope guides).

Remove transport locking devices before commissioning. Reuse them for further transport. When storing low-voltage machines, ensure a dry, dust-free and low-vibration ( $v_{eff} \le 0.2 \text{ mm/s}$ ) environment (damages while being stored).

2

#### Installation

2

Ensure an even surface, solid foot flange mounting and exact alignment if a direct clutch is connected. Avoid resonances with the rotational frequency and double mains frequency which may be caused by the assembly. Turn rotor by hand, listen for unusual slipping noises. Check the direction of rotation when the clutch is not active (observe section "Electrical connection").

Use appropriate means to mount or remove belt pulleys and clutches (heating) and cover them with a touch guard. Avoid impermissible belt tensions.

The machines are half-key balanced. The clutch must be half-key balanced, too. The visible jutting out part of the key must be removed.

If required, provide pipe connections. Designs with shaft end at bottom must be protected with a cover which prevents the ingress of foreign particles into the fan. Free circulation of the cooling air must be ensured. The exhaust air - also the exhaust air of other machines next to the drive system - must not be taken in immediately.

#### **Electrical connection**

All operations must only be carried out by qualified and skilled personnel on the low-voltage machine at standstill and deenergised and provided with a safe guard to prevent an unintentional restart. This also applies to auxiliary circuits (e.g. brake, encoder, separate fan).

Check safe isolation from supply!

If the tolerances specified in EN 60034-1; IEC 34 (VDE 0530-1) - voltage  $\pm 5$  %, frequency  $\pm 2$  %, waveform, symmetry - are exceeded, more heat will be generated and the electromagnetic compatibility will be affected.

Observe the data on the nameplate, operating notes, and the connection diagram in the terminal box.

The connection must ensure a continuous and safe electrical supply (no loose wire ends); use appropriate cable terminals. The connection to the PE conductor must be safe. The plug-in connector must be bolt tightly (to stop).

The clearances between blank, live parts and to earth must not fall below 8 mm at  $U_r \le 550$  V, 10 mm at  $U_r \le 725$  V, 14 mm at  $U_r \le 1000$  V.

The terminal box must be free of foreign particles, dirt and moisture. All unused cable entries and the box itself must be sealed against dust and water.

#### **Commissioning and operation**

Before commissioning after longer storage periods, measure insulation resistance. In case of values  $\leq 1 \text{ k}\Omega$  per volt of rated voltage, dry winding.

For trial run without output elements, lock the featherkey. Do not deactivate off the protective devices, not even in a trial run.

Check the correct operation of the brake before commissioning low-voltage machines with brakes.

Integrated thermal detectors do not provide full protection for the machine. If necessary, limit the maximum current. Parameterise the controller so that the motor will be switched off with  $| > |_r$  after a few seconds of operation, especially at the risk of blocking.

Vibrationalseverities  $v_{eff} \le 3.5 \text{ mm/s}(P_r \le 15 \text{ kW})$  or 4.5 mm/s( $P_r > 15 \text{ kW}$ ) are acceptable if the clutch is activated.

If deviations from normal operation occur, e.g. increased temperatures, noises, vibrations, find the cause and, if required, contact the manufacturer. In case of doubt, switch off the low-voltage machine.

If the machine is exposed to dirt, clean the air channels regularly.

Shaft sealing rings and roller bearings have a limited service life.

Regrease bearings with relubricating devices while the low-voltage machine is running. Only use the grease recommended by the manufacturer. If the grease drain holes are sealed with a plug, (IP54 drive end; IP23 drive and non-drive end), remove plug before commissioning. Seal bore holes with grease. Replace prelubricated bearings (2Z bearing) after approx. 10,000 h - 20,000 h, at the latest however after 3 - 4 years.

The product-specific safety and application notes given in these Instructions must be observed!

#### 2.2 General safety and application notes for Lenze controllers

(to: Low-Voltage Directive 73/23/EEC)

#### General

Lenze controllers (frequency inverters, servo inverters, DC speed controllers) and the accessory components can include live and rotating parts - depending on their type of protection - during operation. Surfaces can be hot.

Non-authorised removal of the required cover, inappropriate use, incorrect installation or operation, create the risk of severe injury to persons or damage to material assets.

More information can be obtained from the documentation.

All operations concerning transport, installation, and commissioning as well as maintenance must be carried out by qualified, skilled personnel (IEC 364 and CENELEC HD 384 or DIN VDE 0100 and IEC report 664 or DIN VDE 0110 and national regulations for the prevention of accidents must be observed).

According to this basic safety information, qualified, skilled personnel are persons who are familiar with the assembly, installation, commissioning, and operation of the product and who have the qualifications necessary for their occupation.



#### **Application as directed**

2

Drive controllers are components which are designed for installation in electrical systems or machinery. They are not to be used as household appliances. They are intended exclusively for professional and commercial purposes according to EN 61000-3-2. The documentation includes information on compliance with the EN 61000-3-2.

When installing the controllers into machines, commissioning (i.e. starting of operation as directed) is prohibited until it is proven that the machine complies with the regulations of the EC Directive 98/37/EC (Machinery Directive); EN 60204 must be observed.

Commissioning (i.e. starting of operation as directed) is only allowed when there is compliance with the EMC Directive (89/336/EEC).

The controllers meet the requirements of the Low-Voltage Directive 73/23/EEC. The harmonised standards of the series EN 61800-5-1 apply to the controllers.

The technical data and information on connection conditions must be obtained from the nameplate and the documentation. They must be observed in any case.

**Warning:** The controllers can be used according to EN 61800-3 in drive systems of the category C2. These products can cause radio interferences in residential areas. In this case, special measures are required.

#### Transport, storage

Please observe the notes on transport, storage and appropriate handling.

Observe the climatic conditions according to EN-61800-5-1.

#### Installation

The controllers must be installed and cooled according to the instructions given in the corresponding documentation.

Ensure proper handling and avoid mechanical stress. Do not bend any components and do not change any insulation distances during transport or handling. Do not touch any electronic components and contacts.

Controllers contain electrostatically sensitive components, which can easily be damaged by inappropriate handling. Do not damage or destroy any electrical components since this might endanger your health!

#### **Electrical connection**

When working on live controllers, the valid national regulations for the prevention of accidents (e. g. VBG 4) must be observed.

The electrical installation must be carried out according to the appropriate regulations (e.g. cable cross-sections, fuses, PE connection). Additional information can be obtained from the documentation.

The documentation contains information about installation in compliance with EMC (shielding, earthing, filters and cables). These notes must also be observed for CE-marked controllers. The manufacturer of the system or machine is responsible for the compliance with the required limit values demanded by the EMC legislation.

In the case of a malfunction (short circuit to frame or earth fault), Lenze controllers can cause a DC residual current in the protective conductor. If an earth-leakage circuit breaker (residual current device) is used as a protective means in the case of indirect contact, only an e.l.c.b. of type B may be used on the current supply side. Otherwise, another protective measure such as separation from the environment through double or reinforced insulation or disconnection from the mains by means of a transformer must be used.

#### Operation

If necessary, systems including controllers must be equipped with additional monitoring and protection devices according to the valid safety regulations (e.g. law on technical equipment, regulations for the prevention of accidents). The controller can be adapted to your application. Please observe the corresponding information given in the documentation.

After a controller has been disconnected from the voltage supply, all live components and power connections must not be touched immediately because capacitors can still be charged. Please observe the corresponding stickers on the controller.

All protection covers and doors must be shut during operation.

**Note for UL approved systems with integrated controllers:** UL warnings are notes that only apply to UL systems. The documentation contains special information about UL.

#### Safe standstill

Some variants of the controllers support safety functions (e.g. "safe standstill") according to the requirements of Appendix I no. 1.2.7 of the EC Directive "Machinery" 98/37/EC, EN 954-1 category 3 and EN 1037. The notes on the safety instructions in the documentation of the variants must be strictly observed.

#### Maintenance and servicing

The controllers do not require any maintenance if the prescribed conditions of operation are observed.

If the ambient air is polluted, the cooling surfaces of the controller may become dirty or the air vents of the controller may be obstructed. Therefore, clean the cooling surfaces and air vents periodically under these operating conditions. Do not use sharp or pointed tools for this purpose!

**Residual hazards** 

### Disposal

Recycle metal and plastic materials. Ensure professional disposal of assembled PCBs.

The product-specific safety and application notes given in these Instructions must be observed!

### 2.3 Residual hazards

#### **Protection of persons**

- The motor surfaces can become very hot. Danger of burns when touching!
   If necessary, provide protection against contact.
- ► If the motor is inverter driven, high-frequency voltages may be capacitively transferred to the motor housing.
  - Ensure careful earthing of motor housing.
- ► Danger through unintended starts or electric shocks
  - Connections must only be made when the equipment is deenergised and the motor is at standstill.
  - Built-in brakes are not fail-safe brakes .

#### **Device protection**

- ► Integrated temperature sensors do not provide **full protection** for the machine.
  - If necessary, limit the maximum current, perform a function block interconnection with disconnection after a few seconds of operation with I > I<sub>N</sub>, particularly if a danger of blocking exists.
  - Integrated overload protection does not protect against overloading under all conditions.
- ▶ Built-in brakes are **not fail-safe brakes** .
  - Torque can be reduced.
- ► Fuses do not protect the motor.
  - Use current-dependent motor protection switches for average switching frequency.
  - Use integrated temperature sensor for high switching frequency.
- Excessive torques may lead to demagnetisation or a breakage of the motor shaft.
   Never exceed the maximum torques specified in the catalogue.
- Shear forces from the motor shaft are possible.
  - Shafts of motor and drive machine must be exactly aligned.

### **Fire protection**

- ► Danger of fire
  - Avoid contact with inflammable substances.

2

#### 2.4 Definition of notes used

The following signal words and symbols are used in this documentation to indicate dangers and important information:

### **Safety instructions**

Structure of safety instructions:

### 

Pictograph and signal word	Meaning
Danger!	Danger of personal injury through dangerous electrical voltage. Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
Danger!	Danger of personal injury through a general source of danger. Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
STOP Stop!	<b>Danger of property damage.</b> Reference to a possible danger that may result in property damage if the corresponding measures are not taken.
Application notes	
Pictograph and signal word	Meaning
1 Note!	Important note to ensure trouble-free operation
-``@ Tip!	Useful tip for simple handling
	Reference to another documentation

### 3 Technical data

### 3.1 General data/operating conditions

Field	Values					
Conformity	CE	ective (73/23/EEC)				
Approvals	UL 1004	Underwriter Lab	oratories (File No. E210321)			
Climatic conditions	Average relative humidity 85 %, wit	hout condensatio	on			
Permissible	Designs					
temperature ranges	<ul> <li>Non-ventilated or with integral fan without brake or with spring-operated brake</li> </ul>	-20 °C +40 °C	Without power reduction, over +40°C with power reduction, see catalogue			
	• With permanent magnet brake	-10 °C +40 °C				
	<ul> <li>With separate fan, without permanent magnet brake</li> </ul>	-15 °C +40 °C	Without power reduction			
Mounting positions	Suitable for all mounting positions		Vertical arrangements to DIN-IEC 34 Part 7 are possible if they meet the designs			
Protection type	See nameplate		Protection types only apply for horizontal installation			
Thermal class	F (155 °C) to DIN-IEC 34 / VDE 0530		If the temperature limit is exceeded, the insulation will be damaged or destroyed			
Tropical insulation	Can not be guaranteed					
Permissible installation height h	h ≤ 1000 m AMSL 1000 m AMSL < h ≤ 4000 m AMSL		Without power reduction With power reduction, see catalogue			
Permissible voltage	1.5 kV peak value		5 kV/μs rate of rise			
Vibration	Up to 2.0g / 20m/s <sup>2</sup> without resonance excitation, e.g. of the fan.					

#### 3.2 Rated data

Rated data	Values	Comment
Motor, separate fan	See respective nameplate Further data is provided in the catalogue.	<ul> <li>The specified values apply:</li> <li>for MDXK, MDFQA, MCS, MCA servo motors for operation with Lenze servo inverters 9300, ECS for operation with 400 V mains and an inverter clock frequency of 4 kHz, 8 kHz and 16 kHz.</li> <li>for MDXM modular three-phase AC motors for mains operation or for operation with Lenze frequency inverters from 4 16 kHz.</li> </ul>
Maximum motor speed [min <sup>-1</sup> ] (mechanical limit)	<ul> <li>Synchronous servo motors MCS: 4000 8000</li> <li>Synchronous servo motors MDXKS: 5000 8000</li> <li>Asynchronous servo motors MDXKA, MCA: 8000</li> <li>Asynchronous servo motors MDFQA: 4500 5000</li> <li>Modular three-phase AC motors: 4500</li> </ul>	
Weights	See catalogue	The specified values serve as reference values for dimensioning.
Torques	See catalogue	<ul> <li>Torques that exceed the maximum values lead to shaft breakage or demagnetisation.</li> <li>The maximum torque values indicated in the catalogue must be observed.</li> <li>The indicated torques can be achieved through the utilisation of corresponding motor-controller combinations.</li> </ul>
Axial forces	See catalogue	Excessive forces reduce the service life of the bearings.
Radial forces	See catalogue	<ul> <li>Please observe the permitted forces indicated in the catalogue.</li> </ul>

# i

Note!

MDXKA / MDFQA / MCS / MCA asynchronous motors and MDXMA modular three-phase AC motors can also be operated with other inverters. Please observe the minimum clock frequency indicated in the table. Depending on the modulation and control characteristic of the inverter, the temperature monitoring of the motor may be activated. If this is the case, reduce the power.

Motor type	Minimal inverter clock frequency [kHz]
MDXKA 056 080 / MCA 10 21	4
MDXKA 090 112	4
MDFQA	8
MDXMA	4
MCS	4

3

Sound pressure level

#### 3.3 Sound pressure level

Motor type	Fan operation	Sound pressure level [db (A)]	Comments
MDSKA 056		60	Sound pressure level, A-weighting
MDSKA 071	¥	60 62	Distance = 1 m Motor in no-load operation, U = 3400 min <sup>-1</sup>
MDIKA 071 MDSKA 080	A	62	
MDFKA 080	Х	64	Operation with 9300 servo inverters or 8200 frequency inverter
MDSKA 090		63	Inverter clock frequency: 8 or 16 kHz
MDFKA 090	X	66	
MDSKA 100		69	
MDFKA 100	Х	72	
MDSKA 112		72	
MDFKA 112	Х	75	
MDFQA 110	Х	81	
MDFQA 112	Х	84	
MDFQA 132	Х	87	
MDFQA 160	Х	89	
MDFMA	Х	≤ 70	



### Note!

The noise generated by motors with a separate fan can be reduced if they are operated with a 9300 servo:

- ► If the application does not require permanent ventilation with a separate fan (e.g. intermittent operation with long cooling periods), the fan should only be activated if the winding temperature exceeds a certain limit.
- ▶ We recommend: from 120 °C upwards

#### 3.4 Holding brake (option)

The MDXKX, MCA and MCS servo motors can be equipped with permanent magnet holding brakes (option). The enclosed-ventilated MDFQA asynchronous servo motors and the MDXMA three-phase AC motors can be equipped with a spring-operated brake. The installation or mounting of the brakes increases the length of the motor.

The brakes used are not fail-safe brakes in the sense that a torque reduction cannot occur through uncontrollable interference factors, such as through the entrance of oil.

With long motor supply cables, the ohmic voltage drop along the cable must be observed and compensated for by a higher voltage at the cable entry.

The following applies to Lenze system cables:

$U^{*}[V] = U_{B}[V] + (0.08 \left[ \frac{V}{m \cdot A} \right] \cdot L[m] \cdot I_{B}[A])$	U*	Resulting supply voltage
	U <sub>B</sub>	Rated voltage of the brake
		Length of cable
	I <sub>B</sub>	Rated current of the brake

### Stop!

If no suitable voltage (incorrect size, incorrect polarity) is applied to the brake, the brake is applied and can overheat and be destroyed by the motor which continues to run.

The shortest operating times of the brakes are achieved by switching the voltage on the DC side and a suppressor circuit (varistor or spark suppressor). Without suppressor circuit, the operating times may increase. A varistor/spark suppressor limits the breaking voltage peaks. It must be observed that the power limit of the suppressor circuit is not exceeded. It is dependent on the brake current, brake voltage, disengagement time and the switchings per time unit.

The suppressor circuit is also required for radio interference suppression and for increasing the service life of the relay contacts (external, not integrated in the motor).

3

### 3.4.1 Permanent magnet holding brakes

These brakes serve as a holding brake to hold the axles when the machine is at standstill or deenergised. When controlling the brake it must be ensured that the brake is activated (released, engaged) at a speed of 0 min<sup>-1</sup> to avoid unnecessary and rapid wear on the friction surfaces of the brake.

When used solely as a holding brake, practically no wear occurs on the friction surfaces. If the max. permissible switching energy per emergency stop (see catalogue) is not exceeded, at least 2000 emergency stop functions are possible at a speed of  $3000 \text{ min}^{-1}$ .

$W = \frac{1}{2} \cdot J_{tatal} \cdot \omega^2$	[l] W	Energy
	J <sub>total</sub> [kgm <sup>2</sup> ]	Total moment of inertia
	ω [ <sup>1</sup> / <sub>s</sub> ]	Angular speed $\omega = 2\pi n/60$ , n = speed [min <sup>-1</sup> ]

The holding torques specified in the catalogue only apply when the motor is at standstill. In the case of a slipping brake, the dynamic braking torque always applies.

### STOP Stop!

The holding brake is only designed for a limited number of emergency stops. Utilisation as a working brake, e.g. to decelerate a load, is not permissible.

### Note!

1

The brakes are maintenance-free and cannot be adjusted. In the event of wear, e.g. through emergency stops, the brakes must be replaced.

These brakes function in accordance with the closed-circuit principle, i.e. the brake is closed when the motor is deenergised.

Brakes with a rated voltage of DC 24 V are designed for smoothed DC voltages with a ripple of <1 %. It must be ensured that the connector on the motor side is supplied with the minimum voltage of DC 24 V -10 %. If necessary, the voltage drop in the cable should also be considered. If the maximum voltage DC 24 V + 5 % is exceeded, the brake can close again. Supplying the brake with bridged DC voltage (bridge rectifier without additional smoothing) or a DC voltage with a ripple of >1 % can lead to a malfunctioning of the brake or an increase in the engagement and disengagement times.

Brakes with a rated voltage of DC 205 V are designed for bridged DC voltage, i.e. for supply via a bridge rectifier from the 230 V mains (half-wave rectifier are not permissible). Supplying the brake with smoothed DC voltage can lead to a malfunction or an increase in the linking and disengagement times. With regard to the minimum and maximum voltages, the same conditions apply as for brakes with 24 V, i.e. the permissible voltage tolerance is 205 V DC +5 %, -10 %.

#### 3.4.2 Spring-operated brakes

The spring-operated brakes serve as a holding brake to hold the axles when the machine is at standstill or deenergised. Permissible operating speeds and characteristics ( $\square$  catalogue for spring-operated brakes). Emergency stops at higher speeds are possible but high switching energy increases wear on the friction surfaces and hub.

### STOP Stop!

In any case, the friction surfaces must be kept free of lubricant and grease, since even small amounts can drastically reduce the braking torque.

When used solely as a holding brake, very little wear occurs on the friction surfaces. Emergency stops lead to wear on the friction surfaces and also lead to the creation of dust. The lenze BFK 458 spring-operated brake can be adjusted up to 5 times. The BFK 418, 457 and 460 cannot be adjusted (Details 🕮 catalogue and operating instructions for spring-operated brakes). Brakes that cannot be adjusted must be replace once the wear limit has been reached.

The friction energy per switching cycle can be calculated using the formula below and may not exceed the limit value (depends on the switching rate) for emergency stops ( $\Box$  catalogue on spring-operated brakes).

M <sub>K</sub>	Q [1]	Friction energy
$Q = \frac{1}{2} \cdot J_{\text{total}} \cdot \Delta \omega^2 \cdot \frac{\kappa}{M_{\text{K}} - M_{\text{L}}}$	J <sub>total</sub> [kgm <sup>2</sup> ]	Total mass moment of inertia (motor + load)
	$\Delta \omega [1/s]$	Angular speed $\omega = 2\pi n/_{60}$ , n = speed [min <sup>-1</sup> ]
	M <sub>K</sub> [Nm]	Characteristic torque
	M <sub>L</sub> [Nm]	Load torque

Depending on the operating conditions and possible heat removal, the surface temperatures can reach up to 130 °C.

The spring-operated brakes operate according to the closed-circuit principle, i.e. the brake is closed in the deenergised state. The brakes can be fed with a bridged DC voltage (bridge rectifier) and a smoothed DC voltage. The permissible voltage tolerance is ±10%.

### Note!

For additional information see the catalogues and operating instructions for spring-operated brakes.

Transport, storage and installation

### 4 Mechanical installation

### 4.1 Transport, storage and installation

Transport	<ul> <li>Motors may only be transported using a suitable means of conveyance and appropriate hoists.</li> <li>Ensure secure fastening: the motors are partially equipped with transport eyelets that are intended for secure fastening to hoists. They are <b>only</b> designed for the weight of the motor and must <b>not</b>. be used if other components are mounted to the motor (weights: see catalogue).</li> <li>Ensure vibration-free transport of motors.</li> <li>The motors must not be exposed to hard knocks and bumps.</li> </ul>
Storage location	<ul> <li>Vibration-free <ul> <li>If vibrations cannot be avoided, the rotor must be rotated in the bearings once a week.</li> </ul> </li> <li>Dry, non-aggressive atmosphere <ul> <li>Dust-free</li> </ul> </li> <li>Without sudden temperature changes</li> <li>In the delivery state, all steel components have corrosion protection. Do not remove the protection! Check every three months and replace, if necessary.</li> </ul>
Installation	<ul> <li>Provide fixings which correspond to the design, weight and torque of the motor.</li> <li>The foot and flange surfaces of the motor must be fitted evenly before the motor is fastened.</li> <li>Incorrect motor alignment reduces the service life of the roller bearings and transmission elements.</li> <li>Couplings and other transmission elements must be fitted in accordance with the regulations.</li> <li>Impacts on shafts can cause bearing damage (□ Ch. 4.2).</li> <li>Do not exceed the permissible range of ambient operating temperature (□ Ch. 3.1).</li> <li>Humidity ≤ 85%, non-condensing</li> <li>Vibration ≤ 2g / 20m/s<sup>2</sup> without resonance excitation</li> <li>Fasten motor securely</li> <li>Ensure that ventilation is not impeded</li> <li>During operation, surfaces are hot, up to 140 °C! Ensure that guard is in place!</li> </ul>

#### 4.2 Assembly of built-on accessories

Follow these instructions carefully. Please note that the warranty and product liability will become void in the event of impermissible alterations or modifications to the motors.

- ► For new motors, you may have to remove the corrosion protection from the shaft ends and flanges. In this case, ensure that no solvent enters the bearings!
- ► The mounting dimensions are standard dimensions in accordance with IEC 34.
- ► Attach transmission elements:
  - shocks and impacts must be avoided! They could destroy the motor.
  - use the centre bore in the motor shaft in accordance with DIN 332, design D.
  - tolerances of the shaft ends:
  - $\leq \emptyset$  50 mm: ISO k6, >  $\emptyset$  50 mm: ISO m6.
- Dismounting must only be carried out with an extracting device.
- ▶ When using belts for torque / power transmission:
  - check the belt tension
  - observe the permissible radial forces specified in the catalogue.

### Lenze

#### 4.3 Mounting of motors on gearboxes with mounting flange (drive-end version N)

- 4.3.1 Important notes
  - Stop!
    - ► In the case of impact load or load alternation, use a coupling hub with a clamping hub or clamping ring hub.
    - ► If necessary, replace the featherkey of the motor with a shorter featherkey (□ Tab. 1).
    - ► The motor shaft should not be exposed to knocks during assembly.
  - 1. Fasten coupling hub with mounting dimension "m" as shown in Tab. 1, the motor shaft must not be exposed to knocks!
  - 2. Connect the motor and the gearbox to the spider.
  - 3. Fasten motor.



- Fig. 1 Drive-end version N
  - A Spider
  - B Coupling hub

4

### 4 Mechanical installation

Mounting of motors on gearboxes with mounting flange (drive-end version N) Installation data

### 4.3.2 Installation data

Lenze motor			Moto	r shaft	Featherkey <sup>1)</sup>	Drive size	Mounting dimension		
MDXKX	MDFQA	MDXMA	МСА	MCS	d [mm]	lmax. [mm]	DIN 6885/1 [mm]		m [mm]
MDSKS 036		MDXMA 063		MCS 06	11	23		1A	23
MDSKX 056		MDXMA 071	MCA 10		14	30	2)	1B	30
MDSKS 036		MDXMA 063			11	23		2B	23
MDXKX 071		MDXMA 080	MCA 13	MCS 06	19	40	B6x6x16	1C	25
					14	40		2C	25
MDSKX 056		MDXMA 071	MCA 10		14	40	B 5 x 5 x 16	3C	25
		MDXMA 071		MCS 09	14	40		4C	25
MDXKA 080 MDXKA 090		MDXMA 090	MCA 14 MCA 17		24	50	2)	1D	50
MDXKX 071			MCA 13	MCS 12	19	40-50		2D	50
MDXKA 100		MDXMA 100 MDXMA 112	MCA 19		28	30-60		1E	30
MDXKA 080 MDXKA 090		MDXMA 090	MCA 14 MCA 17		24	30-60	B 8 x 7 x 18	2E	30
				MCS 14	24	50		2E with flange	50
MDXKX 071		MDXMA 080	MCA 13	MCS 12	19	30-60	B6x6x18	ЗE	30
MDXKA 100		MDXMA 100 MDXMA 112	MCA 19	MCS 12	28	30-60		1F	30
MDXKA 080 MDXKA 090		MDXMA 090	MCA 14 MCA 17		24	30-60	B 8 x 7 x 18	2F	30
				MCS 14	24	50		2F with flange	50
MDXKA 112	MDFQA 100 MDFQA 112	MDXMA 132	MCA 21		38	80	2)	1G	80
MDXKA 100			MCA 19	MCS 19	28	60	2)	2G	60
					38	80		3G	80
		MDXMA 160			42	110		1H	110
		MDXMA 180			48	110	2)	2H	110
MDXKA 112	MDFQA 100 MDFQA 112	MDXMA 132	MCA 21		38	80		ЗH	80
	MDFQA 132 MDFQA 160	MDXMA 200			55	110	2)	1K	110
		MDXMA 225			60	140		2K	140

Tab. 1

Mounting data for motors on gearboxes with mounting flange

1) Featherkey required when mounting with standard or clamping hub

<sup>2)</sup> Use original featherkey for motor!

#### 4.3.3 Tightening torques

Drive size	Standard hub Locking screw	Clampi Termina	ng hub al screw	Clamping Clampir	; ring hub ig screw	
	Thread [mm]	Thread [mm]	Tightening torque [Nm]	Thread [mm]	Tightening torque [Nm]	
1A	M4	M3	1.3	М3	1.3	
1B					1.5	
2B	///4	1015	1.5	1015	1.5	
1C						
2C	AAF	146	10 5		2.0	
3C	1015	INIO	10.5	///4	2.9	
4C						
1D	AAF	M4	2.9			
2D	1015	M6	10.5	M4	2.9	
1E						
2E	A4F	M6	10.5	Μ5	6	
2E with flange	IN15					
3E						
1F		M6	10.5	M5	6	
2F	M5					
2F with flange						
1G						
2G	M6	M8	25	M5	6	
3G						
1H		M10				
2H	M8		69			
3H						
1K		1110	<u> </u>	M8	35	
2К	IVI8	MIO	69			

Tab. 2Tightening torques of hub connections

#### 4.3.4 Mounting the standard hub / clamping hub

- Mounting the motor featherkey (2).
   When using drive sizes □C, □E, □F, mount the featherkey that is provided.
- 2. Push the coupling hub onto the motor shaft observing mounting dimension m.
- 3. Secure the coupling hub against axial movement using the locking screw or terminal screw (1).
- 4. Place spider (ring gear) in the coupling claw at the gear end.
- 5. Align the coupling hub at the motor side with the counterpart.
- 6. Slowly slide on motor and fasten to the flange of the gear unit.

### Lenze

Mounting of motors on gearboxes with mounting flange (drive-end version N) Mounting the clamping ring hub

### 4.3.5 Mounting the clamping ring hub



- 1 Clamping ring hub
- 2 Clamping ring
- 3 Clamping screw (DIN912)
- 1. Push coupling hub onto the motor shaft observing mounting dimension "m" (see Fig. 2 and Tab. 1).
- 2. Align hub and slightly tighten clamping screws.
- 3. Tighten screws evenly and crosswise using a torque spanner until all clamping screws have been tightened to the specified tightening torque.
- 4. Place spider (ring gear) in the coupling claw at the gear end.
- 5. Align the coupling hub at the motor side with the counterpart.
- 6. Slowly slide on motor and fasten to the flange of the gear unit.

#### 4.3.6 Dismounting the clamping ring hub

- 1. Gradually and evenly loosen the clamping screws.
- 2. Remove the screws next to the jacking screw threads and screw these into thread that is provided only tightening the screws slightly.
- 3. When the screws in the jacking screw threads are gradually and evenly tightened crosswise the clamping ring will be pushed off the conical clamping ring hub.
- 4. All contact surfaces including the threads and head contact areas of the clamping screws should be cleaned and oiled slightly prior to reassembly.

5

### 5 Electrical installation



Electrical connections must be carried out in accordance with the national and regional regulations!

Important notes

#### 5.1 Important notes



### Danger!

Hazardous voltage at the power terminals, even if the plug is removed: residual voltage > 60 V!

Before working at the power terminals, disconnect the drive controller from the mains and wait until the motor stands still (voltage at the contact while the motor is turning).

General information		<ul> <li>Observe the notes in the terminal box of the motor.</li> <li>Make sure that the terminal bridges and arranged correctly.</li> <li>Tighten all screw connections.</li> <li>Connect PE conductor to earthing screw.</li> <li>Use a strain relief for the connecting cable.</li> <li>The motor must be earthed carefully.</li> </ul>
Voltage supply	Servo motors	<ul> <li>Servo motors must be supplied by servo inverters.</li> <li>Connect the integrated encoder at the motor side with the corresponding connections of the servo inverter.</li> </ul>
	Holding brake (optional)	<ul> <li>DC supply in accordance with nameplate on brake or AC supply via upstream rectifier (only spring-operated brakes, PM brakes 205 V <sup>1).</sup></li> <li>Brakes for 205 V can be fed from the 230 V mains via bridge rectifiers, brakes for 103 V from the 115 V mains.</li> <li>Brakes must not be supplied from AC mains using half-wave rectifiers.</li> </ul>
Inverter operation		<ul> <li>Observe the connection information in the corresponding operating instructions.</li> <li>Make sure that the motor and inverter are correctly assigned.</li> <li>Special attention must be paid to the speed limit and the winding load.<sup>2)</sup></li> </ul>
Cable cross-section		<ul> <li>Connecting cables must be correctly dimensioned to ensure that no impermissible heating occurs.</li> <li>Adhere to the minimum cross-section in acc. with DIN 57100 and fuse appropriately.</li> </ul>
Motor protection	Protection against overload	<ul> <li>Standard current-dependent motor protection switches for average switching         <ul> <li>Setting to the rated current indicated on the nameplate.</li> </ul> </li> <li>For very high switching rates: use Lenze three-phase AC motors with thermal switches or PTC thermistors in the winding.         <ul> <li>The thermal switches are integrated in the winding as NO contact or NC contact. The response temperature is permanently set.</li> </ul> </li> </ul>
	Motor supply cable	<ul> <li>No protection possible through the overtemperature protector switch or PTC thermistor of the motor winding         <ul> <li>Take measures according to DIN 57100 / VDE 0530.</li> </ul> </li> </ul>
	Inverter operation	<ul> <li>The current or voltage conversion can increase the output current significantly above the input current.</li> <li>The motor supply cable cannot be fused via the mains input fuses of the inverter. Take measures according to DIN 57100 / VDE 0530.</li> </ul>

1) Supply PM brakes for 24 VDC only with smooth DC voltage (ripple  $\leq 1\%$ )

2) Voltage limits: 1.5 kV peak value, 5 kV/µs rate of rise; further information: 🕮 catalogue.



### Stop!

The bore holes in the terminal box are closed with plugs to enhance protection during transport. These must be replaced with screw fittings or blanking plugs to meet the requirements of the protection type.

In the case of MCS motors, the openings are cast closed and can be opened by the customer as required.

Motor type	Power co	nnection	Encoder/fan connection
	Screwed connections	Connection terminal	Screwed connections
MDSK 056 / MCA 10			
MDSK 071 / MCA 13		0.00 25 mm <sup>2</sup>	
MDSK 080 / MCA 14	1 X M20 X 1.5 + 1 X M16 X 1.5	0.08 2.5 mm²	
MDSK 090 / MCA 17			1 X M20 X 1.5 + 1 X M16 X 1.5
MDSK 100 / MCA 19			
MDSK 112 / MCA 21	1 x M32 x 1.5 + 1 x M25 x 1.5	0.2 10 mm <sup>2</sup>	
MCS 09; MCS 12; MCS 14D, MCS 14H; MCS 14L15; MCS 14P14; MCS 19F15; MCS 19J15	2 x M20 + 2 x M25 + 2 x M32	0.08 2.5 mm <sup>2</sup> (4 mm <sup>2</sup> without wire end ferrule)	In the case of MCS motors only one terminal box is used for
MCS 14L32; MCS 14P32; MCS 19F30; MCS 19J30; MCS 19P		0.2 10 mm <sup>2</sup>	power and encoder
	Power con	nnection	Fan connection
	Screwed connections	Connection studs	Screwed connections
MDFQA 100	1 x M40 x 1.5 + 1 x M20 x 1.5 + 1 x M16 x 1.5	M6	1 x M16 x 1.5
MDFQA 112	1 x M50 x 1.5 + 1 x M20 x 1.5 + 1 x M16 x 1.5	M8	1 x M16 x 1.5
MDFQA 132	1 x M63 x 1.5 + 1 x M50 x 1.5 + 2 x M16 x 1.5	M12	1 x M16 x 1.5
MDFQA 160	2 x M63 x 1.5 + 1 x M16 x 1.5	M12	1 x M20 x 1.5

#### Power connections and connection studs when mounting terminal box

Tab. 3Power connections and connection studs

#### 5.1.1 EMC-compliant wiring

The EMC-compliant wiring of the motors is described in detail in the operating instructions of the Lenze servo inverters 9300 and ECS.

- Utilisation of EMC screwed metal connections with shield connection or extensive shield connection on the corresponding surfaces in the terminal box (MCS).
- ► Shield connection on the motor and on the device.

### **Electrical installation**

Motor connection Servo motors MDXK 036 ... 090, MDXK 100 ... 112, MCS 06 ... 19, MCA 10 ... 21

### 5.2 Motor connection

- Stop!
  - ► Tighten coupling ring of connector.
  - ► Also add O-ring in the event of vibrations:
    - power connection MDXK 036...090:
    - power connection MDXK 100...112:
    - encoder, fan connection, MDXK:

PE conductor

Power phase U

Power phase V

Power phase W

- power connection MCA and MCS:
- O-ring 18 x 1.5 mm O-ring 27 x 4 mm O-ring 18 x 1.5 mm O-ring already installed O-ring already installed
- encoder, fan connection MCA and MCS:
- Do not disconnect from the mains when the machine is energised! The plug could be destroyed! Inhibit the controller before disconnecting from the mains.

### 5.2.1 Servo motors MDXK 036 ... 090, MDXK 100 ... 112, MCS 06 ... 19, MCA 10 ... 21

Connector	(external view of poles)		Size	1.0; M23
Pin	Mear	ning	MDXK 036 090, MCS 06 19, MCA 10 17	MDXK 100 112 without UR approval
1 2	Y1 / BD1 Y2 / BD2	Holding brake + Holding brake -	6	
٢	PE	PE conductor	2 4	$\begin{pmatrix} 3 & 1 \\ 0 & 0^6 & 0 \end{pmatrix}$
4 5	U V	Power phase U Power phase V		400
6	W	Power phase W	1 5	5-
Connector	(external view of poles)		Size	1.5; M40
Pin	Mear	ning	MDXK 100 112, M	CS 14 19, MCA 19 21
+ -	Y1 / BD1 Y2 / BD2	Holding brake + Holding brake -	V	+



Terminal b	ox		
Terminal	I	Meaning	MDXK 036 112, MCS 09 19, MCA 10 21
U V W	U1 V1 W1	Motor winding phase U Motor winding phase V Motor winding phase W	
Y1 / BD1 Y2 / BD2	+ -	Holding brake	
S1 / TB1 S2 / TB2		Thermostat (NC contact)	
T1 T2	+ KTY -KTY	Temperature sensor KTY	
P1 / TP1 P2 / TP2	PTC PTC	PTC thermistor	

٢

U

٧

W

PE

U

۷

W



A Brake control

### 5.2.3 Servo motors MDFQA 100/112/132/160, three-phase AC motors MDXMA

Terminal box				
Terminal		Meaning	MDFQA 100	MDFQA 112/132/160, MDXMA
1 2 3	U1 V1 W1	Motor winding phase U Motor winding phase V Motor winding phase W	4 ○ 5 ○ 6 ○ 1 ○ 2 ○ 3 ○ ↓ PE ⊕ (U1) (V1) (W1)	Star connection $ \begin{array}{c} (U2)  (V2)  (W2) \\ 4  5  6 \\ 1  2  3  1 \\ PE(\pm)  (U1)  (V1)  (W1) \end{array} $
Ð	PE	PE conductor for motor housing	L1 L2 L3	L1 L2 L3 Delta connection
S1 / TB1 S2 / TB2		Thermostat (NC contact)	<u>_</u>	$PE \oplus (U1) (V1) (V1) (V1) (V1) (V1) (V1) (V1) (V$
T1 T2	+ KTY -KTY	Temperature sensor KTY	S1          S2          T1          T2	S1           S2           T1           T2

5

### 5.3 Fan connection

#### MDXKX 071 ... 112

Connector (exte	ernal view of poles)		
Pin	Mea	aning	Size 1.0; M23
1		Not assigned	
2	PE	PE conductor	PO OC
3 4		Not assigned	$\left( \begin{array}{c} O_{A} \\ O_{A} \\ O_{A} \end{array} \right)^{4} DO \right)$
A B	L1 N	Winding - fan	$10_{2}O_{\pm}O^{3}$
C D		Not assigned	K33.0018/4

### MCA 13 ... 21

Connector (external view of poles)			Size M17
Pin	Meani	ng	
Ð	PE	PE conductor	
1 2	L1 N	Winding - fan	A O O 2 O 3 O 2 N

#### **Electrical installation** 5 Feedback connection **Resolver connection**

#### **Feedback connection** 5.4

#### **Resolver connection** 5.4.1

Connector (exte	ernal view of po	les)	
Pin		Meaning	Size 1.0; M23
1 2	+ Ref - Ref	Transformer winding (Reference winding)	
3	+VCC ETS	Supply: electronic nameplate <sup>1)</sup>	$ \begin{array}{c} 2 \bigcirc \bigcirc \bigcirc \bigcirc 7 \\ \bigcirc \bigcirc \bigcirc p \oslash 0 \\ 3 & 10 & 0 \\ 11 & 0 \\ 4 \oslash & 05 \end{array} $
4 5	+ Cos - Cos	Stator windings cosine	
6 7	+ Sin - Sin	Stator windings Sine	
8 9 10		Not assigned	0° coded
11 12	+ KTY -KTY	Temperature sensor KTY	

Terminal box					
Terminal		Meaning			
T1 T2	+ KTY -KTY	Temperature sensor KTY			
S1 S2		Thermostat (NC contact)	T2         I         I           S1         I         I		
B1 B2	+ Ref - Ref	Transformer winding (reference winding)			
B3	+ VCC ETS	Supply: electronic nameplate <sup>1)</sup>		B7 O D	
B4 B5	+ Cos - Cos	Stator winding cosine			
B6 B7	+ Sin - Sin	Stator winding sine		<b>B1</b> O	
B8		Not assigned			
U1 U2	L1 N	Separate fan			
Y2 <sup>2)</sup> / BD2 Y1 <sup>2)</sup> / BD1	-+	Holding brake	Y1 💷 🗆		

1) 2) Only for versions with electronic nameplate ETS.

When using the version "with an integrated rectifier" the voltage supply for the brake is applied directly to the rectifier. The terminals Y1 and Y2 are not provided in this version.



#### 5.4.3 Sin-Cos absolute value encoder

Connector (exte	ernal view of po	les)	
Pin		Meaning	Size 1.0; M23
1	В	Track B / + SIN	
2 3	Ā	Track A inverse / - COS Track A / + COS	
4 5	+ 5 V GND	Supply + 5 V / + 8 V Earth	$\begin{pmatrix} 2 & 10 & 0 & 6 \\ 0 & 0 & 12 & 6 \\ 11 & 0 & 0 \end{pmatrix}$
6 7	Z Z	Zero track inverse / - RS485 Zero track / + RS485	
8		Not assigned	
9	B	Track B inverse / - SIN	20° coded
10		Not assigned	
11 12	+ KTY -KTY	Temperature sensor KTY	

### 5 Electrical installation Feedback connection Connection incremental encoder / SinCos encoder

Terminal box			
Terminal		Meaning	
T1 T2	+ KTY -KTY	Temperature sensor KTY	
B1 B2	+ 5 V GND	Supply + 5 V / + 8 V Earth	
B3 B4	A A	Track A / + COS Track A inverse / - COS	T2        B7
B5 B6	B B	Track B / + SIN Track B inverse / - SIN	
B7 B8	Z Z	Zero track inverse / - RS485 Zero track / + RS485	B3 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
B10	Shield for housing	Shield for incremental encoder	B2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
U1 U2	L1+ N	Separate fan	

### 5.4.4 Connection incremental encoder / SinCos encoder



T1
T2
B7
B7
B6
B5
B4
B3
B2
B1

Size 1.0; M23

#### 5.4.5 Sin-Cos absolute value encoder with EnDat interface

MCS connector	(external view o	f poles)
Pin		Meaning
1	UP sensor	Supply UP sensor
2 3		Not assigned
4	0V sensor	Supply 0V sensor
5 6	+ KTY -KTY	Temperature sensor KTY
7	+ 5 V	Supply +5V / +VCC ETS <sup>1)</sup>
8 9	Clock pulse Clock pulse	Clock pulse EnDat interface Clock pulse inverse EnDat interface
10	GNG	Supply 0V / earth
11	Shield	Shield for housing of encoder
12 13	B B	Track B / + SIN Track B inverse / - SIN
14	Data	Data EnDat interface
15 16	A A	Track A / + COS Track A inverse / - COS
17	Data	Data inverse EnDat interface

1) Only for versions with electronic nameplate ETS.

Terminal box					
Terminal		Meaning			
T1 T2	+ KTY -KTY	Temperature sensor KTY			
B1	+5V	Supply +5V / +VCC ETS <sup>1)</sup>			
B2	GNG	Supply 0V / earth		B20 🔾 🗌	<b>D B20</b>
B3 B4	AAA	Track A / + COS Track A inverse / - COS		B21   B22   B22	□ ○ B21 □ ○ B22
B5 B6	B B	Track B / + SIN Track B inverse / - SIN			
B7 B8	Data Data	Data EnDat interface Data inverse EnDat interface	B6 B7		
B20 B21	Clock pulse Clock pulse	Clock pulse EnDat interface Clock pulse inverse EnDat interface	B8 B10 B23		
B22	UP sensor	Supply UP sensor	B20 □ □		
B23	0V sensor	Supply 0V sensor	B24 🗆		
B24	Shield	Shielding for housing of encoder	B21 □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □	B3 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	B3
B25		Not assigned	B22		
U1 U2	L1+ N	Separate fan			

1) Only for versions with electronic nameplate ETS.

### 6 Commissioning

#### 6.1 Before switching on

Before the initial commissioning, before commissioning after an extended standstill time or before commissioning after an overhaul of the motor, you must check the following:

- ► Are all screwed connections of the mechanical and electrical parts firmly tightened?
- ► Is the unrestricted cooling-air inlet and outlet ensured?
- ► Are the protective devices against overheating (thermal sensor evaluation) effective?
- ► Are the electrical connections o.k.?
- ► Does the motor connection have the correct phase sequence?
- Are rotating parts and surfaces, which can become very hot, protected against touching?
- ► Is the permanent lubrication connected?

Danger! Built-in brakes are <u>not fail-safe brakes</u>!

6

#### 6.2 **Parameter setting**

### Stop!

The integrated thermal sensor does not prevent overload under all conditions! At commissioning, reduce the maximum current, e.g. to the rated current of the motor!

Perform function block interconnection (servo inverter 9300) or I<sup>2</sup>xt monitoring (servo inverter ECS) with disconnection after several seconds of operation with I>I<sub>N</sub>, particularly in case of danger of blocking.

- Commission the drive system according to the operating instructions of the drive controller.
  - Entering motor data, parameter setting via Global Drive Control
  - Parameter setting of motor temperature detection (is carried out automatically with parameter setting via GDC)
  - Specifying feedback system for speed and position control
  - Selecting the operating mode (control structure)
  - Entering machine data
  - Optimising the drive behaviour, if necessary (optimisation of current, speed, field and field-weakening control; observe the notes below!).

STOP

### Stop!

The parameter data that are set via GDC are used as default setting and must be optimised specific to each application!

#### 6.2.1 Servo controller 9300

The input variable of the current controller is normalised to the maximum device current Imax. device. This allows the maximum device current to directly influence the current controller gain Vp. If a smaller or larger device is used after the current controller adjustment, the current controller must be adjusted again or the Vp must be matched.

The input and output variables of the speed controller are normalised to the maximum current I<sub>max.</sub> (C0022) and the maximum speed n<sub>max.</sub> (C0011). This allows C0022 and C0011 to directly influence the gain of the speed controller Vpn.

- The following applies to the servo controller 9300:
  - Vp proportional Imax. device
  - Vpn proportional n<sub>max.</sub> (C0011)
  - Vpn proportional 1/I<sub>max</sub> (C0022)

Parameter setting Servo controller ECS

### 6.2.2 Servo controller ECS

The input and output variables of the speed controller are normalised to the maximum current  $I_{max.}$  (C0022) and the maximum speed nmax. (C0011). This allows C0022 and C0011 to directly influence the gain of the speed controller Vpn.

- ► The following applies to the servo controller ECS:
  - Vpn proportional n<sub>max.</sub> (C0011)
  - Vpn proportional 1/I<sub>max.</sub> (C0022)

#### 6.2.3 Parameter setting of motor temperature detection



- Integrated overload protection does not prevent overloading under all conditions!
- ► Limit maximum current to required value!

The motor winding temperature is monitored by temperature sensors.

#### 6.2.4 Parameterisation of the temperature sensor 9300 / ECS

- ► MCS06
  - C1190 = 0 (Standard, KTY83-110)
- ▶ MCS09/12/14/19
  - C1190 = 1 (Characteristic, KTY83-110 + PTC150)
  - -C1191/1 = 30
  - -C1191/2 = 145
  - -C1192/1 = 1180
  - C1192/2 = 2460
- MDXKX, MDFQA, MDXMA

-C1190 = 0

#### 6.3 Function block interconnection servo inverter 9300

### STOP Stop!

Perform function block interconnection (servo inverter 9300) or  $I^2xt$ monitoring (servo inverter ECS) with disconnection after several seconds of operation with  $I > I_N$ , particularly in case of danger of blocking.

Example of function block interconnection for MCS06F41





Display:

- Input value of PT1: C0642
- Output value of PT1: C0689/1
- Limit value: C0689/2

Calculation of limit value (FCODE 0472/1):

FCODE472/1 = $(I_o \cdot \frac{1}{1} \cdot 1.05)^2 \cdot 100$	I <sub>o</sub> [A]	Standstill current of motor
Imax	I <sub>max</sub> [A]	Maximum current set in code C0022

Factor 1.05: for consideration of manufacturing tolerances and reaching the standstill torque; disconnection at  $1>1.05*I_0$ 

Time constant PT1: C0640 (currently 30 s)

### 6.4 Parameterisation of function block interconnection

Basis for this function block interconnection is the configuration 1000 or 1010 (speed control).

Parameter setting arithmetic block ARIT1					
Code	Setting	Signal	Assignment	Meaning	
C0338	3	ARIT1 FUNCT	OUT = IN1*IN2	Multiply input signals	
C0339/1	5004	ARIT1-IN1	MCTRL-IACT	Input signal = motor current	
C0339/2	5004	ARIT1-IN2	MCTRL-IACT		

Parameter setting PT1 element PT1-1					
Code	Setting	Signal	Assignment	Meaning	
C0640	30 s	DELAY T	Time constant = 30 s		
C0641	5500	IN	ARIT1-OUT	Input signal = output from ARIT1	

Parameter setting for the limit value in FCODE472/1

Code	Setting		Meaning
C0472/1	FCODE472/1 = $(\overline{I}$	$\frac{I_0}{\max} \cdot 1.05 \right)^2 \cdot 100 \%$	The factor 1.05 is a starting value for commissioning. This value may need to be adjusted to achieve the standstill torques and maximum
	I <sub>0</sub> [A]	Standstill current of the motor	
	I <sub>max</sub> [A]	Maximum current from C0022	torques.

#### Parameter setting comparator CMP2

	5 1			
Code	Setting	Signal	Assignment	Meaning
C0685	5	FUNCTION	In1  >  IN2	Compare I <sup>2</sup> xt value with limit value
C0686	1.00 %	HYSTERESIS	Hysteresis = 1 %	Hysteresis of the output signal
C0687	1.00 %	WINDOW	Window = 1 %	Window for the output signal
C0688/1	5900	IN1	PT1-1-OUT	Input signal 1 = output from PT1-1 (l <sup>2</sup> xt value)
C0688/2	19521	IN2	FCODE-0472/1	Input signal 2 = FCODE472/1 (limit value)

Parameter setting OR logic OR1				
Code	Setting	Signal	Assignment	Meaning
C0830/1	10665	IN1	CMP2-OUT	Input signal 1 = output from CMP2
C0830/2	54	IN2	DIGIN4	Input signal 2 = digital input E4
C0830/3	1000	IN3	FIXED0	Input signal 3 = "logical 0"

Parameter setting for the error input in the device control DCTRL					
Code	Setting	Signal	Assignment	Meaning	
C0871	10550	TRIP-SET	OR1-OUT	TRIP is triggered if the I <sup>2</sup> xt monitoring has tripped or there is an external fault on E4	

6

Enter function	blocks used	in the	processing table	
Enter runction	biotics asca		processing table	

Code	Setting	Function block
C0465/32	5500	ARIT1
C0465/34	5900	PT1-1
C0465/35	10655	CMP2
C0465/36	10550	OR1

#### 6.5 Functional test

- Check all functions of the drive after commissioning:
  - Direction of rotation of the motor
     If the motor does not rotate in the correct direction, exchange two phases.
    - Torque behaviour and current consumption
  - Function of the feedback system
- ► In case of malfunctions or faults: □ Ch. 8.

### 7 During operation

Perform regular inspections during operation. Check the drives approx. every 50 operating hours. Pay particular attention to:

- Unusual noises
- ► Extremely hot surfaces (temperatures of 140°C can occur during normal operation).
- ► Oil spots on drive or leakage
- ► Irregular running
- ► Increased vibration
- ► Loose fixing elements
- ► Condition of electrical cables
- ► Impeded heat dissipation
  - Deposits on the drive system and in the cooling channels

In case of irregularities or faults: 🕮 Ch. 8.

### 8 Troubleshooting and fault elimination

If faults occur during the operation of the drive system:

- ► First check the possible causes of malfunction according to the following table.
- Also observe the corresponding chapters in the operating instructions to the other components of the drive system.

If the fault cannot be remedied using one of the listed measures, please contact the Lenze Service.



### Danger!

- ▶ Perform all work at the drive system only in the deenergised state!
- ▶ Hot motor surfaces, up to 140 °C. Observe cooling times!
- ▶ Remove the load from the motors or secure loads acting upon the drive!

Fault	Cause	Remedy
Motor too hot	Motor is designed for star connection but is connected in delta	Correct connection
Measurement required; permissible surface temperatures: • non-ventilated motors up to 140 °C • forced or self-ventilated motors up to 110 °C	Mains voltage is more than 10 % higher or lower than the rated motor voltage. A higher voltage is extremely unfavourable for motors with many poles as the idling current of these motors almost reaches the rated current, even at normal current.	Ensure appropriate mains voltage
	Insufficient cooling air, blocked air ducts.	Ensure unimpeded circulation of cooling air
	Prewarmed cooling air	Ensure a sufficient supply of fresh cooling air
	Overload, with normal mains voltage the current is too high and the speed too low	Use larger drive (determined by power measurement)
	Rated operating mode exceeded (S1 to S8 DIN 57530)	Adjust rated operating mode to the specified operating conditions. Determination of correct drive by expert or Lenze customer service
	Loose contact in supply cable (temporary single-phase operation!)	Tighten loose contact
	Fuse blown (single-phasing!)	Replace fuse

## Troubleshooting and fault elimination

Fault	Cause	Remedy
Motor does not start	Voltage supply interrupted	<ul> <li>Check error message at drive controller</li> <li>Check electrical connection (Ш Ch. 5)</li> </ul>
	Controller inhibited	<ul> <li>Check display at drive controller</li> <li>Check controller enable</li> </ul>
	Fuse is blown	Replace fuse
	Motor protection responded	Check motor protection for correct setting and adjust it
	Motor contactor does not engage, fault in the control	Check control of motor contactor and remove fault
	Resolver cable is interrupted	<ul> <li>Check error message at drive controller</li> <li>Check resolver cable</li> </ul>
	Brake does not release	Check electrical connection
		Check air gap (see Brake operating instructions)
		Check continuity of magnetic coil
	Drive is blocked	Check components for easy movement, remove foreign bodies if necessary
	Motor cable polarity is reversed	Check electrical connection
Motor stops suddenly and does not start again	<ul> <li>Polarity reversal of motor cable</li> <li>or</li> <li>polarity reversal of resolver</li> </ul>	<ul> <li>Connect the phases at the motor cable connection correctly and</li> <li>connect the encoder correctly</li> </ul>
	Overtemperature protector switch is activated	<ul> <li>Let motor cool down</li> <li>Reduce load caused by longer acceleration times</li> </ul>
	Overload monitoring of the inverter is activated	<ul> <li>Check settings on controller</li> <li>Reduce load caused by longer acceleration times</li> </ul>
Wrong direction of rotation of the motor, correct display at controller	Reversed motor cable and resolver cable	<ul> <li>Swapping two phases of the motor cable</li> <li>and</li> <li>+COS/-COS connections of the resolver connection</li> </ul>
Motor rotates normally but does not reach the expected torque	Motor cable cyclically interchanged	Connect the phases at the motor cable connection correctly
Motor rotates uncontrolled in one direction at maximum speed	Motor cable is cyclically interchanged or polarity reversal of resolver cable, e.g. connections +Ref/-Ref	Check motor connection for resolver connection
Motor rotates slowly in one direction and cannot be influenced by the controller (only in the case of the asynchronous motors MDXKA, MDFQA, MDXMA)	Polarity reversal of motor or resolver cable	<ul> <li>Swap two phases of the motor cable</li> <li>or</li> <li>the +COS/-COS connections of the resolver</li> </ul>
Motor does not rotate, gearbox output is not	Defective wheel-hub connection	Check the connection, replace the featherkey, if necessary, repair by the manufacturer
running	Toothing worn out	Repair by the manufacturer
Uneven running	Insufficient shielding of motor or resolver cable	Check shielding and earthing (🕮 Ch. LEERER MERKER)
	Drive controller gain too large	Adjust the gains of the controllers (see Drive controller operating instructions)
Vibrations	Insufficiently balanced coupling elements or machine	Rebalance
	Inadequate alignment of drive train	Realign machine, if necessary, check foundation
	Loose fixing screws	Check screwed connections and tighten if necessary
Running noises	Foreign bodies inside the motor	Repair by manufacturer, if necessary
	Bearing damage, spindle damage	Repair by manufacturer, if necessary
Surface temperature > 140 °C	Overload of drive	<ul> <li>Check overload and reduce through longer acceleration times, if necessary</li> <li>Check winding temperature (III Ch. 9.2.2)</li> </ul>
	Heat removal restricted due to deposit build-up	Clean surface and cooling ribs of the drives

Lenze

8

### 9 Maintenance/repair

#### 9.1 Maintenance intervals

- ► In general, the motors are maintenance-free.
- ▶ Wear only occurs on the bearings and shaft sealing rings.
  - Check bearings for running noise (at latest after approx. 15000 h).
  - Check shaft sealing ring (at latest after approx. 2500 h): oil leakage on the motor between the flange and the housing? If necessary, replace after 2500-3000 operating hours.
- ► To avoid overheating, remove deposits from the drives at regular intervals.
- ► It is recommended to regularly perform an inspection after approx. 50 operating hours. This allows for early identification and elimination of irregularities or faults.

#### 9.2 Maintenance operations



### Stop!

- ► Ensure that no foreign particles can gain access to the inside the motor!
- ► Ensure that the drive system is deenergised before working on it!
- Disconnect drives from the mains!
- ► Hot motor surfaces, up to 140 °C. Observe cooling times!
- ► Unload motor or secure loads that are applied to the drive!
- ► Never disconnect from the mains when energised!

### 9 Maintenance/repair

Maintenance operations Adjustment of the resolver using synchronous servo motors/rotor position adjustment

#### 9.2.1 Adjustment of the resolver using synchronous servo motors/rotor position adjustment

The factory settings of the Lenze resolver ensure trouble-free operation without adjustment at the controller.

If the resolver is in the wrong position, e.g. after working on the motor, it will have to be realigned or the rotor will have to be adjusted via the controller.

- ► For the **rotor adjustment**, the motor must be free of load and able to rotate with the controller (□ operating instructions of controller). The rotor adjustment is saved in the controller and only applies for the respective motor-controller combination.
- Resolver adjustment
- 1. If necessary, release the brake and free end of motor shaft.
- 2. Connect the resolver to the drive controller and determine current rotor position (Deperating instructions for drive controller).
- 3. Allow DC current (< I<sub>N</sub> of motor) to flow from phase V (positive connection) to phase W (negative connection), phase U is without current.
- 4. Turn the resolver stator so that the controller displays the rotor position "0".
- 5. Fasten the resolver stator in this position.

#### 9.2.2 Temperature control for servo motors

You must determine the actual winding temperature at a surface temperature > 140 °C:

- ▶ Measuring method: 4-phase resistance measurement at motor power terminal
- The resistance measurement must be performed as quickly as possible after switching off and stopping the servo motor.

9

#### Procedure

- 1. Inhibit controller.
- 2. Disconnect power connection; in the case of terminal box design, disconnect power supply between inverter and motor.
- 3. Measure the resistance between the following contacts or terminals:
  - Connector size 1.0; M23: pins U $\leftrightarrow$ V, V $\leftrightarrow$ W, W $\leftrightarrow$ U
  - Connector size 1.5; M40: pins  $4 \leftrightarrow 5$ ,  $5 \leftrightarrow 6$  and  $6 \leftrightarrow 4$
  - Terminal box: terminals  $1\leftrightarrow 2, 2\leftrightarrow 3$  and  $3\leftrightarrow 1$  and  $U\leftrightarrow V, V\leftrightarrow W, W\leftrightarrow U$
- 4. The mean value calculated from the three measured values corresponds to twice the phase resistance (star connection).
  - Use the mean value as  $R_1$  and  $R_0$  in the following equation to calculate the winding temperature  $\vartheta_1:$

$\vartheta_1 [°C] = \frac{R_1 \cdot 255}{R_0} - 235$	$\vartheta_1$	Winding temperature during operation
	R <sub>1</sub>	Winding resistance at operating temperature
	R <sub>0</sub>	Winding resistance at 20°C

#### 9.3 Repair

- ► It is recommended to have all repairs performed by Lenze Service.
- Delivery of spare parts is available upon request.

10 Notes

10 Notes

### Lenze

### Lenze



### Lenze worldwide

#### Lenze AG

Postfach 10 13 52 D-31763 Hameln Telefon+49 (0)51 54 / 82-0 Telefax +49 (0)51 54 / 82-28 00 E-Mail: Lenze@Lenze.de Internet: www.Lenze.com

Lenze Drive Systems GmbH Postfach 10 13 52 D-31763 Hameln Telefon +49 (0)51 54/82-0 Telefax +49 (0)51 54/82-28 00

Lenze GmbH & Co KG Anlagenbau Buchenweg 1 D-31855 Aerzen Telefon +49 (0)51 54/82-0 Telefax +49 (0)51 54/82-21 00

Lenze GmbH & Co KG Kleinantriebe Hans-Lenze-Straße 1 D-32699 Extertal Telefon +49 (0)51 54 / 82-0 Telefax +49 (0)51 54 / 82-14 85

Lenze Service GmbH Breslauer Straße 3 D-32699 Extertal

Mechanical Drives Telefon +49 (0)51 54/82-1626 Telefax +49 (0)51 54/82-1396

Electronic Drives Telefon +49 (0)51 54/82-11 11 Telefax +49 (0)51 54/82-11 12

Service Helpline +49 (0)180 5 20 24 26

Lenze Verbindungstechnik GmbH Ipf-Landesstraße 1 A-4481 ASTEN Phone +43 (0)72 24/21 1-0 Telefax +43 (0)72 24/21 1998

Lenze Deto Drive Systems GmbH & Co KG апри & Со KG Gewerbepark Süd 11 A-6330 Kufstein Telefon +43 (0)53 72 / 653 15-200 Telefax +43 (0)53 72 / 653 15-299

LS Automation GmbH & Co KG

Jakob-Stadler-Platz 11 Jakob-Stadler-Platz 11 D-78467 Konstanz Telefon +49(0)7531/94219-0 Telefax +49(0)7531/9421920

encoway GmbH Universitätsallee 21-23 D-28359 Bremen Telefon +49 (0)421/24677-0 Telefax +49 (0)421/24677-10

#### Deutschland Germany

Lenze Vertrieb GmbH Ludwig-Erhard-Straße 52-56 D-72760 Reutlingen Telefon +49 (0)71 21 / 9 39 39-0 Telefax +49 (0)71 21 / 9 39 39-29

Region Nord Dornenpark 1 31840 Hessisch Oldendorf Telefon (0 51 52) 90 36-0 Telefax (0 51 52) 90 36-33/44/55

Region West Postfach 10 12 20 47497 Neukirchen-Vluyn Kelvinstraße 7 47506 Neukirchen-Vluyn Telefon (0 28 45) 95 93 93 Telefax (0 28 45) 95 93 93

Region Mitte/Ost Hegion Mitte/Ost Postfach 1463 35724 Herborn Austraße 81 35745 Herborn Telefon (02772) 95 94-0 Telefax (02772) 530 79

Region Südwest Postfach 14 33 71304 Waiblingen Schänzle 8 71332 Waiblingen Telefon (0 71 51) 9 59 81 - 0 Telefax (0 71 51) 9 59 81 50

**Region Süd** Fraunhoferstraße 16 82152 Martinsried Telefon (0 89) 89 56 14-0 Telefax (0 89) 89 56 14 14

#### weltweit worldwide

ALGERIA see FRANCE

#### ARGENTINA

E.R.H.S.A. Girardot 1368, 1427 BUENOS AIRES Phone +54 (0)11 / 4554 32 32 Telefax +54 (0)11 / 4552 36 11

#### AUSTRALIA

FCR Motion Technology Pty. Ltd. Unit 6, Automation Place 38-40 Little Boundary Rd. LAVERTON NORTH, Vic. 3026 Phone +61 (3) 9382 6800 Telefax +61 (3) 9314 3744

#### AUSTRIA

Lenze Antriebstechnik GmbH Ipf-Landesstraße 1 4481 ASTEN Phone +43 (0)7224/21 0-0 Telefax +43 (0)7224/21 0999

Office Dornbirn: Lustenauer Straße 64 6850 DORNBIRN Phone +43 (0)5572 / 26 789-0 Telefax +43 (0)5572 / 26 789-66

Office Wr. Neudorf: Triester Straße 14/109 2351 WR. NEUDORF Phone +43 (0)2236 / 25333-0 Telefax +43 (0)2236 / 25333-66 Office Graz:

Seering 8 8141 UNTERPREMSTÄTTEN Phone +43 (0)3135 / 56 900-0 Telefax +43 (0)3135 / 56 900 999 Lenze Verbindungstechnik GmbH Ipf-Landesstraße 1 4481 ASTEN Phone +43 (0)7224/211-0 Telefax +43 (0)7224/211998

Lenze Anlagentechnik GmbH Mühlenstraße 3 4470 ENNS Phone +43 (0)7223/886-0 Telefax +43 (0)7223/886-997

BELGIUM 
 Declarow

 Lenze b.v.b.a

 Noorderlaan 133, bus 15

 2030 ANTWERPEN

 Phone +32 (0)3 / 54 26 20 0

 Telefax +32 (0)3 / 54 13 75 4

BOSNIA-HERZEGOVINA see AUSTRIA

#### BRAZIL

AC Control Ltda Rua Gustavo da Silveira 1199 Vila Sta. Catarina SÃO PAULO – S.P. 04376-000 Phone +55 (11) 55 64 65 79 ramal: 214 Telefax +55 (11) 56 79 75 10

BULGARIA

see MACEDONIA

CANADA see USA

#### CHILE

 CHILE

 Sargent S.A.

 Tecnica Thomas C. Sargent

 S.A.C.ć.I., Casilla 166-D

 SANTIAGO DE CHILE

 Phone +56 (0)2 / 51 03 000

 Telefax +56 (0)2 / 69 83 989

#### CHINA

Lenze Mechatronic Drives (Shanghai) Co. Ltd., Section B, Sold B, S Beijing Office Rm. 401, Huaxin Mansion No. 33 An Ding Road Chaoyang District BEIJING 100029 Phone +86-10-64411470 Telefax +86-10-64411467

#### CROATIA

Lenze Antriebstechnik GmbH Predstavnista Zagreb Ulica Grada Gospica 3 HR-1000 ZAGREB Phone +385-1-2498056 Telefax +385-1-2498057

CZECH REPUBLIC

Lenze, s.r.o. Central Trade Park D1 396 01 HUMPOLEC Phone +420 565 507-111 Telefax +420 565 507-399

Büro Červený Kostelec: 17. listopadu 510 549 41 ČERVENÝ KOSTELEC Phone +420 491 467-111 Telefax +420 491 467-166

#### DENMARK

Lenze A/S Vallensbækvej 18A 2605 BRØNDBY Phone +45/46966666 Telefax +45/469666660 24 stunde service +45/40930411 Buero Jylland: Lenze A/S Langhøjvej 1 8381 TILST

Phone +45 / 46 96 66 66 Telefax +45 / 46 96 66 80

EGYPT

WADI Co. for technologies WADI Co. for technologies and development P.O.Box 209, new center Ramses 11794 CAIRO, Egypt 11 Syria St., Mohandessin GIZA, Egypt Phone +20 (2) 347 6842 Telefax +20 (2) 347 6843

ESTONIA see FINLAND

FINI AND Lenze Drives Rykmentintie 2 b 20810 TURKU Phone +35822748180 Telefax +35822748189

FRANCE

Lenze S.A. Siege Z.A. de Chanteloup Rue Albert Einstein 93603 AULNAY-SOUS-BOIS CEDEX

Services Commerciaux Tel. 0 825 086 036 Fax 0 825 086 346

Centre de formation E-Mail : semin.sidonie@lenze.fr

Questions générales / Documentation E-Mail : info@lenze.fr

Service Après-vente / assistance en ligne Helpline 24/24 : 0 825 826 117 E-Mail : helpline@lenze.fr

Agences en France

**Région France Nord :** Z.A. de Chanteloup Rue Albert Einstein 93603 AULNAY-SOUS-BOIS CEDEX Lille 59420 MOUVAUX

Strasbourg 67960 ENTZHEIM

Rouen 76500 ELBEUF

Région France Sud : Rond point du sans souci 69578 LIMONEST Cedex

Toulouse 31400 TOULOUSE

Agen 47270 SAINT-PIERRE DE CLAIRAC

### Lenze worldwide

#### GREECE

 GREECL
 George P. Alexandris S.A.

 12K. Mavromichali Str.
 18545 PIRAEUS

 Phone +30 (0)210/41118415
 Telefax +30 (0)210/4118171

 4127058
 4127058

4127038 183 Monastiriou Str. 54627 THESSALONIKI Phone +30 (0)310/5566504 Telefax +30 (0)310/511815

#### HUNGARY

Lenze Antriebstechnik Handelsgesellschaft mbH 2040 BUDAÖRS Gyár utca 2., P.O.Box 322. Phone +36 (0)23/501-320 Telefax +36 (0)23/501-339

#### ICELAND

see DENMARK

#### INDIA

Electronic Service: National Power Systems, 10, Saibaba Shopping Centre Keshav Rao Kadam Marg, Off Lamington Rd, MUMBAI 400 008 Phone +91 22/2300 5667, 2301 3712 Telefax +91 22/2300 5668 V3 Controls Pvt. Ltd. 1, "Devyani", Next to SBI, Baner ITI Road, Sanewadi, Aundh, PUNE 411 007, MS Phone +91 20 / 25 88 68 62 Telefax +91 20 / 25 88 03 50

Mechanical Service: Emco Lenze Pvt. Ltd. 1st Floor, Sita Mauli Madanlal Dhingra Road Panch Pakhadi, Thane (West) MAHARASHATRA 400.602 Phone +9122/25405488 +9122/25452244 Telefax +9122/25452233

#### INDONESIA

JI: Prof. Dr. Latumenten No. 18 Kompleks Perkantoran Kota Grogol Permai Blok A 35 JAKARTA 11460 Buero 1: Phone +62 (0)21/7664234 Telefax +62 (0)21 / 765 86 23 Telefax +62 (0)21 / 766 44 20 Buero 2: Phone +62 (0)21 / 567 96 31

567 96 32 Telefax +62 (0)21 / 566 87 50

#### IRAN

Tavan Ressan Co. Ltd. P.O.Box. 19395-5177, No. 44, Habibi St., South Dastour St., Sadr EXP'Way, TEHRAN 19396 Phone +98 21 / 2602655 260 67 66 260 92 99 Telefax +98 21 / 200 28 83

#### ISBAEL

Greenshpon Engineering Works LTD Bar-Lev Industrial Park MISGAV 20179 Phone +972 499 13 18 1 Telefax +972 499 13 47 7

#### ITALY

Gerit Trasmissioni S.p.A. Viale Monza 338 20128 MILANO Phone +39 02 / 270 98.1 Telefax +39 02 / 270 98 290

#### JAPAN

Miki Pulley Co., Ltd. 1-39-7 Komatsubara Zama-city KANAGAWA 228-8577 Phone +81 (0)462/581661 Telefax +81 (0)462/5817 04

LATVIA see LITHUANIA

#### LITHUANIA

Lenze UAB Breslaujos g.3 44403 KAUNAS Phone +370 37 407174 Telefax +370 37 407175

#### LUXEMBOURG see BELGIUM

#### MACEDONIA

Lenze Antriebstechnik GmbH Pretstavnistvo Skopje ul. Nikola Rusinski 3/A/2 1000 SKOPJE Phone +389 2 30 90 090 Telefax +389 2 30 90 091

#### MALAYSIA

D.S.C. Engineering SDN BHD 3A & 3B, Jalan SS21/56B 3A & 35, Jalan SS2 //56B Damansara Utama 47400, PETALING JAYA, SELANGOR Phone +60 (0)3 / 772562 46 772865 30 Telefax +60 (0)3 / 7729 50 31

Lenze S.E.A. Sdn Bhd Damansara Technology Park No. 28, Jalan PJU 3/47 47810, PETALING JAYA, SELANGOR

#### MAURITIUS

Automation & Controls Engineering Ltd 3, Royal Road, Le Hochet, Terre Rouge MAURITIUS Phone +230 248 8211 Telefax +230 248 8968

#### MEXICO

Automatización y Control de Energía S.A. de C.V. Av. 2 No. 89 Esq Calle 13 Col. San Pedro de los Pinos C.P. 03800 MEXICO D.F. Phone +52 (55)5277/5938 Telefax +52 (55)5277/5937

#### MOROCCO

GUORFET G.T.D.R Automatisation Industrielle Bd Chefchaouni Route 110 km. 11.500 No. 353-Aîn-Sabaâ CASABLANCA Phone +212/22-357078 Telefax +212/22-357104

#### NETHERLANDS

Lenze B.V., Postbus 31 01 5203 DC'S-HERTOGENBOSCH Ploegweg 15 5232 BR'S-HERTOGENBOSCH Phone +31 (0)73 / 64 56 50 0 Telefax +31 (0)73 / 64 56 51 0

#### NEW ZEALAND

Tranz Corporation 343 Church Street P.O. Box 12-320, Penrose AUCKLAND Phone +64 (0)9 / 63 45 51 1 Telefax +64 (0)9 / 63 45 51 8

#### NORWAY

Dtc- Lenze as Stallbakken 5, 2005 RAELINGEN Phone +47 / 64 80 25 10 Telefax +47 / 64 80 25 11

#### PHILIPPINES

 Prilippines

 Jupp & Company Inc.

 Unit 224 Cityland Pioneer Bldg.,

 Pioneer Street

 MANDALUYONG CITY

 Phone +632/6877423

 683 0042

 683 0047

 Telefax +632/6877421

POLAND Lenze-Rotiw Sp. z o.o. ul. Roździeńskiego 188b 40-203 KATOWICE Phone +48 (0)32 / 2039773 Telefax +48 (0)32 / 7 81 01 80 Lenze Systemy Automatyki Sp. z o.o. UI. Rydygiera 47 87-100 TORUŃ Phone +48 (0)56 / 6 58 28 00 6 45 34 60 6 45 35 70 Telefax +48 (0)56 / 645 33 56

#### PORTUGAL

PORTUGAL Costa Leal el Victor Electronica-Pneumatica, Lda. Rua Prof. Augusto Lessa, 269, Apart. 52053 4202-801 PORTO Phone +351-22/5 508520 Telefax +351-22/5 024005

#### ROMANIA ee AUSTRIA

RUSSIA Inteldrive 1 Buhvostova Street 12/11 Korpus 18 Office 322 MOSCOW 107258 Phone +7 (0)095 / 963 96 86 Telefax +7 (0)095 / 962 67 94

SERBIA-MONTENEGRO see MACEDONIA

SINGAPORE see MALAYSIA

SLOVAC REPUBLIC ECS Sluzby spol. s.r.o. Staromlynska 29 82106 BRATISLAVA Phone +421 2 45259606 +421 2 45643147 +421 2 45643148 Telefax +421 2 45259606

#### SLOVENIA

Lenze pogonska tehnika GmbH Zbiljska Cesta 4 1215 MEDVODE Phone +386 (0)1 361 61 41 Telefax +386 (0)1 361 22 88

#### SOUTH AFRICA

SA. Power Services (Pty.) Ltd. Unit 14, Meadowbrook Business Estates Jacaranda Ave, Olivedale Randburg 2158, P.O.Box 1137 RANDBURG 2125 Phone +27(11) 462-8810 Telefax +27(11) 704-5775

#### SOUTH KOREA

Hankuk Mechatro Ltd. Room# 1409, Samhwan officetel 830-295 Beomil-dong, Dong-Gu PUSAN Phone +82 (0)51-635-6663 Telefax +82 (0)51-635-6632

#### SPAIN

Lenze Transmisiones, S.A. (Headquarter) Milà i Fontanals, 135-139 08205 SABADELL Barcelona Phone +34 937 207 680 Telefax +34 937 120 215

Lenze Delegación Bilbao P.I. Ibarrabarri. Ed. METRO 2°-E 48940 LEJONA

Vizcaya Phone +34 944 630 510/ 507 Telefax +34 944 314 196

Lenze Delegación Levante Cullera, 73 – 4°D 46035 BENIMAMET Valencia Phone +34 963 905 220/335 Telefax +34 963 900 647

Lenze Delegación Madrid Arturo Soria, 187 – Of. 8 28043 MADRID Phone +34 915 103 341 Telefax +34 915 102 061

#### SWEDEN

SWEDEN Lenze Transmissioner AB P.O.Box 10 74, Attorpsgatan, Tornby Ind. 58110 LINKÖPING Phone +46 (0)13 / 355800 Telefax +46 (0)13 / 103623

#### SWITZERLAND

Lenze Bachofen AG Ackerstrasse 45 8610 USTER Phone +41 (0) 43 399 14 14 Telefax +41 (0) 43 399 14 24

Vente Suisse Romande: Route de Prilly 25 1023 CRISSIER Phone +41 (0)21 / 63 72 19 0 Telefax +41 (0)21 / 63 72 19 9

# Stria Zahabi Co. 8/5 Shouhadaa Street P.O.Box 8262 ALEPPO-SYRIA Phone +963 21 21 22 23 5 Telefax +963 21 21 22 23 7

#### TAIWAN

SYRIA

ACE Pillar Co. Ltd. No.12, Lane 61, Sec. 1, Kuanfu Road San-Chung City TAIPEI HSIEN Phone +886 (0)2 / 299 58 40 0 Telefax +886 (0)2 / 299 53 46 6

#### THAILAND

PackSys Global (Thailand) Ltd. 429 Moo 7, Theparak Road, Tambol Theparak Amphur Muang SAMUTPRAKARN 10270 Phone +66 2 383 5633 Telefax +66 2 383 5637

#### TUNESIA

AMF Industrielle Sarl Route de Gremda - Km 0,2 Immeuble El Madina, Centre Bloc B - 5 ème - appt 52 3002 SFAX Phone +21674403514 Telefax +21674402516

#### TURKEY

TURKEY LSE Elektrik Elektronik Makina Otomasyon Mühendislik San. Ve Tic. Ltd. Şti. Atatürk mah. Cumhuriyet cad. Yurt sok. No;7 UMRANIYE/ISTANBUL Phone +90 (0)216 / 3165138 pbx Telefax +90 (0)216 / 443 4277 Bursa Address: Demirtaspasa Mh. Ata Sk. Petek Bozkaya Is Merkezi Ata Sk. Petek Bozkaya Is Merkez D Blok No: 5/A OSMANGAZI / BURSA Phone +90 (0)224-2733232 pbx +90 (0)224-2733238 Telefax +90 (0)224-2733238 Telefax +90 (0)224-2734150

#### UKRAINE SV Altera, Ltd.

Lepse ave., 4 KIEV. 03067 Phone +38 044 496 18 88 Telefax +38 044 496 18-18

#### UNITED ARAB EMIRATES

UNITED ARAB EMIRATES LPT (FZC) Executive Suite X4-37 P.O. Box: 9304, SAIF ZONE SHARJAH AIRPORT INTERNATIONAL FREE ZONE (SAIF ZONE) Phone +971 6 5573205 Telefax +971 6 5573206

#### UNITED KINGDOM/EIRE

Lenze Ltd. Caxton Road BEDFORD MK 41 OHT Phone +44 (0)1234 / 32 13 21 Telefax +44 (0)1234 / 26 18 15

### USA AC Technology Corp. 630 Douglas Street UXBRIDGE, MA 01569 Phone +1 508/278-9100 Telefax +1 508/278-7873

Lenze Corporation 1730 East Logan Avenue EMPORIA, KS 66 801 +1 620/343-8401 +1 888/269-2381 Telefax +1 620/342-2595 +1 800/469-0931

Lenze DETO Drive Systems USA, LLC 5912 Sterling Drive HOWELL, MI 48843 Phone +1517/586-4057 Telefax +1517/586-4058

# CE

Lenze Drive Systems GmbH Hans-Lenze-Straße 1 D-31855 Aerzen Germany

<b>A</b>	+49 (0) 51 54 82-0
🖀 Service	00 80 00 24 4 68 77 (24 h helpline)
🖻 Service	+49 (0) 51 54 82-1112
E-Mail	Lenze@Lenze.de
Internet	www.Lenze.com

BA33.0001 2.0 06/2005 © 2005 TD09

10 9 8 7 6 5 4 3 2 1