
## ECS servo system

for multi-axis applications





No matter which drive solution you imagine, we make your dreams come true.

True to our slogan (one stop shopping) we offer you a complete program of electronic and mechanical drive systems which is distinguished by reliability and efficiency.


The scope of our program includes frequency inverters, servo controllers, variable-speed drives, speed reduction gearboxes, motors, brakes, clutches, decentralised I/O and operator and display units.
























Many well-known companies use Lenze products in various applications.

# **Overview** ECS servo system and accessories



# ECS servo system Dynamic, powerful, compact

Lenze's ECS servo system is the ideal solution wherever high overload capacity for highly dynamic drive tasks is required in conjunction with compact dimensions, fast assembly and problem-free commissioning.

The rugged axis modules, which are supplied with power via the DC bus, provide peak currents up to 64 A. Designs for control cabinet installation, thermal separation (push-through technique), or cold plate mounting support operation in almost any operating conditions. Dedicated software modules ensure optimum adaptation to the required function combined with fast and problem-free commissioning. The "safe standstill" function (EN 954-1, Control Category 3) is a standard component in all axis modules.

Built-in monitoring functions in the central supply modules support a simple and transparent system structure. The high overload capacity optimises the power supply whatever the operating conditions.

Common to all modules are the compact dimensions, fast and well-designed assembly and easy commissioning. An extensive range of system accessories supports tailoring even to specific operating requirements. Two on-board CAN system bus interfaces and a slot for all standard fieldbus systems complete the picture.



Power supply module ECSEE020 (standard mounting)



Axis module ECSCA008 (cold plate version)



Axis module ECSDA064 (push-through technique)

### Lenze An introduction

Lenze is the competent partner for your application. Lenze is not only a supplier for single components but also offers solutions for complete drive systems including planning, execution and commissioning.

Furthermore, a worldwide service and distribution network lets you engage a qualified customer advisory service and an after sales service that is fast and extensive.

Our quality assurance system for design, production, sales and service is certified according to DIN ISO 9001: 2000. Our environmental management system is also certified to DIN EN ISO 14001. Our customers set the standards for measuring the quality of our products. Our task is to meet your requirements, since customer orientation is a Lenze principle demanding the best quality.

See for yourself.













A worldwide service –
Our team of experts provides reliable and professional assistance.

## A true system Drive and automation technology


Products which are setting the pace in terms of technology and complete drive solutions for machine and system production - just what Lenze is all about. We provide our customers with frequency and servo inverters with powers up to 400 kW. We support both central control cabinet solutions and decentralised drive concepts, e.g. with motor inverters with IP65 type of protection.

Both standard three-phase AC motors and synchronous and asynchronous servo motors are available to complement the various controllers, all of which can be combined with various types of gearboxes. Human Machine Interfaces, decentralised I/O systems and modules for fieldbus interfacing are also available for exchanging information.

Lenze boasts extensive application know-how in all manner of industries. This knowledge has been applied in the design of the controller and PC software, providing an efficient means of implementing numerous standard applications using simple parameter settings.


An all-round service comprising component selection advice, training, commissioning support and even a helpline which can be accessed all over the world and independent system engineering completes the offer.












Communication modules













# Contents | ECS servo system

General	1-1
Product information	2-1
System accessories	3-1
Dimensioning information	4-1
Services	5-1



# General ECS servo system

List of abbreviations	1-3
A step-by-step guide	
to selecting your system	1-4



## **General** List of abbreviations

Conti	roller		General	
U <sub>mair</sub> I <sub>mains</sub> U <sub>DC</sub> U <sub>k</sub>		Mains voltage Mains current DC-bus voltage Short circuit voltage	ECS□A ECS□E ECS□K	Servo axis module Supply module Capacitor module
I <sub>r</sub>	[A] [A]	Rated current/Output current Maximum output current	AIF	Application interface (can be plugged into ECS modules)
I <sub>Amax</sub> I <sub>Orms</sub>		Maximum acceleration current Standstill current (rms value)	AC DC	Alternating current/voltage Direct current/voltage
P <sub>r</sub>	[kW]	Rated power	DIN	Deutsches Institut für Normung
S <sub>r</sub> P <sub>V</sub> P <sub>brake</sub>	[kVA] [W] _ [kW]	Output power, inverter Power loss, inverter Maximum braking power	EMC	Electromagnetic compatibility
		<u> </u>	EN	European standard
f <sub>ch</sub> f <sub>max</sub> f <sub>d</sub>	[kHz] [Hz] [Hz]	Switching frequency Set maximum frequency Field frequency	IEC	International Electrotechnical Commission
L	[mH]	Inductance	IP	International Protection Code
n <sub>r</sub>	[min <sup>-1</sup> ]	Rated speed	NEMA	National Electrical Manufacturers Association
R	[Ω]	Resistance	VDE	Verband deutscher Elektrotechniker
$R_{th}$	[k/W]	Thermal resistance	CE	Communauté Européenne
k <sub>c</sub>	[μF/kW]	Capacity factor	IM	International Mounting Code
			UL UR	Underwriters Laboratory Listed Product Underwriters Laboratory Recognized Product



#### Step 1

#### Calculation of the motor power required for each axis

This section contains a brief description of the essential

then use this catalog to identify and order the required

steps required to select an ECS servo system for your appli-

cation. Once you have the general system selected, you can

The maximum torque required for this axis  $(M_{max})$ , the maximum speed (n<sub>max</sub>), the effective torque (M<sub>rms</sub>) and, if applicable, the transmission ratio i must be calculated for

this purpose. (The Lenze formula collection ID no. 473 731 provides more detailed information about dimensioning drives correctly.)

#### Gearbox ratio:

► for optimum dynamics

$$i = \sqrt{\frac{J_{load}}{J_{mot}}}$$

▶ for excellent utilisation in continuous operation

$$i = \frac{n_r}{n_{load}}$$

#### Effective torque:

(for steps with constant torque characteristics)

$$M_{rms} = \sqrt{\frac{1}{t} \sum_{i} M_{i}^{2} t_{i}}$$

#### **Maximum torque:**

$$M_{max} = M_{accel} + \frac{1}{i} \frac{1}{n_{qearbox}} M_{load}$$

$$M_{accel} = 2 \cdot \pi \frac{\Delta_n}{\Delta_t} \left( J_{mot} + \frac{1}{i^2} J_{load} \right)$$

#### Step 2

#### Selection of suitable motors

Please see the "MCS Synchronous Servo Motors" and "Global Drive Servo Motors MDXK/MDFQA" catalogs for more detailed information about selecting suitable Lenze servo motors.

Select the motor according to  $n_{max}$ ,  $M_r > M_{rms}$ , for highly dynamic applications, you should also take M<sub>max</sub> and M<sub>0</sub> into account in addition to the following points:

- ▶ No air flow permissible in the process
- ▶ Fluff or similar which may block the air ducts
- ► High type of protection required
- ► High dynamics required
- ▶ Operation at constant power at high speeds (field weakening mode)
- ► Very high power density
- > Parallel operation of servo motors

- Motor without fan MCS, MCA
- Motor without fan MCS, MCA
- Motor without fan MCS, MCA
- Synchronous motor without fan MCS
- Asynchronous servo motor MDXKA, MCA
- $\rightarrow$ Synchronous servo motor MCS
- Asynchronous servo motor MDXKA, MCA

It is also at this point that you need to specify the appropriate encoder system for your application. Resolvers, SinCos single-turn and multi-turn encoders as well as incremental encoders can be provided to suit your application requirements and selected motor types. Please see the "MCS Synchronous Servo Motors" and "Global Drive Servo Motors MDXK/MDFQA" catalogs for more detailed selection information about the various encoder systems.

#### Step 3

#### Select the appropriate ECS axis modules

The axis modules are selected on the basis of the maximum currents required ( $I_{max}$ ), the average power required ( $P_{rms}$ ) and, if applicable, the holding currents required ( $I_0$ ).

(Please see the "Global Drive Servo Motors" catalog for the required motor data. The selection tables for ECS axis modules appear on page 2-5 of this catalog.)


#### Step 4

#### Select the required ECS supply module

The best way to select the ideal ECS supply module for a multi-axis application is to use a time/power diagram for a complete machine cycle for all axes. The total power characteristic can be calculated by adding the time-based individual axis power ratings and used as the basis for selecting the most suitable ECS supply module. This calculation can also be used to check whether the dimensions of the inter-

nal brake resistor built into the supply module are sufficient for the total braking power which may be required or if an external resistor with a higher rating will be needed. Information about brake resistors appears on page 3-9.

#### Time/power diagram of a multi-axis servo system



#### Step 5

### Specifying the installation methods for axis and supply modules

ECS servo system axis and supply modules are available in three different versions:

- ➤ As built-in units for fixing to an appropriate mounting plate in the control cabinet
- ▶ In a push-through technique (thermal separation) design, in which the heatsink is plugged into the modules via the backplane of the control cabinet or other assembly space so that the heat loss is dissipated directly outwards, significantly reducing the heat rise inside the control cabinet.

Tip: 1.) It may be possible to select a smaller control cabinet 2.) Less cooling power may be required in the control cabinet.

▶ As a cold plate unit. In this version, the ECS modules do not have their own heatsinks but are mounted directly on an existing heatsink in the customer system via the rear-side mounting plate. (It is absolutely essential to take the necessary values for heat transmission and dissipation resistances into account, see page 2-21). If the cold plate method is used, please also note that the ECS supply module does not have a built-in brake resistor. If a brake resistor is required, it must be provided externally (page 3-9).

#### Step 6

#### Selection of accessories on the supply side

The following accessories can be selected according to local requirements:

- ► Circuit-breakers (see page 3-15)
- ► RFI filters (if required) (see page 3-8)
- ▶ Mains chokes (the use of a choke on the mains side is always recommended to reduce the mains r.m.s. current and the stress applied to the DC-bus capacitors. Please take the voltage drop in the DC-bus voltage into account.) (see page 3-6).

Note: DC-bus fuses do not need to be used on the ECS servo system.

#### Step 7

### Selection of additional accessories for control or communication

Lenze offers a wide range of accessories to complete your overall system:

- Motor and encoder system cables (see "MCS Synchronous Servo Motors" and "Global Drive Servo Motors MDXK/MDFOA" catalogs)
- Pluggable modules for local operation (page 3-2) and/or connection to a fieldbus (page 3-3)
- ► ECSZ□ connector sets for power and control connections (page 3-16)
- ► ECSZS shield assembly sets for the EMC-compliant and safe connection of cable shields
- ➤ Text or graphic human machine interfaces, connectable via system bus (page 3-22)
- Decentralised I/O modules, connectable via system bus (page 3-23)
- Software for parameter setting and monitoring (page 3-18)
- ► ETC Motion Control controller for co-ordinated multi-axis synchronisation (page 3-24)





# **Product information** | ECS servo system

ECS product info	ormation
------------------	----------

Features of the system	2-2
Operating conditions/General data	2-4
Overview of module selection	2-5

#### **Axis modules**

Features	2-7
Rated data	2-8
Control connections	2-9
Characteristics for maximum	
output currents	2-10
Type codes for ECS □A axis modules	2-11

### **Supply modules**

Features	2-12
Rated data	2-13
Control connections	2-14
Type codes for	
ECS□E supply modules	2-15

### **Capacitor modules**

Features	2-16
Rated data	2-17
Connections for FCS□K capacitor modules	2-17

## Mechanical dimensions

ECS E□ built-in unit	2-18
ECS D□, push-through technique	
(with thermal separation)	2-19
ECS D□, cold plate design	2-20
Requirements of external coolers for	
cold plate design	2-21

### **Application software**

2-22


#### **ECS product information**

Features of the system

The ECS servo system comprises DC-supplied servo modules capable of overloads up to several hundred percent which have been designed specifically for multi-axis applications with high dynamics and drive performance.

The ECS servo system's functions are designed for use with central control concepts. The distribution of intelligence between the control system and servo modules can be optimised for specific applications. A high degree of

precision is achieved when carrying out multi-axis coordinated movements by transferring synchronised speed and torque setpoints via the integrated CAN motion bus at cycle times below 1 ms. The ECS servo system is therefore ideal for gantry systems, robots, packaging machines or feeding and removal devices in industrial handling.



#### The advantages of the ECS servo system

#### **High dynamics**

- ▶ 200% to 300% overload of axis modules
- ▶ Dynamic energy exchange via DC-bus connection

#### Wide power range

- $ightharpoonup P_r = 1.1...13.8 \text{ kW}$
- ► I<sub>max</sub> = 4.0 ... 64 A

#### **Central supply modules**

- ▶ Minimum cabling
- ➤ Reduced expenditure on switching and fuse elements on the supply side
- ▶ Built-in mains and DC-bus monitoring function
- ► Central interference suppression

#### Couldn't be easier to assemble

- ▶ Pluggable, polarised connection system for power and control terminals, accessible from the front
- ➤ Suitable for wall mounting, push-through technique (thermal separation) or cold plate technique

#### Little space required

- ► Compact design
- ▶ No DC-bus fuses required

#### Flexible configuration for adaptation to motion control

▶ Setpoint selection and actual value feedback via bus

#### Full network capabilities

- ▶ 2 CAN interfaces as standard in the axis module
- ► All popular fieldbus systems are available as optional additional pluggable communication modules

"Safe standstill" acc. to EN 954-1 Control Category 3

UL-approved (File No. E132659), CE-compliant


#### **Built-in motor brake control**

- ▶ Internal functions minimise external expenditure
- ▶ Built-in monitoring functions for brake circuit

### Can be combined with synchronous and asynchronous motors

 Resolver or encoder as feedback system (TTL, SinCos, SinCos absolute value)

Optimum matching to MCS range of highly dynamic motors





# **ECS product information** Features of the system

#### Standards and operating conditions

Conformity		CE	Low-Voltage Directive (73/23/EEC)		
Approvals		UL508C Underwriter Laboratories (File No. E132659) Power conversion equipment			
Max. permissible motor cable length	shielded	50 m	At mains rated voltage and switching frequency 8 kHz		
Vibration resistance		Accelerational stability	y up to 0.7 g (Germanischer Lloyd, general conditions)		
Climatic conditions		Class 3K3 to EN 50178 (no condensation, average relative humidity 30 95%)			
Degree of pollution		VDE 0110 Part 2 Degree of pollution 2			
Packaging (DIN 4180)		Shipping container			
Permissible temperature ranges	Transport	-25 +70°C			
	Storage	-25 +55°C			
	Operation	0 +55°C	Derate output rated current by 2%/°C above +40°C		
Permissible installation height		0 4000 m amsl	Derate output rated current by 5%/1000 above 1000 m amsl		
Installation		Installation in control	cabinet IP54 for operation with "safe standstill" function		
Mounting position		Vertically suspended			
Free space	Above/below	≥ 50 mm			
	To the side	Can be mounted direc	tly side by side without any clearance		

#### **General electrical data**

EMC	Meets the requirements of EN 61800-3				
Noise emission	Compliance with limit class A to EN 55011 (achieved with application-typical collective filter)				
Noise immunity	Requirements to EN 61800-3				
	Requirement	Standard	Severity		
	ESD 1)	EN 61000-4-2	3, i.e. 8 kV for air discharge 6 kV for contact discharge		
	Cable-guided high frequency	EN 61000-4-6	10 V; 0.15 80 MHz		
	RF interference (housing)	EN 61000-4-3	3, i.e. 10 V/m; 80 1000 MHz		
	Burst	EN 61000-4-4	3/4, i.e. 2 kV/5 kHz		
	Surge (impulse voltage on mains cable)	EN 61000-4-5	3, i.e. 1.2/50 μs 1 kV phase-phase 2 kV phase-PE		
Insulation resistance	Overvoltage category III to VI	DE 0110			
Discharge current to PE (acc. to EN 50178)	> 3.5 mA AC for operation wi	th appropriate cor	ntrollers		
Enclosure	IP20 for standard assembly IP20 for assembly in "cold plate technique" IP20 for assembly in "push-through technique" (IP54 on heatsink side)				
Protective measures against	Short circuit, short to earth (protected against short to earth during operation, limited protection against short to earth on mains power-up), overvoltage, motor stalling, motor overtemperature (input for PTC, I <sup>2</sup> t monitoring)				
Protective insulation of control circuits	Safe isolation of mains: Double/reinforced insulation to EN 50178; Rated insulation voltage 300 x √2 [V]				

<sup>&</sup>lt;sup>1)</sup> The control cabinet must be able to ensure noise immunity to the degrees of severity listed! The user must check adherence to the degrees of severity listed!



# **ECS product information**Features of the system

#### Overview of module selection

To speed up the preselection process, this page contains an overview of all ECS system modules. Additional more detailed information about the individual modules appears on the pages indicated.

#### ECS□A axis modules

Overview of ECS□A axis modules (data for 400 V mains)							
		ECS□A 004	ECS□A 008	ECS□A 016	ECS□A 032	ECS□A 048	ECS□A 064
I <sub>Amax</sub>	[A]	4.0	8.0	16.0	32.0	48.0	64.0
I <sub>r</sub> (4 kHz)	[A]	2.0	4.0	8.0	12.7	17.0	20.0
I <sub>o rms</sub> (4 kHz)	[A]	2.0	4.0	8.0	16.0	23.0	27.0
S <sub>r</sub>	[kVA]	1.1	2.2	5.5	8.8	11.8	13.8
Rated data		Page 2-8					

#### **ECS**□**E** supply modules

		Overview of ECS□E supply modules (data for 400 V mains)				
		ECS□E 012	ECS□E 020	ECS□E 040		
I <sub>mains r</sub>	[A]	9.6	15.9	31.9		
I <sub>DC r rms</sub>	[A]	12.0	20.0	38.5		
$P_{r}$	[kW]	6.0	10.0	20.0		
P <sub>brake max</sub>	[kW]	7.8	16.0	31.2		
Rated data		Page 2-13				

#### **ECS**□K capacitor modules

Rated data page 2-17.



ECSCA032 axis module for 32 A peak current in cold plate design



ECSCE020 supply module for 20 A DC in cold plate design





#### **Features**

The compact axis modules are designed for operation in a DC-bus link. Six power stages ( $I_{Amax}$ : 4 A to 64 A,  $P_r$ : 1.1 to 13.8 kW) ensure optimum operation for dynamic servo applications. Ease and speed of assembly and commissioning was prioritised when designing the modules.

#### **Basic functions of axis controllers**

- ➤ Speed control via terminal or fieldbus system (terminal, AIF, CAN)
- ➤ Torque control via terminal or fieldbus system (terminal, AIF, CAN)
- Master frequency follower via terminal or fieldbus system (terminal, AIF, CAN)<sup>1)</sup>

#### Possible control system configurations

- Motion control systems based on analog setpoints and incremental feedback systems
- Motion control systems with CAN-based communication options
- ▶ IPC-based motion control systems with at least one of the above setpoint/actual value paths
- ➤ Process control systems which use torque or speed setpoints to control the process (e.g. winder computers, coil winder systems)

#### Pluggable accessories

- ▶ 9371BC operating module for parameter setting and parameter transfer
- ➤ Serial RS232/485 module via wire or optical fibre 2102IB
- ► INTERBUS-S module 2113IB
- ▶ PROFIBUS module 2131IB
- ► DeviceNet module 2175IB

#### **Features**

- ► Field-based control
- ▶ Phase controller, can be integrated ¹)
- ▶ Direct connection of resolver and encoder, TTL or SinCos encoder
- Connection option for a second rotary encoder
- ▶ Direct evaluation of a SinCos absolute value encoder
- ▶ Digital synchronisation system via master frequency
- ► Individual user configurations
- ► Modular function blocks
- Oscilloscope function (in conjunction with the DriveServer and GDC PC software)
- ► Integrated fan (only for built-in unit)
- ► IP54 design of the rear of the module (only for push-through technique)
- ➤ Thermal separation (push-through or cold plate technique)
- ► Completely pluggable terminals
- ▶ DC-bus connections at the top
- ▶ Motor connections at the bottom
- ▶ 4 digital inputs
- ▶ 1 digital output
- ▶ 1 analog input
- ▶ 24 V brake connection with monitoring
- ➤ "Safe standstill" safety function to EN 954-1 Control Category 3
- ▶ 2 integrated system bus interfaces (CAN)
- ► CAN address and baud rate switch
- Integrated master frequency input or output, can be switched over
- ► UL approval
- ► CE conformity to Low-Voltage Directive (73/23/EEC)





<sup>1)</sup> Additional individual software required

### **ECS** product information

Axis modules

#### Rated data

	Type <sup>1)</sup>	ECS□A004	ECS□A008	ECS□A016	ECS□A032	ECS□A048	ECS□A064
Max. output current (acceleration current)	I <sub>Amax</sub> [A]	4.0	8.0	16.0	32.0	48.0	64.0
Rated current for 4 kHz <sup>5)</sup>	I <sub>r4</sub> [A]	2.0	4.0	8.0	12.7	17.0	20.0
Rated current for 8 kHz <sup>5)</sup>	I <sub>r8</sub> [A]	1.35	2.7	5.3	8.5	11.3	13.3
Continuous current at standstill	I <sub>o, rms 4 kHz</sub> [A]	2.0	4.0	8.0	16.0	23.0	27.0
Short-time standstill current	I <sub>o, rms 4 kHz</sub> [A]	3.0	6.0	12.0	24.0	36.0	48.0
Output power at U <sub>mains</sub> = 400 V	S <sub>r</sub> [kVA]	1.1	2.2	5.5	8.8	11.8	13.8
DC-bus current	I <sub>DCr</sub> [A]	2.5	4.9	9.8	15.6	20.9	24.5
DC-bus capacity	[μF]	165	165	165	165	330	330
DC-bus voltage $ \qquad \qquad U_{DC}\left[V\right] $		0 770					
Max. output frequency f <sub>out</sub> [Hz]		600					
Ambient temperature T <sub>amb</sub> [°C]		0 +55 <sup>3)</sup>					
Speed of cooling air (only for push-through technique)	V <sub>cooling</sub> [m/s]	3					
Weight (incl. packaging) [kg]		2.2 3.1			1		
Dimensions of cold plate design <sup>2) 4) 6)</sup> (WxHxD) [mm]		88 x 287 x 121			132 x 287 x 121		
Dimensions of built-in unit, push-through technique $^{2)4)}(WxHxD)[mm]$			88 x 247 x 176			132 x 247 x 176	

 $<sup>^{1)}</sup>$  " $\square$ " indicates the design and should be replaced as follows:

 $^{\rm 3)}$  Derating must be applied by the user at and above 40°C 0°C ... +40°C no power reduction +40°C ... +55°C power reduction

2.0%/K (based on IN) Permissible installation h = 1000 m amsl no power reduction

1000m amsl < h = 4000 m amsl with power reduction 5%/1000 m.

- <sup>4)</sup> Dimensions without fastenings or AIF modules
- $^{5)}$  Please refer to the diagrams on page 2-10 for output frequencies  $\,<$  5 Hz!
- 6) Please refer to the data for dimensioning the external heatsink on page 2-21 if you are using the cold plate design!



ECSDA048 with PROFIBUS-DP communication module connected (thermal separation design)

Cold plate: "C"; built-in unit: "E"; push-through technique: "D" <sup>2)</sup> The mounting depth of the devices increases by 8 mm when the AIF module is connected (basic height) or by 24 mm when the AIF module 2113 is connected.


## **ECS product information**Axis modules

#### **Control connections**

	Electrical data	Additional notes
Voltage supply, control section	GND, 24 V DC, 0.5 A <sup>1)</sup>	20 30 V DC
4 x digital input	24 V DC	can be parameterised
Digital output	24 V DC, 0.7 A	protected against short circuits, I <sub>max</sub> 1.4 A
Safe standstill	24 V DC	2x input, 1x output, 1x voltage supply, 18 30 V DC
Motor holding brake	24 V DC, 1.5 A	18 30 V DC
Analog input	-10 V +10 V or -20 mA +20 mA	configurable
Communication interface	2x CAN bus	on-board
Resolver input	9-pin SUB-D	
Encoder connection	9-pin SUB-D	can be switched over as: 1) Encoder input 2) Encoder simulation 3) Encoder output

<sup>&</sup>lt;sup>1)</sup> The current requirement of the digital output may need to be included when dimensioning a 24 V supply for this connection.

All control connections are electrically isolated from the device ground. All control connections have a common reference potential.




ECS module power and control connections, pluggable (the illustration shows an ECSCA008 axis module in cold plate design)

#### **Characteristics for maximum output currents**


The axis controllers work with switching frequencies of 4 and 8 kHz. At field frequencies < 5 Hz, the output current is derated on the controllers.

If the characteristic for 8 kHz is exceeded by the current, the frequency is automatically switched down to 4 kHz. The output current is limited when the 4 kHz characteristic is reached.

If a heatsink temperature of 70°C is exceeded, the switching frequency is also reduced to 4 kHz. It switches back to 8 kHz with a hysteresis of 5°C.



Device currents in the range 0 ... 10 Hz output frequency  $(f_{chop} = 4 \text{ kHz})$ 



Device currents in the range 0 ... 10 Hz output frequency  $(f_{chop} = 8 \text{ kHz})$ 

#### Type codes for ECS□A axis modules



#### Ordering example:

ECS axis modules, thermal separation (push-through technique), peak current 32 A, CAN system bus, for 400 V mains, standard design

Order number: ECSDA032 C4B

## **ECS product information** Supply modules

#### **Features**

The supply units provide the DC voltage for the axis controllers. In terms of size and structure, they are identical to the axis controllers and can be mounted directly alongside the axis controllers.

#### The following designs are available:

- ▶ Built-in unit (wall mounting) with integrated fan
- Push-through technique (thermal separation) without integrated fan
- ► Cold plate

#### Features:

- Generation of DC-bus voltage for a drive controller network
- Speedy assembly/disassembly, e.g. because all terminals can simply be plugged in
- ▶ Address/baud rate switch for system bus
- ► Controlled charging of DC bus
- Communication via integrated system bus (CAN) interface for process data parameter settings and transfer
- ► Communication via AIF for parameter setting
- ► Internal brake chopper
- ► Internal brake resistor with monitoring (not for cold plate)
- Alternative connection option for external brake resistor with thermostat
- ➤ Automatic detection of mains voltage with adaptation of brake chopper switch-on voltage
- Checking of the DC bus on power-up for short to earth and short circuit
- ▶ Phase-specific mains failure monitoring
- ► Monitoring of mains current
- > 2 digital inputs, 1 digital output (floating)



ECSDE020, push-through technique



ECSEE040, built-in unit

#### ECS product information Supply modules

#### Rated data

The supply module is approved only for operation on symmetrical systems. Operation on systems with earthed phase conductor is not permitted.

The unit is fitted with an automatic mains voltage detection function with adaptation of the brake chopper switch-on voltage.

Supply units	Туре	ECS□E012 <sup>1)</sup>	ECS□E020 <sup>1)</sup>	ECS□E040 1)	
Mains voltage	U <sub>mains</sub> [V]	3x 180	3x 528 ±0%; 45 Hz 6	5 Hz ±0%	
Mains rated voltage	U <sub>mains r</sub> [V]		3x 400		
Mains rated current	I <sub>mains r</sub> [A]	9.6	15.9	31.3	
Maximum mains current		Max. 5x mains rated current for 50 ms, 2x mains rated current for 1 s 1.5x mains rated current for 10 s <sup>2)</sup>			
Rated direct current (effective value)	I <sub>DC r,reff</sub> [A]	12.0	20.0	38.5	
Output power 400 V mains	P <sub>r</sub> [kW]	6.0	10.0	20.0	
Brake chopper resistance, internal 4)	$R_{B}[\Omega]$	82.0	39.0	20.0	
Brake chopper resistance, external	$R_{B}[\Omega]$	≥82.0	≥ 39.0	≥ 20.0	
Max. braking power with int./ext. brake resistor 4)	P <sub>B, max</sub> [kW]	7.6	16.0	31.2	
Continuous braking power with int. brake resistor 4)	P <sub>BD, int</sub> [kW]	0.10	0.12	0.15	
Continuous braking power with ext. brake resistor	P <sub>B, ext</sub> [kW]	2.0	3.0	6.0	
Ambient temperature	T <sub>amb</sub> [°C]		0 +55 <sup>3)</sup>		
Speed of cooling air	V <sub>cooling</sub> [m/s]		3		
Weight (incl. packaging)	[kg]		2.5	3.0	
Dimensions of cold plate design <sup>6) 7)</sup>	(WxHxD) [mm]	88.5 x 2	87 x 121	131 x 287 x 121	
Dimensions of built-in unit, push-through technique $^{7)}$	(WxHxD) [mm]	88.5 x 2	47 x 176	131 x 247 x 176	

 <sup>&</sup>quot;" indicates the design and should be replaced as follows: Cold plate: "C"; built-in unit: "E"; push-through technique: "D"

 $5x \text{ mains rated current} \qquad 4\% \ I_{\text{max}}, 96\% \ I = 0$   $2x \text{ mains rated current:} \qquad 25\% \ I_{\text{max}}, 75\% \ I = 0$   $1.5x \text{ mains rated current:} \qquad 44\% \ I_{\text{max}}, 56\% \ I = 0$   $3) \text{ Derating must be applied by the user at and above } 40^{\circ}\text{C}$   $-10^{\circ}\text{C} \dots + 40^{\circ}\text{C} \qquad \text{no power reduction}$   $+40^{\circ}\text{C} \dots + 55^{\circ}\text{C} \qquad \text{power reduction}$ 

+40°C ... +55°C power reduction 2.0%/K (based on IN) Permissible installation height h = 1000 m amsl no

power reduction 1000 m amsl < h = 4000 amsl with.

- 4) The internal brake resistor indicated here is integrated into the heatsink on the "built-in unit" (order designation ECSEE□□□) and "thermal separation" (order designation ECSDE□□□) designs. On the "cold plate" design (order designation ECSCE□□□), an external resistor must be used instead.

  An external resistor is also required if the continuous braking power of the built-in resistor is exceeded.
- External brake resistors are described on page 3-9.
- 6) Please refer to the data for dimensioning the external cooler on page 2-21 if you are using the cold plate design!
- 7) The height of the units increases by 8 mm when the communication module is plugged in.



<sup>&</sup>lt;sup>2)</sup> The maximum currents indicated are valid for the following continuing switch-on conditions:




# **ECS product information** Supply modules

#### **Control connections**

Function	Electrical data	Additional notes	
Voltage supply, control section	GND, 24 V DC, 0.5 A <sup>1)</sup>	20 30 V DC	
Digital input mains enable	24 V DC		
Digital input controller enable	24 V DC		
Digital output, ready for operation and controller enable	24 V DC, 0.7 A	protected against short circuits, I <sub>max</sub> 1.4 A	
Thermostat, contact 1			
Thermostat, contact 2			

 $<sup>^{1\!\!1}</sup>$  The current requirement of the digital output may need to be included when dimensioning a 24 V supply.

All control connections are electrically isolated from the device ground. All control connections have a common reference potential.



Pluggable power and control connections for ECS supply modules (the illustration shows an ECSEE020, built-in version)

## **ECS product information**Supply modules

#### Type codes for ECS□E supply modules



#### Ordering example:

ECS supply module, built-in unit, continuous direct current 20 A, CAN system bus, 400 V voltage, standard mains Order number: ECSEE020C4B



### ECS product information

#### Capacitor modules

#### **Features**

The ECS servo system is ideal for use in dynamic multi-axis applications. As, depending on the specific conditions, operating modes may be used in these applications which require significantly increased DC-bus power for long periods of time, ECSDK capacitor modules have been provided. These modules will optimise the dimensioning of the required DC-bus capacity for the specific application.

Use the following formula for a preliminary assessment of whether a capacitor module is required:

 $\frac{\text{Total capacity of DC-bus connection } [\mu F]}{\text{Temporal average of total rated power of all drives } [kW]} = k_c \frac{[\mu F]}{[kW]}$ 

If  $k_c \ge 100 \, [\mu F/kW]$ , an additional capacitor module will not generally be required.

Example:

Three axes with a cyclical positioning operation with delta profile and a pause with the following time ratio:

Accelerate: Brake: Pause = 1:1:1

The following equation applies for this travel profile  $^{1)}$ : Average power = Power required x 0.222

Assumption: Power required 2x 2.2 kW + 1x 5.5 kWAxis modules used:  $2x \text{ EXS}\square A008$  and  $1x \text{ ECS}\square A016$ 

Sum of DC-bus capacities (see page 2-8):  $3x 165 \mu F = 495 \mu F$ 

Average power:  $((2x 2.2 \text{ kW}) + 5.5 \text{ kW}) \times 0.222 = 2.2 \text{ kW}$ 

$$k_c = \frac{495 \,\mu\text{F}}{2.2 \;\text{kW}} = 225 \;\; \frac{\left[\mu\text{F}\right]}{\left[\text{kW}\right]}$$

As  $k_c > 100 \mu F/kW$ , a capacitor module does not have to be used.

Should you have any questions about calculations, please contact your local Lenze sales representative, who will be happy to help you.



<sup>1)</sup> Please see the relevant formula collection for more detailed calculation information.

# ECS product information Capacitor modules

#### Rated data

Capacitor module	Type <sup>1)</sup>	ECS□K001	ECS□K002	
Capacity	[μF]	705	1410	
Rated power	[kW]	10.0	20.0	
DC-bus voltage	U <sub>DC</sub> [V]	0 770		
Ambient temperature	T <sub>amb</sub> [°C]	0 +55		
Speed of cooling air (only for push-through technique)		No specific measures required		
Weight (incl. packaging)	[kg]	2.0	3.1	
Dimensions without fastenings or AIF modules Cold plate Built-in unit, push-through technique	(WxHxD) [mm]	88.5 x 286 x 121 88.5 x 247 x 176	132 x 286 x 121 132 x 247 x 176	

¹) "D" indicates the design and should be replaced as follows: Cold plate: "C"; built-in unit: "E"; push-through technique: "D"


#### Connections for ECS K capacitor modules



Pluggable power and control connections for ECS capacitor modules (the illustration shows an ECSDK01 in pushthrough technique)

# ECS product information Mechanical dimensions

#### ECS *E* □ built-in unit




		Dimensions [mm]					
Туре	Frame size	a	b	d	е	h	g
ECSEA004							
ECSEA008							
ECSEA016							
ECSEA032	1	88.5					
ECSEE012							
ECSEE020			276	260	174 <sup>1)2)</sup>	10	6.5
ECSEK001							(M6)
ECSEA048							
ECSEA064	2	131					
ECSEE040	_						
ECSEK002							

<sup>1)</sup> Dimension "e" without fastenings or AIF module



<sup>&</sup>lt;sup>2)</sup> Dimension "e" increases by 8 mm when the AIF module is connected (basic height) or by 24 mm when the AIF module 2113 is connected.

### ECS D □, push-through technique (with thermal separation)




		Dimensions [mm]									
Туре	Frame size	a	a1	b	b1	<b>c1</b>	d	е	e1	h	g
ECSDA004											
ECSDA008											
ECSDA016											
ECSDA032	1	88.5	78.5								
ECSDE012											
ECSDE020				240	197	75	250	116 <sup>1) 2)</sup>	58	10.5	M5
ECSDK001											
ECSDA048											
ECSDA064	2	131	121.5								
ECSDE040	_										
ECSDK002											

<sup>1)</sup> Dimension "e" without fastenings or AIF module

In order to provide sufficient cooling for the drive system, an air flow with a flow velocity of at least 3 m/s is required behind the backplane of the control cabinet.

<sup>2)</sup> Dimension "e" increases by 8 mm when the AIF module is connected (basic height) or by 24 mm when the AIF module 2113 is connected.

### ECS C□, cold plate design



		Dimensions [mm]							
Туре	Frame size	а	a1	b	c1	d	е	g	
ECSCA004									
ECSCA008									
ECSCA016									
ECSCA032	1	88.5	60						
ECSCE012									
ECSCE020				282	50	286	121 <sup>1) 2)</sup>	M6	
ECSCK001									
ECSCA048									
ECSCA064	2	131	90						
ECSCE040	_								
ECSCK002									

Dimension "e" without fastenings or AIF module
 Dimension "e" increases by 8 mm when the AIF module is connected (basic height) or by 24 mm when the AIF module 2113 is connected.

### **ECS product information**

### Requirements of external coolers for cold plate design

The following conditions must be met for the safe operation of cold plate design axis modules:

- ▶ Evenness of contact surface of cooler: ≤ 0.5 mm
- ► Roughness of contact area: Ra = 0.8
- ▶ Good thermal connection to cooler
- ➤ The entire cooling surface of the axis module must make contact with the collective cooler
- ► Temperature of cold plate below +85°C
- ▶ Do not exceed the thermal resistance R<sub>th</sub> specified in the table. The values are valid when operating the axis modules under rated conditions.

Туре	R <sub>th</sub> [K/W]
ECSCA004	
ECSCA008	0.31
ECSCA016	
ECSCA032	0.13
ECSCA048	
ECSCA064	0.11
ECSCE012	0.45
ECSCE020	0.34
ECSCE040	0.17

There are no specific specifications to be observed for ECSCK modules.

### **ECS product information**

**Application software** 

The ECS servo system axis modules can be used in a wide variety of applications. In order to ensure simple and efficient configuration and commissioning under all circumstances, the axis module application software has been divided into task-specific "Speed and Torque", "Posi and Shaft" and "ETC001" packages.

These software packages have been designed specifically for operation in a multi-axis grouping controlled by a PLC, a motion control controller or a PC-based control system and ensure precise control cycle synchronisation for all axes to the microsecond.

If a customer requires a specific solution for an application which cannot be handled using these standard solutions, this is also possible. Please contact your local Lenze sales representative for more information.

#### **Speed and Torque**

This application software provides the basic functions for speed and torque control. Relevant setpoints can be specified either manually, via analog values or serially via the CAN bus (or other bus systems). Up to 15 default speed setpoints can also be used. Ramps for the selection of new setpoints can be linear or S-shaped. In the event of a quick stop, drift-free standstill is assured. As standard, the package also features the "safe standstill" function to EN 954-1, Category 3 and supports the control of a motor holding brake with a monitoring function.

#### **Posi and Shaft**

This application software can be used to predefine and save up to 15 positioning profiles. Positioning can be absolute, relative, modulo (i.e. relative and infinite) or based on a manual fixed speed value or master frequency follower. Various forms of touch probe positioning are also supported as well as torque derating once the target position has been reached and speed override. In addition to eight different options for referencing, the "safe standstill" and motor holding brake logic are also standard features.

#### **ETC001**

The ETC001 application software has been designed specifically for multi-axis groupings controlled by an ETC motion control controller. It features a CAN motion bus angular follower with two different modes as well as position value detection (touch probe). Eight different referencing modes, two types of interpolation (linear and 2nd order polynomial) and torque precontrol are also available to the user. In addition, the "safe standstill" and motor holding brake logic are also standard features.

All ECS axis modules are supplied with the "Speed and Torque" application software loaded on delivery.

The "Speed and Torque", "Posi and Shaft" and "ETC001" application software packages can be downloaded free of charge from Lenze's Internet site and can be transferred to the axis modules using the Global Drive Loader PC software (see page 3-20).







#### 8

# System accessories | ECS servo system


Operating module/ PC system bus adapter	3-2	Connectors
Communication	3-2	Shield terminals
Communication modules for LECOM system interfaceCommunication module for	3-3	PC software
PROFIBUS-DP  Communication module for  CANopen/DeviceNet	3-4	Operating and configuration software Global Drive Control Global Drive oscilloscope
Communication module for INTERBUS Communication module for LON	3-5	Standard set-up program Global Drive Loader
Mains chokes	3-6	Automation components
RFI filters for limit class A	3-8	I/O system to IP20 Human machine interfaces Drive PLC
External Brake resistors		ETC motion controller
System cables	3-9	Regenerative power supply modules
Cable protection fuses	3-15	



# **System accessories**Operating module/PC system bus adapter

#### Operating module





**Keypad XT** 

Order number EMZ9371BC

The Keypad XT is available for visualisation and for entering parameters and codes. 8 keys and a text display speed up access to all parameters for the axis and supply modules in the ECS servo system via the transparent menu structure. The Keypad XT is also used for status display, error diagnostics and, with its built-in memory, for the transmission of parameters to other modules.

The Keypad XT can also be used on 8200 vector, 9300 vector, 9300 servo and Drive PLC devices as well as on 8200 motec decentralised motor inverters (via the diagnosis terminal).

See our "Automation" catalog (ID no. 494 445) for more detailed information about design formats, control cabinet door installation options, operation as a diagnosis terminal and accessories.

#### PC system bus adapter

The PC system bus adapter provides a quick and easy means of connecting the PC to the Lenze system bus (CAN) for setting parameters on and programming the controller.

#### For the printer port

This adapter simply plugs into the PC's parallel port. The relevant drivers are installed automatically with the appropriate Lenze software. Depending on the version, the voltage supply is provided via the DIN or PS2 connection on the PC.

Order no.	Brief description
EMF2173IB 1)	System bus adapter; voltage supply via DIN connection on PC
EMF2173IB V002 1)	System bus adapter; voltage supply via PS2 connection on PC
EMF2173IB V003 1)	System bus adapter; voltage supply via PS2 connection on PC; electrically isolated from the CAN bus



#### For the USB port

This adapter simply plugs into the PC's USB port. The relevant drivers are installed automatically with the appropriate Lenze software. The voltage supply is provided by the USB port on whichever PC/laptop is used.

no.	
voltage via the on the	stem bus adapter; supply also provided USB connection PC; electrically isolated from the is as standard

Please note: The Microsoft® Windows® NT operating system does not support the USB interface.

<sup>1)</sup> A CAN connecting cable (5 m) is included in the scope of supply



### **System accessories**Communication

The ECS servo system supply and axis modules can be networked with a host system (PLC or PC) via pluggable communication modules.

The modules are connected instead of the operating module.

The following combinations are possible:

		LEC	:OM		PROFIBUS-DP	CANopen	LON	INTERBUS
	-A/B	-B	-A	-LI		DeviceNet		
Axis modules ECS□A	•	•	•	•	•	•	•	•
Supply modules ECS□E	•	•	•	•	_	_	_	-
Capacitor modules ECS□K	0	0	0	0	0	0	0	0

- Combination possible
- Combination not possible
- O Communication not required

### Communication modules for LECOM system interface

If another Lenze system bus interface is required in addition to the CAN interfaces for the motion bus and system bus integrated as standard into the axis and supply modules, four types are available to meet varying requirements.









	LECOM-A/B	LECOM-B	LECOM-A	LECOM-LI
	Ideal for for simple parameter setting with GDC	Suitable for universal use with the open Lenze protocol for PC-PLC interfacing	Absolutely ideal for simple parameter setting with GDC. Voltage supplied internally from the ECS module	High noise immunity data transmission via optical fibres
Interface	RS232/RS485	RS485	RS232	OF
Baud rate	19.2 kB	19.2 kB	19.2 kB	19.2 kB
Max. length	A: 15 m/B: 1000m	1000 m	15 m	40 m per segment
Topology	Point-to-point/line	Line	Point-to-point	Ring
Max. no. of stations	2/32	32	2	52
Order number	EMF2102IBCV001	EMF2102IBCV002	EMF2102IBCV004	EMF2102IBCV003



# **System accessories**Communication

#### Communication module for PROFIBUS-DP

The PROFIBUS-DP module is a slave connection module with the PROFIBUS-DP communication profile. It is used for networking between control system and inverter at high processing speeds. It provides a user-friendly way of integrating the inverter into the overall system network. The Lenze PROFIBUS module has been certified by the PNO. Addresses can be allocated easily via DIP switches.



Interface	RS485
Baud rate	9.6 12.000 kBaud (automatic detection)
Max. bus length	1000 m (depends on baud rate)
Topology	Line (with repeaters also tree)
Max. no. of stations	32 (with repeaters max. 125 total)
Order number	EMF2133IB

### Communication module for CANopen/DeviceNet

The DeviceNet fieldbus has been particularly successful in the American and Asian markets. The Lenze CANopen/DeviceNet module can function in two operating modes - DeviceNet and CANopen.

The DIP switch on the front panel of the function module can be used to make the following settings:

- ► Station address
- ► Baud rate
- ► Communication profile: DeviceNet or CANopen

Interface	DIN ISO 11898
Baud rate	500 kBaud
Max. bus length	1000 m (depends on baud rate)
Topology	Line (with repeaters also tree)
Max. no. of stations	63
Order number	EMF2175IB



3-4





#### **Communication module for INTERBUS**

The INTERBUS connection is made directly on the remote bus. The remote bus module power supply can be provided either internally or externally.



	INTERBUS (remote bus)
Baud rate	500 2000 kB
Process data words	10 <sup>1)</sup>
Parameter data words	0, 1, 2 or 4 <sup>1)</sup>
Drive profile	Lenze device control DRIVECOM profile Drive technology 21
Voltage supply	Internal or external
Order number	EMF2113IB

 $<sup>^{1)}</sup>$  The total for the process and data words must be  $\leq$  10.

#### **Communication module for LON**

The LON fieldbus is primarily used in building services systems.

The Lenze communication module adds the LONMARK functional profile "Variable Speed Motor Drive" to the functionality of the inverter. The communication status is displayed via two LEDs on the communication module.



Interface	FTT
Baud rate	78 kBaud
Max. bus length	2000 m (without repeaters)
Topology	Line, tree, star, ring
Max. no. of stations	32385 (64 per segment)
Order number	EMF2141IB





## **System accessories**Mains chokes

A mains choke does not necessarily have to be installed in order to operate the ECS servo system. Checks should be made on a case-by-case basis to ascertain whether a mains choke needs to be installed. However, the use of a mains choke does offer the user the following advantages:

- ► Reduced mains disturbance
- ► The wave form of the mains supply is a closer approximation of a sine wave
- ▶ Reduction in the r.m.s. mains current by up to 25%
- ▶ Reduction in mains, line and fuse load
- ▶ Reduction in low-frequency radio interference voltages

#### Please note the following if you are using a mains choke:


- ► The maximum possible output voltage does not reach the full value of the mains voltage.
- ▶ If you are running acceleration drives with high peak currents, the use of Lenze mains chokes type ELN3 with linear L/I characteristic is recommended.




Mains choke for ECS supply modules

ECS supply module	Mains choke Order number	I <sub>rated</sub>	L <sub>rated</sub>	U <sub>k</sub>
ECS□E012	ELN3-0150H024	3x 24 A	3x 1.5 mH	4.9 %
ECS□E020	ELN3-0088H035	3x 35 A	3x 0.88 mH	4.2 %
ECS□E040	ELN3-0055H055	3x 55 A	3x 0.55 mH	4.1 %

#### Dimensions



Туре	Dimensions [mm]									
	a	a b c de f k m n								
ELN3-0150H024	180	86	136	67	192	_	120	7	12	



Туре	Dimensions [mm] a b c d e f k m n								
ELN3-0088H035	180	91	161	74	225	165	120	6.3	11
ELN3-0055H055	228	88	206	69	263	205	120	6.3	11

# System accessories RFI filters for limit class A

The measures required for servo systems on the mains side in order to reduce the mains current and for interference suppression will vary depending on the area of application. Although these measures are not usually essential, they will enable universal use of a servo system.


There are two limit classes for electromagnetic interference. Limit class A is required for industrial networks connected directly to the public supply system (no plant power supply transformer). Limit class B applies in residential areas. The use of Lenze mains filters type ECSZZ ensures adherence to the requirements of limit class A.

The RFI filters are designed for the assigned ECS supply module and up to 10 axis modules, each with 25 m of motor cable (Lenze system cable). If your motor cables are longer than 25 m, please contact your local Lenze sales representative.



ECS supply module	Mains filter Order number
ECS□E012	ECSZZ 020X4B
ECS□E020	ECSZZ 020X4B
ECS□E040	ECSZZ 040X4B

#### Dimensions of Lenze mains filter type ECSZZ



Order number	I <sub>r</sub>	U <sub>mains</sub>	$P_V$	m	a	a1	a2	b	b1	b2	С	<b>c1</b>	d
	[A]	[V]	[W]	[kg]	[mm]	[mm]							
ECSZZ 020X4B	16	500	6.2	3.0	105	80	28	260	245	215	96	70	6.6
ECSZZ 040X4B	32	500	9.3	3.0	105	80	28	260	245	215	96	70	6.6

### System accessories External brake resistors

All ECSDEDDD supply modules feature an integrated brake transistor as standard. "Built-in" and "thermal separation" (push-through technique) ECS supply modules also feature a brake resistor fixed permanently in the heatsink. If the power of the built-in brake resistor is not sufficient (e.g. extremely long brake phases), external brake resistors can also be connected to all supply modules.

Depending on application-specific conditions, an external brake resistor may need to be fitted to cold plate supply modules (ECSCEDDD), as these modules are not designed with a built-in brake resistor as standard. For each of these applications, we can provide a selection of resistors with pulse performance specifically tailored to each supply unit.

In addition, in order to provide adequate protection against impermissible heat rise in the brake resistors whatever the operating conditions, all brake resistors are fitted with a thermal sensor as standard which will send an appropriate warning message in advance to the axis module concerned.

	Brake resistor		ECS□E		Rated data
	Order number	012	020	040	
		ECS□EE ECS□DE ECS	ICE ECS□EE ECS□DE ECS□C	E ECSDEE ECSDDEECSDCE	
External resistors	ERBM082R100W				
for "cold plate" supply modules	ERBM039R120W		•		Page 3-10
	ERBM020R200W			•	
Increased power external	ERBD082R600W	• • •			
resistors	ERBD047R01K2		• • •		Page 3-11
	ERBD022R03K0			• • •	
Increased power external resistors with IP65 enclosure	ERBS082R780W	• • •			
	ERBS039R01K2		• • •		Page 3-12
	ERBS022R03K2			• • •	




# System accessories External brake resistors

### External brake resistors for cold plate supply modules type ERBM

As ECSCE (cold plate) supply modules are not designed with a separate heatsink, the module does not feature a built-in brake resistor. In terms of their dimensioning, type ERBM brake resistors are exactly identical to the brake resistors integrated into the heatsinks on type ECSEE and ECSDE supply modules.

These resistors are recommended for use in applications with short pulse-type loads.

The resistors are housed in IP50 enclosures.





Brake resistor	Dimensions [mm]									
Order number	a	b	d	е	e1	f	g	k1	k2	
ERBM082R100W		217	200							
ERBM039R120W	31	267	250	68	60	700	5.3	19.5	11.5	
ERBM020R150W		337	320							

Brake resistor	Resistance	Permanent power	Thermal capacity	m
Order number	[Ω]	[W]	[kWs]	[kg]
ERBM082R100W	82	100	3	0.72
ERBM039R120W	39	120	6	0.91
ERBM020R150W	20	150	13	1.1

The above data requires an OT of approx. 5% with a maximum cycle time of 95 s (5 s braking/90 s idling).


PE connection: 6.3 mm flat connector.



### Brake resistors with increased permanent power, type ERBD

Type ERBD increased power brake resistors are used wherever high braking energies are required for long periods of time (e.g. in hoist applications). Type ERBD brake resistors are housed in **IP20 enclosures**.

Increased power brake resistors in **IP65** enclosures appear on page 3-12.





Brake resistor type ERBD

Brake resistor		Dimensions [mm]									
Order number	a	a b c d e f g h									
ERBD082R600W	640	89	554	64	115	526	6.5	13			
ERBD047R01K2	640	177	554	150	115	526	6.5	13			
ERBD022R03K0	740	177	654	150	229	626	6.5	13			


Brake resistor	Resistance	Permanent power	Peak power	Thermal capacity	m
Order number	[Ω]	[kW]	[kW]	[kWs]	[kg]
ERBD082R600W	82	0.6	5.8	90	3.1
ERBD047R01K2	47	1.2	11.6	180	4.9
ERBD022R03K0	22	3.0	25.0	450	10.6

The above peak power is valid for a maximum OT of 10% with a maximum cycle time of 150 s (15 s braking/ 135 s idling).

### Increased power brake resistors in IP65 enclosure, type ERBS

Type ERBS increased power brake resistors in **IP65 enclosures** are used wherever high braking energies are required for long periods of time (e.g. in hoist applications) and the harsh environmental conditions necessitate a high type of protection.


Increased power brake resistors in **IP20** enclosures appear on page 3-11.






Brake resistor type ERBS

Brake resistor	Dimensions [mm]									
Order number	a	a b c d d1 e								
ERBS082R780W	123	666	101	554	101	104				






Brake resistor	Dimensions [mm]									
Order number	a	a b c d d1 e								
ERBS039R01K2	200	747	178	510	145	106				
ERBS022R03K2	276	810	254	550	168	121				

Brake resistor	Resistance	Permanent power	Peak power	Thermal capacity	m
Order number	[Ω]	[kW]	[kW]	[kWs]	[kg]
ERBS082R780W	82	0.78	7.8	117	3.7
ERBS039R01K2	39	1.2	16.4	248	8.4
ERBS022R03K2	22	3.2	32.0	485	13.2


The above data requires a maximum OT of 10% with a maximum cycle time of 150 s (15 s braking/ 135 s idling).

# System accessories System cables

It couldn't be easier to connect the Lenze servo motors to the servo controllers thanks to the Lenze system cable concept. A general schematic overview of the extensive range appears below. As the selection of the required cable type depends primarily on the requirements of the servo motor used, the detailed selection tables for all motor-side cables appear in the Lenze Global Drive servo motors catalogs.



## **System accessories**System cables/Cable protection fuses



☐ Cable length [m]

#### Master frequency cable

The master frequency input (X8) provides a means via which ECS servo system axis modules can be operated in the master frequency network with other servo controllers.

Order number	Length	Cross-section/ No. of wires			Bend radius	
	[m]	[mm <sup>2</sup> ]	[mm]	Fixed installation	${\it Flex.}\ in stall at ion$	[kg]
EWLD002GGBS93	2.5	1x (2x 0.5) + 3x (2x 0.14)	9.3	7.5x d	15x d	0.4

#### **Cable protection fuses**

Circuit-breakers or UL-approved fuses are recommended as cable protection. Depending on the mains currents of the supply modules, the following rated currents must be applied on the protective devices:

Supply module	Design Circuit- breaker	to VDE Cable cross-section [mm <sup>2</sup> ]	Design to UL UL fuse	AWG	Note
ECS□E012	C16 A	2.5	25 A	10	With UL fuse
ECS□E020	C16 A	2.5	25 A	10	characteristic K5 or H
ECS□E040	C32 A	6	35 A	8	With UL fuse characteristic K5 or H, only 400% rated current permissible

This table is only a recommendation. The requirements of national and regional legislation (VDE, UL, EVU, etc.) must also be taken into account.

Only use UL-approved cables, fuses and fuse holders in UL-approved systems.



## **System accessories**Connectors

The universal connection concept for all power and control connections on the ECS servo system ensures fast and service-friendly connections between the servo controllers, the connected motors and all control connections. As the system connectors can be ordered separately from the

active system components, this concept enables the user to set up the entire system cabling in advance under optimum conditions before inserting the active components at a later point in time.





Accessories set ECSZA

Accessories set ECSZE

	Order number	Contents
ECSZA accessories set for axis modules ECS□A□□□	ECSZA000XB	Connector set for power and control connections (axis module)
ECSZE accessories set for supply modules ECS□E□□□	ECSZE000XB	Connector set for power and control connections (supply module)
ECSZK accessories set for capacitor modules ECS□K□□□	ECSZK000XB	Connector set for power and control connections (capacitor module)

# System accessories Shield terminals

Lenze ECSZS shield assembly sets ensure the EMC-compliant and safe connection of cable shields for all cables connected to ECS modules. The wide cable shield contact area ensures safe and problem-free operation with minimum noise radiation. The shield assembly set can be used on all ECS axis and supply modules.



Shield assembly set

Shield assembly set for	Order number	Contents
ECS□A and ECS□E	ECSZS000X0B001	Mounting plate and shield terminals for motor, communication and control cables (ECS□A) or mains cable



## **System accessories** PC software

### Operating and configuration software Global Drive Control

Version 4.6

The Global Drive Control (GDC) PC software is an easy-touse and transparent tool for operating, parameter setting and diagnosing drive tasks with the ECS servo system.

#### **GDC** features include:

- Quick and easy commissioning of the drive by means of the short setup function
- ► Easy operation even for inexperienced users thanks to extensive help functions
- ► User-friendly diagnostics options via various monitor windows and oscilloscope functions
- ► Easy drive connection via RS232/485, optical fibres or via the system bus


#### **Global Drive Control system requirements**

In order to be able to use Global Drive Control, the following minimum hardware and software requirements must be met by the PC:


- ➤ Microsoft® Windows® 95/98/Me, Windows NT® 4.0 SP5 or higher or Windows 2000 SP2/XP or higher
- ▶ IBM compatible PC with Intel® Pentium®-90 processor
- ▶ 128 MB RAM
- ▶ 180 MB free hard disk space
- ► CD-ROM drive
- ▶ Internet Explorer Version 5 or higher
- ➤ Free slots/interfaces in accordance with the requirements of the fieldbus interface module to be used We also recommend the use of a mouse.

In software version 4.7 and higher, the Global Drive Control PC software is also available as "GDCeasy" with restricted function level as a free download for the ECS system from Lenze's Internet site.

More detailed information about the "Global Drive Control" configuration software appears in the Lenze "Automation" catalog, ID no 494 445.









### Global Drive oscilloscope (integrated into Global Drive Control) Version 2.1

The Global Drive oscilloscope (GD oscilloscope) has been developed specifically for the 9300 Servo PLC and the ECS servo system to provide these target systems with a powerful oscilloscope function.

On large systems in particular, it can be difficult to determine speeds or torques on individual drives. However, it is knowledge of precisely these values which can make setting up these machines much easier.

The GD oscilloscope means that it is no longer necessary to connect and install complex measuring instruments — the target systems themselves are the comprehensive measuring instrument for all measured variables affecting the drive.

#### The advantages for you

- ▶ Precise detection of device-specific process factors with 8 channels
- ▶ No need to temporary install measuring sensors in the system
- User-friendly documentation when fine-tuning control loops
- ► Easy maintenance and troubleshooting

### The GD oscilloscope is characterised by the following features:

- Recording and storage of measured values in the controller
- The size of the measured value memory can be configured
- Measurement of up to eight independent channels at the same time
- Configurable time per scan for measuring fast and slow signals
- ► Trigger on channel, variable
- ► Trigger on error message
- ➤ Pre-triggering and post-triggering (detection of pre-trigger and post-trigger history)
- ► Graphic display and evaluation of measured values on a
- ► Cursor and zoom function for analysing measurements
- ► Loading and saving of cams
- ▶ Messages can be annotated and printed
- Overlap function makes it easy to compare measurements
- ➤ Cam data can be transferred to the clipboard for subsequent processing


More detailed information about the Global Drive oscilloscope appears in the Lenze "Automation" catalog, ID no. 494 445.

#### Global Drive oscilloscope system requirements

In order to be able to use the Global Drive oscilloscope, the following minimum hardware and software requirements must be met by the PC:

- ➤ Microsoft® Windows® 98/Me, Windows NT® 4.0 or Windows 2000/XP
- ▶ IBM compatible PC with Intel® Pentium®-166 processor
- ► 64 MB RAM
- ▶ 40 MB free hard disk space
- ► CD-ROM drive
- Mouse

The ECS operating system must be V3.0 or higher.





### **System accessories** PC software

#### **Global Drive Loader**

#### Version 2.1

The Global Drive Loader is the ideal tool for problem-free and secure standard set-up. It couldn't be easier to use, as there is no need for a development environment or parameter settings. Only compiled PLC programs (files from the Drive PLC Developer Studio) and parameter set files (files from Global Drive Control) can be transferred from the PC to the target system. As these files cannot be modified with GD Loader, this prevents data being tampered with by unauthorised users.

#### The advantages for you

- Dedicated program for setting up inverters in standard machines
- ▶ Data cannot be tampered with
- ► Operation couldn't be easier
- Automatic batch mode provides a quick and easy way of transferring a variety of files to a number of target systems
- ► Free download from the Internet

You can continue to use the following software products to modify and create files:

- ▶ Drive PLC Developer Studio V1.0 or higher
- ▶ Global Drive Control V4.31 or higher

The latest version of GD Loader can be downloaded free of charge from the Downloads area at www.Lenze.com. A GD Loader is also supplied on the CDs for the following software products. Depending on the version, the CDs may not contain the latest version of GD Loader.

- Drive PLC Developer Studio V2.0 or higher
- ► Global Drive Control V4.5 and higher
- ► Global Drive Control easy V4.5 or higher



More detailed information about the Global Drive Loader appears in the Lenze "Automation" catalog, ID no. 494 445.

#### **Target systems**

GD Loader V2.1 can be used for the following target systems:

- ▶ 8200 vector/8200 motec
- ▶ 9300 Servo PLC
- ► Drive PLC
- ► Terminal extension
- ▶ ECS servo system

#### **Global Drive Loader system requirements**

In order to be able to use the Global Drive Loader, the following minimum hardware and software requirements must be met by the PC:

- ➤ Microsoft® Windows® 98/Me, Windows NT® 4.0 SP5 or higher or Windows 2000 SP2/XP or higher
- ▶ IBM compatible PC with Intel® Pentium®-90 processor
- ► 32 MB RAM
- ▶ 15 MB free hard disk space
- ► CD-ROM drive for CD version
- ► Free slots/interfaces in accordance with the requirements of the fieldbus interface module to be used
- ▶ Mouse

	GD Loader V2.1
Communication via	
System bus (CAN) via USB	with PC system bus adapter (USB) 1)
System bus (CAN) via parallel interface	with PC system bus adapter
Languages	German, English, French
Order no.	Corporate licence can be downloaded free of charge from www.Lenze.com

Not valid for Microsoft Windows NT. This operating system does not support USB.

#### I/O system to IP20

#### The ideal solution for every application

The increasing level of automation in machines and systems and the consequent rise in the number of I/O devices have in turn increased the amount of wiring required. Decentralised I/O systems bring order to this chaos. Lenze has developed two product concepts which are suitable for both basic digital applications and more complex automation tasks.

#### The compact system

The product family comprises a range of compact products with a fixed number of digital inputs and outputs. It has a built-in communication interface in the form of the CAN system bus. The compact system is available in four different versions — one of which is bound to meet your exact application requirements.

8, 16 and 32-channel modules can be supplied in one or three-wire technology with up to 24 inputs and 8 outputs.

The modules have a SUB-D plug for the connection of the system bus, pluggable tension spring terminal strips to speed up the wiring process and a switch for the node address. The compact system offers operational reliability, can be mounted quickly and easily on 35 mm standard mounting rails and is even easy to configure. All in all, this makes for speedy commissioning.



#### The modular system

We can provide a complete range of I/O systems for more complex automation applications. The modular system comprises three components: a gateway, electronics modules and a backplane bus.

The modular system is connected to the CAN system bus via the gateway. An internal backplane bus is used for the intra-station communication of process and parameter data, as well as diagnostic data.

The electronics modules house the actual I/O functions. Up to 32 units can be combined as required to form an overall station where each module is optimised for the individual application in which it is to be used.

### The electronics module range comprises the following products:

- ▶ Digital input 8 channels
- ▶ Digital output 8 channels 1 A, 2 A
- ▶ Digital output 4 channels 5 A relay
- ▶ Digital I/O 8 channels
- ➤ Analog input 4 channels
- ▶ Analog output 4 channels
- ► Counter 1 MHz



More detailed information about I/O systems appears in the Lenze "Automation" catalog, ID no. 494 445.



# **System accessories** Automation components

#### **Human machine interfaces**


#### Visualisation made easy

Requirements of today's machines and systems in terms of efficiency and effectiveness are constantly on the increase. User-friendliness and monitoring reliability for complex machines are characteristics which are beginning to dominate. Lenze can provide a wide range of human machine interface products, from text displays to graphics displays and beyond to touch screen units, with just one software program common to all: the HMI Designer.

### Select a multiplicity of functions according to device type, e.g.:

- ▶ Display of text, images, bar graphs, bitmaps and animated graphics
- ► Recipe management
- Display of system and alarm messages
- Windows fonts
- Automatic operations
- ► Communication via Lenze system bus

#### Text displays



### Touch screens









#### **Graphics displays**



A more detailed description of the Lenze human machine interfaces appears in the "Global Drive Automation" catalog, ID no. 494 445.

### System accessories Automation components

#### **Drive PLC**

The Drive PLC is ideal for managing central control tasks in a multi-axis servo application. The languages of the international standard IEC 61131-3 are used for programming.

Three different extension boards and two function modules are available to create additional device interfaces.

#### A true system

- ➤ Straightforward engineering using a special software library for simple integration of Lenze drive technology into the PLC program
- No need for control cables due to the integrated system bus interface
- ► Can be mounted side-by-side with drive modules
- ▶ Slots for extension boards and communication modules

#### **Extension boards**

The extension boards are plugged into the side of the Drive PLC.

#### ► Extension board 1

For the connection of three-wire sensors and switching outputs for 24 V DC  $\,$ 

#### ► Extension board 2

For the cost-effective connection of digital sensors and actuators

#### ► Extension board 3

For high-speed counting, length measurements and closed-loop control applications

#### **Built-in gateway function**

No additional costs for gateway function on higher-level bus systems such as INTERBUS, PROFIBUS or DeviceNet to devices connected to the Drive PLC via the system bus (CAN).

#### **CE** conformance

The Drive PLC meets the requirements of the EC's Low Voltage Directive.

#### **UL** approval

Approval to UL 508C means that the Drive PLC can be used anywhere in the world.


More detailed information about the Drive PLC appears in the Lenze "Automation" catalog, ID no. 494 445.





### **System accessories** ETC motion control controller

The ETC motion control controller is available for system-compliant multi-axis co-ordination. This controller, which is an integral component of the Lenze Global Drive system, can be used for the universal automation of your assembly, handling or production machines.



The ETC motion control controller is available in two versions: ETCHC for 4 or 8 axes with problem-free mounting on DIN rails and ETCPC for controlling 4, 8 or 12 axes as a compact pluggable card controller for your PC. Both designs provide the same extensive functions:

- Standardised bus communication via Ethernet (TCP/IP) and CAN interface
- ▶ Additional, separate motion control bus (CAN) with 1 ms cycle time
- ➤ Powerful motion control operating system with 32-bit controller
- Extensive and extendable command sets for programming to DIN 66025
- ► For the built-in PLC part, free programming in IEC 61131-3 languages
- ► Extensive scope of application, from simple positioning tasks to complex 3D path controls
- ▶ Additional pluggable I/O modules for DIN rail mounting

Simple and efficient programming as well as transparent and clear visualisation and operation using the ETCMMI software package with the following functions:

- ► Program generation
- ► Extensive diagnostics tools
- ► Automatic control
- ▶ PLC control via freely programmable buttons
- ▶ Visualisation
- ▶ Operation via keyboard, mouse or touch panel



We would be delighted to advise you on your specific application.

### **System accessories**Regenerative power supply modules

Power recovery is not usually required in the highly dynamic multi-axis applications for which the ECS servo system is primarily used. However, should it be necessary to recover braking energy to the supply system in an application due to specific supplementary conditions, the 9341, 9342 and 9343 regenerative power supply modules from the Global Drive 9300 servo controller range are the ideal solution. Technical data for these devices appears in the Lenze "Servo inverters 9300" catalog (ID no. 454 202). The regenerative power supply modules are available both as built-in units and with thermal separation (push-through technique). Please note that the regenerative power supply modules can only be used as an alternative to the ECS supply modules.

Please contact us should you require dimensioning assistance.



934□ regenerative power supply module



#### 4

# **Dimensioning information** | ECS servo system

### **Device connection**

Power network	4-2
Connection for control signals	4-3



# **Dimensioning information**Device connection

#### **Power network**

A typical wiring diagram for a power network comprising ECS axis and supply modules appears below.

Please select the cable cross-section for the mains cable based on the maximum input current of the supply module (see page 3-15).

A minimum conductor cross-section of 6 mm<sup>2</sup> should be selected for wiring the DC-bus connection.


A fuse does not need to be provided for the DC-bus connection.

In order to ensure the problem-free and EMC-compliant wiring of the motor cables, please use the Lenze ECSZS shield assembly set for the shield connection (see page 3-17).

Please select the cross-section of the motor connecting cables based on the maximum motor standstill current.

Please dimension the input-side circuit-breaker in accordance with the table on page 3-15.

#### Power network with external or internal ballast resistor



PES HF shield termination by means of wide contact with PE

\_/ Twisted wires

\*1 System cable feedback system

- - Operation with external ballast resistor

## **Dimensioning information**Device connection



#### **Connection for control signals**

A typical control cable layout for a power network comprising ECS axis and supply modules appears below.

Please use a minimum conductor cross-section of  $0.25 \ mm^2$  for the control cables.


In order to ensure the problem-free and EMC-compliant wiring of the control cables, please use the Lenze ECSZS shield assembly set for the shield connection (see page 3-17).

An external 24 V DC voltage is required at terminals X6:+24 and X6:GND for the power supply for the control electronics.

If an external brake resistor is not used, terminals X6:T1 and X6:T2 should be bypassed.

Input X6:DI1 is used to enable mains voltage detection on the supply module. X6:DI2 enables the control and initiates the charging of the DC circuit. Once the circuit has charged without errors, a ready for operation signal is set at X6:DO1. X6:D24 is the supply voltage input for X6:DO1.

#### **Example circuit for wiring control signals**



- PES HF shield termination by means of wide contact with PE
  - Twisted wires
- A Enable axis module
- B Voltage supply motor holding brake 18 ... 30 V DC, max. 1.5 A



# Services ECS servo system

Services	5-2
Related documentation	5-3
Fax order form	5-5
Lenze worldwide	5-8



### **Services**Services

For us, service is more than just supporting the use of our drives. The Lenze system approach begins with your enquiry. Next you get technical information and advice from a network of sales outlets staffed by knowledgeable engineers. If you want, we follow up with training, commissioning, maintenance and repair. Our service is always at your disposal.

#### With passion

The Lenze team does not just offer the necessary manpower and technical know-how — we are passionate and meticulous about what we do. We will only be happy once you are entirely satisfied with our work. Our team of professionals provides assistance over the telephone or on site, ensures the express delivery of spare parts and carries out repairs with incredible urgency. We're fast and reliable.

#### Someone to talk to

Expert advice is available for all your technical queries via our helpline. In cases of urgent need, call 008000 24 hours (008000 24 46877), Lenze's worldwide expert helpline – 24 hours a day, 365 days a year. For more direct assistance, you can of course contact your local Lenze service support centre. We can tell you where it is – or you can find out for yourself by visiting us on the Internet at www.Lenze.com.

#### Around the world

Our products are available for speedy delivery worldwide. Lenze companies, Lenze factories and sales agencies are based in major industrial countries around the world. Contact them through our website **www.Lenze.com**, which also gives you 24-hour access to technical instructions and product manuals. Local support, on site if you need it, is available.



### **Services**Related documentation



#### **Technical documentation**

The technical documentation provides more detailed information about our products:

- ► Mounting Instructions in three languages are supplied with our products.
- ➤ Our System Manuals for controllers, our Communication Manuals for bus systems and our Operating Instructions for electromechanical products and accessories provide the information required for planning, designing and developing machines and systems. System Manuals and Communication Manuals are supplied in loose-leaf format. Operating Instructions are bound.
- ➤ Our User's Manuals for our controllers are designed for the operators and users of machines and systems. The information in User's Manuals has been put together so that it can be integrated directly into the machine or system documentation.

All our technical documentation is available free of charge in PDF format

- ➤ Via Internet download from "www.lenze.de", "Downloads" area
- ▶ On the "Lenze Library" CD

System Manuals and Communication Manuals can also be supplied in ring binder format for a nominal fee.

#### Technical documentation at a glance

Documentation	Contents	Target group	Available languages
Mounting Instructions	Safety instructions, handling and installation	Installation personnel	In three languages: German, English, French
System Manual Communication Manual Operating Instructions	Extensive and comprehensive information for design, construction, development and programming	Planning engineers, design engineers and developers of machines and systems	Single-language version: German, English or French
User's Manual	Safety instructions, handling, troubleshooting and fault elimination	Operators and users of machines and systems	Single-language version German, English or French. Other languages will shortly be available on request







#### ļ,

### Fax order form



To the Lenze sales office	Page of
☐ Order	
☐ Quotation	
Fax no.	
Fuere	Contamon
From	Customer no.
Company	
Street/PO Box	Order no.
Postcode City	Name
	Department
Date Signature	Tel. no.
Dallingur address (if different)	
Delivery address (if different)	
Street	
Postcode City	
Tosteode City	
Invoice to (if different)	
Street/PO Box	
Postcode City	
De accepted delicement de te	
Requested delivery date	
Despatch information	



Customer no.	Page of
Order no.	

### **Axis modules**

Number	Design "Built-in"	Number	Design "Push-through technique"	Number	Design "Cold plate"	Price
	ECSEA004		ECSDA004		ECSCA004	
	ECSEA008		ECSDA008		ECSCA008	
	ECSEA016		ECSDA016		ECSCA016	
	ECSEA032		ECSDA032		ECSCA032	
	ECSEA048		ECSDA048		ECSCA048	
	ECSEA064		ECSDA064		ECSCA064	

### **Supply modules**

Number	Design "Built-in"	Number	Design "Push-through technique"	Number	Design "Cold plate"	Price
	ECSEE012		ECSDE012		ECSCE012	
	ECSEE020		ECSDE020		ECSCE020	
	ECSEE040		ECSDE040		ECSCE040	

### **Capacitor modules**

Number	Design "Built-in"	Number	Design "Push-through technique"	Number	Design "Cold plate"	Price
	ECSEK001		ECSDK001		ECSCK001	
	ECSEK002		ECSDK002		ECSCK002	

#### Accessories

Number	Designation	Order number	Price
	Shield assembly set	ECSZS000X0B001	
	Accessories set for axis modules	ECSZA000X0B	
	Accessories set for supply modules	ECSZE000X0B	
	Accessories set for capacitor modules	ECSZK000X0B	

### PC system bus adapter

Number	Designation	Order number	Price
	PC system bus adapter, printer port connection	EMF2173IB	
	PC system bus adapter, PS2 port connection	EMF2173IBV002	
	PC system bus adapter, electrically isolated, PS2 port connection	EMF2173IBV003	
	PC system bus adapter, electrically isolated, USB port connection	EMF2177IB	







Customer no.	Page of
Order no.	

### Pluggable modules for operation or communication

Number	Designation	Order number	Price
	Operating module	EMZ9371BC	
	LECOM-A/B	EMF2102IBC V001	
	LECOM-B	EMF2102IBC V002	
	LECOM-A	EMF2102IBC V004	
	LECOM-LI	EMF2102IBC V003	
	PROFIBUS-DP	EMF2133IB	
	CANopen/DeviceNet	EMF2175IB	
	LON	EMF2141IB	
	INTERBUS 2000 kB	EMF2113IB	

#### **Mains chokes**

Number	Designation	Order number	Price
	for ECS□E012	ELN3-0150H024	
	for ECS□E020	ELN3-0088H035	
	for ECS□E040	ELN3-0055H055	

#### RFI filter limit class A

Number	Designation	Order number	Price
	for ECS□E012	ECSZZ020X4B	
	for ECS□E020	ECSZZ020X4B	
	for ECS□E040	ECSZZ040X4B	

#### **Brake resistors**

Number	Resistance [Ω]	Power [kW]	Type of protection	Order number	Price
	82	0.1	IP50	ERBM082R100W	
	39	0.12	IP50	ERBM039R120W	
	20	0.15	IP50	ERBM020R150W	
	82	0.6	IP20	ERBD082R600W	
	47	1.2	IP20	ERBD047R01K2	
	22	3	IP20	ERBD022R03K0	
	82	0.78	IP65	ERBS082R780W	
	39	1.2	IP65	ERBS039R01k2	
	22	3.2	IP65	ERBS022R03k2	

# enze

#### Lenze worldwide

Lenze AG Postfach 101352 D-31763 Hameln Telefon +49 (0)5154/82-0

Telefax +49 (0)5154/82-2800 E-Mail: Lenze@Lenze.de Internet: www.Lenze.com

#### Lenze Drive Systems GmbH

Postfach 10 13 52, D-31763 Hameln Telefon +49 (0)51 54 / 82-0 Telefax +49 (0)51 54 / 82-28 00

#### Lenze GmbH & Co KG Anlagenbau

Buchenweg 1 D-31855 Aerzen Telefon +49 (0)51 54 / 82-0 Telefax +49 (0)51 54 / 82-21 00

Wülmser Weg 5 D-31855 Aerzen Telefon +49 (0)51 54 / 82-14 53 Telefax +49 (0)51 54 / 82-11 04

#### Lenze GmbH & Co KG Kleinantriebe

Hans-Lenze-Straße 1 D-32699 Extertal Telefon +49 (0)51 54 / 82-0 Telefax +49 (0)51 54 / 82-14 85

#### Lenze Service GmbH

Breslauer Straße 3 D-32699 Extertal

**Mechanical Drives** 

Telefon +49 (0)51 54 / 82-16 26 Telefax +49 (0)51 54 / 82-13 96

**Electronic Drives** 

Telefon +49 (0)51 54 / 82-11 11 Telefax +49 (0)51 54 / 82-11 12

Service Helpline +49 (0)180 5 20 24 26

#### Lenze Verbindungstechnik GmbH & Co KG

Inf-Landesstraße 1 A-4481 ASTEN

Phone +43 (0)72 24 / 21 1-0 Telefax +43 (0)72 24 / 21 19 98

#### Lenze Deto Drive Systems GmbH & Co KG

Gewerbepark Süd 11 A-6330 Kufstein Telefon +43 (0)53 72 / 6 53 15-200 Telefax +43 (0)53 72 / 6 53 15-299

#### LS Automation GmbH & Co KG

Jakob-Stadler-Platz 11 D-78467 Konstanz Telefon +49 (0)75 31 /9 42 19-0 Telefax +49 (0)75 31/9 42 19 20

#### encoway GmbH & Co KC

Universitätsallee 21-23 D-28359 Bremen Telefon +49 (0)4 21 /2 46 77-0 Telefax +49 (0)4 21 /2 46 77-10

#### **DEUTSCHLAND/GERMANY**

#### Lenze Vertrieb GmbH

Ludwig-Erhard-Straße 52-56 D-72760 Reutlingen Telefon +49 (0)71 21 / 9 39 39-0 Telefax +49 (0)71 21 / 9 39 39-29

Region Nord Dornenpark 1 31840 Hessisch Oldendorf Telefon (0 51 52) 90 36-0 Telefax (0 51 52) 90 36-33/44/55

Region West Postfach 10 12 20 47497 Neukirchen-Vluyn Kelvinstraße 7 47506 Neukirchen-Vluyn Telefon (0 28 45) 95 93-0 Telefax (0 28 45) 95 93 93

Region Mitte/Ost Postfach 1463 35724 Herborn Austraße 81 35745 Herborn Telefon (0 27 72) 95 94-0 Telefax (0 27 72) 5 30 79

Region Südwest Postfach 14 33 71304 Waiblingen 71304 Walblingen Schänzle 8 71332 Waiblingen Telefon (07151) 95981-0 Telefax (07151) 9598150

Region Süd Fraunhoferstraße 16 82152 Martinsried Telefon (0 89) 89 56 14-0 Telefax (0 89) 89 56 14 14

#### WELTWEIT/WORLDWIDE

#### **ALGERIA**

see FRANCE

#### ARGENTINA \* FRHSA

Girardot 1368, 1427 BUENOS AIRES Phone +54 (0)11 / 45 54 32 32 Telefax +54 (0)11 / 45 52 36 11

#### **AUSTRALIA\***

FCR Motion Technology Pty. Ltd. Unit 6, Automation Place 38-40 Little Boundary Rd. LAVERTON NORTH, Vic. 3026 Phone +61 (3) 9362 6800 Telefax +61 (3) 9314 3744

#### AUSTRIA\*

Lenze Antriebstechnik GmbH Ipf-Landesstraße 1 4481 ASTEN
Phone +43 (0)7224/210-0
Telefax +43 (0)7224/210999

Office Dornbirn: Lustenauer Straße 64 6850 DORNBIRN

Phone +43 (0)5572 / 26789-0 Telefax +43 (0)5572 / 26789-66

Office Wr Neudorf Triester Straße 14/109 2351 WR. NEUDORF Phone +43 (0)2236 / 253 33-0 Telefax +43 (0)2236 / 253 33-66

Office Graz:

Seering 8 8141 UNTERPREMSTÄTTEN Phone +43 (0)3135 / 56 900-0 Telefax +43 (0)3135 / 56 900 999

Lenze Verbindungstechnik GmbH & Co KG Ipf-Landesstraße 1 4481 ASTEN

Phone +43 (0)7224/211-0 Telefax +43 (0)7224/211998

Lenze Anlagentechnik GmbH & Co KG Mühlenstraße 3 4470 FNNS

Phone +43 (0)7223 / 886-0 Telefax +43 (0)7223 / 886-997

#### BELGIUM\*

Lenze b.v.b.a Noorderlaan 133 hus 15

2030 ANTWERPEN Phone +32 (0)3 / 54 26 20 0 Telefax +32 (0)3 / 54 13 75 4

#### BOSNIA-HERZEGOVINA

see AUSTRIA

#### BRAZIL\*

AC Control Ltda Rua Gustavo da Silveira 1199 Vila Sta. Catarina SÃO PAULO – S.P.

04376-000 Phone (+55) 11 55 64 65 79 ramal: 214 Telefax (+55) 11 56 79 75 10

#### BUIGARIA

see MACEDONIA

#### CANADA

see USA

#### CHILE

Sargent S.A. Tecnica Thomas C. Sargent S.A.C.é.I. Casilla 166-D SANTIAGO DE CHILE Phone +56 (0)2 / 51 03 000 Telefax +56 (0)2 / 69 83 989

Aupi Ltda. Automation y Proceso Industrial Camino a Melipilla No. 262 Casilla 80 SANTIAGO DE CHILE

Phone +56 (0)2 / 811 45 20 Telefax +56 (0)2 / 811 11 02 / 811 18 04

Lenze Mechatronic Drives (Shanghai) Co. Ltd., Section B, 50# building, No.199 North Ri Ying Road, Waigaoqiao Free Trade Zone SHANGHAI, 200131 Phone +86-21-5046 0848 Telefax +86-21-5046 0850

Beijing Office Rm. 401, Huaxin Mansion No. 33 An Ding Road Chaoyang District BEIJING 100029 Phone +86-10-64411470 Telefax +86-10-64411467

Lenze Antriebstechnik GmbH Predstavnista Zagreb Ulica Grada Gospica 3 HR-1000 ZAGREB Phone +385-1-249 80 56 Telefax +385-1-249 80 57

#### CZECH REPUBLIC

CROATIA

Lenze, s.r.o. Central Trade Park D1 396 01 HUMPOLEC Phone +420 565 507-111 Telefax +420 565 507-399

Büro Červený Kostelec: 17. listopadu 510 549 41 ČERVENÝ KOSTELEC Phone +420 491 467-111 Telefax +420 491 467-166

#### **DENMARK\***

Lenze A/S Vallensbækvej 18A 2605 BRØNDBY Phone +45/46966666 Telefax +45/46966660 24 stunde service +45/40930411

Buero Jylland: Lenze A/S Enebærvej 11 8653 THEM

Phone +45 / 46 96 66 66 Telefax +45 / 46 96 66 80

#### **EGYPT**

WADI Co. for technologies and development P.O.Box 209, new center Ramses 11794 CAIRO, Egypt 11 Syria St., Mohandessin GIZA, Egypt
Phone +20 (2) 347 6842
Telefax +20 (2) 347 6843

#### **ESTONIA**

see FINLAND

### FINLAND\*

Lenze Drives Rykmentintie 2 b 20810 TURKU Phone +358 2 2748 180 Telefax +358 2 2748 189

#### FRANCE\*

Lenze S.A. Siege Z.A. de Chanteloup

Rue Albert Einstei 93603 AULNAY-SOUS-BOIS

Services Commerciaux Tel. 0 825 086 036 Fax 0 825 086 346

Centre de formation E-Mail:semin.sidonie@lenze.fr

Question générales / Documentation E-Mail:lenze@lenze.fr

Service Après-vente / asssistance en ligne Helpline 24/24 : 0 825 826 117 E-Mail:helpline@lenze.fr

Agences en France Région France Nord : Z.A. de Chanteloup Rue Albert Einstein 93603 AULNAY-SOUS-BOIS

59420 MOUVAUX

Strasbourg 67960 ENTZHEIM

Rouen 76500 ELBEUF

Région France Sud : Rond point du sans souci 69578 LIMONEST Cedex

Toulouse 31400 TOULOUSE

Agen 47270 SAINT-PIERRE DE CLAIRAC

#### GREECE

GREECE
George P. Alexandris S.A.
12K. Mavromichali Str.
185 45 PIRAEUS
Phone +30 (0)210 / 41 1184 15
Telefax +30 (0)210 / 4118171
412 70 58
183 Monastiriou Str.

546 27 THESSALONIKI Phone +30 (0)310 / 5 56 65 04 Telefax +30 (0)310 / 51 18 15

#### **HUNGARY\***

Lenze Antriebstechnik Handelsgesellschaft mbH 2040 BUDAÖRS Gyár utca 2., P.O.Box 322. Phone +36 (0)23 / 501-320 Telefax +36 (0)23 / 501-339

#### ICELAND

see DENMARK

# SNZE

Electronic Service: National Power Systems 10, Saibaba Shopping Centre Keshav Rao Kadam Marg Off Lamington Road MUMBAI 400 008

Phone +91-22-2300 5667, 2301 3712 Telefax +91-22-2300 5668

Mechanical Service Emco Lenze Pvt. Ltd 1st Floor, Sita Mauli Madanlal Dhingra Road Panch Pakhadi, Thane (West) MAHARASHATRA 400 602 Phone +91-22-25405488 +91-22-25452244 Telefax +91-22-25452233

V3 Controls Pvt 1td 1, "Devyani", Next to SBI, Baner ITI Road, Sanewadi, Aundh,

PUNE 411 007 MS Phone +91-20-25 88 68 62 Telefax +91-20-25 88 03 50

#### INDONESIA

P.T. Futurindo Globalsatya Jl.: Prof. Dr. Latumenten No. 18 Kompleks Perkantoran Kota Grogol Permai Blok A 35 JAKARTA 11460 Buero 1:

Phone +62 (0)21/766 42 34 765 86 23 Telefax +62 (0)21 / 766 44 20

Buero 2: Phone +62 (0)21/567 96 31 567 96 32 Telefax +62 (0)21/566 87 50

#### IRAN

Tavan Ressan Co. Ltd P.O.Box. 19395-5177 No. 44, Habibi St., South Dastour St., Sadr EXP'Way, TEHRAN 19396 Phone +98 21 / 260 26 55

260 67 66 260 92 99 Telefax +98 21 / 200 28 83

Greensphon Engineering Works LTD P.O.Box 10 108 HAIFA-BAY 26110 Phone +972 (0)4 / 87 21 18 7 Telefax +972 (0)4 / 87 26 23 1

Gerit Trasmissioni S.p.A. Viale Monza 338 **20128 MILANO** Phone +39 02 / 270 98.1 Telefax +39 02 / 270 98 290

#### JAPAN\*

Miki Pulley Co., Ltd. 1-39-7 Komatsubara, Zama-city KANAGAWA 228-8577 Phone +81 (0)462 / 58 16 61 Telefax +81 (0)462 / 58 17 04

#### LATVIA

see LITHUANIA

#### LITHUANIA

Lenze UAB Breslauios g 3 44403 KAUNAS Phone +370 37 407174 Fax./Tel.+370 37 407175

#### LUXEMBOURG

see BELGIUM

Lenze Antriebstechnik GmbH Pretstavnistvo Skopje ul. Nikola Rusinski 3/A/2, 1000 SKOPJE Phone +389 2 30 90 090 Telefax +389 2 30 90 091

D.S.C. Engineering SDN BHD 3A & 3B, Jalan SS21/56B Damansara Utama 47400, PETALING JAYA, SELANGOR Phone +60 (0)3 / 77 25 62 43 77 25 62 46 77 28 65 30 Telefax +60 (0)3 / 77 29 50 31

#### MAURITIUS

Automation & Controls Engineering Ltd 3, Royal Road, Le Hochet, Terre Rouge MAURITIUS

Phone +230 248 8211 Telefax +230 248 8968

#### MEXICO

Automatización y Control de Energía S.A. de C.V. Av. 2 No. 89 Esq Calle 13 Col. San Pedro de los Pinos C.P. 03800 MEXICO D.F. Phone +52 (55)5277/5998 Telefax +52 (55)5277/5937

#### MOROCCO

GUORFET G.T.D.R Automatisation Industrielle Bd Chefchaouni Route 110 km, 11.500 No. 353-Aîn-Sabaâ

CASABLANCA Phone +212/22-35 70 78 Telefax +212/22-35 71 04

#### **NETHERLANDS\***

Lenze B.V., Postbus 31 01 5203 DC`S-HERTOGENBOSCH Ploegweg 15 5232 BR`S-HERTOGENBOSCH Phone +31 (0)73 / 64 56 50 0 Telefax +31 (0)73 / 64 56 51 0

#### **NEW ZEALAND\***

Tranz Corporation 343 Church Street P.O. Box 12-320, Penrose AUCKLAND

Phone +64 (0)9 / 63 45 51 1 Telefax +64 (0)9 / 63 45 51 8

#### NORWAY\*

Dtc-Lenze as Stallbakken 5, 2005 RAELINGEN Phone +47 / 64 80 25 10 Telefax +47 / 64 80 25 11

#### **PHILIPPINES**

Jupp & Company Inc. Unit 224 Cityland Pioneer Bldg., Pioneer Sreet, MANDALUYONG CITY +632/6877423 683 0042 683 0047 Telefax +632/6877421

#### POLAND

Lenze-Rotiw Sp. z o.o. ul. Roździeńskiego 188b 40-203 KATOWICE Phone +48 (0)32 / 2 03 97 73 Telefax +48 (0)32 / 781 01 80 Lenze Systemy Automatyki Sp. z o.o. Ul. Rydygiera 47 87-100 TORUŃ

6 45 34 60 6 45 35 70 Telefax +48 (0)56 / 645 33 56

Phone +48 (0)56 / 658 28 00

Costa Leal el Victor Electronica-Pneumatica, Lda, Rua Prof. Augusto Lessa, 269, Apart. 52053 4202-801 PORTO

Lenze worldwide

Phone +351-22/5508520 Telefax +351-22/5024005

#### ROMANIA

see ALISTRIA

#### RUSSIA Inteldrive

1 Ruhvostova Street 12/11 1 Bunvostova Street 12/11 Korpus 18 Office 322 MOSCOW 107258 Phone +7 (0)095 / 963 96 86 Telefax +7 (0)095 / 962 67 94

#### SERBIA-MONTENEGRO

see MACEDONIA

#### SINGAPORE\*

see MALAYSIA

### SLOVAC REPUBLIC

ECS Sluzby spol. s.r.o. Staromlynska 29 82106 BRATISLAVA +421 2 45 25 96 06 +421 2 45 64 31 47 +421 2 45 64 31 48 Telefax +421 2 45 25 96 06

#### SLOVENIA

Lenze pogonska tehnika GmbH Zbiljska Cesta 4 1215 MEDVODE Phone +386 (0)13616141 Telefax +386 (0)13612288

#### **SOUTH AFRICA\***

S.A. Power Services (Pty.) Ltd. P.O. Box 11 37 RANDBURG 2125 Phone +27 (0)11 / 78 71 80 1 Telefax +27 (0)11 / 78 75 04 0

#### **SOUTH KOREA\***

Hankuk Mechatro Ltd. Room# 1409 Samhwan officetel 830-295 Beomil-dong, Dong-Gu PUSAN Phone +82 (0)51-635-6663 Telefax +82 (0)51-635-6632

Lenze Transmisiones, S.A. Mila i Fontanals, 135-139 08205 SABADELL (Barcelona) Phone +34 93 / 72 07 68 0 Telefax +34 93 / 71 22 54 1

Lenze Transmissioner AB P.O.Box 10 74, Attorpsgatan, Tornby Ind. 58110 LINKÖPING Phone +46 (0)13 / 35 58 00 Telefax +46 (0)13 / 10 36 23

#### SWITZERLAND \*

Lenze Bachofen AG Ackerstrasse 45 **8610 USTER** Phone +41 (0) 43 399 14 14 Telefax +41 (0) 43 399 14 24 Vente Suisse Romande: Route de Prilly 25 1023 CRISSIER Phone +41 (0)21 / 63 72 19 0 Telefax +41 (0)21 / 63 72 19 9

#### SYRIA

Zahabi Co. 8/5 Shouhadaa Street PO Box 8262 ALEPPO-SYRIA Phone +963 21 21 22 23 5 Telefax +963 21 21 22 23 7

#### TAIWAN\*

ACE Pillar Co. Ltd. No.12, Lane 61, Sec. 1, Kuanfu Road San-Chung City TAIPEI HSIEN

Phone +886 (0)2 / 299 58 40 0 Telefax +886 (0)2 / 299 53 46 6

#### THAILAND

PackSys Global (Thailand) Ltd. 429 Moo 7, Theparak Road, Tambol Theparak Amphur Muang SAMUTPRAKARN 10270 Phone +66 2 383 5633 Telefax +66 2 383 5637

#### TUNESIA

see FRANCE

#### TURKEY

LSE Elektrik Elektronik Makina Otomasyon Mühendislik San. Ve Tic. Ltd. Şti. Atatürk mah. Cumhuriyet cad. Yurt sok. No:7 ÜMRANIYE/İSTANBUL Phone +90 (0)216 / 316 5138 pbx Telefax +90 (0)216 / 443 4277 Bursa Address: Demirtaspasa Mh. Ata Sk. Petek Bozkaya Is Merkezi

D Blok No :5 / A OSMANGAZI / BURSA Phone +90 (0)224-2733232 pbx

+90 (0)224-27334151 +90 (0)224-2733238 Telefax +90 (0)224-2734150

#### UKRAINE SV Altera

Pobedy Av. 44, KIYV Phone +380-44-2416777 Telefax +380-44-2419084

#### UNITED KINGDOM/EIRE\*

Lenze Ltd. Caxton Road BEDFORD MK 41 OHT Phone +44 (0)1234 / 3213 21 Telefax +44 (0)1234 / 261815

#### USA\*

AC Technology Corp. 660 Douglas Street UXBRIDGE, MA 01569 Phone +1508/278-9100 Telefax +1508/278-7873 AC Technology Corp. 1730 East Logan Avenue EMPORIA, KS 66 801 Phone +1620/343-8401 +1888/269-2381 Telefax +1620/342-2595 +1800/469-0931

AC Technology Corp. 1 W. Illinois Street, Suite 24 ST. CHARLES, IL 60174 Phone +1630/377-7534 Telefax +1630/377-9623 Suite 240



\*Countries connected to the free expert helpline 008000 24 hours (008000 24 46877)



# **Service** you can trust

For us, service is more than just supporting the use of our drives. The Lenze system approach begins with your enquiry. Next you get technical information and advice from a network of sales outlets staffed by knowledgeable engineers. If you want, we follow up with training, commissioning, maintenance and repair. Our service is always at your disposal.

#### With passion

The Lenze team does not just offer the necessary manpower and technical knowhow – we are passionate and meticulous about what we do. We will only be happy once you are entirely satisfied with our work. Our team of professionals provides assistance over the telephone or on site, ensures the express delivery of spare parts and carries out repairs with incredible urgency. We're fast and reliable.

#### Someone to talk to

Expert advice is available for all your technical queries via our helpline. In cases of urgent need, call 008000 24 hours (008000 24 46877), Lenze's worldwide expert helpline – 24 hours a day, 365 days a year. For more direct assistance, you can of course contact your local Lenze service support centre. We can tell you where it is – or you can find out for yourself by visiting us on the Internet at www.Lenze.com.

#### Around the world

Our products are available for speedy delivery worldwide. Lenze companies, Lenze factories and sales agencies are based in major industrial countries around the world. Contact them through our website www.Lenze.com, which also gives you 24-hour access to technical instructions and product manuals. Local support, on site if you need it, is available.

**Worldwide** Algeria

Algeria Argentina Australia Austria Belgium Bosnia-Herzegovina

Brazil
Bulgaria
Canada
Chile
China
Croatia
Czech Republic
Denmark
Egypt
Estonia

Finland

France

Greece Hungary Iceland India Indonesia Iran Israel Italy

Germany

Japan
Latvia
Lithuania
Luxembourg
Macedonia
Malaysia
Mauritius
Mexico

Morocco Netherlands New Zealand Norway Philippines

Philippines
Poland
Portugal
Romania
Russia
Serbia-Montenegro

Singapore Slovak Republic Slovenia

Slovenia South Africa South Korea Spain

Sweden
Switzerland

Syria Taiwan Thailand Tunesia

Turkey
Ukraine
United Kingdom/Eire

United Ki USA www.Lenze.com